Linux Device Drivers

Linux Device Drivers

This documentation is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

For more details see the file COPYING in the source distribution of Linux.

Table of Contents

1. Driver Basics 1
    Driver Entry and Exit points 1
    Atomic and pointer manipulation 2
    Delaying, scheduling, and timer routines 16
    Wait queues and Wake events 76
    High-resolution timers 109
    Workqueues and Kevents 129
    Internal Functions 158
    Kernel objects manipulation 195
    Kernel utility functions 209
    Device Resource Management 268
2. Device drivers infrastructure 292
    The Basic Device Driver-Model Structures 292
    Device Drivers Base 305
    Device Drivers DMA Management 410
    Device Drivers Power Management 464
    Device Drivers ACPI Support 470
    Device drivers PnP support 475
    Userspace IO devices 487
3. Parallel Port Devices 494
    parport_yield 495
    parport_yield_blocking 496
    parport_wait_event 497
    parport_wait_peripheral 498
    parport_negotiate 499
    parport_write 500
    parport_read 501
    parport_set_timeout 502
    __parport_register_driver 503
    parport_unregister_driver 504
    parport_get_port 505
    parport_put_port 506
    parport_register_port 507
    parport_announce_port 508
    parport_remove_port 509
    parport_register_device 510
    parport_unregister_device 512
    parport_find_number 513
    parport_find_base 514
    parport_claim 515
    parport_claim_or_block 516
    parport_release 517
    parport_open 518
    parport_close 519
4. Message-based devices 520
    Fusion message devices 520
5. Sound Devices 639
    snd_printk 640
    snd_printd 641
    snd_BUG 642
    snd_printd_ratelimit 643

snd_BUG_ON 644
snd_printdd 645
register_sound_special_device 646
register_sound_mixer 647
register_sound_midi 648
register_sound_dsp 649
unregister_sound_special 650
unregister_sound_mixer 651
unregister_sound_midi 652
unregister_sound_dsp 653
snd_pcm_stream_linked 654
snd_pcm_stream_lock_irqsave 655
snd_pcm_group_for_each_entry 656
snd_pcm_running 657
bytes_to_samples 658
bytes_to_frames 659
samples_to_bytes 660
frames_to_bytes 661
frame_aligned 662
snd_pcm_lib_buffer_bytes 663
snd_pcm_lib_period_bytes 664
snd_pcm_playback_avail 665
snd_pcm_capture_avail 666
snd_pcm_playback_hw_avail 667
snd_pcm_capture_hw_avail 668
snd_pcm_playback_ready 669
snd_pcm_capture_ready 670
snd_pcm_playback_data 671
snd_pcm_playback_empty 672
snd_pcm_capture_empty 673
snd_pcm_trigger_done 674
params_channels 675
params_rate 676
params_period_size 677
params_periods 678
params_buffer_size 679
params_buffer_bytes 680
snd_pcm_hw_constraint_single 681
snd_pcm_format_cpu_endian 682
snd_pcm_set_runtime_buffer 683
snd_pcm_gettime 684
snd_pcm_lib_alloc_vmalloc_buffer 685
snd_pcm_lib_alloc_vmalloc_32_buffer 686
snd_pcm_sgbuf_get_addr 687
snd_pcm_sgbuf_get_ptr 688
snd_pcm_sgbuf_get_chunk_size 689
snd_pcm_mmap_data_open 690
snd_pcm_mmap_data_close 691
snd_pcm_limit_isa_dma_size 692
snd_pcm_stream_str 693
snd_pcm_chmap_substream 694
pcm_format_to_bits 695
snd_pcm_format_name 696
snd_pcm_new_stream 697

snd_pcm_new 698
snd_pcm_new_internal 699
snd_pcm_notify 700
snd_device_new 701
snd_device_disconnect 702
snd_device_free 703
snd_device_register 704
snd_info_get_line 705
snd_info_get_str 706
snd_info_create_module_entry 707
snd_info_create_card_entry 708
snd_info_free_entry 709
snd_info_register 710
snd_rawmidi_receive 711
snd_rawmidi_transmit_empty 712
__snd_rawmidi_transmit_peek 713
snd_rawmidi_transmit_peek 714
__snd_rawmidi_transmit_ack 715
snd_rawmidi_transmit_ack 716
snd_rawmidi_transmit 717
snd_rawmidi_new 718
snd_rawmidi_set_ops 719
snd_request_card 720
snd_lookup_minor_data 721
snd_register_device 722
snd_unregister_device 723
copy_to_user_fromio 724
copy_from_user_toio 725
snd_pcm_lib_preallocate_free_for_all 726
snd_pcm_lib_preallocate_pages 727
snd_pcm_lib_preallocate_pages_for_all 728
snd_pcm_sgbuf_ops_page 729
snd_pcm_lib_malloc_pages 730
snd_pcm_lib_free_pages 731
snd_pcm_lib_free_vmalloc_buffer 732
snd_pcm_lib_get_vmalloc_page 733
snd_device_initialize 734
snd_card_new 735
snd_card_disconnect 736
snd_card_free_when_closed 737
snd_card_free 738
snd_card_set_id 739
snd_card_add_dev_attr 740
snd_card_register 741
snd_component_add 742
snd_card_file_add 743
snd_card_file_remove 744
snd_power_wait 745
snd_dma_program 746
snd_dma_disable 747
snd_dma_pointer 748
snd_ctl_notify 749
snd_ctl_new1 750
snd_ctl_free_one 751

snd_ctl_add 752
snd_ctl_replace 753
snd_ctl_remove 754
snd_ctl_remove_id 755
snd_ctl_activate_id 756
snd_ctl_rename_id 757
snd_ctl_find_numid 758
snd_ctl_find_id 759
snd_ctl_register_ioctl 760
snd_ctl_register_ioctl_compat 761
snd_ctl_unregister_ioctl 762
snd_ctl_unregister_ioctl_compat 763
snd_ctl_boolean_mono_info 764
snd_ctl_boolean_stereo_info 765
snd_ctl_enum_info 766
snd_pcm_set_ops 767
snd_pcm_set_sync 768
snd_interval_refine 769
snd_interval_ratnum 770
snd_interval_list 771
snd_interval_ranges 772
snd_pcm_hw_rule_add 773
snd_pcm_hw_constraint_mask64 774
snd_pcm_hw_constraint_integer 775
snd_pcm_hw_constraint_minmax 776
snd_pcm_hw_constraint_list 777
snd_pcm_hw_constraint_ranges 778
snd_pcm_hw_constraint_ratnums 779
snd_pcm_hw_constraint_ratdens 780
snd_pcm_hw_constraint_msbits 781
snd_pcm_hw_constraint_step 782
snd_pcm_hw_constraint_pow2 783
snd_pcm_hw_rule_noresample 784
snd_pcm_hw_param_value 785
snd_pcm_hw_param_first 786
snd_pcm_hw_param_last 787
snd_pcm_lib_ioctl 788
snd_pcm_period_elapsed 789
snd_pcm_add_chmap_ctls 790
snd_hwdep_new 791
snd_pcm_stream_lock 792
snd_pcm_stream_unlock 793
snd_pcm_stream_lock_irq 794
snd_pcm_stream_unlock_irq 795
snd_pcm_stream_unlock_irqrestore 796
snd_pcm_stop 797
snd_pcm_stop_xrun 798
snd_pcm_suspend 799
snd_pcm_suspend_all 800
snd_pcm_lib_default_mmap 801
snd_pcm_lib_mmap_iomem 802
snd_malloc_pages 803
snd_free_pages 804
snd_dma_alloc_pages 805

snd_dma_alloc_pages_fallback 806
snd_dma_free_pages 807
6. Media Devices 808
Video2Linux devices 808
Digital TV (DVB) devices 926
Remote Controller devices 976
Media Controller devices 983
7. 16x50 UART Driver 987
uart_update_timeout 988
uart_get_baud_rate 989
uart_get_divisor 990
uart_console_write 991
uart_parse_earlycon 992
uart_parse_options 993
uart_set_options 994
uart_register_driver 995
uart_unregister_driver 996
uart_add_one_port 997
uart_remove_one_port 998
uart_handle_dcd_change 999
uart_handle_cts_change 1000
uart_insert_char 1001
serial8250_get_port 1002
serial8250_suspend_port 1003
serial8250_resume_port 1004
serial8250_register_8250_port 1005
serial8250_unregister_port 1006
8. Frame Buffer Library 1007
Frame Buffer Memory 1007
Frame Buffer Colormap 1010
Frame Buffer Video Mode Database 1015
Frame Buffer Macintosh Video Mode Database 1027
Frame Buffer Fonts 1030
9. Input Subsystem 1031
Input core 1031
Multitouch Library 1073
Polled input devices 1085
Matrix keyboars/keypads 1091
Sparse keymap support 1094
10. Serial Peripheral Interface (SPI) 1102
struct spi_statistics 1103
struct spi_device 1104
struct spi_driver 1106
spi_unregister_driver 1107
module_spi_driver 1108
struct spi_master 1109
struct spi_transfer 1113
struct spi_message 1115
spi_message_init_with_transfers 1116
spi_write 1117
spi_read 1118
spi_sync_transfer 1119
spi_w8r8 1120
spi_w8r16 1121

spi_w8r16be 1122
struct spi_board_info 1123
spi_register_board_info 1124
__spi_register_driver 1125
spi_alloc_device 1126
spi_add_device 1127
spi_new_device 1128
spi_finalize_current_transfer 1129
spi_get_next_queued_message 1130
spi_finalize_current_message 1131
spi_alloc_master 1132
spi_register_master 1133
devm_spi_register_master 1134
spi_unregister_master 1135
spi_busnum_to_master 1136
spi_setup 1137
spi_async 1138
spi_async_locked 1139
spi_sync 1140
spi_sync_locked 1141
spi_bus_lock 1142
spi_bus_unlock 1143
spi_write_then_read 1144
11. I²C and SMBus Subsystem 1145
struct i2c_driver 1146
struct i2c_client 1148
struct i2c_board_info 1149
I2C_BOARD_INFO 1150
struct i2c_algorithm 1151
struct i2c_bus_recovery_info 1152
struct i2c_adapter_quirks 1153
module_i2c_driver 1154
i2c_register_board_info 1155
i2c_verify_client 1156
i2c_lock_adapter 1157
i2c_unlock_adapter 1158
i2c_new_device 1159
i2c_unregister_device 1160
i2c_new_dummy 1161
i2c_verify_adapter 1162
i2c_add_adapter 1163
i2c_add_numbered_adapter 1164
i2c_del_adapter 1165
i2c_del_driver 1166
i2c_use_client 1167
i2c_release_client 1168
__i2c_transfer 1169
i2c_transfer 1170
i2c_master_send 1171
i2c_master_recv 1172
i2c_smbus_read_byte 1173
i2c_smbus_write_byte 1174
i2c_smbus_read_byte_data 1175
i2c_smbus_write_byte_data 1176

i2c_smbus_read_word_data 1177
i2c_smbus_write_word_data 1178
i2c_smbus_read_block_data 1179
i2c_smbus_write_block_data 1180
i2c_smbus_xfer 1181
i2c_smbus_read_i2c_block_data_or_emulated 1182
12. High Speed Synchronous Serial Interface (HSI) 1183
struct hsi_channel 1184
struct hsi_config 1185
struct hsi_board_info 1186
struct hsi_client 1187
struct hsi_client_driver 1188
struct hsi_msg 1189
struct hsi_port 1190
struct hsi_controller 1191
hsi_id 1192
hsi_port_id 1193
hsi_setup 1194
hsi_flush 1195
hsi_async_read 1196
hsi_async_write 1197
hsi_start_tx 1198
hsi_stop_tx 1199
hsi_port_unregister_clients 1200
hsi_unregister_controller 1201
hsi_register_controller 1202
hsi_register_client_driver 1203
hsi_put_controller 1204
hsi_alloc_controller 1205
hsi_free_msg 1206
hsi_alloc_msg 1207
hsi_async 1208
hsi_claim_port 1209
hsi_release_port 1210
hsi_register_port_event 1211
hsi_unregister_port_event 1212
hsi_event 1213
hsi_get_channel_id_by_name 1214
13. Pulse-Width Modulation (PWM) 1215
enum pwm_polarity 1216
struct pwm_device 1217
struct pwm_ops 1218
struct pwm_chip 1219
pwm_set_chip_data 1220
pwm_get_chip_data 1221
pwmchip_add_with_polarity 1222
pwmchip_add 1223
pwmchip_remove 1224
pwm_request 1225
pwm_request_from_chip 1226
pwm_free 1227
pwm_config 1228
pwm_set_polarity 1229
pwm_enable 1230

pwm_disable 1231
of_pwm_get 1232
pwm_get 1233
pwm_put 1234
devm_pwm_get 1235
devm_of_pwm_get 1236
devm_pwm_put 1237
pwm_can_sleep 1238

Chapter 1. Driver Basics

Driver Entry and Exit points

Name

include/linux/init.h — Document generation inconsistency

Oops

Warning

The template for this document tried to insert the structured comment from the file `include/linux/init.h` at this point, but none was found. This dummy section is inserted to allow generation to continue.

Atomic and pointer manipulation

Name

atomic_read — read atomic variable

Synopsis

```
int atomic_read (const atomic_t * v);
```

Arguments

v pointer of type atomic_t

Description

Atomically reads the value of *v*.

Name

atomic_set — set atomic variable

Synopsis

```
void atomic_set (atomic_t * v, int i);
```

Arguments

v pointer of type atomic_t

i required value

Description

Atomically sets the value of *v* to *i*.

Name

atomic_add — add integer to atomic variable

Synopsis

```
void atomic_add (int i, atomic_t * v);
```

Arguments

i integer value to add

v pointer of type atomic_t

Description

Atomically adds *i* to *v*.

Name

atomic_sub — subtract integer from atomic variable

Synopsis

```
void atomic_sub (int i, atomic_t * v);
```

Arguments

i integer value to subtract

v pointer of type atomic_t

Description

Atomically subtracts *i* from *v*.

Name

atomic_sub_and_test — subtract value from variable and test result

Synopsis

```
int atomic_sub_and_test (int i, atomic_t * v);
```

Arguments

i integer value to subtract

v pointer of type atomic_t

Description

Atomically subtracts *i* from *v* and returns true if the result is zero, or false for all other cases.

Name

atomic_inc — increment atomic variable

Synopsis

```
void atomic_inc (atomic_t * v);
```

Arguments

v pointer of type atomic_t

Description

Atomically increments *v* by 1.

Name

atomic_dec — decrement atomic variable

Synopsis

```
void atomic_dec (atomic_t * v);
```

Arguments

v pointer of type atomic_t

Description

Atomically decrements *v* by 1.

Name

atomic_dec_and_test — decrement and test

Synopsis

```
int atomic_dec_and_test (atomic_t * v);
```

Arguments

v pointer of type atomic_t

Description

Atomically decrements *v* by 1 and returns true if the result is 0, or false for all other cases.

Name

atomic_inc_and_test — increment and test

Synopsis

```
int atomic_inc_and_test (atomic_t * v);
```

Arguments

v pointer of type atomic_t

Description

Atomically increments *v* by 1 and returns true if the result is zero, or false for all other cases.

Name

atomic_add_negative — add and test if negative

Synopsis

```
int atomic_add_negative (int i, atomic_t * v);
```

Arguments

i integer value to add

v pointer of type atomic_t

Description

Atomically adds *i* to *v* and returns true if the result is negative, or false when result is greater than or equal to zero.

Name

atomic_add_return — add integer and return

Synopsis

```
int atomic_add_return (int i, atomic_t * v);
```

Arguments

i integer value to add

v pointer of type atomic_t

Description

Atomically adds *i* to *v* and returns *i* + *v*

Name

atomic_sub_return — subtract integer and return

Synopsis

```
int atomic_sub_return (int i, atomic_t * v);
```

Arguments

i integer value to subtract

v pointer of type atomic_t

Description

Atomically subtracts *i* from *v* and returns *v* - *i*

Name

__atomic_add_unless — add unless the number is already a given value

Synopsis

```
int __atomic_add_unless (atomic_t * v, int a, int u);
```

Arguments

v pointer of type atomic_t

a the amount to add to v...

u ...unless v is equal to u.

Description

Atomically adds *a* to *v*, so long as *v* was not already *u*. Returns the old value of *v*.

Name

atomic_inc_short — increment of a short integer

Synopsis

```
short int atomic_inc_short (short int * v);
```

Arguments

v pointer to type int

Description

Atomically adds 1 to *v* Returns the new value of *u*

Delaying, scheduling, and timer routines

Name

struct prev_cputime — snaphsot of system and user cputime

Synopsis

```
struct prev_cputime {
#ifndef CONFIG_VIRT_CPU_ACCOUNTING_NATIVE
  cputime_t utime;
  cputime_t stime;
  raw_spinlock_t lock;
#endif
};
```

Members

utime time spent in user mode

stime time spent in system mode

lock protects the above two fields

Description

Stores previous user/system time values such that we can guarantee monotonicity.

Name

struct task_cputime — collected CPU time counts

Synopsis

```
struct task_cputime {
  cputime_t utime;
  cputime_t stime;
  unsigned long long sum_exec_runtime;
};
```

Members

utime	time spent in user mode, in cputime_t units
stime	time spent in kernel mode, in cputime_t units
sum_exec_runtime	total time spent on the CPU, in nanoseconds

Description

This structure groups together three kinds of CPU time that are tracked for threads and thread groups. Most things considering CPU time want to group these counts together and treat all three of them in parallel.

Name

struct thread_group_cputimer — thread group interval timer counts

Synopsis

```
struct thread_group_cputimer {
  struct task_cputime_atomic cputime_atomic;
  bool running;
  bool checking_timer;
};
```

Members

cputime_atomic	atomic thread group interval timers.
running	true when there are timers running and *`cputime_atomic`* receives updates.
checking_timer	true when a thread in the group is in the process of checking for thread group timers.

Description

This structure contains the version of task_cputime, above, that is used for thread group CPU timer calculations.

Name

pid_alive — check that a task structure is not stale

Synopsis

```
int pid_alive (const struct task_struct * p);
```

Arguments

p Task structure to be checked.

Description

Test if a process is not yet dead (at most zombie state) If pid_alive fails, then pointers within the task structure can be stale and must not be dereferenced.

Return

1 if the process is alive. 0 otherwise.

Name

is_global_init — check if a task structure is init. Since init is free to have sub-threads we need to check tgid.

Synopsis

```
int is_global_init (struct task_struct * tsk);
```

Arguments

tsk Task structure to be checked.

Description

Check if a task structure is the first user space task the kernel created.

Return

1 if the task structure is init. 0 otherwise.

Name

task_nice — return the nice value of a given task.

Synopsis

```
int task_nice (const struct task_struct * p);
```

Arguments

p the task in question.

Return

The nice value [-20 ... 0 ... 19].

Name

is_idle_task — is the specified task an idle task?

Synopsis

```
bool is_idle_task (const struct task_struct * p);
```

Arguments

p the task in question.

Return

1 if *p* is an idle task. 0 otherwise.

Name

threadgroup_change_begin — mark the beginning of changes to a threadgroup

Synopsis

```
void threadgroup_change_begin (struct task_struct * tsk);
```

Arguments

tsk task causing the changes

Description

All operations which modify a threadgroup - a new thread joining the group, death of a member thread (the assertion of PF_EXITING) and exec(2) dethreading the process and replacing the leader - are wrapped by threadgroup_change_{begin|end}(). This is to provide a place which subsystems needing threadgroup stability can hook into for synchronization.

Name

threadgroup_change_end — mark the end of changes to a threadgroup

Synopsis

```
void threadgroup_change_end (struct task_struct * tsk);
```

Arguments

tsk task causing the changes

Description

See `threadgroup_change_begin`.

Name

wake_up_process — Wake up a specific process

Synopsis

```
int wake_up_process (struct task_struct * p);
```

Arguments

p The process to be woken up.

Description

Attempt to wake up the nominated process and move it to the set of runnable processes.

Return

1 if the process was woken up, 0 if it was already running.

It may be assumed that this function implies a write memory barrier before changing the task state if and only if any tasks are woken up.

Name

preempt_notifier_register — tell me when current is being preempted & rescheduled

Synopsis

```
void preempt_notifier_register (struct preempt_notifier * notifier);
```

Arguments

notifier notifier struct to register

Name

preempt_notifier_unregister — no longer interested in preemption notifications

Synopsis

```
void preempt_notifier_unregister (struct preempt_notifier * notifier);
```

Arguments

notifier notifier struct to unregister

Description

This is *not* safe to call from within a preemption notifier.

Name

preempt_schedule_notrace — preempt_schedule called by tracing

Synopsis

```
__visible void __sched notrace preempt_schedule_notrace ( void);
```

Arguments

void no arguments

Description

The tracing infrastructure uses preempt_enable_notrace to prevent recursion and tracing preempt enabling caused by the tracing infrastructure itself. But as tracing can happen in areas coming from userspace or just about to enter userspace, a preempt enable can occur before `user_exit` is called. This will cause the scheduler to be called when the system is still in usermode.

To prevent this, the preempt_enable_notrace will use this function instead of `preempt_schedule` to exit user context if needed before calling the scheduler.

Name

sched_setscheduler — change the scheduling policy and/or RT priority of a thread.

Synopsis

```
int sched_setscheduler (struct task_struct * p, int policy, const struct
sched_param * param);
```

Arguments

p the task in question.

policy new policy.

param structure containing the new RT priority.

Return

0 on success. An error code otherwise.

NOTE that the task may be already dead.

Name

sched_setscheduler_nocheck — change the scheduling policy and/or RT priority of a thread from kernelspace.

Synopsis

```
int sched_setscheduler_nocheck (struct task_struct * p, int policy,
const struct sched_param * param);
```

Arguments

p the task in question.

policy new policy.

param structure containing the new RT priority.

Description

Just like sched_setscheduler, only don't bother checking if the current context has permission. For example, this is needed in `stop_machine`: we create temporary high priority worker threads, but our caller might not have that capability.

Return

0 on success. An error code otherwise.

Name

yield — yield the current processor to other threads.

Synopsis

```
void __sched yield ( void);
```

Arguments

void no arguments

Description

Do not ever use this function, there's a 99% chance you're doing it wrong.

The scheduler is at all times free to pick the calling task as the most eligible task to run, if removing the `yield` call from your code breaks it, its already broken.

Typical broken usage is

while (!event) `yield`;

where one assumes that `yield` will let 'the other' process run that will make event true. If the current task is a SCHED_FIFO task that will never happen. Never use `yield` as a progress guarantee!!

If you want to use `yield` to wait for something, use `wait_event`. If you want to use `yield` to be 'nice' for others, use `cond_resched`. If you still want to use `yield`, do not!

Name

yield_to — yield the current processor to another thread in your thread group, or accelerate that thread toward the processor it's on.

Synopsis

```
int __sched yield_to (struct task_struct * p, bool preempt);
```

Arguments

p target task

preempt whether task preemption is allowed or not

Description

It's the caller's job to ensure that the target task struct can't go away on us before we can do any checks.

Return

true (>0) if we indeed boosted the target task. false (0) if we failed to boost the target. -ESRCH if there's no task to yield to.

Name

cpupri_find — find the best (lowest-pri) CPU in the system

Synopsis

```
int cpupri_find (struct cpupri * cp, struct task_struct * p, struct
cpumask * lowest_mask);
```

Arguments

cp	The cpupri context
p	The task
lowest_mask	A mask to fill in with selected CPUs (or NULL)

Note

This function returns the recommended CPUs as calculated during the current invocation. By the time the call returns, the CPUs may have in fact changed priorities any number of times. While not ideal, it is not an issue of correctness since the normal rebalancer logic will correct any discrepancies created by racing against the uncertainty of the current priority configuration.

Return

(int)bool - CPUs were found

Name

cpupri_set — update the cpu priority setting

Synopsis

```
void cpupri_set (struct cpupri * cp, int cpu, int newpri);
```

Arguments

cp The cpupri context

cpu The target cpu

newpri The priority (INVALID-RT99) to assign to this CPU

Note

Assumes cpu_rq(cpu)->lock is locked

Returns

(void)

Name

cpupri_init — initialize the cpupri structure

Synopsis

```
int cpupri_init (struct cpupri * cp);
```

Arguments

cp The cpupri context

Return

-ENOMEM on memory allocation failure.

Name

cpupri_cleanup — clean up the cpupri structure

Synopsis

```
void cpupri_cleanup (struct cpupri * cp);
```

Arguments

cp The cpupri context

Name

update_tg_load_avg — update the tg's load avg

Synopsis

```
void update_tg_load_avg (struct cfs_rq * cfs_rq, int force);
```

Arguments

cfs_rq the cfs_rq whose avg changed

force update regardless of how small the difference

Description

This function 'ensures': tg->load_avg := \Sum tg->cfs_rq[]->avg.load. However, because tg->load_avg is a global value there are performance considerations.

In order to avoid having to look at the other cfs_rq's, we use a differential update where we store the last value we propagated. This in turn allows skipping updates if the differential is 'small'.

Updating tg's load_avg is necessary before `update_cfs_share` (which is done) and `effective_load` (which is not done because it is too costly).

Name

update_cfs_rq_load_avg — update the cfs_rq's load/util averages

Synopsis

```
int update_cfs_rq_load_avg (u64 now, struct cfs_rq * cfs_rq);
```

Arguments

now current time, as per `cfs_rq_clock_task`

cfs_rq cfs_rq to update

Description

The cfs_rq avg is the direct sum of all its entities (blocked and runnable) avg. The immediate corollary is that all (fair) tasks must be attached, see `post_init_entity_util_avg`.

cfs_rq->avg is used for `task_h_load` and `update_cfs_share` for example.

Returns true if the load decayed or we removed load.

Since both these conditions indicate a changed cfs_rq->avg.load we should call `update_tg_load_avg` when this function returns true.

Name

attach_entity_load_avg — attach this entity to its cfs_rq load avg

Synopsis

```
void attach_entity_load_avg (struct cfs_rq * cfs_rq, struct sched_entity
* se);
```

Arguments

cfs_rq cfs_rq to attach to

se sched_entity to attach

Description

Must call `update_cfs_rq_load_avg` before this, since we rely on cfs_rq->avg.last_update_time being current.

Name

detach_entity_load_avg — detach this entity from its cfs_rq load avg

Synopsis

```
void detach_entity_load_avg (struct cfs_rq * cfs_rq, struct sched_entity
* se);
```

Arguments

cfs_rq cfs_rq to detach from

se sched_entity to detach

Description

Must call `update_cfs_rq_load_avg` before this, since we rely on cfs_rq->avg.last_update_time being current.

Name

__update_cpu_load — update the rq->cpu_load[] statistics

Synopsis

```
void __update_cpu_load (struct rq * this_rq, unsigned long this_load,
unsigned long pending_updates, int active);
```

Arguments

this_rq	The rq to update statistics for
this_load	The current load
pending_updates	The number of missed updates
active	!0 for NOHZ_FULL

Description

Update rq->cpu_load[] statistics. This function is usually called every scheduler tick (TICK_NSEC).

This function computes a decaying average

load[i]' = (1 - 1/2^i) * load[i] + (1/2^i) * load

Because of NOHZ it might not get called on every tick which gives need for the *pending_updates* argument.

load[i]_n = (1 - 1/2^i) * load[i]_n-1 + (1/2^i) * load_n-1 = A * load[i]_n-1 + B ; A := (1 - 1/2^i), B := (1/2^i) * load = A * (A * load[i]_n-2 + B) + B = A * (A * (A * load[i]_n-3 + B) + B) + B = A^3 * load[i]_n-3 + (A^2 + A + 1) * B = A^n * load[i]_0 + (A^(n-1) + A^(n-2) + ... + 1) * B = A^n * load[i]_0 + ((1 - A^n) / (1 - A)) * B = (1 - 1/2^i)^n * (load[i]_0 - load) + load

In the above we've assumed load_n := load, which is true for NOHZ_FULL as any change in load would have resulted in the tick being turned back on.

For regular NOHZ, this reduces to:

load[i]_n = (1 - 1/2^i)^n * load[i]_0

see `decay_load_misses`. For NOHZ_FULL we get to subtract and add the extra term. See the *active* paramter.

Name

get_sd_load_idx — Obtain the load index for a given sched domain.

Synopsis

```
int get_sd_load_idx (struct sched_domain * sd, enum cpu_idle_type idle);
```

Arguments

sd The sched_domain whose load_idx is to be obtained.

idle The idle status of the CPU for whose sd load_idx is obtained.

Return

The load index.

Name

update_sg_lb_stats — Update sched_group's statistics for load balancing.

Synopsis

```
void update_sg_lb_stats (struct lb_env * env, struct sched_group *
group, int load_idx, int local_group, struct sg_lb_stats * sgs, bool
* overload);
```

Arguments

env	The load balancing environment.
group	sched_group whose statistics are to be updated.
load_idx	Load index of sched_domain of this_cpu for load calc.
local_group	Does group contain this_cpu.
sgs	variable to hold the statistics for this group.
overload	Indicate more than one runnable task for any CPU.

Name

update_sd_pick_busiest — return 1 on busiest group

Synopsis

```
bool update_sd_pick_busiest (struct lb_env * env, struct sd_lb_stats *
sds, struct sched_group * sg, struct sg_lb_stats * sgs);
```

Arguments

env The load balancing environment.

sds sched_domain statistics

sg sched_group candidate to be checked for being the busiest

sgs sched_group statistics

Description

Determine if *sg* is a busier group than the previously selected busiest group.

Return

`true` if *sg* is a busier group than the previously selected busiest group. `false` otherwise.

Name

update_sd_lb_stats — Update sched_domain's statistics for load balancing.

Synopsis

```
void update_sd_lb_stats (struct lb_env * env, struct sd_lb_stats * sds);
```

Arguments

env The load balancing environment.

sds variable to hold the statistics for this sched_domain.

Name

check_asym_packing — Check to see if the group is packed into the sched doman.

Synopsis

```
int check_asym_packing (struct lb_env * env, struct sd_lb_stats * sds);
```

Arguments

env The load balancing environment.

sds Statistics of the sched_domain which is to be packed

Description

This is primarily intended to used at the sibling level. Some cores like POWER7 prefer to use lower numbered SMT threads. In the case of POWER7, it can move to lower SMT modes only when higher threads are idle. When in lower SMT modes, the threads will perform better since they share less core resources. Hence when we have idle threads, we want them to be the higher ones.

This packing function is run on idle threads. It checks to see if the busiest CPU in this domain (core in the P7 case) has a higher CPU number than the packing function is being run on. Here we are assuming lower CPU number will be equivalent to lower a SMT thread number.

Return

1 when packing is required and a task should be moved to this CPU. The amount of the imbalance is returned in *imbalance.

Name

fix_small_imbalance — Calculate the minor imbalance that exists amongst the groups of a sched_domain, during load balancing.

Synopsis

```
void fix_small_imbalance (struct lb_env * env, struct sd_lb_stats * sds);
```

Arguments

env The load balancing environment.

sds Statistics of the sched_domain whose imbalance is to be calculated.

Name

calculate_imbalance — Calculate the amount of imbalance present within the groups of a given sched_domain during load balance.

Synopsis

```
void calculate_imbalance (struct lb_env * env, struct sd_lb_stats * sds);
```

Arguments

env load balance environment

sds statistics of the sched_domain whose imbalance is to be calculated.

Name

find_busiest_group — Returns the busiest group within the sched_domain if there is an imbalance.

Synopsis

```
struct sched_group * find_busiest_group (struct lb_env * env);
```

Arguments

env The load balancing environment.

Description

Also calculates the amount of weighted load which should be moved to restore balance.

Return

- The busiest group if imbalance exists.

Name

DECLARE_COMPLETION — declare and initialize a completion structure

Synopsis

```
DECLARE_COMPLETION ( work);
```

Arguments

work identifier for the completion structure

Description

This macro declares and initializes a completion structure. Generally used for static declarations. You should use the _ONSTACK variant for automatic variables.

Name

DECLARE_COMPLETION_ONSTACK — declare and initialize a completion structure

Synopsis

```
DECLARE_COMPLETION_ONSTACK ( work);
```

Arguments

work identifier for the completion structure

Description

This macro declares and initializes a completion structure on the kernel stack.

Name

init_completion — Initialize a dynamically allocated completion

Synopsis

```
void init_completion (struct completion * x);
```

Arguments

x pointer to completion structure that is to be initialized

Description

This inline function will initialize a dynamically created completion structure.

Name

reinit_completion — reinitialize a completion structure

Synopsis

```
void reinit_completion (struct completion * x);
```

Arguments

x pointer to completion structure that is to be reinitialized

Description

This inline function should be used to reinitialize a completion structure so it can be reused. This is especially important after `complete_all` is used.

Name

__round_jiffies — function to round jiffies to a full second

Synopsis

```
unsigned long __round_jiffies (unsigned long j, int cpu);
```

Arguments

j the time in (absolute) jiffies that should be rounded

cpu the processor number on which the timeout will happen

Description

`__round_jiffies` rounds an absolute time in the future (in jiffies) up or down to (approximately) full seconds. This is useful for timers for which the exact time they fire does not matter too much, as long as they fire approximately every X seconds.

By rounding these timers to whole seconds, all such timers will fire at the same time, rather than at various times spread out. The goal of this is to have the CPU wake up less, which saves power.

The exact rounding is skewed for each processor to avoid all processors firing at the exact same time, which could lead to lock contention or spurious cache line bouncing.

The return value is the rounded version of the *j* parameter.

Name

__round_jiffies_relative — function to round jiffies to a full second

Synopsis

```
unsigned long __round_jiffies_relative (unsigned long j, int cpu);
```

Arguments

j the time in (relative) jiffies that should be rounded

cpu the processor number on which the timeout will happen

Description

`__round_jiffies_relative` rounds a time delta in the future (in jiffies) up or down to (approximately) full seconds. This is useful for timers for which the exact time they fire does not matter too much, as long as they fire approximately every X seconds.

By rounding these timers to whole seconds, all such timers will fire at the same time, rather than at various times spread out. The goal of this is to have the CPU wake up less, which saves power.

The exact rounding is skewed for each processor to avoid all processors firing at the exact same time, which could lead to lock contention or spurious cache line bouncing.

The return value is the rounded version of the *j* parameter.

Name

round_jiffies — function to round jiffies to a full second

Synopsis

```
unsigned long round_jiffies (unsigned long j);
```

Arguments

j the time in (absolute) jiffies that should be rounded

Description

`round_jiffies` rounds an absolute time in the future (in jiffies) up or down to (approximately) full seconds. This is useful for timers for which the exact time they fire does not matter too much, as long as they fire approximately every X seconds.

By rounding these timers to whole seconds, all such timers will fire at the same time, rather than at various times spread out. The goal of this is to have the CPU wake up less, which saves power.

The return value is the rounded version of the *j* parameter.

Name

round_jiffies_relative — function to round jiffies to a full second

Synopsis

```
unsigned long round_jiffies_relative (unsigned long j);
```

Arguments

j the time in (relative) jiffies that should be rounded

Description

`round_jiffies_relative` rounds a time delta in the future (in jiffies) up or down to (approximately) full seconds. This is useful for timers for which the exact time they fire does not matter too much, as long as they fire approximately every X seconds.

By rounding these timers to whole seconds, all such timers will fire at the same time, rather than at various times spread out. The goal of this is to have the CPU wake up less, which saves power.

The return value is the rounded version of the *j* parameter.

Name

__round_jiffies_up — function to round jiffies up to a full second

Synopsis

```
unsigned long __round_jiffies_up (unsigned long j, int cpu);
```

Arguments

j the time in (absolute) jiffies that should be rounded

cpu the processor number on which the timeout will happen

Description

This is the same as `__round_jiffies` except that it will never round down. This is useful for timeouts for which the exact time of firing does not matter too much, as long as they don't fire too early.

Name

__round_jiffies_up_relative — function to round jiffies up to a full second

Synopsis

```
unsigned long __round_jiffies_up_relative (unsigned long j, int cpu);
```

Arguments

j the time in (relative) jiffies that should be rounded

cpu the processor number on which the timeout will happen

Description

This is the same as `__round_jiffies_relative` except that it will never round down. This is useful for timeouts for which the exact time of firing does not matter too much, as long as they don't fire too early.

Name

round_jiffies_up — function to round jiffies up to a full second

Synopsis

```
unsigned long round_jiffies_up (unsigned long j);
```

Arguments

j the time in (absolute) jiffies that should be rounded

Description

This is the same as `round_jiffies` except that it will never round down. This is useful for timeouts for which the exact time of firing does not matter too much, as long as they don't fire too early.

Name

round_jiffies_up_relative — function to round jiffies up to a full second

Synopsis

```
unsigned long round_jiffies_up_relative (unsigned long j);
```

Arguments

j the time in (relative) jiffies that should be rounded

Description

This is the same as `round_jiffies_relative` except that it will never round down. This is useful for timeouts for which the exact time of firing does not matter too much, as long as they don't fire too early.

Name

set_timer_slack — set the allowed slack for a timer

Synopsis

```
void set_timer_slack (struct timer_list * timer, int slack_hz);
```

Arguments

timer the timer to be modified

slack_hz the amount of time (in jiffies) allowed for rounding

Description

Set the amount of time, in jiffies, that a certain timer has in terms of slack. By setting this value, the timer subsystem will schedule the actual timer somewhere between the time `mod_timer` asks for, and that time plus the slack.

By setting the slack to -1, a percentage of the delay is used instead.

Name

init_timer_key — initialize a timer

Synopsis

```
void init_timer_key (struct timer_list * timer, unsigned int flags,
const char * name, struct lock_class_key * key);
```

Arguments

timer the timer to be initialized

flags timer flags

name name of the timer

key lockdep class key of the fake lock used for tracking timer sync lock dependencies

Description

`init_timer_key` must be done to a timer prior calling *any* of the other timer functions.

Name

mod_timer_pending — modify a pending timer's timeout

Synopsis

```
int mod_timer_pending (struct timer_list * timer, unsigned long expires);
```

Arguments

timer the pending timer to be modified

expires new timeout in jiffies

Description

`mod_timer_pending` is the same for pending timers as `mod_timer`, but will not re-activate and modify already deleted timers.

It is useful for unserialized use of timers.

Name

mod_timer — modify a timer's timeout

Synopsis

```
int mod_timer (struct timer_list * timer, unsigned long expires);
```

Arguments

timer the timer to be modified

expires new timeout in jiffies

Description

`mod_timer` is a more efficient way to update the expire field of an active timer (if the timer is inactive it will be activated)

mod_timer(timer, expires) is equivalent to:

del_timer(timer); timer->expires = expires; add_timer(timer);

Note that if there are multiple unserialized concurrent users of the same timer, then `mod_timer` is the only safe way to modify the timeout, since `add_timer` cannot modify an already running timer.

The function returns whether it has modified a pending timer or not. (ie. `mod_timer` of an inactive timer returns 0, `mod_timer` of an active timer returns 1.)

Name

mod_timer_pinned — modify a timer's timeout

Synopsis

```
int mod_timer_pinned (struct timer_list * timer, unsigned long expires);
```

Arguments

timer the timer to be modified

expires new timeout in jiffies

Description

`mod_timer_pinned` is a way to update the expire field of an active timer (if the timer is inactive it will be activated) and to ensure that the timer is scheduled on the current CPU.

Note that this does not prevent the timer from being migrated when the current CPU goes offline. If this is a problem for you, use CPU-hotplug notifiers to handle it correctly, for example, cancelling the timer when the corresponding CPU goes offline.

mod_timer_pinned(timer, expires) is equivalent to:

del_timer(timer); timer->expires = expires; add_timer(timer);

Name

add_timer — start a timer

Synopsis

```
void add_timer (struct timer_list * timer);
```

Arguments

timer the timer to be added

Description

The kernel will do a ->function(->data) callback from the timer interrupt at the ->expires point in the future. The current time is 'jiffies'.

The timer's ->expires, ->function (and if the handler uses it, ->data) fields must be set prior calling this function.

Timers with an ->expires field in the past will be executed in the next timer tick.

Name

add_timer_on — start a timer on a particular CPU

Synopsis

```
void add_timer_on (struct timer_list * timer, int cpu);
```

Arguments

timer the timer to be added

cpu the CPU to start it on

Description

This is not very scalable on SMP. Double adds are not possible.

Name

del_timer — deactive a timer.

Synopsis

```
int del_timer (struct timer_list * timer);
```

Arguments

timer the timer to be deactivated

Description

`del_timer` deactivates a timer - this works on both active and inactive timers.

The function returns whether it has deactivated a pending timer or not. (ie. `del_timer` of an inactive timer returns 0, `del_timer` of an active timer returns 1.)

Name

try_to_del_timer_sync — Try to deactivate a timer

Synopsis

```
int try_to_del_timer_sync (struct timer_list * timer);
```

Arguments

timer timer do del

Description

This function tries to deactivate a timer. Upon successful (ret >= 0) exit the timer is not queued and the handler is not running on any CPU.

Name

del_timer_sync — deactivate a timer and wait for the handler to finish.

Synopsis

```
int del_timer_sync (struct timer_list * timer);
```

Arguments

timer the timer to be deactivated

Description

This function only differs from `del_timer` on SMP: besides deactivating the timer it also makes sure the handler has finished executing on other CPUs.

Synchronization rules

Callers must prevent restarting of the timer, otherwise this function is meaningless. It must not be called from interrupt contexts unless the timer is an irqsafe one. The caller must not hold locks which would prevent completion of the timer's handler. The timer's handler must not call `add_timer_on`. Upon exit the timer is not queued and the handler is not running on any CPU.

Note

For !irqsafe timers, you must not hold locks that are held in interrupt context while calling this function. Even if the lock has nothing to do with the timer in question. Here's why:

CPU0 CPU1 ---- ---- <SOFTIRQ> `call_timer_fn`; base->running_timer = mytimer; spin_lock_irq(somelock); <IRQ> spin_lock(somelock); del_timer_sync(mytimer); while (base->running_timer == mytimer);

Now `del_timer_sync` will never return and never release somelock. The interrupt on the other CPU is waiting to grab somelock but it has interrupted the softirq that CPU0 is waiting to finish.

The function returns whether it has deactivated a pending timer or not.

Name

schedule_timeout — sleep until timeout

Synopsis

```
signed long __sched schedule_timeout (signed long timeout);
```

Arguments

timeout timeout value in jiffies

Description

Make the current task sleep until *timeout* jiffies have elapsed. The routine will return immediately unless the current task state has been set (see `set_current_state`).

You can set the task state as follows -

`TASK_UNINTERRUPTIBLE` - at least *timeout* jiffies are guaranteed to pass before the routine returns. The routine will return 0

`TASK_INTERRUPTIBLE` - the routine may return early if a signal is delivered to the current task. In this case the remaining time in jiffies will be returned, or 0 if the timer expired in time

The current task state is guaranteed to be TASK_RUNNING when this routine returns.

Specifying a *timeout* value of `MAX_SCHEDULE_TIMEOUT` will schedule the CPU away without a bound on the timeout. In this case the return value will be `MAX_SCHEDULE_TIMEOUT`.

In all cases the return value is guaranteed to be non-negative.

Name

msleep — sleep safely even with waitqueue interruptions

Synopsis

```
void msleep (unsigned int msecs);
```

Arguments

msecs Time in milliseconds to sleep for

Name

msleep_interruptible — sleep waiting for signals

Synopsis

```
unsigned long msleep_interruptible (unsigned int msecs);
```

Arguments

msecs Time in milliseconds to sleep for

Name

usleep_range — Drop in replacement for udelay where wakeup is flexible

Synopsis

```
void __sched usleep_range (unsigned long min, unsigned long max);
```

Arguments

min Minimum time in usecs to sleep

max Maximum time in usecs to sleep

Wait queues and Wake events

Name

waitqueue_active — - locklessly test for waiters on the queue

Synopsis

```
int waitqueue_active (wait_queue_head_t * q);
```

Arguments

q the waitqueue to test for waiters

Description

returns true if the wait list is not empty

NOTE

this function is lockless and requires care, incorrect usage _will_ lead to sporadic and non-obvious failure.

Use either while holding wait_queue_head_t

:lock or when used for wakeups with an extra `smp_mb` like:

CPU0 - waker CPU1 - waiter

for (;;) { *cond* = true; prepare_to_wait(wq, wait, state); `smp_mb`; // `smp_mb` from `set_current_state` if (waitqueue_active(wq)) if (*cond*) wake_up(wq); break; `schedule`; } finish_wait(wq, wait);

Because without the explicit `smp_mb` it's possible for the `waitqueue_active` load to get hoisted over the *cond* store such that we'll observe an empty wait list while the waiter might not observe *cond*.

Also note that this 'optimization' trades a `spin_lock` for an `smp_mb`, which (when the lock is uncontended) are of roughly equal cost.

Name

wait_event — sleep until a condition gets true

Synopsis

```
wait_event ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

Name

wait_event_freezable — sleep (or freeze) until a condition gets true

Synopsis

```
wait_event_freezable ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE -- so as not to contribute to system load) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

Name

wait_event_timeout — sleep until a condition gets true or a timeout elapses

Synopsis

```
wait_event_timeout ( wq, condition, timeout);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
timeout	timeout, in jiffies

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

Returns

0 if the *condition* evaluated to false after the *timeout* elapsed, 1 if the *condition* evaluated to true after the *timeout* elapsed, or the remaining jiffies (at least 1) if the *condition* evaluated to true before the *timeout* elapsed.

Name

wait_event_cmd — sleep until a condition gets true

Synopsis

```
wait_event_cmd ( wq, condition, cmd1, cmd2);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
cmd1	the command will be executed before sleep
cmd2	the command will be executed after sleep

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

Name

wait_event_interruptible — sleep until a condition gets true

Synopsis

```
wait_event_interruptible ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_timeout — sleep until a condition gets true or a timeout elapses

Synopsis

```
wait_event_interruptible_timeout ( wq, condition, timeout);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
timeout	timeout, in jiffies

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

Returns

0 if the *condition* evaluated to false after the *timeout* elapsed, 1 if the *condition* evaluated to true after the *timeout* elapsed, the remaining jiffies (at least 1) if the *condition* evaluated to true before the *timeout* elapsed, or -ERESTARTSYS if it was interrupted by a signal.

Name

wait_event_hrtimeout — sleep until a condition gets true or a timeout elapses

Synopsis

```
wait_event_hrtimeout ( wq, condition, timeout);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
timeout	timeout, as a ktime_t

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

The function returns 0 if *condition* became true, or -ETIME if the timeout elapsed.

Name

wait_event_interruptible_hrtimeout — sleep until a condition gets true or a timeout elapses

Synopsis

```
wait_event_interruptible_hrtimeout ( wq, condition, timeout);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
timeout	timeout, as a ktime_t

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

The function returns 0 if *condition* became true, -ERESTARTSYS if it was interrupted by a signal, or -ETIME if the timeout elapsed.

Name

wait_event_interruptible_locked — sleep until a condition gets true

Synopsis

```
wait_event_interruptible_locked ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

It must be called with wq.lock being held. This spinlock is unlocked while sleeping but *condition* testing is done while lock is held and when this macro exits the lock is held.

The lock is locked/unlocked using spin_lock/spin_unlock functions which must match the way they are locked/unlocked outside of this macro.

wake_up_locked has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_locked_irq — sleep until a condition gets true

Synopsis

```
wait_event_interruptible_locked_irq ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

It must be called with wq.lock being held. This spinlock is unlocked while sleeping but *condition* testing is done while lock is held and when this macro exits the lock is held.

The lock is locked/unlocked using `spin_lock_irq`/`spin_unlock_irq` functions which must match the way they are locked/unlocked outside of this macro.

`wake_up_locked` has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_exclusive_locked — sleep exclusively until a condition gets true

Synopsis

```
wait_event_interruptible_exclusive_locked ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

It must be called with wq.lock being held. This spinlock is unlocked while sleeping but *condition* testing is done while lock is held and when this macro exits the lock is held.

The lock is locked/unlocked using spin_lock/spin_unlock functions which must match the way they are locked/unlocked outside of this macro.

The process is put on the wait queue with an WQ_FLAG_EXCLUSIVE flag set thus when other process waits process on the list if this process is awaken further processes are not considered.

wake_up_locked has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_exclusive_locked_irq — sleep until a condition gets true

Synopsis

```
wait_event_interruptible_exclusive_locked_irq ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

It must be called with wq.lock being held. This spinlock is unlocked while sleeping but *condition* testing is done while lock is held and when this macro exits the lock is held.

The lock is locked/unlocked using spin_lock_irq/spin_unlock_irq functions which must match the way they are locked/unlocked outside of this macro.

The process is put on the wait queue with an WQ_FLAG_EXCLUSIVE flag set thus when other process waits process on the list if this process is awaken further processes are not considered.

wake_up_locked has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_killable — sleep until a condition gets true

Synopsis

```
wait_event_killable ( wq, condition);
```

Arguments

wq the waitqueue to wait on

condition a C expression for the event to wait for

Description

The process is put to sleep (TASK_KILLABLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

The function will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_lock_irq_cmd — sleep until a condition gets true. The condition is checked under the lock. This is expected to be called with the lock taken.

Synopsis

wait_event_lock_irq_cmd (*wq*, *condition*, *lock*, *cmd*);

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
lock	a locked spinlock_t, which will be released before cmd and schedule and reacquired afterwards.
cmd	a command which is invoked outside the critical section before sleep

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

This is supposed to be called while holding the lock. The lock is dropped before invoking the cmd and going to sleep and is reacquired afterwards.

Name

wait_event_lock_irq — sleep until a condition gets true. The condition is checked under the lock. This is expected to be called with the lock taken.

Synopsis

wait_event_lock_irq (*wq*, *condition*, *lock*);

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
lock	a locked spinlock_t, which will be released before `schedule` and reacquired afterwards.

Description

The process is put to sleep (TASK_UNINTERRUPTIBLE) until the *condition* evaluates to true. The *condition* is checked each time the waitqueue *wq* is woken up.

`wake_up` has to be called after changing any variable that could change the result of the wait condition.

This is supposed to be called while holding the lock. The lock is dropped before going to sleep and is reacquired afterwards.

Name

wait_event_interruptible_lock_irq_cmd — sleep until a condition gets true. The condition is checked under the lock. This is expected to be called with the lock taken.

Synopsis

wait_event_interruptible_lock_irq_cmd (*wq*, *condition*, *lock*, *cmd*);

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
lock	a locked spinlock_t, which will be released before cmd and schedule and reacquired afterwards.
cmd	a command which is invoked outside the critical section before sleep

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or a signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

This is supposed to be called while holding the lock. The lock is dropped before invoking the cmd and going to sleep and is reacquired afterwards.

The macro will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_lock_irq — sleep until a condition gets true. The condition is checked under the lock. This is expected to be called with the lock taken.

Synopsis

```
wait_event_interruptible_lock_irq ( wq, condition, lock);
```

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
lock	a locked spinlock_t, which will be released before `schedule` and reacquired afterwards.

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

`wake_up` has to be called after changing any variable that could change the result of the wait condition.

This is supposed to be called while holding the lock. The lock is dropped before going to sleep and is reacquired afterwards.

The macro will return -ERESTARTSYS if it was interrupted by a signal and 0 if *condition* evaluated to true.

Name

wait_event_interruptible_lock_irq_timeout — sleep until a condition gets true or a timeout elapses. The condition is checked under the lock. This is expected to be called with the lock taken.

Synopsis

wait_event_interruptible_lock_irq_timeout (*wq*, *condition*, *lock*, *timeout*);

Arguments

wq	the waitqueue to wait on
condition	a C expression for the event to wait for
lock	a locked spinlock_t, which will be released before schedule and reacquired afterwards.
timeout	timeout, in jiffies

Description

The process is put to sleep (TASK_INTERRUPTIBLE) until the *condition* evaluates to true or signal is received. The *condition* is checked each time the waitqueue *wq* is woken up.

wake_up has to be called after changing any variable that could change the result of the wait condition.

This is supposed to be called while holding the lock. The lock is dropped before going to sleep and is reacquired afterwards.

The function returns 0 if the *timeout* elapsed, -ERESTARTSYS if it was interrupted by a signal, and the remaining jiffies otherwise if the condition evaluated to true before the timeout elapsed.

Name

wait_on_bit — wait for a bit to be cleared

Synopsis

```
int wait_on_bit (unsigned long * word, int bit, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

mode the task state to sleep in

Description

There is a standard hashed waitqueue table for generic use. This is the part of the hashtable's accessor API that waits on a bit. For instance, if one were to have waiters on a bitflag, one would call `wait_on_bit` in threads waiting for the bit to clear. One uses `wait_on_bit` where one is waiting for the bit to clear, but has no intention of setting it. Returned value will be zero if the bit was cleared, or non-zero if the process received a signal and the mode permitted wakeup on that signal.

Name

wait_on_bit_io — wait for a bit to be cleared

Synopsis

```
int wait_on_bit_io (unsigned long * word, int bit, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

mode the task state to sleep in

Description

Use the standard hashed waitqueue table to wait for a bit to be cleared. This is similar to `wait_on_bit`, but calls `io_schedule` instead of `schedule` for the actual waiting.

Returned value will be zero if the bit was cleared, or non-zero if the process received a signal and the mode permitted wakeup on that signal.

Name

wait_on_bit_timeout — wait for a bit to be cleared or a timeout elapses

Synopsis

```
int wait_on_bit_timeout (unsigned long * word, int bit, unsigned mode,
unsigned long timeout);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

mode the task state to sleep in

timeout timeout, in jiffies

Description

Use the standard hashed waitqueue table to wait for a bit to be cleared. This is similar to `wait_on_bit`, except also takes a timeout parameter.

Returned value will be zero if the bit was cleared before the *timeout* elapsed, or non-zero if the *timeout* elapsed or process received a signal and the mode permitted wakeup on that signal.

Name

wait_on_bit_action — wait for a bit to be cleared

Synopsis

```
int wait_on_bit_action (unsigned long * word, int bit, wait_bit_action_f
* action, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

action the function used to sleep, which may take special actions

mode the task state to sleep in

Description

Use the standard hashed waitqueue table to wait for a bit to be cleared, and allow the waiting action to be specified. This is like `wait_on_bit` but allows fine control of how the waiting is done.

Returned value will be zero if the bit was cleared, or non-zero if the process received a signal and the mode permitted wakeup on that signal.

Name

wait_on_bit_lock — wait for a bit to be cleared, when wanting to set it

Synopsis

```
int wait_on_bit_lock (unsigned long * word, int bit, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

mode the task state to sleep in

Description

There is a standard hashed waitqueue table for generic use. This is the part of the hashtable's accessor API that waits on a bit when one intends to set it, for instance, trying to lock bitflags. For instance, if one were to have waiters trying to set bitflag and waiting for it to clear before setting it, one would call `wait_on_bit` in threads waiting to be able to set the bit. One uses `wait_on_bit_lock` where one is waiting for the bit to clear with the intention of setting it, and when done, clearing it.

Returns zero if the bit was (eventually) found to be clear and was set. Returns non-zero if a signal was delivered to the process and the *mode* allows that signal to wake the process.

Name

wait_on_bit_lock_io — wait for a bit to be cleared, when wanting to set it

Synopsis

```
int wait_on_bit_lock_io (unsigned long * word, int bit, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

mode the task state to sleep in

Description

Use the standard hashed waitqueue table to wait for a bit to be cleared and then to atomically set it. This is similar to `wait_on_bit`, but calls `io_schedule` instead of `schedule` for the actual waiting.

Returns zero if the bit was (eventually) found to be clear and was set. Returns non-zero if a signal was delivered to the process and the *mode* allows that signal to wake the process.

Name

wait_on_bit_lock_action — wait for a bit to be cleared, when wanting to set it

Synopsis

```
int wait_on_bit_lock_action (unsigned long * word, int bit,
wait_bit_action_f * action, unsigned mode);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

action the function used to sleep, which may take special actions

mode the task state to sleep in

Description

Use the standard hashed waitqueue table to wait for a bit to be cleared and then to set it, and allow the waiting action to be specified. This is like `wait_on_bit` but allows fine control of how the waiting is done.

Returns zero if the bit was (eventually) found to be clear and was set. Returns non-zero if a signal was delivered to the process and the *mode* allows that signal to wake the process.

Name

wait_on_atomic_t — Wait for an atomic_t to become 0

Synopsis

```
int wait_on_atomic_t (atomic_t * val, int (*action) (atomic_t *),
unsigned mode);
```

Arguments

val The atomic value being waited on, a kernel virtual address

action the function used to sleep, which may take special actions

mode the task state to sleep in

Description

Wait for an atomic_t to become 0. We abuse the bit-wait waitqueue table for the purpose of getting a waitqueue, but we set the key to a bit number outside of the target 'word'.

Name

__wake_up — wake up threads blocked on a waitqueue.

Synopsis

```
void __wake_up (wait_queue_head_t * q, unsigned int mode, int nr_exclusive, void * key);
```

Arguments

q	the waitqueue
mode	which threads
nr_exclusive	how many wake-one or wake-many threads to wake up
key	is directly passed to the wakeup function

Description

It may be assumed that this function implies a write memory barrier before changing the task state if and only if any tasks are woken up.

Name

__wake_up_sync_key — wake up threads blocked on a waitqueue.

Synopsis

```
void __wake_up_sync_key (wait_queue_head_t * q, unsigned int mode, int
nr_exclusive, void * key);
```

Arguments

q	the waitqueue
mode	which threads
nr_exclusive	how many wake-one or wake-many threads to wake up
key	opaque value to be passed to wakeup targets

Description

The sync wakeup differs that the waker knows that it will schedule away soon, so while the target thread will be woken up, it will not be migrated to another CPU - ie. the two threads are 'synchronized' with each other. This can prevent needless bouncing between CPUs.

On UP it can prevent extra preemption.

It may be assumed that this function implies a write memory barrier before changing the task state if and only if any tasks are woken up.

Name

finish_wait — clean up after waiting in a queue

Synopsis

```
void finish_wait (wait_queue_head_t * q, wait_queue_t * wait);
```

Arguments

q waitqueue waited on

wait wait descriptor

Description

Sets current thread back to running state and removes the wait descriptor from the given waitqueue if still queued.

Name

abort_exclusive_wait — abort exclusive waiting in a queue

Synopsis

```
void abort_exclusive_wait (wait_queue_head_t * q, wait_queue_t * wait,
unsigned int mode, void * key);
```

Arguments

q waitqueue waited on

wait wait descriptor

mode runstate of the waiter to be woken

key key to identify a wait bit queue or NULL

Description

Sets current thread back to running state and removes the wait descriptor from the given waitqueue if still queued.

Wakes up the next waiter if the caller is concurrently woken up through the queue.

This prevents waiter starvation where an exclusive waiter aborts and is woken up concurrently and no one wakes up the next waiter.

Name

wake_up_bit — wake up a waiter on a bit

Synopsis

```
void wake_up_bit (void * word, int bit);
```

Arguments

word the word being waited on, a kernel virtual address

bit the bit of the word being waited on

Description

There is a standard hashed waitqueue table for generic use. This is the part of the hashtable's accessor API that wakes up waiters on a bit. For instance, if one were to have waiters on a bitflag, one would call `wake_up_bit` after clearing the bit.

In order for this to function properly, as it uses `waitqueue_active` internally, some kind of memory barrier must be done prior to calling this. Typically, this will be `smp_mb__after_atomic`, but in some cases where bitflags are manipulated non-atomically under a lock, one may need to use a less regular barrier, such fs/inode.c's `smp_mb`, because `spin_unlock` does not guarantee a memory barrier.

Name

wake_up_atomic_t — Wake up a waiter on a atomic_t

Synopsis

```
void wake_up_atomic_t (atomic_t * p);
```

Arguments

p The atomic_t being waited on, a kernel virtual address

Description

Wake up anyone waiting for the atomic_t to go to zero.

Abuse the bit-waker function and its waitqueue hash table set (the atomic_t check is done by the waiter's wake function, not the by the waker itself).

High-resolution timers

Name

ktime_set — Set a ktime_t variable from a seconds/nanoseconds value

Synopsis

```
ktime_t ktime_set (const s64 secs, const unsigned long nsecs);
```

Arguments

secs seconds to set

nsecs nanoseconds to set

Return

The ktime_t representation of the value.

Name

ktime_equal — Compares two ktime_t variables to see if they are equal

Synopsis

```
int ktime_equal (const ktime_t cmp1, const ktime_t cmp2);
```

Arguments

cmp1 comparable1

cmp2 comparable2

Description

Compare two ktime_t variables.

Return

1 if equal.

Name

ktime_compare — Compares two ktime_t variables for less, greater or equal

Synopsis

```
int ktime_compare (const ktime_t cmp1, const ktime_t cmp2);
```

Arguments

cmp1 comparable1

cmp2 comparable2

Return

... cmp1 < cmp2: return <0 cmp1 == cmp2: return 0 cmp1 > cmp2: return >0

Name

ktime_after — Compare if a ktime_t value is bigger than another one.

Synopsis

```
bool ktime_after (const ktime_t cmp1, const ktime_t cmp2);
```

Arguments

cmp1 comparable1

cmp2 comparable2

Return

true if cmp1 happened after cmp2.

Name

ktime_before — Compare if a ktime_t value is smaller than another one.

Synopsis

```
bool ktime_before (const ktime_t cmp1, const ktime_t cmp2);
```

Arguments

cmp1 comparable1

cmp2 comparable2

Return

true if cmp1 happened before cmp2.

Name

ktime_to_timespec_cond — convert a ktime_t variable to timespec format only if the variable contains data

Synopsis

```
bool ktime_to_timespec_cond (const ktime_t kt, struct timespec * ts);
```

Arguments

kt the ktime_t variable to convert

ts the timespec variable to store the result in

Return

`true` if there was a successful conversion, `false` if kt was 0.

Name

ktime_to_timespec64_cond — convert a ktime_t variable to timespec64 format only if the variable contains data

Synopsis

```
bool ktime_to_timespec64_cond (const ktime_t kt, struct timespec64 * ts);
```

Arguments

kt the ktime_t variable to convert

ts the timespec variable to store the result in

Return

`true` if there was a successful conversion, `false` if kt was 0.

Name

struct hrtimer — the basic hrtimer structure

Synopsis

```
struct hrtimer {
  struct timerqueue_node node;
  ktime_t _softexpires;
  enum hrtimer_restart  (* function) (struct hrtimer *);
  struct hrtimer_clock_base * base;
  u8 state;
  u8 is_rel;
#ifdef CONFIG_TIMER_STATS
  int start_pid;
  void * start_site;
  char start_comm[16];
#endif
};
```

Members

node	timerqueue node, which also manages node.expires, the absolute expiry time in the hrtimers internal representation. The time is related to the clock on which the timer is based. Is setup by adding slack to the _softexpires value. For non range timers identical to _softexpires.
_softexpires	the absolute earliest expiry time of the hrtimer. The time which was given as expiry time when the timer was armed.
function	timer expiry callback function
base	pointer to the timer base (per cpu and per clock)
state	state information (See bit values above)
is_rel	Set if the timer was armed relative
start_pid	timer statistics field to store the pid of the task which started the timer
start_site	timer statistics field to store the site where the timer was started
start_comm[16]	timer statistics field to store the name of the process which started the timer

Description

The hrtimer structure must be initialized by `hrtimer_init`

Name

struct hrtimer_sleeper — simple sleeper structure

Synopsis

```
struct hrtimer_sleeper {
  struct hrtimer timer;
  struct task_struct * task;
};
```

Members

timer embedded timer structure

task task to wake up

Description

task is set to NULL, when the timer expires.

Name

struct hrtimer_clock_base — the timer base for a specific clock

Synopsis

```
struct hrtimer_clock_base {
  struct hrtimer_cpu_base * cpu_base;
  int index;
  clockid_t clockid;
  struct timerqueue_head active;
  ktime_t (* get_time) (void);
  ktime_t offset;
};
```

Members

cpu_base	per cpu clock base
index	clock type index for per_cpu support when moving a timer to a base on another cpu.
clockid	clock id for per_cpu support
active	red black tree root node for the active timers
get_time	function to retrieve the current time of the clock
offset	offset of this clock to the monotonic base

Name

hrtimer_start — (re)start an hrtimer on the current CPU

Synopsis

```
void hrtimer_start (struct hrtimer * timer, ktime_t tim, const enum
hrtimer_mode mode);
```

Arguments

timer the timer to be added

tim expiry time

mode expiry mode: absolute (HRTIMER_MODE_ABS) or relative (HRTIMER_MODE_REL)

Name

hrtimer_forward_now — forward the timer expiry so it expires after now

Synopsis

```
u64 hrtimer_forward_now (struct hrtimer * timer, ktime_t interval);
```

Arguments

timer hrtimer to forward

interval the interval to forward

Description

Forward the timer expiry so it will expire after the current time of the hrtimer clock base. Returns the number of overruns.

Can be safely called from the callback function of *timer*. If called from other contexts *timer* must neither be enqueued nor running the callback and the caller needs to take care of serialization.

Note

This only updates the timer expiry value and does not requeue the timer.

Name

hrtimer_forward — forward the timer expiry

Synopsis

```
u64 hrtimer_forward (struct hrtimer * timer, ktime_t now, ktime_t interval);
```

Arguments

timer	hrtimer to forward
now	forward past this time
interval	the interval to forward

Description

Forward the timer expiry so it will expire in the future. Returns the number of overruns.

Can be safely called from the callback function of *timer*. If called from other contexts *timer* must neither be enqueued nor running the callback and the caller needs to take care of serialization.

Note

This only updates the timer expiry value and does not requeue the timer.

Name

hrtimer_start_range_ns — (re)start an hrtimer on the current CPU

Synopsis

```
void hrtimer_start_range_ns (struct hrtimer * timer, ktime_t tim,
unsigned long delta_ns, const enum hrtimer_mode mode);
```

Arguments

timer	the timer to be added
tim	expiry time
delta_ns	"slack" range for the timer
mode	expiry mode: absolute (HRTIMER_MODE_ABS) or relative (HRTIMER_MODE_REL)

Name

hrtimer_try_to_cancel — try to deactivate a timer

Synopsis

```
int hrtimer_try_to_cancel (struct hrtimer * timer);
```

Arguments

timer hrtimer to stop

Returns

0 when the timer was not active 1 when the timer was active -1 when the timer is currently excuting the callback function and cannot be stopped

Name

hrtimer_cancel — cancel a timer and wait for the handler to finish.

Synopsis

```
int hrtimer_cancel (struct hrtimer * timer);
```

Arguments

timer the timer to be cancelled

Returns

0 when the timer was not active 1 when the timer was active

Name

__hrtimer_get_remaining — get remaining time for the timer

Synopsis

```
ktime_t __hrtimer_get_remaining (const struct hrtimer * timer, bool adjust);
```

Arguments

timer the timer to read

adjust adjust relative timers when CONFIG_TIME_LOW_RES=y

Name

hrtimer_init — initialize a timer to the given clock

Synopsis

```
void hrtimer_init (struct hrtimer * timer, clockid_t clock_id, enum
hrtimer_mode mode);
```

Arguments

timer	the timer to be initialized
clock_id	the clock to be used
mode	timer mode abs/rel

Name

schedule_hrtimeout_range — sleep until timeout

Synopsis

```
int __sched schedule_hrtimeout_range (ktime_t * expires, unsigned long
delta, const enum hrtimer_mode mode);
```

Arguments

expires timeout value (ktime_t)

delta slack in expires timeout (ktime_t)

mode timer mode, HRTIMER_MODE_ABS or HRTIMER_MODE_REL

Description

Make the current task sleep until the given expiry time has elapsed. The routine will return immediately unless the current task state has been set (see `set_current_state`).

The *delta* argument gives the kernel the freedom to schedule the actual wakeup to a time that is both power and performance friendly. The kernel give the normal best effort behavior for "*expires*+*delta*", but may decide to fire the timer earlier, but no earlier than *expires*.

You can set the task state as follows -

`TASK_UNINTERRUPTIBLE` - at least *timeout* time is guaranteed to pass before the routine returns.

`TASK_INTERRUPTIBLE` - the routine may return early if a signal is delivered to the current task.

The current task state is guaranteed to be TASK_RUNNING when this routine returns.

Returns 0 when the timer has expired otherwise -EINTR

Name

schedule_hrtimeout — sleep until timeout

Synopsis

```
int __sched schedule_hrtimeout (ktime_t * expires, const enum hrtimer_mode mode);
```

Arguments

expires timeout value (ktime_t)

mode timer mode, HRTIMER_MODE_ABS or HRTIMER_MODE_REL

Description

Make the current task sleep until the given expiry time has elapsed. The routine will return immediately unless the current task state has been set (see `set_current_state`).

You can set the task state as follows -

`TASK_UNINTERRUPTIBLE` - at least *`timeout`* time is guaranteed to pass before the routine returns.

`TASK_INTERRUPTIBLE` - the routine may return early if a signal is delivered to the current task.

The current task state is guaranteed to be TASK_RUNNING when this routine returns.

Returns 0 when the timer has expired otherwise -EINTR

Workqueues and Kevents

Name

work_pending — Find out whether a work item is currently pending

Synopsis

```
work_pending ( work);
```

Arguments

work The work item in question

Name

delayed_work_pending — Find out whether a delayable work item is currently pending

Synopsis

```
delayed_work_pending ( w);
```

Arguments

w The work item in question

Name

alloc_workqueue — allocate a workqueue

Synopsis

```
alloc_workqueue ( fmt, flags, max_active, args...);
```

Arguments

fmt	printf format for the name of the workqueue
flags	WQ_* flags
max_active	max in-flight work items, 0 for default *args*...: args for *fmt*
args...	variable arguments

Description

Allocate a workqueue with the specified parameters. For detailed information on WQ_* flags, please refer to Documentation/workqueue.txt.

The __lock_name macro dance is to guarantee that single lock_class_key doesn't end up with different namesm, which isn't allowed by lockdep.

RETURNS

Pointer to the allocated workqueue on success, NULL on failure.

Name

alloc_ordered_workqueue — allocate an ordered workqueue

Synopsis

```
alloc_ordered_workqueue ( fmt, flags, args...);
```

Arguments

fmt printf format for the name of the workqueue

flags WQ_* flags (only WQ_FREEZABLE and WQ_MEM_RECLAIM are meaningful) *args*...: args for *fmt*

args... variable arguments

Description

Allocate an ordered workqueue. An ordered workqueue executes at most one work item at any given time in the queued order. They are implemented as unbound workqueues with *max_active* of one.

RETURNS

Pointer to the allocated workqueue on success, NULL on failure.

Name

queue_work — queue work on a workqueue

Synopsis

```
bool queue_work (struct workqueue_struct * wq, struct work_struct *
work);
```

Arguments

wq workqueue to use

work work to queue

Description

Returns `false` if *work* was already on a queue, `true` otherwise.

We queue the work to the CPU on which it was submitted, but if the CPU dies it can be processed by another CPU.

Name

queue_delayed_work — queue work on a workqueue after delay

Synopsis

```
bool queue_delayed_work (struct workqueue_struct * wq, struct
delayed_work * dwork, unsigned long delay);
```

Arguments

wq workqueue to use

dwork delayable work to queue

delay number of jiffies to wait before queueing

Description

Equivalent to `queue_delayed_work_on` but tries to use the local CPU.

Name

mod_delayed_work — modify delay of or queue a delayed work

Synopsis

```
bool mod_delayed_work (struct workqueue_struct * wq, struct delayed_work
* dwork, unsigned long delay);
```

Arguments

wq workqueue to use

dwork work to queue

delay number of jiffies to wait before queueing

Description

`mod_delayed_work_on` on local CPU.

Name

schedule_work_on — put work task on a specific cpu

Synopsis

```
bool schedule_work_on (int cpu, struct work_struct * work);
```

Arguments

cpu cpu to put the work task on

work job to be done

Description

This puts a job on a specific cpu

Name

schedule_work — put work task in global workqueue

Synopsis

```
bool schedule_work (struct work_struct * work);
```

Arguments

work job to be done

Description

Returns `false` if *work* was already on the kernel-global workqueue and `true` otherwise.

This puts a job in the kernel-global workqueue if it was not already queued and leaves it in the same position on the kernel-global workqueue otherwise.

Name

flush_scheduled_work — ensure that any scheduled work has run to completion.

Synopsis

```
void flush_scheduled_work ( void);
```

Arguments

void no arguments

Description

Forces execution of the kernel-global workqueue and blocks until its completion.

Think twice before calling this function! It's very easy to get into trouble if you don't take great care. Either of the following situations

will lead to deadlock

One of the work items currently on the workqueue needs to acquire a lock held by your code or its caller.

Your code is running in the context of a work routine.

They will be detected by lockdep when they occur, but the first might not occur very often. It depends on what work items are on the workqueue and what locks they need, which you have no control over.

In most situations flushing the entire workqueue is overkill; you merely need to know that a particular work item isn't queued and isn't running. In such cases you should use `cancel_delayed_work_sync` or `cancel_work_sync` instead.

Name

schedule_delayed_work_on — queue work in global workqueue on CPU after delay

Synopsis

```
bool schedule_delayed_work_on (int cpu, struct delayed_work * dwork,
unsigned long delay);
```

Arguments

cpu cpu to use

dwork job to be done

delay number of jiffies to wait

Description

After waiting for a given time this puts a job in the kernel-global workqueue on the specified CPU.

Name

schedule_delayed_work — put work task in global workqueue after delay

Synopsis

```
bool schedule_delayed_work (struct delayed_work * dwork, unsigned long delay);
```

Arguments

dwork job to be done

delay number of jiffies to wait or 0 for immediate execution

Description

After waiting for a given time this puts a job in the kernel-global workqueue.

Name

keventd_up — is workqueue initialized yet?

Synopsis

```
bool keventd_up ( void);
```

Arguments

void no arguments

Name

queue_work_on — queue work on specific cpu

Synopsis

```
bool queue_work_on (int cpu, struct workqueue_struct * wq, struct
work_struct * work);
```

Arguments

cpu CPU number to execute work on

wq workqueue to use

work work to queue

Description

We queue the work to a specific CPU, the caller must ensure it can't go away.

Return

`false` if *work* was already on a queue, `true` otherwise.

Name

queue_delayed_work_on — queue work on specific CPU after delay

Synopsis

```
bool queue_delayed_work_on (int cpu, struct workqueue_struct * wq,
struct delayed_work * dwork, unsigned long delay);
```

Arguments

cpu CPU number to execute work on

wq workqueue to use

dwork work to queue

delay number of jiffies to wait before queueing

Return

`false` if *work* was already on a queue, `true` otherwise. If *delay* is zero and *dwork* is idle, it will be scheduled for immediate execution.

Name

mod_delayed_work_on — modify delay of or queue a delayed work on specific CPU

Synopsis

```
bool mod_delayed_work_on (int cpu, struct workqueue_struct * wq, struct
delayed_work * dwork, unsigned long delay);
```

Arguments

cpu CPU number to execute work on

wq workqueue to use

dwork work to queue

delay number of jiffies to wait before queueing

Description

If *dwork* is idle, equivalent to `queue_delayed_work_on`; otherwise, modify *dwork*'s timer so that it expires after *delay*. If *delay* is zero, *work* is guaranteed to be scheduled immediately regardless of its current state.

Return

`false` if *dwork* was idle and queued, `true` if *dwork* was pending and its timer was modified.

This function is safe to call from any context including IRQ handler. See `try_to_grab_pending` for details.

Name

flush_workqueue — ensure that any scheduled work has run to completion.

Synopsis

```
void flush_workqueue (struct workqueue_struct * wq);
```

Arguments

wq workqueue to flush

Description

This function sleeps until all work items which were queued on entry have finished execution, but it is not livelocked by new incoming ones.

Name

drain_workqueue — drain a workqueue

Synopsis

```
void drain_workqueue (struct workqueue_struct * wq);
```

Arguments

wq workqueue to drain

Description

Wait until the workqueue becomes empty. While draining is in progress, only chain queueing is allowed. IOW, only currently pending or running work items on *wq* can queue further work items on it. *wq* is flushed repeatedly until it becomes empty. The number of flushing is determined by the depth of chaining and should be relatively short. Whine if it takes too long.

Name

flush_work — wait for a work to finish executing the last queueing instance

Synopsis

```
bool flush_work (struct work_struct * work);
```

Arguments

work the work to flush

Description

Wait until *work* has finished execution. *work* is guaranteed to be idle on return if it hasn't been requeued since flush started.

Return

`true` if `flush_work` waited for the work to finish execution, `false` if it was already idle.

Name

cancel_work_sync — cancel a work and wait for it to finish

Synopsis

```
bool cancel_work_sync (struct work_struct * work);
```

Arguments

work the work to cancel

Description

Cancel *work* and wait for its execution to finish. This function can be used even if the work re-queues itself or migrates to another workqueue. On return from this function, *work* is guaranteed to be not pending or executing on any CPU.

cancel_work_sync(delayed_work->work) must not be used for delayed_work's. Use `cancel_delayed_work_sync` instead.

The caller must ensure that the workqueue on which *work* was last queued can't be destroyed before this function returns.

Return

`true` if *work* was pending, `false` otherwise.

Name

flush_delayed_work — wait for a dwork to finish executing the last queueing

Synopsis

```
bool flush_delayed_work (struct delayed_work * dwork);
```

Arguments

dwork the delayed work to flush

Description

Delayed timer is cancelled and the pending work is queued for immediate execution. Like `flush_work`, this function only considers the last queueing instance of *dwork*.

Return

`true` if `flush_work` waited for the work to finish execution, `false` if it was already idle.

Name

cancel_delayed_work — cancel a delayed work

Synopsis

```
bool cancel_delayed_work (struct delayed_work * dwork);
```

Arguments

dwork delayed_work to cancel

Description

Kill off a pending delayed_work.

Return

`true` if *dwork* was pending and canceled; `false` if it wasn't pending.

Note

The work callback function may still be running on return, unless it returns `true` and the work doesn't re-arm itself. Explicitly flush or use `cancel_delayed_work_sync` to wait on it.

This function is safe to call from any context including IRQ handler.

Name

cancel_delayed_work_sync — cancel a delayed work and wait for it to finish

Synopsis

```
bool cancel_delayed_work_sync (struct delayed_work * dwork);
```

Arguments

dwork the delayed work cancel

Description

This is `cancel_work_sync` for delayed works.

Return

`true` if *dwork* was pending, `false` otherwise.

Name

execute_in_process_context — reliably execute the routine with user context

Synopsis

```
int execute_in_process_context (work_func_t fn, struct execute_work *
ew);
```

Arguments

fn the function to execute

ew guaranteed storage for the execute work structure (must be available when the work executes)

Description

Executes the function immediately if process context is available, otherwise schedules the function for delayed execution.

Return

0 - function was executed 1 - function was scheduled for execution

Name

destroy_workqueue — safely terminate a workqueue

Synopsis

```
void destroy_workqueue (struct workqueue_struct * wq);
```

Arguments

wq target workqueue

Description

Safely destroy a workqueue. All work currently pending will be done first.

Name

workqueue_set_max_active — adjust max_active of a workqueue

Synopsis

```
void workqueue_set_max_active (struct workqueue_struct * wq, int max_active);
```

Arguments

wq target workqueue

max_active new max_active value.

Description

Set max_active of *wq* to *max_active*.

CONTEXT

Don't call from IRQ context.

Name

workqueue_congested — test whether a workqueue is congested

Synopsis

```
bool workqueue_congested (int cpu, struct workqueue_struct * wq);
```

Arguments

cpu CPU in question

wq target workqueue

Description

Test whether *wq*'s cpu workqueue for *cpu* is congested. There is no synchronization around this function and the test result is unreliable and only useful as advisory hints or for debugging.

If *cpu* is WORK_CPU_UNBOUND, the test is performed on the local CPU. Note that both per-cpu and unbound workqueues may be associated with multiple pool_workqueues which have separate congested states. A workqueue being congested on one CPU doesn't mean the workqueue is also contested on other CPUs / NUMA nodes.

Return

`true` if congested, `false` otherwise.

Name

work_busy — test whether a work is currently pending or running

Synopsis

```
unsigned int work_busy (struct work_struct * work);
```

Arguments

work the work to be tested

Description

Test whether *work* is currently pending or running. There is no synchronization around this function and the test result is unreliable and only useful as advisory hints or for debugging.

Return

OR'd bitmask of WORK_BUSY_* bits.

Name

work_on_cpu — run a function in user context on a particular cpu

Synopsis

```
long work_on_cpu (int cpu, long (*fn) (void *), void * arg);
```

Arguments

cpu the cpu to run on

fn the function to run

arg the function arg

Description

It is up to the caller to ensure that the cpu doesn't go offline. The caller must not hold any locks which would prevent *fn* from completing.

Return

The value *fn* returns.

Internal Functions

Name

wait_task_stopped — Wait for TASK_STOPPED or TASK_TRACED

Synopsis

```
int wait_task_stopped (struct wait_opts * wo, int ptrace, struct task_struct * p);
```

Arguments

wo	wait options
ptrace	is the wait for ptrace
p	task to wait for

Description

Handle sys_wait4 work for p in state TASK_STOPPED or TASK_TRACED.

CONTEXT

read_lock(tasklist_lock), which is released if return value is non-zero. Also, grabs and releases *p*->sighand->siglock.

RETURNS

0 if wait condition didn't exist and search for other wait conditions should continue. Non-zero return, -errno on failure and *p*'s pid on success, implies that tasklist_lock is released and wait condition search should terminate.

Name

task_set_jobctl_pending — set jobctl pending bits

Synopsis

```
bool task_set_jobctl_pending (struct task_struct * task, unsigned long mask);
```

Arguments

task target task

mask pending bits to set

Description

Clear *mask* from *task*->jobctl. *mask* must be subset of JOBCTL_PENDING_MASK | JOBCTL_STOP_CONSUME | JOBCTL_STOP_SIGMASK | JOBCTL_TRAPPING. If stop signo is being set, the existing signo is cleared. If *task* is already being killed or exiting, this function becomes noop.

CONTEXT

Must be called with *task*->sighand->siglock held.

RETURNS

true if *mask* is set, false if made noop because *task* was dying.

Name

task_clear_jobctl_trapping — clear jobctl trapping bit

Synopsis

```
void task_clear_jobctl_trapping (struct task_struct * task);
```

Arguments

task target task

Description

If JOBCTL_TRAPPING is set, a ptracer is waiting for us to enter TRACED. Clear it and wake up the ptracer. Note that we don't need any further locking. *task*->siglock guarantees that *task*->parent points to the ptracer.

CONTEXT

Must be called with *task*->sighand->siglock held.

Name

task_clear_jobctl_pending — clear jobctl pending bits

Synopsis

```
void task_clear_jobctl_pending (struct task_struct * task, unsigned long mask);
```

Arguments

task target task

mask pending bits to clear

Description

Clear *mask* from *task*->jobctl. *mask* must be subset of JOBCTL_PENDING_MASK. If JOBCTL_STOP_PENDING is being cleared, other STOP bits are cleared together.

If clearing of *mask* leaves no stop or trap pending, this function calls task_clear_jobctl_trapping.

CONTEXT

Must be called with *task*->sighand->siglock held.

Name

task_participate_group_stop — participate in a group stop

Synopsis

```
bool task_participate_group_stop (struct task_struct * task);
```

Arguments

task task participating in a group stop

Description

task has JOBCTL_STOP_PENDING set and is participating in a group stop. Group stop states are cleared and the group stop count is consumed if JOBCTL_STOP_CONSUME was set. If the consumption completes the group stop, the appropriate SIGNAL_* flags are set.

CONTEXT

Must be called with *task*->sighand->siglock held.

RETURNS

true if group stop completion should be notified to the parent, false otherwise.

Name

ptrace_trap_notify — schedule trap to notify ptracer

Synopsis

```
void ptrace_trap_notify (struct task_struct * t);
```

Arguments

t tracee wanting to notify tracer

Description

This function schedules sticky ptrace trap which is cleared on the next TRAP_STOP to notify ptracer of an event. *t* must have been seized by ptracer.

If *t* is running, STOP trap will be taken. If trapped for STOP and ptracer is listening for events, tracee is woken up so that it can re-trap for the new event. If trapped otherwise, STOP trap will be eventually taken without returning to userland after the existing traps are finished by PTRACE_CONT.

CONTEXT

Must be called with *task*->sighand->siglock held.

Name

do_notify_parent_cldstop — notify parent of stopped/continued state change

Synopsis

```
void do_notify_parent_cldstop (struct task_struct * tsk, bool for_ptracer, int why);
```

Arguments

tsk	task reporting the state change
for_ptracer	the notification is for ptracer
why	CLD_{CONTINUED|STOPPED|TRAPPED} to report

Description

Notify *tsk*'s parent that the stopped/continued state has changed. If *for_ptracer* is false, *tsk*'s group leader notifies to its real parent. If true, *tsk* reports to *tsk*->parent which should be the ptracer.

CONTEXT

Must be called with tasklist_lock at least read locked.

Name

do_signal_stop — handle group stop for SIGSTOP and other stop signals

Synopsis

```
bool do_signal_stop (int signr);
```

Arguments

signr signr causing group stop if initiating

Description

If JOBCTL_STOP_PENDING is not set yet, initiate group stop with *signr* and participate in it. If already set, participate in the existing group stop. If participated in a group stop (and thus slept), true is returned with siglock released.

If ptraced, this function doesn't handle stop itself. Instead, JOBCTL_TRAP_STOP is scheduled and false is returned with siglock untouched. The caller must ensure that INTERRUPT trap handling takes places afterwards.

CONTEXT

Must be called with *current*->sighand->siglock held, which is released on true return.

RETURNS

false if group stop is already cancelled or ptrace trap is scheduled. true if participated in group stop.

Name

do_jobctl_trap — take care of ptrace jobctl traps

Synopsis

```
void do_jobctl_trap ( void);
```

Arguments

void no arguments

Description

When PT_SEIZED, it's used for both group stop and explicit SEIZE/INTERRUPT traps. Both generate PTRACE_EVENT_STOP trap with accompanying siginfo. If stopped, lower eight bits of exit_code contain the stop signal; otherwise, SIGTRAP.

When !PT_SEIZED, it's used only for group stop trap with stop signal number as exit_code and no siginfo.

CONTEXT

Must be called with *current*->sighand->siglock held, which may be released and re-acquired before returning with intervening sleep.

Name

signal_delivered —

Synopsis

```
void signal_delivered (struct ksignal * ksig, int stepping);
```

Arguments

ksig kernel signal struct

stepping nonzero if debugger single-step or block-step in use

Description

This function should be called when a signal has successfully been delivered. It updates the blocked signals accordingly (*ksig*->ka.sa.sa_mask is always blocked, and the signal itself is blocked unless SA_NODEFER is set in *ksig*->ka.sa.sa_flags. Tracing is notified.

Name

sys_restart_syscall — restart a system call

Synopsis

```
long sys_restart_syscall ( void);
```

Arguments

void no arguments

Name

set_current_blocked — change current->blocked mask

Synopsis

```
void set_current_blocked (sigset_t * newset);
```

Arguments

newset new mask

Description

It is wrong to change ->blocked directly, this helper should be used to ensure the process can't miss a shared signal we are going to block.

Name

sys_rt_sigprocmask — change the list of currently blocked signals

Synopsis

```
long sys_rt_sigprocmask (int how, sigset_t __user * nset, sigset_t
__user * oset, size_t sigsetsize);
```

Arguments

how	whether to add, remove, or set signals
nset	stores pending signals
oset	previous value of signal mask if non-null
sigsetsize	size of sigset_t type

Name

sys_rt_sigpending — examine a pending signal that has been raised while blocked

Synopsis

```
long sys_rt_sigpending (sigset_t __user * uset, size_t sigsetsize);
```

Arguments

uset stores pending signals

sigsetsize size of sigset_t type or larger

Name

do_sigtimedwait — wait for queued signals specified in *which*

Synopsis

```
int do_sigtimedwait (const sigset_t * which, siginfo_t * info, const
struct timespec * ts);
```

Arguments

which queued signals to wait for

info if non-null, the signal's siginfo is returned here

ts upper bound on process time suspension

Name

sys_rt_sigtimedwait — synchronously wait for queued signals specified in *uthese*

Synopsis

```
long sys_rt_sigtimedwait (const sigset_t __user * uthese, siginfo_t
__user * uinfo, const struct timespec __user * uts, size_t sigsetsize);
```

Arguments

uthese	queued signals to wait for
uinfo	if non-null, the signal's siginfo is returned here
uts	upper bound on process time suspension
sigsetsize	size of sigset_t type

Name

sys_kill — send a signal to a process

Synopsis

```
long sys_kill (pid_t pid, int sig);
```

Arguments

pid the PID of the process

sig signal to be sent

Name

sys_tgkill — send signal to one specific thread

Synopsis

```
long sys_tgkill (pid_t tgid, pid_t pid, int sig);
```

Arguments

tgid the thread group ID of the thread

pid the PID of the thread

sig signal to be sent

Description

This syscall also checks the *tgid* and returns -ESRCH even if the PID exists but it's not belonging to the target process anymore. This method solves the problem of threads exiting and PIDs getting reused.

Name

sys_tkill — send signal to one specific task

Synopsis

```
long sys_tkill (pid_t pid, int sig);
```

Arguments

pid the PID of the task

sig signal to be sent

Description

Send a signal to only one task, even if it's a CLONE_THREAD task.

Name

sys_rt_sigqueueinfo — send signal information to a signal

Synopsis

```
long sys_rt_sigqueueinfo (pid_t pid, int sig, siginfo_t __user * uinfo);
```

Arguments

pid the PID of the thread

sig signal to be sent

uinfo signal info to be sent

Name

sys_sigpending — examine pending signals

Synopsis

```
long sys_sigpending (old_sigset_t __user * set);
```

Arguments

set where mask of pending signal is returned

Name

sys_sigprocmask — examine and change blocked signals

Synopsis

```
long sys_sigprocmask (int how, old_sigset_t __user * nset, old_sigset_t
__user * oset);
```

Arguments

how whether to add, remove, or set signals

nset signals to add or remove (if non-null)

oset previous value of signal mask if non-null

Description

Some platforms have their own version with special arguments; others support only sys_rt_sigprocmask.

Name

sys_rt_sigaction — alter an action taken by a process

Synopsis

```
long sys_rt_sigaction (int sig, const struct sigaction __user * act,
struct sigaction __user * oact, size_t sigsetsize);
```

Arguments

sig	signal to be sent
act	new sigaction
oact	used to save the previous sigaction
sigsetsize	size of sigset_t type

Name

sys_rt_sigsuspend — replace the signal mask for a value with the *unewset* value until a signal is received

Synopsis

```
long sys_rt_sigsuspend (sigset_t __user * unewset, size_t sigsetsize);
```

Arguments

unewset new signal mask value

sigsetsize size of sigset_t type

Name

kthread_run — create and wake a thread.

Synopsis

```
kthread_run ( threadfn, data, namefmt, ...);
```

Arguments

threadfn	the function to run until signal_pending(current).
data	data ptr for *threadfn*.
namefmt	printf-style name for the thread.
...	variable arguments

Description

Convenient wrapper for kthread_create followed by wake_up_process. Returns the kthread or ERR_PTR(-ENOMEM).

Name

kthread_should_stop — should this kthread return now?

Synopsis

```
bool kthread_should_stop ( void);
```

Arguments

void no arguments

Description

When someone calls `kthread_stop` on your kthread, it will be woken and this will return true. You should then return, and your return value will be passed through to `kthread_stop`.

Name

kthread_should_park — should this kthread park now?

Synopsis

```
bool kthread_should_park ( void);
```

Arguments

void no arguments

Description

When someone calls `kthread_park` on your kthread, it will be woken and this will return true. You should then do the necessary cleanup and call `kthread_parkme`

Similar to `kthread_should_stop`, but this keeps the thread alive and in a park position. `kthread_unpark` “restarts” the thread and calls the thread function again.

Name

kthread_freezable_should_stop — should this freezable kthread return now?

Synopsis

```
bool kthread_freezable_should_stop (bool * was_frozen);
```

Arguments

was_frozen optional out parameter, indicates whether `current` was frozen

Description

`kthread_should_stop` for freezable kthreads, which will enter refrigerator if necessary. This function is safe from `kthread_stop` / freezer deadlock and freezable kthreads should use this function instead of calling `try_to_freeze` directly.

Name

kthread_create_on_node — create a kthread.

Synopsis

```
struct task_struct * kthread_create_on_node (int (*threadfn) (void
*data), void * data, int node, const char namefmt[], ...);
```

Arguments

threadfn	the function to run until signal_pending(current).
data	data ptr for *threadfn*.
node	task and thread structures for the thread are allocated on this node
namefmt[]	printf-style name for the thread.
...	variable arguments

Description

This helper function creates and names a kernel thread. The thread will be stopped: use `wake_up_process` to start it. See also `kthread_run`. The new thread has SCHED_NORMAL policy and is affine to all CPUs.

If thread is going to be bound on a particular cpu, give its node in *node*, to get NUMA affinity for kthread stack, or else give NUMA_NO_NODE. When woken, the thread will run *threadfn*() with *data* as its argument. *threadfn*() can either call `do_exit` directly if it is a standalone thread for which no one will call `kthread_stop`, or return when '`kthread_should_stop`' is true (which means `kthread_stop` has been called). The return value should be zero or a negative error number; it will be passed to `kthread_stop`.

Returns a task_struct or ERR_PTR(-ENOMEM) or ERR_PTR(-EINTR).

Name

kthread_bind — bind a just-created kthread to a cpu.

Synopsis

```
void kthread_bind (struct task_struct * p, unsigned int cpu);
```

Arguments

p thread created by `kthread_create`.

cpu cpu (might not be online, must be possible) for *k* to run on.

Description

This function is equivalent to `set_cpus_allowed`, except that *cpu* doesn't need to be online, and the thread must be stopped (i.e., just returned from `kthread_create`).

Name

kthread_unpark — unpark a thread created by `kthread_create`.

Synopsis

```
void kthread_unpark (struct task_struct * k);
```

Arguments

k thread created by `kthread_create`.

Description

Sets `kthread_should_park` for *k* to return false, wakes it, and waits for it to return. If the thread is marked percpu then its bound to the cpu again.

Name

kthread_park — park a thread created by `kthread_create`.

Synopsis

```
int kthread_park (struct task_struct * k);
```

Arguments

k thread created by `kthread_create`.

Description

Sets `kthread_should_park` for *k* to return true, wakes it, and waits for it to return. This can also be called after `kthread_create` instead of calling `wake_up_process`: the thread will park without calling `threadfn`.

Returns 0 if the thread is parked, -ENOSYS if the thread exited. If called by the kthread itself just the park bit is set.

Name

kthread_stop — stop a thread created by `kthread_create`.

Synopsis

```
int kthread_stop (struct task_struct * k);
```

Arguments

k thread created by `kthread_create`.

Description

Sets `kthread_should_stop` for *k* to return true, wakes it, and waits for it to exit. This can also be called after `kthread_create` instead of calling `wake_up_process`: the thread will exit without calling `threadfn`.

If `threadfn` may call `do_exit` itself, the caller must ensure task_struct can't go away.

Returns the result of `threadfn`, or `-EINTR` if `wake_up_process` was never called.

Name

kthread_worker_fn — kthread function to process kthread_worker

Synopsis

```
int kthread_worker_fn (void * worker_ptr);
```

Arguments

worker_ptr pointer to initialized kthread_worker

Description

This function can be used as *threadfn* to kthread_create or kthread_run with *worker_ptr* argument pointing to an initialized kthread_worker. The started kthread will process work_list until the it is stopped with kthread_stop. A kthread can also call this function directly after extra initialization.

Different kthreads can be used for the same kthread_worker as long as there's only one kthread attached to it at any given time. A kthread_worker without an attached kthread simply collects queued kthread_works.

Name

queue_kthread_work — queue a kthread_work

Synopsis

```
bool queue_kthread_work (struct kthread_worker * worker, struct kthread_work * work);
```

Arguments

worker target kthread_worker

work kthread_work to queue

Description

Queue *work* to work processor *task* for async execution. *task* must have been created with `kthread_worker_create`. Returns `true` if *work* was successfully queued, `false` if it was already pending.

Name

flush_kthread_work — flush a kthread_work

Synopsis

```
void flush_kthread_work (struct kthread_work * work);
```

Arguments

work work to flush

Description

If *work* is queued or executing, wait for it to finish execution.

Name

flush_kthread_worker — flush all current works on a kthread_worker

Synopsis

```
void flush_kthread_worker (struct kthread_worker * worker);
```

Arguments

worker worker to flush

Description

Wait until all currently executing or pending works on *worker* are finished.

Kernel objects manipulation

Name

kobject_get_path — generate and return the path associated with a given kobj and kset pair.

Synopsis

```
char * kobject_get_path (struct kobject * kobj, gfp_t gfp_mask);
```

Arguments

kobj kobject in question, with which to build the path

gfp_mask the allocation type used to allocate the path

Description

The result must be freed by the caller with `kfree`.

Name

kobject_set_name — Set the name of a kobject

Synopsis

```
int kobject_set_name (struct kobject * kobj, const char * fmt, ...);
```

Arguments

kobj struct kobject to set the name of

fmt format string used to build the name

... variable arguments

Description

This sets the name of the kobject. If you have already added the kobject to the system, you must call `kobject_rename` in order to change the name of the kobject.

Name

kobject_init — initialize a kobject structure

Synopsis

```
void kobject_init (struct kobject * kobj, struct kobj_type * ktype);
```

Arguments

kobj pointer to the kobject to initialize

ktype pointer to the ktype for this kobject.

Description

This function will properly initialize a kobject such that it can then be passed to the `kobject_add` call.

After this function is called, the kobject MUST be cleaned up by a call to `kobject_put`, not by a call to kfree directly to ensure that all of the memory is cleaned up properly.

Name

kobject_add — the main kobject add function

Synopsis

```
int kobject_add (struct kobject * kobj, struct kobject * parent, const
char * fmt, ...);
```

Arguments

kobj the kobject to add

parent pointer to the parent of the kobject.

fmt format to name the kobject with.

... variable arguments

Description

The kobject name is set and added to the kobject hierarchy in this function.

If *parent* is set, then the parent of the *kobj* will be set to it. If *parent* is NULL, then the parent of the *kobj* will be set to the kobject associated with the kset assigned to this kobject. If no kset is assigned to the kobject, then the kobject will be located in the root of the sysfs tree.

If this function returns an error, kobject_put must be called to properly clean up the memory associated with the object. Under no instance should the kobject that is passed to this function be directly freed with a call to kfree, that can leak memory.

Note, no “add” uevent will be created with this call, the caller should set up all of the necessary sysfs files for the object and then call kobject_uevent with the UEVENT_ADD parameter to ensure that userspace is properly notified of this kobject's creation.

Name

kobject_init_and_add — initialize a kobject structure and add it to the kobject hierarchy

Synopsis

```
int kobject_init_and_add (struct kobject * kobj, struct kobj_type *
ktype, struct kobject * parent, const char * fmt, ...);
```

Arguments

kobj pointer to the kobject to initialize

ktype pointer to the ktype for this kobject.

parent pointer to the parent of this kobject.

fmt the name of the kobject.

... variable arguments

Description

This function combines the call to `kobject_init` and `kobject_add`. The same type of error handling after a call to `kobject_add` and kobject lifetime rules are the same here.

Name

kobject_rename — change the name of an object

Synopsis

```
int kobject_rename (struct kobject * kobj, const char * new_name);
```

Arguments

kobj object in question.

new_name object's new name

Description

It is the responsibility of the caller to provide mutual exclusion between two different calls of kobject_rename on the same kobject and to ensure that new_name is valid and won't conflict with other kobjects.

Name

kobject_move — move object to another parent

Synopsis

```
int kobject_move (struct kobject * kobj, struct kobject * new_parent);
```

Arguments

kobj object in question.

new_parent object's new parent (can be NULL)

Name

kobject_del — unlink kobject from hierarchy.

Synopsis

```
void kobject_del (struct kobject * kobj);
```

Arguments

kobj object.

Name

kobject_get — increment refcount for object.

Synopsis

```
struct kobject * kobject_get (struct kobject * kobj);
```

Arguments

kobj object.

Name

kobject_put — decrement refcount for object.

Synopsis

```
void kobject_put (struct kobject * kobj);
```

Arguments

kobj object.

Description

Decrement the refcount, and if 0, call `kobject_cleanup`.

Name

kobject_create_and_add — create a struct kobject dynamically and register it with sysfs

Synopsis

```
struct kobject * kobject_create_and_add (const char * name, struct kobject * parent);
```

Arguments

name the name for the kobject

parent the parent kobject of this kobject, if any.

Description

This function creates a kobject structure dynamically and registers it with sysfs. When you are finished with this structure, call `kobject_put` and the structure will be dynamically freed when it is no longer being used.

If the kobject was not able to be created, NULL will be returned.

Name

kset_register — initialize and add a kset.

Synopsis

```
int kset_register (struct kset * k);
```

Arguments

k kset.

Name

kset_unregister — remove a kset.

Synopsis

```
void kset_unregister (struct kset * k);
```

Arguments

k kset.

Name

kset_create_and_add — create a struct kset dynamically and add it to sysfs

Synopsis

```
struct kset * kset_create_and_add (const char * name, const struct
kset_uevent_ops * uevent_ops, struct kobject * parent_kobj);
```

Arguments

name the name for the kset

uevent_ops a struct kset_uevent_ops for the kset

parent_kobj the parent kobject of this kset, if any.

Description

This function creates a kset structure dynamically and registers it with sysfs. When you are finished with this structure, call `kset_unregister` and the structure will be dynamically freed when it is no longer being used.

If the kset was not able to be created, NULL will be returned.

Kernel utility functions

Name

upper_32_bits — return bits 32-63 of a number

Synopsis

```
upper_32_bits ( n);
```

Arguments

n the number we're accessing

Description

A basic shift-right of a 64- or 32-bit quantity. Use this to suppress the “right shift count >= width of type” warning when that quantity is 32-bits.

Name

lower_32_bits — return bits 0-31 of a number

Synopsis

```
lower_32_bits ( n);
```

Arguments

n the number we're accessing

Name

might_sleep — annotation for functions that can sleep

Synopsis

```
might_sleep (void);
```

Arguments

None

Description

this macro will print a stack trace if it is executed in an atomic context (spinlock, irq-handler, ...).

This is a useful debugging help to be able to catch problems early and not be bitten later when the calling function happens to sleep when it is not supposed to.

Name

abs — return absolute value of an argument

Synopsis

```
abs ( x);
```

Arguments

x the value. If it is unsigned type, it is converted to signed type first. char is treated as if it was signed (regardless of whether it really is) but the macro's return type is preserved as char.

Return

an absolute value of x.

Name

reciprocal_scale — "scale" a value into range [0, ep_ro)

Synopsis

```
u32 reciprocal_scale (u32 val, u32 ep_ro);
```

Arguments

val value

ep_ro right open interval endpoint

Description

Perform a “reciprocal multiplication” in order to “scale” a value into range [0, ep_ro), where the upper interval endpoint is right-open. This is useful, e.g. for accessing a index of an array containing ep_ro elements, for example. Think of it as sort of modulus, only that the result isn't that of modulo. ;) Note that if initial input is a small value, then result will return 0.

Return

a result based on val in interval [0, ep_ro).

Name

kstrtoul — convert a string to an unsigned long

Synopsis

```
int kstrtoul (const char * s, unsigned int base, unsigned long * res);
```

Arguments

s The start of the string. The string must be null-terminated, and may also include a single newline before its terminating null. The first character may also be a plus sign, but not a minus sign.

base The number base to use. The maximum supported base is 16. If base is given as 0, then the base of the string is automatically detected with the conventional semantics - If it begins with 0x the number will be parsed as a hexadecimal (case insensitive), if it otherwise begins with 0, it will be parsed as an octal number. Otherwise it will be parsed as a decimal.

res Where to write the result of the conversion on success.

Description

Returns 0 on success, -ERANGE on overflow and -EINVAL on parsing error. Used as a replacement for the obsolete simple_strtoull. Return code must be checked.

Name

kstrtol — convert a string to a long

Synopsis

```
int kstrtol (const char * s, unsigned int base, long * res);
```

Arguments

s The start of the string. The string must be null-terminated, and may also include a single newline before its terminating null. The first character may also be a plus sign or a minus sign.

base The number base to use. The maximum supported base is 16. If base is given as 0, then the base of the string is automatically detected with the conventional semantics - If it begins with 0x the number will be parsed as a hexadecimal (case insensitive), if it otherwise begins with 0, it will be parsed as an octal number. Otherwise it will be parsed as a decimal.

res Where to write the result of the conversion on success.

Description

Returns 0 on success, -ERANGE on overflow and -EINVAL on parsing error. Used as a replacement for the obsolete simple_strtoull. Return code must be checked.

Name

trace_printk — printf formatting in the ftrace buffer

Synopsis

```
trace_printk ( fmt, ...);
```

Arguments

fmt the printf format for printing

... variable arguments

Note

__trace_printk is an internal function for trace_printk and the *ip* is passed in via the trace_printk macro.

This function allows a kernel developer to debug fast path sections that printk is not appropriate for. By scattering in various printk like tracing in the code, a developer can quickly see where problems are occurring.

This is intended as a debugging tool for the developer only. Please refrain from leaving trace_printks scattered around in your code. (Extra memory is used for special buffers that are allocated when `trace_printk` is used)

A little optization trick is done here. If there's only one argument, there's no need to scan the string for printf formats. The `trace_puts` will suffice. But how can we take advantage of using `trace_puts` when `trace_printk` has only one argument? By stringifying the args and checking the size we can tell whether or not there are args. __stringify((__VA_ARGS__)) will turn into “()\0” with a size of 3 when there are no args, anything else will be bigger. All we need to do is define a string to this, and then take its size and compare to 3. If it's bigger, use `do_trace_printk` otherwise, optimize it to `trace_puts`. Then just let gcc optimize the rest.

Name

trace_puts — write a string into the ftrace buffer

Synopsis

```
trace_puts ( str);
```

Arguments

str the string to record

Note

__trace_bputs is an internal function for trace_puts and the *ip* is passed in via the trace_puts macro.

This is similar to `trace_printk` but is made for those really fast paths that a developer wants the least amount of “Heisenbug” affects, where the processing of the print format is still too much.

This function allows a kernel developer to debug fast path sections that printk is not appropriate for. By scattering in various printk like tracing in the code, a developer can quickly see where problems are occurring.

This is intended as a debugging tool for the developer only. Please refrain from leaving trace_puts scattered around in your code. (Extra memory is used for special buffers that are allocated when `trace_puts` is used)

Returns

0 if nothing was written, positive # if string was. (1 when __trace_bputs is used, strlen(str) when __trace_puts is used)

Name

min_not_zero — return the minimum that is _not_ zero, unless both are zero

Synopsis

```
min_not_zero ( x, y);
```

Arguments

x value1

y value2

Name

clamp — return a value clamped to a given range with strict typechecking

Synopsis

```
clamp ( val, lo, hi);
```

Arguments

val current value

lo lowest allowable value

hi highest allowable value

Description

This macro does strict typechecking of lo/hi to make sure they are of the same type as val. See the unnecessary pointer comparisons.

Name

clamp_t — return a value clamped to a given range using a given type

Synopsis

```
clamp_t ( type, val, lo, hi);
```

Arguments

type the type of variable to use

val current value

lo minimum allowable value

hi maximum allowable value

Description

This macro does no typechecking and uses temporary variables of type 'type' to make all the comparisons.

Name

clamp_val — return a value clamped to a given range using val's type

Synopsis

```
clamp_val ( val, lo, hi);
```

Arguments

val current value

lo minimum allowable value

hi maximum allowable value

Description

This macro does no typechecking and uses temporary variables of whatever type the input argument 'val' is. This is useful when val is an unsigned type and min and max are literals that will otherwise be assigned a signed integer type.

Name

container_of — cast a member of a structure out to the containing structure

Synopsis

```
container_of ( ptr, type, member);
```

Arguments

ptr the pointer to the member.

type the type of the container struct this is embedded in.

member the name of the member within the struct.

Name

printk — print a kernel message

Synopsis

```
__visible int printk (const char * fmt, ...);
```

Arguments

fmt format string

... variable arguments

Description

This is `printk`. It can be called from any context. We want it to work.

We try to grab the console_lock. If we succeed, it's easy - we log the output and call the console drivers. If we fail to get the semaphore, we place the output into the log buffer and return. The current holder of the console_sem will notice the new output in `console_unlock`; and will send it to the consoles before releasing the lock.

One effect of this deferred printing is that code which calls `printk` and then changes console_loglevel may break. This is because console_loglevel is inspected when the actual printing occurs.

See also

printf(3)

See the `vsnprintf` documentation for format string extensions over C99.

Name

console_lock — lock the console system for exclusive use.

Synopsis

```
void console_lock ( void);
```

Arguments

void no arguments

Description

Acquires a lock which guarantees that the caller has exclusive access to the console system and the console_drivers list.

Can sleep, returns nothing.

Name

console_trylock — try to lock the console system for exclusive use.

Synopsis

```
int console_trylock ( void);
```

Arguments

void no arguments

Description

Try to acquire a lock which guarantees that the caller has exclusive access to the console system and the console_drivers list.

returns 1 on success, and 0 on failure to acquire the lock.

Name

console_unlock — unlock the console system

Synopsis

```
void console_unlock ( void);
```

Arguments

void no arguments

Description

Releases the console_lock which the caller holds on the console system and the console driver list.

While the console_lock was held, console output may have been buffered by `printk`. If this is the case, `console_unlock`; emits the output prior to releasing the lock.

If there is output waiting, we wake /dev/kmsg and `syslog` users.

`console_unlock`; may be called from any context.

Name

console_conditional_schedule — yield the CPU if required

Synopsis

```
void __sched console_conditional_schedule ( void);
```

Arguments

void no arguments

Description

If the console code is currently allowed to sleep, and if this CPU should yield the CPU to another task, do so here.

Must be called within `console_lock`;.

Name

printk_timed_ratelimit — caller-controlled printk ratelimiting

Synopsis

```
bool printk_timed_ratelimit (unsigned long * caller_jiffies, unsigned
int interval_msecs);
```

Arguments

caller_jiffies pointer to caller's state

interval_msecs minimum interval between prints

Description

printk_timed_ratelimit returns true if more than *interval_msecs* milliseconds have elapsed since the last time printk_timed_ratelimit returned true.

Name

kmsg_dump_register — register a kernel log dumper.

Synopsis

```
int kmsg_dump_register (struct kmsg_dumper * dumper);
```

Arguments

dumper pointer to the kmsg_dumper structure

Description

Adds a kernel log dumper to the system. The dump callback in the structure will be called when the kernel oopses or panics and must be set. Returns zero on success and `-EINVAL` or `-EBUSY` otherwise.

Name

kmsg_dump_unregister — unregister a kmsg dumper.

Synopsis

```
int kmsg_dump_unregister (struct kmsg_dumper * dumper);
```

Arguments

dumper pointer to the kmsg_dumper structure

Description

Removes a dump device from the system. Returns zero on success and `-EINVAL` otherwise.

Name

kmsg_dump_get_line — retrieve one kmsg log line

Synopsis

```
bool kmsg_dump_get_line (struct kmsg_dumper * dumper, bool syslog, char
* line, size_t size, size_t * len);
```

Arguments

dumper	registered kmsg dumper
syslog	include the “<4>” prefixes
line	buffer to copy the line to
size	maximum size of the buffer
len	length of line placed into buffer

Description

Start at the beginning of the kmsg buffer, with the oldest kmsg record, and copy one record into the provided buffer.

Consecutive calls will return the next available record moving towards the end of the buffer with the youngest messages.

A return value of FALSE indicates that there are no more records to read.

Name

kmsg_dump_get_buffer — copy kmsg log lines

Synopsis

```
bool kmsg_dump_get_buffer (struct kmsg_dumper * dumper, bool syslog,
char * buf, size_t size, size_t * len);
```

Arguments

dumper	registered kmsg dumper
syslog	include the “<4>” prefixes
buf	buffer to copy the line to
size	maximum size of the buffer
len	length of line placed into buffer

Description

Start at the end of the kmsg buffer and fill the provided buffer with as many of the the *youngest* kmsg records that fit into it. If the buffer is large enough, all available kmsg records will be copied with a single call.

Consecutive calls will fill the buffer with the next block of available older records, not including the earlier retrieved ones.

A return value of FALSE indicates that there are no more records to read.

Name

kmsg_dump_rewind — reset the interator

Synopsis

```
void kmsg_dump_rewind (struct kmsg_dumper * dumper);
```

Arguments

dumper registered kmsg dumper

Description

Reset the dumper's iterator so that `kmsg_dump_get_line` and `kmsg_dump_get_buffer` can be called again and used multiple times within the same dumper.`dump` callback.

Name

panic — halt the system

Synopsis

```
void panic (const char * fmt, ...);
```

Arguments

fmt The text string to print

... variable arguments

Description

Display a message, then perform cleanups.

This function never returns.

Name

add_taint —

Synopsis

```
void add_taint (unsigned flag, enum lockdep_ok lockdep_ok);
```

Arguments

flag one of the TAINT_* constants.

lockdep_ok whether lock debugging is still OK.

Description

If something bad has gone wrong, you'll want *lockdebug_ok* = false, but for some noteworthy-but-not-corrupting cases, it can be set to true.

Name

kernel/sys.c — Document generation inconsistency

Oops

Warning

The template for this document tried to insert the structured comment from the file `kernel/sys.c` at this point, but none was found. This dummy section is inserted to allow generation to continue.

Name

init_srcu_struct — initialize a sleep-RCU structure

Synopsis

```
int init_srcu_struct (struct srcu_struct * sp);
```

Arguments

sp structure to initialize.

Description

Must invoke this on a given srcu_struct before passing that srcu_struct to any other function. Each srcu_struct represents a separate domain of SRCU protection.

Name

cleanup_srcu_struct — deconstruct a sleep-RCU structure

Synopsis

```
void cleanup_srcu_struct (struct srcu_struct * sp);
```

Arguments

sp structure to clean up.

Description

Must invoke this after you are finished using a given srcu_struct that was initialized via `init_srcu_struct`, else you leak memory.

Name

synchronize_srcu — wait for prior SRCU read-side critical-section completion

Synopsis

```
void synchronize_srcu (struct srcu_struct * sp);
```

Arguments

sp srcu_struct with which to synchronize.

Description

Wait for the count to drain to zero of both indexes. To avoid the possible starvation of `synchronize_srcu`, it waits for the count of the index=((->completed & 1) ^ 1) to drain to zero at first, and then flip the completed and wait for the count of the other index.

Can block; must be called from process context.

Note that it is illegal to call `synchronize_srcu` from the corresponding SRCU read-side critical section; doing so will result in deadlock. However, it is perfectly legal to call `synchronize_srcu` on one srcu_struct from some other srcu_struct's read-side critical section, as long as the resulting graph of srcu_structs is acyclic.

There are memory-ordering constraints implied by `synchronize_srcu`. On systems with more than one CPU, when `synchronize_srcu` returns, each CPU is guaranteed to have executed a full memory barrier since the end of its last corresponding SRCU-sched read-side critical section whose beginning preceded the call to `synchronize_srcu`. In addition, each CPU having an SRCU read-side critical section that extends beyond the return from `synchronize_srcu` is guaranteed to have executed a full memory barrier after the beginning of `synchronize_srcu` and before the beginning of that SRCU read-side critical section. Note that these guarantees include CPUs that are offline, idle, or executing in user mode, as well as CPUs that are executing in the kernel.

Furthermore, if CPU A invoked `synchronize_srcu`, which returned to its caller on CPU B, then both CPU A and CPU B are guaranteed to have executed a full memory barrier during the execution of `synchronize_srcu`. This guarantee applies even if CPU A and CPU B are the same CPU, but again only if the system has more than one CPU.

Of course, these memory-ordering guarantees apply only when `synchronize_srcu`, `srcu_read_lock`, and `srcu_read_unlock` are passed the same srcu_struct structure.

Name

synchronize_srcu_expedited — Brute-force SRCU grace period

Synopsis

```
void synchronize_srcu_expedited (struct srcu_struct * sp);
```

Arguments

sp srcu_struct with which to synchronize.

Description

Wait for an SRCU grace period to elapse, but be more aggressive about spinning rather than blocking when waiting.

Note that `synchronize_srcu_expedited` has the same deadlock and memory-ordering properties as does `synchronize_srcu`.

Name

srcu_barrier — Wait until all in-flight `call_srcu` callbacks complete.

Synopsis

```
void srcu_barrier (struct srcu_struct * sp);
```

Arguments

sp srcu_struct on which to wait for in-flight callbacks.

Name

srcu_batches_completed — return batches completed.

Synopsis

```
unsigned long srcu_batches_completed (struct srcu_struct * sp);
```

Arguments

sp srcu_struct on which to report batch completion.

Description

Report the number of batches, correlated with, but not necessarily precisely the same as, the number of grace periods that have elapsed.

Name

rcu_idle_enter — inform RCU that current CPU is entering idle

Synopsis

```
void rcu_idle_enter ( void);
```

Arguments

void no arguments

Description

Enter idle mode, in other words, -leave- the mode in which RCU read-side critical sections can occur. (Though RCU read-side critical sections can occur in irq handlers in idle, a possibility handled by `irq_enter` and `irq_exit`.)

We crowbar the ->dynticks_nesting field to zero to allow for the possibility of usermode upcalls having messed up our count of interrupt nesting level during the prior busy period.

Name

rcu_idle_exit — inform RCU that current CPU is leaving idle

Synopsis

```
void rcu_idle_exit ( void);
```

Arguments

void no arguments

Description

Exit idle mode, in other words, -enter- the mode in which RCU read-side critical sections can occur.

We crowbar the ->dynticks_nesting field to DYNTICK_TASK_NEST to allow for the possibility of usermode upcalls messing up our count of interrupt nesting level during the busy period that is just now starting.

Name

rcu_is_watching — see if RCU thinks that the current CPU is idle

Synopsis

```
bool notrace rcu_is_watching ( void);
```

Arguments

void no arguments

Description

If the current CPU is in its idle loop and is neither in an interrupt or NMI handler, return true.

Name

synchronize_sched — wait until an rcu-sched grace period has elapsed.

Synopsis

```
void synchronize_sched ( void);
```

Arguments

void no arguments

Description

Control will return to the caller some time after a full rcu-sched grace period has elapsed, in other words after all currently executing rcu-sched read-side critical sections have completed. These read-side critical sections are delimited by `rcu_read_lock_sched` and `rcu_read_unlock_sched`, and may be nested. Note that `preempt_disable`, `local_irq_disable`, and so on may be used in place of `rcu_read_lock_sched`.

This means that all preempt_disable code sequences, including NMI and non-threaded hardware-interrupt handlers, in progress on entry will have completed before this primitive returns. However, this does not guarantee that softirq handlers will have completed, since in some kernels, these handlers can run in process context, and can block.

Note that this guarantee implies further memory-ordering guarantees. On systems with more than one CPU, when `synchronize_sched` returns, each CPU is guaranteed to have executed a full memory barrier since the end of its last RCU-sched read-side critical section whose beginning preceded the call to `synchronize_sched`. In addition, each CPU having an RCU read-side critical section that extends beyond the return from `synchronize_sched` is guaranteed to have executed a full memory barrier after the beginning of `synchronize_sched` and before the beginning of that RCU read-side critical section. Note that these guarantees include CPUs that are offline, idle, or executing in user mode, as well as CPUs that are executing in the kernel.

Furthermore, if CPU A invoked `synchronize_sched`, which returned to its caller on CPU B, then both CPU A and CPU B are guaranteed to have executed a full memory barrier during the execution of `synchronize_sched` -- even if CPU A and CPU B are the same CPU (but again only if the system has more than one CPU).

This primitive provides the guarantees made by the (now removed) `synchronize_kernel` API. In contrast, `synchronize_rcu` only guarantees that `rcu_read_lock` sections will have completed. In “classic RCU”, these two guarantees happen to be one and the same, but can differ in realtime RCU implementations.

Name

synchronize_rcu_bh — wait until an rcu_bh grace period has elapsed.

Synopsis

```
void synchronize_rcu_bh ( void);
```

Arguments

void no arguments

Description

Control will return to the caller some time after a full rcu_bh grace period has elapsed, in other words after all currently executing rcu_bh read-side critical sections have completed. RCU read-side critical sections are delimited by `rcu_read_lock_bh` and `rcu_read_unlock_bh`, and may be nested.

See the description of `synchronize_sched` for more detailed information on memory ordering guarantees.

Name

get_state_synchronize_rcu — Snapshot current RCU state

Synopsis

```
unsigned long get_state_synchronize_rcu ( void);
```

Arguments

void no arguments

Description

Returns a cookie that is used by a later call to `cond_synchronize_rcu` to determine whether or not a full grace period has elapsed in the meantime.

Name

cond_synchronize_rcu — Conditionally wait for an RCU grace period

Synopsis

```
void cond_synchronize_rcu (unsigned long oldstate);
```

Arguments

`oldstate` return value from earlier call to `get_state_synchronize_rcu`

Description

If a full RCU grace period has elapsed since the earlier call to `get_state_synchronize_rcu`, just return. Otherwise, invoke `synchronize_rcu` to wait for a full grace period.

Yes, this function does not take counter wrap into account. But counter wrap is harmless. If the counter wraps, we have waited for more than 2 billion grace periods (and way more on a 64-bit system!), so waiting for one additional grace period should be just fine.

Name

get_state_synchronize_sched — Snapshot current RCU-sched state

Synopsis

```
unsigned long get_state_synchronize_sched ( void);
```

Arguments

void no arguments

Description

Returns a cookie that is used by a later call to `cond_synchronize_sched` to determine whether or not a full grace period has elapsed in the meantime.

Name

cond_synchronize_sched — Conditionally wait for an RCU-sched grace period

Synopsis

```
void cond_synchronize_sched (unsigned long oldstate);
```

Arguments

oldstate return value from earlier call to `get_state_synchronize_sched`

Description

If a full RCU-sched grace period has elapsed since the earlier call to `get_state_synchronize_sched`, just return. Otherwise, invoke `synchronize_sched` to wait for a full grace period.

Yes, this function does not take counter wrap into account. But counter wrap is harmless. If the counter wraps, we have waited for more than 2 billion grace periods (and way more on a 64-bit system!), so waiting for one additional grace period should be just fine.

Name

synchronize_sched_expedited — Brute-force RCU-sched grace period

Synopsis

```
void synchronize_sched_expedited ( void);
```

Arguments

void no arguments

Description

Wait for an RCU-sched grace period to elapse, but use a “big hammer” approach to force the grace period to end quickly. This consumes significant time on all CPUs and is unfriendly to real-time workloads, so is thus not recommended for any sort of common-case code. In fact, if you are using `synchronize_sched_expedited` in a loop, please restructure your code to batch your updates, and then use a single `synchronize_sched` instead.

This implementation can be thought of as an application of sequence locking to expedited grace periods, but using the sequence counter to determine when someone else has already done the work instead of for retrying readers.

Name

rcu_barrier_bh — Wait until all in-flight `call_rcu_bh` callbacks complete.

Synopsis

```
void rcu_barrier_bh ( void);
```

Arguments

`void` no arguments

Name

rcu_barrier_sched — Wait for in-flight `call_rcu_sched` callbacks.

Synopsis

```
void rcu_barrier_sched ( void);
```

Arguments

`void` no arguments

Name

synchronize_rcu — wait until a grace period has elapsed.

Synopsis

```
void synchronize_rcu ( void);
```

Arguments

void no arguments

Description

Control will return to the caller some time after a full grace period has elapsed, in other words after all currently executing RCU read-side critical sections have completed. Note, however, that upon return from `synchronize_rcu`, the caller might well be executing concurrently with new RCU read-side critical sections that began while `synchronize_rcu` was waiting. RCU read-side critical sections are delimited by `rcu_read_lock` and `rcu_read_unlock`, and may be nested.

See the description of `synchronize_sched` for more detailed information on memory ordering guarantees.

Name

synchronize_rcu_expedited — Brute-force RCU grace period

Synopsis

```
void synchronize_rcu_expedited ( void);
```

Arguments

void no arguments

Description

Wait for an RCU-preempt grace period, but expedite it. The basic idea is to invoke `synchronize_sched_expedited` to push all the tasks to the ->blkd_tasks lists and wait for this list to drain. This consumes significant time on all CPUs and is unfriendly to real-time workloads, so is thus not recommended for any sort of common-case code. In fact, if you are using `synchronize_rcu_expedited` in a loop, please restructure your code to batch your updates, and then Use a single `synchronize_rcu` instead.

Name

rcu_barrier — Wait until all in-flight `call_rcu` callbacks complete.

Synopsis

```
void rcu_barrier ( void);
```

Arguments

`void` no arguments

Description

Note that this primitive does not necessarily wait for an RCU grace period to complete. For example, if there are no RCU callbacks queued anywhere in the system, then `rcu_barrier` is within its rights to return immediately, without waiting for anything, much less an RCU grace period.

Name

rcu_read_lock_sched_held — might we be in RCU-sched read-side critical section?

Synopsis

```
int rcu_read_lock_sched_held ( void);
```

Arguments

void no arguments

Description

If CONFIG_DEBUG_LOCK_ALLOC is selected, returns nonzero iff in an RCU-sched read-side critical section. In absence of CONFIG_DEBUG_LOCK_ALLOC, this assumes we are in an RCU-sched read-side critical section unless it can prove otherwise. Note that disabling of preemption (including disabling irqs) counts as an RCU-sched read-side critical section. This is useful for debug checks in functions that required that they be called within an RCU-sched read-side critical section.

Check `debug_lockdep_rcu_enabled` to prevent false positives during boot and while lockdep is disabled.

Note that if the CPU is in the idle loop from an RCU point of view (ie: that we are in the section between `rcu_idle_enter` and `rcu_idle_exit`) then `rcu_read_lock_held` returns false even if the CPU did an `rcu_read_lock`. The reason for this is that RCU ignores CPUs that are in such a section, considering these as in extended quiescent state, so such a CPU is effectively never in an RCU read-side critical section regardless of what RCU primitives it invokes. This state of affairs is required --- we need to keep an RCU-free window in idle where the CPU may possibly enter into low power mode. This way we can notice an extended quiescent state to other CPUs that started a grace period. Otherwise we would delay any grace period as long as we run in the idle task.

Similarly, we avoid claiming an SRCU read lock held if the current CPU is offline.

Name

rcu_expedite_gp — Expedite future RCU grace periods

Synopsis

```
void rcu_expedite_gp ( void);
```

Arguments

void no arguments

Description

After a call to this function, future calls to `synchronize_rcu` and friends act as the corresponding `synchronize_rcu_expedited` function had instead been called.

Name

rcu_unexpedite_gp — Cancel prior `rcu_expedite_gp` invocation

Synopsis

```
void rcu_unexpedite_gp ( void);
```

Arguments

`void` no arguments

Description

Undo a prior call to `rcu_expedite_gp`. If all prior calls to `rcu_expedite_gp` are undone by a subsequent call to `rcu_unexpedite_gp`, and if the rcu_expedited sysfs/boot parameter is not set, then all subsequent calls to `synchronize_rcu` and friends will return to their normal non-expedited behavior.

Name

rcu_read_lock_held — might we be in RCU read-side critical section?

Synopsis

```
int rcu_read_lock_held ( void);
```

Arguments

void no arguments

Description

If CONFIG_DEBUG_LOCK_ALLOC is selected, returns nonzero iff in an RCU read-side critical section. In absence of CONFIG_DEBUG_LOCK_ALLOC, this assumes we are in an RCU read-side critical section unless it can prove otherwise. This is useful for debug checks in functions that require that they be called within an RCU read-side critical section.

Checks `debug_lockdep_rcu_enabled` to prevent false positives during boot and while lockdep is disabled.

Note that `rcu_read_lock` and the matching `rcu_read_unlock` must occur in the same context, for example, it is illegal to invoke `rcu_read_unlock` in process context if the matching `rcu_read_lock` was invoked from within an irq handler.

Note that `rcu_read_lock` is disallowed if the CPU is either idle or offline from an RCU perspective, so check for those as well.

Name

rcu_read_lock_bh_held — might we be in RCU-bh read-side critical section?

Synopsis

```
int rcu_read_lock_bh_held ( void);
```

Arguments

void no arguments

Description

Check for bottom half being disabled, which covers both the CONFIG_PROVE_RCU and not cases. Note that if someone uses `rcu_read_lock_bh`, but then later enables BH, lockdep (if enabled) will show the situation. This is useful for debug checks in functions that require that they be called within an RCU read-side critical section.

Check `debug_lockdep_rcu_enabled` to prevent false positives during boot.

Note that `rcu_read_lock` is disallowed if the CPU is either idle or offline from an RCU perspective, so check for those as well.

Name

wakeme_after_rcu — Callback function to awaken a task after grace period

Synopsis

```
void wakeme_after_rcu (struct rcu_head * head);
```

Arguments

head Pointer to rcu_head member within rcu_synchronize structure

Description

Awaken the corresponding task now that a grace period has elapsed.

Name

init_rcu_head_on_stack — initialize on-stack rcu_head for debugobjects

Synopsis

```
void init_rcu_head_on_stack (struct rcu_head * head);
```

Arguments

head pointer to rcu_head structure to be initialized

Description

This function informs debugobjects of a new rcu_head structure that has been allocated as an auto variable on the stack. This function is not required for rcu_head structures that are statically defined or that are dynamically allocated on the heap. This function has no effect for ! CONFIG_DEBUG_OBJECTS_RCU_HEAD kernel builds.

Name

destroy_rcu_head_on_stack — destroy on-stack rcu_head for debugobjects

Synopsis

```
void destroy_rcu_head_on_stack (struct rcu_head * head);
```

Arguments

head pointer to rcu_head structure to be initialized

Description

This function informs debugobjects that an on-stack rcu_head structure is about to go out of scope. As with `init_rcu_head_on_stack`, this function is not required for rcu_head structures that are statically defined or that are dynamically allocated on the heap. Also as with `init_rcu_head_on_stack`, this function has no effect for !CONFIG_DEBUG_OBJECTS_RCU_HEAD kernel builds.

Name

synchronize_rcu_tasks — wait until an rcu-tasks grace period has elapsed.

Synopsis

```
void synchronize_rcu_tasks ( void);
```

Arguments

void no arguments

Description

Control will return to the caller some time after a full rcu-tasks grace period has elapsed, in other words after all currently executing rcu-tasks read-side critical sections have elapsed. These read-side critical sections are delimited by calls to `schedule`, `cond_resched_rcu_qs`, idle execution, userspace execution, calls to `synchronize_rcu_tasks`, and (in theory, anyway) `cond_resched`.

This is a very specialized primitive, intended only for a few uses in tracing and other situations requiring manipulation of function preambles and profiling hooks. The `synchronize_rcu_tasks` function is not (yet) intended for heavy use from multiple CPUs.

Note that this guarantee implies further memory-ordering guarantees. On systems with more than one CPU, when `synchronize_rcu_tasks` returns, each CPU is guaranteed to have executed a full memory barrier since the end of its last RCU-tasks read-side critical section whose beginning preceded the call to `synchronize_rcu_tasks`. In addition, each CPU having an RCU-tasks read-side critical section that extends beyond the return from `synchronize_rcu_tasks` is guaranteed to have executed a full memory barrier after the beginning of `synchronize_rcu_tasks` and before the beginning of that RCU-tasks read-side critical section. Note that these guarantees include CPUs that are offline, idle, or executing in user mode, as well as CPUs that are executing in the kernel.

Furthermore, if CPU A invoked `synchronize_rcu_tasks`, which returned to its caller on CPU B, then both CPU A and CPU B are guaranteed to have executed a full memory barrier during the execution of `synchronize_rcu_tasks` -- even if CPU A and CPU B are the same CPU (but again only if the system has more than one CPU).

Name

rcu_barrier_tasks — Wait for in-flight `call_rcu_tasks` callbacks.

Synopsis

```
void rcu_barrier_tasks ( void);
```

Arguments

`void` no arguments

Description

Although the current implementation is guaranteed to wait, it is not obligated to, for example, if there are no pending callbacks.

Device Resource Management

Name

devres_alloc_node — Allocate device resource data

Synopsis

```
void * devres_alloc_node (dr_release_t release, size_t size, gfp_t gfp,
int nid);
```

Arguments

release Release function devres will be associated with

size Allocation size

gfp Allocation flags

nid NUMA node

Description

Allocate devres of *size* bytes. The allocated area is zeroed, then associated with *release*. The returned pointer can be passed to other devres_*() functions.

RETURNS

Pointer to allocated devres on success, NULL on failure.

Name

devres_for_each_res — Resource iterator

Synopsis

```
void devres_for_each_res (struct device * dev, dr_release_t release,
dr_match_t match, void * match_data, void (*fn) (struct device *, void
*, void *), void * data);
```

Arguments

dev	Device to iterate resource from
release	Look for resources associated with this release function
match	Match function (optional)
match_data	Data for the match function
fn	Function to be called for each matched resource.
data	Data for *fn*, the 3rd parameter of *fn*

Description

Call *fn* for each devres of *dev* which is associated with *release* and for which *match* returns 1.

RETURNS

void

Name

devres_free — Free device resource data

Synopsis

```
void devres_free (void * res);
```

Arguments

res Pointer to devres data to free

Description

Free devres created with `devres_alloc`.

Name

devres_add — Register device resource

Synopsis

```
void devres_add (struct device * dev, void * res);
```

Arguments

dev Device to add resource to

res Resource to register

Description

Register devres *res* to *dev*. *res* should have been allocated using devres_alloc. On driver detach, the associated release function will be invoked and devres will be freed automatically.

Name

devres_find — Find device resource

Synopsis

```
void * devres_find (struct device * dev, dr_release_t release, dr_match_t
match, void * match_data);
```

Arguments

dev	Device to lookup resource from
release	Look for resources associated with this release function
match	Match function (optional)
match_data	Data for the match function

Description

Find the latest devres of *dev* which is associated with *release* and for which *match* returns 1. If *match* is NULL, it's considered to match all.

RETURNS

Pointer to found devres, NULL if not found.

Name

devres_get — Find devres, if non-existent, add one atomically

Synopsis

```
void * devres_get (struct device * dev, void * new_res, dr_match_t match, void * match_data);
```

Arguments

dev	Device to lookup or add devres for
new_res	Pointer to new initialized devres to add if not found
match	Match function (optional)
match_data	Data for the match function

Description

Find the latest devres of *dev* which has the same release function as *new_res* and for which *match* return 1. If found, *new_res* is freed; otherwise, *new_res* is added atomically.

RETURNS

Pointer to found or added devres.

Name

devres_remove — Find a device resource and remove it

Synopsis

```
void * devres_remove (struct device * dev, dr_release_t release,
dr_match_t match, void * match_data);
```

Arguments

dev	Device to find resource from
release	Look for resources associated with this release function
match	Match function (optional)
match_data	Data for the match function

Description

Find the latest devres of *dev* associated with *release* and for which *match* returns 1. If *match* is NULL, it's considered to match all. If found, the resource is removed atomically and returned.

RETURNS

Pointer to removed devres on success, NULL if not found.

Name

devres_destroy — Find a device resource and destroy it

Synopsis

```
int devres_destroy (struct device * dev, dr_release_t release,
dr_match_t match, void * match_data);
```

Arguments

dev	Device to find resource from
release	Look for resources associated with this release function
match	Match function (optional)
match_data	Data for the match function

Description

Find the latest devres of *dev* associated with *release* and for which *match* returns 1. If *match* is NULL, it's considered to match all. If found, the resource is removed atomically and freed.

Note that the release function for the resource will not be called, only the devres-allocated data will be freed. The caller becomes responsible for freeing any other data.

RETURNS

0 if devres is found and freed, -ENOENT if not found.

Name

devres_release — Find a device resource and destroy it, calling release

Synopsis

```
int devres_release (struct device * dev, dr_release_t release,
dr_match_t match, void * match_data);
```

Arguments

dev	Device to find resource from
release	Look for resources associated with this release function
match	Match function (optional)
match_data	Data for the match function

Description

Find the latest devres of *dev* associated with *release* and for which *match* returns 1. If *match* is NULL, it's considered to match all. If found, the resource is removed atomically, the release function called and the resource freed.

RETURNS

0 if devres is found and freed, -ENOENT if not found.

Name

devres_open_group — Open a new devres group

Synopsis

```
void * devres_open_group (struct device * dev, void * id, gfp_t gfp);
```

Arguments

dev Device to open devres group for

id Separator ID

gfp Allocation flags

Description

Open a new devres group for *dev* with *id*. For *id*, using a pointer to an object which won't be used for another group is recommended. If *id* is NULL, address-wise unique ID is created.

RETURNS

ID of the new group, NULL on failure.

Name

devres_close_group — Close a devres group

Synopsis

```
void devres_close_group (struct device * dev, void * id);
```

Arguments

dev Device to close devres group for

id ID of target group, can be NULL

Description

Close the group identified by *id*. If *id* is NULL, the latest open group is selected.

Name

devres_remove_group — Remove a devres group

Synopsis

```
void devres_remove_group (struct device * dev, void * id);
```

Arguments

dev Device to remove group for

id ID of target group, can be NULL

Description

Remove the group identified by *id*. If *id* is NULL, the latest open group is selected. Note that removing a group doesn't affect any other resources.

Name

devres_release_group — Release resources in a devres group

Synopsis

```
int devres_release_group (struct device * dev, void * id);
```

Arguments

dev Device to release group for

id ID of target group, can be NULL

Description

Release all resources in the group identified by *id*. If *id* is NULL, the latest open group is selected. The selected group and groups properly nested inside the selected group are removed.

RETURNS

The number of released non-group resources.

Name

devm_add_action — add a custom action to list of managed resources

Synopsis

```
int devm_add_action (struct device * dev, void (*action) (void *), void
* data);
```

Arguments

dev Device that owns the action

action Function that should be called

data Pointer to data passed to *action* implementation

Description

This adds a custom action to the list of managed resources so that it gets executed as part of standard resource unwinding.

Name

devm_remove_action — removes previously added custom action

Synopsis

```
void devm_remove_action (struct device * dev, void (*action) (void *),
void * data);
```

Arguments

dev Device that owns the action

action Function implementing the action

data Pointer to data passed to *action* implementation

Description

Removes instance of *action* previously added by devm_add_action. Both action and data should match one of the existing entries.

Name

devm_kmalloc — Resource-managed kmalloc

Synopsis

```
void * devm_kmalloc (struct device * dev, size_t size, gfp_t gfp);
```

Arguments

dev Device to allocate memory for

size Allocation size

gfp Allocation gfp flags

Description

Managed kmalloc. Memory allocated with this function is automatically freed on driver detach. Like all other devres resources, guaranteed alignment is unsigned long long.

RETURNS

Pointer to allocated memory on success, NULL on failure.

Name

devm_kstrdup — Allocate resource managed space and copy an existing string into that.

Synopsis

```
char * devm_kstrdup (struct device * dev, const char * s, gfp_t gfp);
```

Arguments

dev Device to allocate memory for

s the string to duplicate

gfp the GFP mask used in the `devm_kmalloc` call when allocating memory

RETURNS

Pointer to allocated string on success, NULL on failure.

Name

devm_kvasprintf — Allocate resource managed space and format a string into that.

Synopsis

```
char * devm_kvasprintf (struct device * dev, gfp_t gfp, const char *
fmt, va_list ap);
```

Arguments

dev Device to allocate memory for

gfp the GFP mask used in the `devm_kmalloc` call when allocating memory

fmt The `printf`-style format string

ap Arguments for the format string

RETURNS

Pointer to allocated string on success, NULL on failure.

Name

devm_kasprintf — Allocate resource managed space and format a string into that.

Synopsis

```
char * devm_kasprintf (struct device * dev, gfp_t gfp, const char *
fmt, ...);
```

Arguments

dev Device to allocate memory for

gfp the GFP mask used in the devm_kmalloc call when allocating memory

fmt The printf-style format string @...: Arguments for the format string

... variable arguments

RETURNS

Pointer to allocated string on success, NULL on failure.

Name

devm_kfree — Resource-managed kfree

Synopsis

```
void devm_kfree (struct device * dev, void * p);
```

Arguments

dev Device this memory belongs to

p Memory to free

Description

Free memory allocated with `devm_kmalloc`.

Name

devm_kmemdup — Resource-managed kmemdup

Synopsis

```
void * devm_kmemdup (struct device * dev, const void * src, size_t len,
gfp_t gfp);
```

Arguments

dev Device this memory belongs to

src Memory region to duplicate

len Memory region length

gfp GFP mask to use

Description

Duplicate region of a memory using resource managed kmalloc

Name

devm_get_free_pages — Resource-managed __get_free_pages

Synopsis

```
unsigned long devm_get_free_pages (struct device * dev, gfp_t gfp_mask,
unsigned int order);
```

Arguments

dev	Device to allocate memory for
gfp_mask	Allocation gfp flags
order	Allocation size is (1 << order) pages

Description

Managed get_free_pages. Memory allocated with this function is automatically freed on driver detach.

RETURNS

Address of allocated memory on success, 0 on failure.

Name

devm_free_pages — Resource-managed free_pages

Synopsis

```
void devm_free_pages (struct device * dev, unsigned long addr);
```

Arguments

dev Device this memory belongs to

addr Memory to free

Description

Free memory allocated with `devm_get_free_pages`. Unlike free_pages, there is no need to supply the *order*.

Chapter 2. Device drivers infrastructure

The Basic Device Driver-Model Structures

Name

struct bus_type — The bus type of the device

Synopsis

```
struct bus_type {
  const char * name;
  const char * dev_name;
  struct device * dev_root;
  struct device_attribute * dev_attrs;
  const struct attribute_group ** bus_groups;
  const struct attribute_group ** dev_groups;
  const struct attribute_group ** drv_groups;
  int (* match) (struct device *dev, struct device_driver *drv);
  int (* uevent) (struct device *dev, struct kobj_uevent_env *env);
  int (* probe) (struct device *dev);
  int (* remove) (struct device *dev);
  void (* shutdown) (struct device *dev);
  int (* online) (struct device *dev);
  int (* offline) (struct device *dev);
  int (* suspend) (struct device *dev, pm_message_t state);
  int (* resume) (struct device *dev);
  const struct dev_pm_ops * pm;
  const struct iommu_ops * iommu_ops;
  struct subsys_private * p;
  struct lock_class_key lock_key;
};
```

Members

name	The name of the bus.
dev_name	Used for subsystems to enumerate devices like (“foou”, dev->id).
dev_root	Default device to use as the parent.
dev_attrs	Default attributes of the devices on the bus.
bus_groups	Default attributes of the bus.
dev_groups	Default attributes of the devices on the bus.
drv_groups	Default attributes of the device drivers on the bus.
match	Called, perhaps multiple times, whenever a new device or driver is added for this bus. It should return a nonzero value if the given device can be handled by the given driver.
uevent	Called when a device is added, removed, or a few other things that generate uevents to add the environment variables.
probe	Called when a new device or driver add to this bus, and callback the specific driver's probe to initial the matched device.
remove	Called when a device removed from this bus.

shutdown	Called at shut-down time to quiesce the device.
online	Called to put the device back online (after offlining it).
offline	Called to put the device offline for hot-removal. May fail.
suspend	Called when a device on this bus wants to go to sleep mode.
resume	Called to bring a device on this bus out of sleep mode.
pm	Power management operations of this bus, callback the specific device driver's pm-ops.
iommu_ops	IOMMU specific operations for this bus, used to attach IOMMU driver implementations to a bus and allow the driver to do bus-specific setup
p	The private data of the driver core, only the driver core can touch this.
lock_key	Lock class key for use by the lock validator

Description

A bus is a channel between the processor and one or more devices. For the purposes of the device model, all devices are connected via a bus, even if it is an internal, virtual, “platform” bus. Buses can plug into each other. A USB controller is usually a PCI device, for example. The device model represents the actual connections between buses and the devices they control. A bus is represented by the bus_type structure. It contains the name, the default attributes, the bus' methods, PM operations, and the driver core's private data.

Name

enum probe_type — device driver probe type to try Device drivers may opt in for special handling of their respective probe routines. This tells the core what to expect and prefer.

Synopsis

```
enum probe_type {
  PROBE_DEFAULT_STRATEGY,
  PROBE_PREFER_ASYNCHRONOUS,
  PROBE_FORCE_SYNCHRONOUS
};
```

Constants

PROBE_DEFAULT_STRATEGY
: Used by drivers that work equally well whether probed synchronously or asynchronously.

PROBE_PREFER_ASYNCHRONOUS
: Drivers for “slow” devices which probing order is not essential for booting the system may opt into executing their probes asynchronously.

PROBE_FORCE_SYNCHRONOUS
: Use this to annotate drivers that need their probe routines to run synchronously with driver and device registration (with the exception of -EPROBE_DEFER handling - re-probing always ends up being done asynchronously).

Description

Note that the end goal is to switch the kernel to use asynchronous probing by default, so annotating drivers with `PROBE_PREFER_ASYNCHRONOUS` is a temporary measure that allows us to speed up boot process while we are validating the rest of the drivers.

Name

struct device_driver — The basic device driver structure

Synopsis

```
struct device_driver {
  const char * name;
  struct bus_type * bus;
  struct module * owner;
  const char * mod_name;
  bool suppress_bind_attrs;
  enum probe_type probe_type;
  const struct of_device_id * of_match_table;
  const struct acpi_device_id * acpi_match_table;
  int (* probe) (struct device *dev);
  int (* remove) (struct device *dev);
  void (* shutdown) (struct device *dev);
  int (* suspend) (struct device *dev, pm_message_t state);
  int (* resume) (struct device *dev);
  const struct attribute_group ** groups;
  const struct dev_pm_ops * pm;
  struct driver_private * p;
};
```

Members

name	Name of the device driver.
bus	The bus which the device of this driver belongs to.
owner	The module owner.
mod_name	Used for built-in modules.
suppress_bind_attrs	Disables bind/unbind via sysfs.
probe_type	Type of the probe (synchronous or asynchronous) to use.
of_match_table	The open firmware table.
acpi_match_table	The ACPI match table.
probe	Called to query the existence of a specific device, whether this driver can work with it, and bind the driver to a specific device.
remove	Called when the device is removed from the system to unbind a device from this driver.
shutdown	Called at shut-down time to quiesce the device.
suspend	Called to put the device to sleep mode. Usually to a low power state.
resume	Called to bring a device from sleep mode.
groups	Default attributes that get created by the driver core automatically.

pm	Power management operations of the device which matched this driver.
p	Driver core's private data, no one other than the driver core can touch this.

Description

The device driver-model tracks all of the drivers known to the system. The main reason for this tracking is to enable the driver core to match up drivers with new devices. Once drivers are known objects within the system, however, a number of other things become possible. Device drivers can export information and configuration variables that are independent of any specific device.

Name

struct subsys_interface — interfaces to device functions

Synopsis

```
struct subsys_interface {
  const char * name;
  struct bus_type * subsys;
  struct list_head node;
  int (* add_dev) (struct device *dev, struct subsys_interface *sif);
  void (* remove_dev) (struct device *dev, struct subsys_interface *sif);
};
```

Members

name	name of the device function
subsys	subsytem of the devices to attach to
node	the list of functions registered at the subsystem
add_dev	device hookup to device function handler
remove_dev	device hookup to device function handler

Description

Simple interfaces attached to a subsystem. Multiple interfaces can attach to a subsystem and its devices. Unlike drivers, they do not exclusively claim or control devices. Interfaces usually represent a specific functionality of a subsystem/class of devices.

Name

struct class — device classes

Synopsis

```
struct class {
  const char * name;
  struct module * owner;
  struct class_attribute * class_attrs;
  const struct attribute_group ** dev_groups;
  struct kobject * dev_kobj;
  int (* dev_uevent) (struct device *dev, struct kobj_uevent_env *env);
  char *(* devnode) (struct device *dev, umode_t *mode);
  void (* class_release) (struct class *class);
  void (* dev_release) (struct device *dev);
  int (* suspend) (struct device *dev, pm_message_t state);
  int (* resume) (struct device *dev);
  const struct kobj_ns_type_operations * ns_type;
  const void *(* namespace) (struct device *dev);
  const struct dev_pm_ops * pm;
  struct subsys_private * p;
};
```

Members

name	Name of the class.
owner	The module owner.
class_attrs	Default attributes of this class.
dev_groups	Default attributes of the devices that belong to the class.
dev_kobj	The kobject that represents this class and links it into the hierarchy.
dev_uevent	Called when a device is added, removed from this class, or a few other things that generate uevents to add the environment variables.
devnode	Callback to provide the devtmpfs.
class_release	Called to release this class.
dev_release	Called to release the device.
suspend	Used to put the device to sleep mode, usually to a low power state.
resume	Used to bring the device from the sleep mode.
ns_type	Callbacks so sysfs can detemine namespaces.
namespace	Namespace of the device belongs to this class.
pm	The default device power management operations of this class.
p	The private data of the driver core, no one other than the driver core can touch this.

Description

A class is a higher-level view of a device that abstracts out low-level implementation details. Drivers may see a SCSI disk or an ATA disk, but, at the class level, they are all simply disks. Classes allow user space to work with devices based on what they do, rather than how they are connected or how they work.

Name

struct device — The basic device structure

Synopsis

```
struct device {
  struct device * parent;
  struct device_private * p;
  struct kobject kobj;
  const char * init_name;
  const struct device_type * type;
  struct mutex mutex;
  struct bus_type * bus;
  struct device_driver * driver;
  void * platform_data;
  void * driver_data;
  struct dev_pm_info power;
  struct dev_pm_domain * pm_domain;
#ifdef CONFIG_GENERIC_MSI_IRQ_DOMAIN
  struct irq_domain * msi_domain;
#endif
#ifdef CONFIG_PINCTRL
  struct dev_pin_info * pins;
#endif
#ifdef CONFIG_GENERIC_MSI_IRQ
  struct list_head msi_list;
#endif
#ifdef CONFIG_NUMA
  int numa_node;
#endif
  u64 * dma_mask;
  u64 coherent_dma_mask;
  unsigned long dma_pfn_offset;
  struct device_dma_parameters * dma_parms;
  struct list_head dma_pools;
  struct dma_coherent_mem * dma_mem;
#ifdef CONFIG_DMA_CMA
  struct cma * cma_area;
#endif
  struct dev_archdata archdata;
  struct device_node * of_node;
  struct fwnode_handle * fwnode;
  dev_t devt;
  u32 id;
  spinlock_t devres_lock;
  struct list_head devres_head;
  struct klist_node knode_class;
  struct class * class;
  const struct attribute_group ** groups;
  void (* release) (struct device *dev);
  struct iommu_group * iommu_group;
  bool offline_disabled:1;
```

```
  bool offline:1;
};
```

Members

parent	The device's “parent” device, the device to which it is attached. In most cases, a parent device is some sort of bus or host controller. If parent is NULL, the device, is a top-level device, which is not usually what you want.
p	Holds the private data of the driver core portions of the device. See the comment of the struct device_private for detail.
kobj	A top-level, abstract class from which other classes are derived.
init_name	Initial name of the device.
type	The type of device. This identifies the device type and carries type-specific information.
mutex	Mutex to synchronize calls to its driver.
bus	Type of bus device is on.
driver	Which driver has allocated this
platform_data	Platform data specific to the device.
driver_data	Private pointer for driver specific info.
power	For device power management. See Documentation/power/devices.txt for details.
pm_domain	Provide callbacks that are executed during system suspend, hibernation, system resume and during runtime PM transitions along with subsystem-level and driver-level callbacks.
msi_domain	The generic MSI domain this device is using.
pins	For device pin management. See Documentation/pinctrl.txt for details.
msi_list	Hosts MSI descriptors
numa_node	NUMA node this device is close to.
dma_mask	Dma mask (if dma'ble device).
coherent_dma_mask	Like dma_mask, but for alloc_coherent mapping as not all hardware supports 64-bit addresses for consistent allocations such descriptors.
dma_pfn_offset	offset of DMA memory range relatively of RAM
dma_parms	A low level driver may set these to teach IOMMU code about segment limitations.
dma_pools	Dma pools (if dma'ble device).
dma_mem	Internal for coherent mem override.

cma_area	Contiguous memory area for dma allocations
archdata	For arch-specific additions.
of_node	Associated device tree node.
fwnode	Associated device node supplied by platform firmware.
devt	For creating the sysfs “dev”.
id	device instance
devres_lock	Spinlock to protect the resource of the device.
devres_head	The resources list of the device.
knode_class	The node used to add the device to the class list.
class	The class of the device.
groups	Optional attribute groups.
release	Callback to free the device after all references have gone away. This should be set by the allocator of the device (i.e. the bus driver that discovered the device).
iommu_group	IOMMU group the device belongs to.
offline_disabled	If set, the device is permanently online.
offline	Set after successful invocation of bus type's .`offline`.

Example

```
For devices on custom boards, as typical of embedded
  and SOC based hardware, Linux often uses platform_data to point
  to board-specific structures describing devices and how they
  are wired.  That can include what ports are available, chip
  variants, which GPIO pins act in what additional roles, and so
  on.  This shrinks the “Board Support Packages” (BSPs) and
  minimizes board-specific #ifdefs in drivers.
```

Description

At the lowest level, every device in a Linux system is represented by an instance of struct device. The device structure contains the information that the device model core needs to model the system. Most subsystems, however, track additional information about the devices they host. As a result, it is rare for devices to be represented by bare device structures; instead, that structure, like kobject structures, is usually embedded within a higher-level representation of the device.

Name

module_driver — Helper macro for drivers that don't do anything special in module init/exit. This eliminates a lot of boilerplate. Each module may only use this macro once, and calling it replaces `module_init` and `module_exit`.

Synopsis

```
module_driver ( __driver, __register, __unregister, ...);
```

Arguments

__driver	driver name
__register	register function for this driver type
__unregister	unregister function for this driver type @...: Additional arguments to be passed to __register and __unregister.
...	variable arguments

Description

Use this macro to construct bus specific macros for registering drivers, and do not use it on its own.

Name

builtin_driver — Helper macro for drivers that don't do anything special in init and have no exit. This eliminates some boilerplate. Each driver may only use this macro once, and calling it replaces device_initcall (or in some cases, the legacy __initcall). This is meant to be a direct parallel of `module_driver` above but without the __exit stuff that is not used for builtin cases.

Synopsis

```
builtin_driver ( __driver, __register, ...);
```

Arguments

__driver	driver name
__register	register function for this driver type @...: Additional arguments to be passed to __register
...	variable arguments

Description

Use this macro to construct bus specific macros for registering drivers, and do not use it on its own.

Device Drivers Base

Name

driver_init — initialize driver model.

Synopsis

```
void driver_init ( void);
```

Arguments

void no arguments

Description

Call the driver model init functions to initialize their subsystems. Called early from init/main.c.

Name

driver_for_each_device — Iterator for devices bound to a driver.

Synopsis

```
int driver_for_each_device (struct device_driver * drv, struct device
* start, void * data, int (*fn) (struct device *, void *));
```

Arguments

drv Driver we're iterating.

start Device to begin with

data Data to pass to the callback.

fn Function to call for each device.

Description

Iterate over the *drv*'s list of devices calling *fn* for each one.

Name

driver_find_device — device iterator for locating a particular device.

Synopsis

```
struct device * driver_find_device (struct device_driver * drv, struct
device * start, void * data, int (*match) (struct device *dev, void
*data));
```

Arguments

drv The device's driver

start Device to begin with

data Data to pass to match function

match Callback function to check device

Description

This is similar to the `driver_for_each_device` function above, but it returns a reference to a device that is 'found' for later use, as determined by the *match* callback.

The callback should return 0 if the device doesn't match and non-zero if it does. If the callback returns non-zero, this function will return to the caller and not iterate over any more devices.

Name

driver_create_file — create sysfs file for driver.

Synopsis

```
int driver_create_file (struct device_driver * drv, const struct
driver_attribute * attr);
```

Arguments

drv driver.

attr driver attribute descriptor.

Name

driver_remove_file — remove sysfs file for driver.

Synopsis

```
void driver_remove_file (struct device_driver * drv, const struct
driver_attribute * attr);
```

Arguments

drv driver.

attr driver attribute descriptor.

Name

driver_register — register driver with bus

Synopsis

```
int driver_register (struct device_driver * drv);
```

Arguments

drv driver to register

Description

We pass off most of the work to the `bus_add_driver` call, since most of the things we have to do deal with the bus structures.

Name

driver_unregister — remove driver from system.

Synopsis

```
void driver_unregister (struct device_driver * drv);
```

Arguments

drv driver.

Description

Again, we pass off most of the work to the bus-level call.

Name

driver_find — locate driver on a bus by its name.

Synopsis

```
struct device_driver * driver_find (const char * name, struct bus_type
* bus);
```

Arguments

name name of the driver.

bus bus to scan for the driver.

Description

Call `kset_find_obj` to iterate over list of drivers on a bus to find driver by name. Return driver if found.

This routine provides no locking to prevent the driver it returns from being unregistered or unloaded while the caller is using it. The caller is responsible for preventing this.

Name

dev_driver_string — Return a device's driver name, if at all possible

Synopsis

```
const char * dev_driver_string (const struct device * dev);
```

Arguments

dev struct device to get the name of

Description

Will return the device's driver's name if it is bound to a device. If the device is not bound to a driver, it will return the name of the bus it is attached to. If it is not attached to a bus either, an empty string will be returned.

Name

device_create_file — create sysfs attribute file for device.

Synopsis

```
int device_create_file (struct device * dev, const struct
device_attribute * attr);
```

Arguments

dev device.

attr device attribute descriptor.

Name

device_remove_file — remove sysfs attribute file.

Synopsis

```
void device_remove_file (struct device * dev, const struct
device_attribute * attr);
```

Arguments

dev device.

attr device attribute descriptor.

Name

device_remove_file_self — remove sysfs attribute file from its own method.

Synopsis

```
bool device_remove_file_self (struct device * dev, const struct
device_attribute * attr);
```

Arguments

dev device.

attr device attribute descriptor.

Description

See `kernfs_remove_self` for details.

Name

device_create_bin_file — create sysfs binary attribute file for device.

Synopsis

```
int device_create_bin_file (struct device * dev, const struct
bin_attribute * attr);
```

Arguments

dev device.

attr device binary attribute descriptor.

Name

device_remove_bin_file — remove sysfs binary attribute file

Synopsis

```
void device_remove_bin_file (struct device * dev, const struct
bin_attribute * attr);
```

Arguments

dev device.

attr device binary attribute descriptor.

Name

device_initialize — init device structure.

Synopsis

```
void device_initialize (struct device * dev);
```

Arguments

dev device.

Description

This prepares the device for use by other layers by initializing its fields. It is the first half of `device_register`, if called by that function, though it can also be called separately, so one may use *dev*'s fields. In particular, `get_device`/`put_device` may be used for reference counting of *dev* after calling this function.

All fields in *dev* must be initialized by the caller to 0, except for those explicitly set to some other value. The simplest approach is to use `kzalloc` to allocate the structure containing *dev*.

NOTE

Use `put_device` to give up your reference instead of freeing *dev* directly once you have called this function.

Name

dev_set_name — set a device name

Synopsis

```
int dev_set_name (struct device * dev, const char * fmt, ...);
```

Arguments

dev device

fmt format string for the device's name

... variable arguments

Name

device_add — add device to device hierarchy.

Synopsis

```
int device_add (struct device * dev);
```

Arguments

dev device.

Description

This is part 2 of `device_register`, though may be called separately _iff_ `device_initialize` has been called separately.

This adds *dev* to the kobject hierarchy via `kobject_add`, adds it to the global and sibling lists for the device, then adds it to the other relevant subsystems of the driver model.

Do not call this routine or `device_register` more than once for any device structure. The driver model core is not designed to work with devices that get unregistered and then spring back to life. (Among other things, it's very hard to guarantee that all references to the previous incarnation of *dev* have been dropped.) Allocate and register a fresh new struct device instead.

NOTE

Never directly free *dev* after calling this function, even if it returned an error! Always use `put_device` to give up your reference instead.

Name

device_register — register a device with the system.

Synopsis

```
int device_register (struct device * dev);
```

Arguments

dev pointer to the device structure

Description

This happens in two clean steps - initialize the device and add it to the system. The two steps can be called separately, but this is the easiest and most common. I.e. you should only call the two helpers separately if have a clearly defined need to use and refcount the device before it is added to the hierarchy.

For more information, see the kerneldoc for `device_initialize` and `device_add`.

NOTE

Never directly free *dev* after calling this function, even if it returned an error! Always use `put_device` to give up the reference initialized in this function instead.

Name

get_device — increment reference count for device.

Synopsis

```
struct device * get_device (struct device * dev);
```

Arguments

dev device.

Description

This simply forwards the call to `kobject_get`, though we do take care to provide for the case that we get a NULL pointer passed in.

Name

put_device — decrement reference count.

Synopsis

```
void put_device (struct device * dev);
```

Arguments

dev device in question.

Name

device_del — delete device from system.

Synopsis

```
void device_del (struct device * dev);
```

Arguments

dev device.

Description

This is the first part of the device unregistration sequence. This removes the device from the lists we control from here, has it removed from the other driver model subsystems it was added to in `device_add`, and removes it from the kobject hierarchy.

NOTE

this should be called manually _iff_ `device_add` was also called manually.

Name

device_unregister — unregister device from system.

Synopsis

```
void device_unregister (struct device * dev);
```

Arguments

dev device going away.

Description

We do this in two parts, like we do `device_register`. First, we remove it from all the subsystems with `device_del`, then we decrement the reference count via `put_device`. If that is the final reference count, the device will be cleaned up via `device_release` above. Otherwise, the structure will stick around until the final reference to the device is dropped.

Name

device_for_each_child — device child iterator.

Synopsis

```
int device_for_each_child (struct device * parent, void * data, int
(*fn) (struct device *dev, void *data));
```

Arguments

parent parent struct device.

data data for the callback.

fn function to be called for each device.

Description

Iterate over *parent*'s child devices, and call *fn* for each, passing it *data*.

We check the return of *fn* each time. If it returns anything other than 0, we break out and return that value.

Name

device_for_each_child_reverse — device child iterator in reversed order.

Synopsis

```
int device_for_each_child_reverse (struct device * parent, void * data,
int (*fn) (struct device *dev, void *data));
```

Arguments

parent parent struct device.

data data for the callback.

fn function to be called for each device.

Description

Iterate over *parent*'s child devices, and call *fn* for each, passing it *data*.

We check the return of *fn* each time. If it returns anything other than 0, we break out and return that value.

Name

device_find_child — device iterator for locating a particular device.

Synopsis

```
struct device * device_find_child (struct device * parent, void * data,
int (*match) (struct device *dev, void *data));
```

Arguments

parent parent struct device

data Data to pass to match function

match Callback function to check device

Description

This is similar to the `device_for_each_child` function above, but it returns a reference to a device that is 'found' for later use, as determined by the *match* callback.

The callback should return 0 if the device doesn't match and non-zero if it does. If the callback returns non-zero and a reference to the current device can be obtained, this function will return to the caller and not iterate over any more devices.

NOTE

you will need to drop the reference with `put_device` after use.

Name

__root_device_register — allocate and register a root device

Synopsis

```
struct device * __root_device_register (const char * name, struct module
* owner);
```

Arguments

name root device name

owner owner module of the root device, usually THIS_MODULE

Description

This function allocates a root device and registers it using `device_register`. In order to free the returned device, use `root_device_unregister`.

Root devices are dummy devices which allow other devices to be grouped under /sys/devices. Use this function to allocate a root device and then use it as the parent of any device which should appear under /sys/devices/{name}

The /sys/devices/{name} directory will also contain a 'module' symlink which points to the *owner* directory in sysfs.

Returns struct device pointer on success, or ERR_PTR on error.

Note

You probably want to use `root_device_register`.

Name

root_device_unregister — unregister and free a root device

Synopsis

```
void root_device_unregister (struct device * dev);
```

Arguments

dev device going away

Description

This function unregisters and cleans up a device that was created by `root_device_register`.

Name

device_create_vargs — creates a device and registers it with sysfs

Synopsis

```
struct device * device_create_vargs (struct class * class, struct device
* parent, dev_t devt, void * drvdata, const char * fmt, va_list args);
```

Arguments

class	pointer to the struct class that this device should be registered to
parent	pointer to the parent struct device of this new device, if any
devt	the dev_t for the char device to be added
drvdata	the data to be added to the device for callbacks
fmt	string for the device's name
args	va_list for the device's name

Description

This function can be used by char device classes. A struct device will be created in sysfs, registered to the specified class.

A “dev” file will be created, showing the dev_t for the device, if the dev_t is not 0,0. If a pointer to a parent struct device is passed in, the newly created struct device will be a child of that device in sysfs. The pointer to the struct device will be returned from the call. Any further sysfs files that might be required can be created using this pointer.

Returns struct device pointer on success, or ERR_PTR on error.

Note

the struct class passed to this function must have previously been created with a call to class_create.

Name

device_create — creates a device and registers it with sysfs

Synopsis

```
struct device * device_create (struct class * class, struct device *
parent, dev_t devt, void * drvdata, const char * fmt, ...);
```

Arguments

class	pointer to the struct class that this device should be registered to
parent	pointer to the parent struct device of this new device, if any
devt	the dev_t for the char device to be added
drvdata	the data to be added to the device for callbacks
fmt	string for the device's name
...	variable arguments

Description

This function can be used by char device classes. A struct device will be created in sysfs, registered to the specified class.

A “dev” file will be created, showing the dev_t for the device, if the dev_t is not 0,0. If a pointer to a parent struct device is passed in, the newly created struct device will be a child of that device in sysfs. The pointer to the struct device will be returned from the call. Any further sysfs files that might be required can be created using this pointer.

Returns struct device pointer on success, or ERR_PTR on error.

Note

the struct class passed to this function must have previously been created with a call to class_create.

Name

device_create_with_groups — creates a device and registers it with sysfs

Synopsis

```
struct device * device_create_with_groups (struct class * class, struct
device * parent, dev_t devt, void * drvdata, const struct attribute_group
** groups, const char * fmt, ...);
```

Arguments

class	pointer to the struct class that this device should be registered to
parent	pointer to the parent struct device of this new device, if any
devt	the dev_t for the char device to be added
drvdata	the data to be added to the device for callbacks
groups	NULL-terminated list of attribute groups to be created
fmt	string for the device's name
...	variable arguments

Description

This function can be used by char device classes. A struct device will be created in sysfs, registered to the specified class. Additional attributes specified in the groups parameter will also be created automatically.

A “dev” file will be created, showing the dev_t for the device, if the dev_t is not 0,0. If a pointer to a parent struct device is passed in, the newly created struct device will be a child of that device in sysfs. The pointer to the struct device will be returned from the call. Any further sysfs files that might be required can be created using this pointer.

Returns struct device pointer on success, or ERR_PTR on error.

Note

the struct class passed to this function must have previously been created with a call to `class_create`.

Name

device_destroy — removes a device that was created with `device_create`

Synopsis

```
void device_destroy (struct class * class, dev_t devt);
```

Arguments

`class` pointer to the struct class that this device was registered with

`devt` the dev_t of the device that was previously registered

Description

This call unregisters and cleans up a device that was created with a call to `device_create`.

Name

device_rename — renames a device

Synopsis

```
int device_rename (struct device * dev, const char * new_name);
```

Arguments

dev the pointer to the struct device to be renamed

new_name the new name of the device

Description

It is the responsibility of the caller to provide mutual exclusion between two different calls of device_rename on the same device to ensure that new_name is valid and won't conflict with other devices.

Note

Don't call this function. Currently, the networking layer calls this function, but that will change. The following text from Kay Sievers offers

some insight

Renaming devices is racy at many levels, symlinks and other stuff are not replaced atomically, and you get a “move” uevent, but it's not easy to connect the event to the old and new device. Device nodes are not renamed at all, there isn't even support for that in the kernel now.

In the meantime, during renaming, your target name might be taken by another driver, creating conflicts. Or the old name is taken directly after you renamed it -- then you get events for the same DEVPATH, before you even see the “move” event. It's just a mess, and nothing new should ever rely on kernel device renaming. Besides that, it's not even implemented now for other things than (driver-core wise very simple) network devices.

We are currently about to change network renaming in udev to completely disallow renaming of devices in the same namespace as the kernel uses, because we can't solve the problems properly, that arise with swapping names of multiple interfaces without races. Means, renaming of eth[0-9]* will only be allowed to some other name than eth[0-9]*, for the aforementioned reasons.

Make up a “real” name in the driver before you register anything, or add some other attributes for userspace to find the device, or use udev to add symlinks -- but never rename kernel devices later, it's a complete mess. We don't even want to get into that and try to implement the missing pieces in the core. We really have other pieces to fix in the driver core mess. :)

Name

device_move — moves a device to a new parent

Synopsis

```
int device_move (struct device * dev, struct device * new_parent, enum
dpm_order dpm_order);
```

Arguments

dev	the pointer to the struct device to be moved
new_parent	the new parent of the device (can by NULL)
dpm_order	how to reorder the dpm_list

Name

set_primary_fwnode — Change the primary firmware node of a given device.

Synopsis

```
void set_primary_fwnode (struct device * dev, struct fwnode_handle *
fwnode);
```

Arguments

dev Device to handle.

fwnode New primary firmware node of the device.

Description

Set the device's firmware node pointer to *fwnode*, but if a secondary firmware node of the device is present, preserve it.

Name

register_syscore_ops — Register a set of system core operations.

Synopsis

```
void register_syscore_ops (struct syscore_ops * ops);
```

Arguments

ops System core operations to register.

Name

unregister_syscore_ops — Unregister a set of system core operations.

Synopsis

```
void unregister_syscore_ops (struct syscore_ops * ops);
```

Arguments

ops System core operations to unregister.

Name

syscore_suspend — Execute all the registered system core suspend callbacks.

Synopsis

```
int syscore_suspend ( void);
```

Arguments

void no arguments

Description

This function is executed with one CPU on-line and disabled interrupts.

Name

syscore_resume — Execute all the registered system core resume callbacks.

Synopsis

```
void syscore_resume ( void);
```

Arguments

void no arguments

Description

This function is executed with one CPU on-line and disabled interrupts.

Name

__class_create — create a struct class structure

Synopsis

```
struct class * __class_create (struct module * owner, const char * name,
struct lock_class_key * key);
```

Arguments

owner pointer to the module that is to “own” this struct class

name pointer to a string for the name of this class.

key the lock_class_key for this class; used by mutex lock debugging

Description

This is used to create a struct class pointer that can then be used in calls to `device_create`.

Returns struct class pointer on success, or `ERR_PTR` on error.

Note, the pointer created here is to be destroyed when finished by making a call to `class_destroy`.

Name

class_destroy — destroys a struct class structure

Synopsis

```
void class_destroy (struct class * cls);
```

Arguments

cls pointer to the struct class that is to be destroyed

Description

Note, the pointer to be destroyed must have been created with a call to `class_create`.

Name

class_dev_iter_init — initialize class device iterator

Synopsis

```
void class_dev_iter_init (struct class_dev_iter * iter, struct class *
class, struct device * start, const struct device_type * type);
```

Arguments

iter class iterator to initialize

class the class we wanna iterate over

start the device to start iterating from, if any

type device_type of the devices to iterate over, NULL for all

Description

Initialize class iterator *iter* such that it iterates over devices of *class*. If *start* is set, the list iteration will start there, otherwise if it is NULL, the iteration starts at the beginning of the list.

Name

class_dev_iter_next — iterate to the next device

Synopsis

```
struct device * class_dev_iter_next (struct class_dev_iter * iter);
```

Arguments

iter class iterator to proceed

Description

Proceed *iter* to the next device and return it. Returns NULL if iteration is complete.

The returned device is referenced and won't be released till iterator is proceed to the next device or exited. The caller is free to do whatever it wants to do with the device including calling back into class code.

Name

class_dev_iter_exit — finish iteration

Synopsis

```
void class_dev_iter_exit (struct class_dev_iter * iter);
```

Arguments

iter class iterator to finish

Description

Finish an iteration. Always call this function after iteration is complete whether the iteration ran till the end or not.

Name

class_for_each_device — device iterator

Synopsis

```
int class_for_each_device (struct class * class, struct device * start,
void * data, int (*fn) (struct device *, void *));
```

Arguments

class the class we're iterating

start the device to start with in the list, if any.

data data for the callback

fn function to be called for each device

Description

Iterate over *class*'s list of devices, and call *fn* for each, passing it *data*. If *start* is set, the list iteration will start there, otherwise if it is NULL, the iteration starts at the beginning of the list.

We check the return of *fn* each time. If it returns anything other than 0, we break out and return that value.

fn is allowed to do anything including calling back into class code. There's no locking restriction.

Name

class_find_device — device iterator for locating a particular device

Synopsis

```
struct device * class_find_device (struct class * class, struct device *
start, const void * data, int (*match) (struct device *, const void *));
```

Arguments

class the class we're iterating

start Device to begin with

data data for the match function

match function to check device

Description

This is similar to the `class_for_each_dev` function above, but it returns a reference to a device that is 'found' for later use, as determined by the *match* callback.

The callback should return 0 if the device doesn't match and non-zero if it does. If the callback returns non-zero, this function will return to the caller and not iterate over any more devices.

Note, you will need to drop the reference with `put_device` after use.

match is allowed to do anything including calling back into class code. There's no locking restriction.

Name

class_compat_register — register a compatibility class

Synopsis

```
struct class_compat * class_compat_register (const char * name);
```

Arguments

name the name of the class

Description

Compatibility class are meant as a temporary user-space compatibility workaround when converting a family of class devices to a bus devices.

Name

class_compat_unregister — unregister a compatibility class

Synopsis

```
void class_compat_unregister (struct class_compat * cls);
```

Arguments

cls the class to unregister

Name

class_compat_create_link — create a compatibility class device link to a bus device

Synopsis

```
int class_compat_create_link (struct class_compat * cls, struct device
* dev, struct device * device_link);
```

Arguments

cls	the compatibility class
dev	the target bus device
device_link	an optional device to which a “device” link should be created

Name

class_compat_remove_link — remove a compatibility class device link to a bus device

Synopsis

```
void class_compat_remove_link (struct class_compat * cls, struct device
* dev, struct device * device_link);
```

Arguments

cls	the compatibility class
dev	the target bus device
device_link	an optional device to which a “device” link was previously created

Name

unregister_node — unregister a node device

Synopsis

```
void unregister_node (struct node * node);
```

Arguments

node node going away

Description

Unregisters a node device *node*. All the devices on the node must be unregistered before calling this function.

Name

request_firmware — send firmware request and wait for it

Synopsis

```
int request_firmware (const struct firmware ** firmware_p, const char
* name, struct device * device);
```

Arguments

firmware_p	pointer to firmware image
name	name of firmware file
device	device for which firmware is being loaded

Description

firmware_p will be used to return a firmware image by the name of *name* for device *device*.

Should be called from user context where sleeping is allowed.

name will be used as $FIRMWARE in the uevent environment and should be distinctive enough not to be confused with any other firmware image for this or any other device.

Caller must hold the reference count of *device*.

The function can be called safely inside device's suspend and resume callback.

Name

request_firmware_direct — load firmware directly without usermode helper

Synopsis

```
int request_firmware_direct (const struct firmware ** firmware_p, const
char * name, struct device * device);
```

Arguments

firmware_p	pointer to firmware image
name	name of firmware file
device	device for which firmware is being loaded

Description

This function works pretty much like `request_firmware`, but this doesn't fall back to usermode helper even if the firmware couldn't be loaded directly from fs. Hence it's useful for loading optional firmwares, which aren't always present, without extra long timeouts of udev.

Name

release_firmware — release the resource associated with a firmware image

Synopsis

```
void release_firmware (const struct firmware * fw);
```

Arguments

fw firmware resource to release

Name

request_firmware_nowait — asynchronous version of request_firmware

Synopsis

```
int request_firmware_nowait (struct module * module, bool uevent, const
char * name, struct device * device, gfp_t gfp, void * context, void
(*cont) (const struct firmware *fw, void *context));
```

Arguments

module module requesting the firmware

uevent sends uevent to copy the firmware image if this flag is non-zero else the firmware copy must be done manually.

name name of firmware file

device device for which firmware is being loaded

gfp allocation flags

context will be passed over to *cont*, and *fw* may be NULL if firmware request fails.

cont function will be called asynchronously when the firmware request is over.

Description

Caller must hold the reference count of *device*.

Asynchronous variant of request_firmware for user contexts: - sleep for as small periods as possible since it may increase kernel boot time of built-in device drivers requesting firmware in their ->probe methods, if *gfp* is GFP_KERNEL.

- can't sleep at all if *gfp* is GFP_ATOMIC.

Name

transport_class_register — register an initial transport class

Synopsis

```
int transport_class_register (struct transport_class * tclass);
```

Arguments

tclass a pointer to the transport class structure to be initialised

Description

The transport class contains an embedded class which is used to identify it. The caller should initialise this structure with zeros and then generic class must have been initialised with the actual transport class unique name. There's a macro DECLARE_TRANSPORT_CLASS to do this (declared classes still must be registered).

Returns 0 on success or error on failure.

Name

transport_class_unregister — unregister a previously registered class

Synopsis

```
void transport_class_unregister (struct transport_class * tclass);
```

Arguments

tclass The transport class to unregister

Description

Must be called prior to deallocating the memory for the transport class.

Name

anon_transport_class_register — register an anonymous class

Synopsis

```
int anon_transport_class_register (struct anon_transport_class * atc);
```

Arguments

atc The anon transport class to register

Description

The anonymous transport class contains both a transport class and a container. The idea of an anonymous class is that it never actually has any device attributes associated with it (and thus saves on container storage). So it can only be used for triggering events. Use prezero and then use DECLARE_ANON_TRANSPORT_CLASS to initialise the anon transport class storage.

Name

anon_transport_class_unregister — unregister an anon class

Synopsis

```
void anon_transport_class_unregister (struct anon_transport_class * atc);
```

Arguments

atc Pointer to the anon transport class to unregister

Description

Must be called prior to deallocating the memory for the anon transport class.

Name

transport_setup_device — declare a new dev for transport class association but don't make it visible yet.

Synopsis

```
void transport_setup_device (struct device * dev);
```

Arguments

dev the generic device representing the entity being added

Description

Usually, dev represents some component in the HBA system (either the HBA itself or a device remote across the HBA bus). This routine is simply a trigger point to see if any set of transport classes wishes to associate with the added device. This allocates storage for the class device and initialises it, but does not yet add it to the system or add attributes to it (you do this with transport_add_device). If you have no need for a separate setup and add operations, use transport_register_device (see transport_class.h).

Name

transport_add_device — declare a new dev for transport class association

Synopsis

```
void transport_add_device (struct device * dev);
```

Arguments

dev the generic device representing the entity being added

Description

Usually, dev represents some component in the HBA system (either the HBA itself or a device remote across the HBA bus). This routine is simply a trigger point used to add the device to the system and register attributes for it.

Name

transport_configure_device — configure an already set up device

Synopsis

```
void transport_configure_device (struct device * dev);
```

Arguments

dev generic device representing device to be configured

Description

The idea of configure is simply to provide a point within the setup process to allow the transport class to extract information from a device after it has been setup. This is used in SCSI because we have to have a setup device to begin using the HBA, but after we send the initial inquiry, we use configure to extract the device parameters. The device need not have been added to be configured.

Name

transport_remove_device — remove the visibility of a device

Synopsis

```
void transport_remove_device (struct device * dev);
```

Arguments

dev generic device to remove

Description

This call removes the visibility of the device (to the user from sysfs), but does not destroy it. To eliminate a device entirely you must also call transport_destroy_device. If you don't need to do remove and destroy as separate operations, use `transport_unregister_device` (see transport_class.h) which will perform both calls for you.

Name

transport_destroy_device — destroy a removed device

Synopsis

```
void transport_destroy_device (struct device * dev);
```

Arguments

dev device to eliminate from the transport class.

Description

This call triggers the elimination of storage associated with the transport classdev. Note: all it really does is relinquish a reference to the classdev. The memory will not be freed until the last reference goes to zero. Note also that the classdev retains a reference count on dev, so dev too will remain for as long as the transport class device remains around.

Name

device_bind_driver — bind a driver to one device.

Synopsis

```
int device_bind_driver (struct device * dev);
```

Arguments

dev device.

Description

Allow manual attachment of a driver to a device. Caller must have already set *dev*->driver.

Note that this does not modify the bus reference count nor take the bus's rwsem. Please verify those are accounted for before calling this. (It is ok to call with no other effort from a driver's `probe` method.)

This function must be called with the device lock held.

Name

wait_for_device_probe —

Synopsis

```
void wait_for_device_probe ( void);
```

Arguments

void no arguments

Description

Wait for device probing to be completed.

Name

device_attach — try to attach device to a driver.

Synopsis

```
int device_attach (struct device * dev);
```

Arguments

dev device.

Description

Walk the list of drivers that the bus has and call `driver_probe_device` for each pair. If a compatible pair is found, break out and return.

Returns 1 if the device was bound to a driver; 0 if no matching driver was found; -ENODEV if the device is not registered.

When called for a USB interface, *dev*->parent lock must be held.

Name

driver_attach — try to bind driver to devices.

Synopsis

```
int driver_attach (struct device_driver * drv);
```

Arguments

drv driver.

Description

Walk the list of devices that the bus has on it and try to match the driver with each one. If `driver_probe_device` returns 0 and the *dev*->driver is set, we've found a compatible pair.

Name

device_release_driver — manually detach device from driver.

Synopsis

```
void device_release_driver (struct device * dev);
```

Arguments

dev device.

Description

Manually detach device from driver. When called for a USB interface, *dev*->parent lock must be held.

Name

platform_device_register_resndata — add a platform-level device with resources and platform-specific data

Synopsis

```
struct platform_device * platform_device_register_resndata (struct device * parent, const char * name, int id, const struct resource * res, unsigned int num, const void * data, size_t size);
```

Arguments

parent parent device for the device we're adding

name base name of the device we're adding

id instance id

res set of resources that needs to be allocated for the device

num number of resources

data platform specific data for this platform device

size size of platform specific data

Description

Returns struct platform_device pointer on success, or ERR_PTR on error.

Name

platform_device_register_simple — add a platform-level device and its resources

Synopsis

```
struct platform_device * platform_device_register_simple (const char *
name, int id, const struct resource * res, unsigned int num);
```

Arguments

name base name of the device we're adding

id instance id

res set of resources that needs to be allocated for the device

num number of resources

Description

This function creates a simple platform device that requires minimal resource and memory management. Canned release function freeing memory allocated for the device allows drivers using such devices to be unloaded without waiting for the last reference to the device to be dropped.

This interface is primarily intended for use with legacy drivers which probe hardware directly. Because such drivers create sysfs device nodes themselves, rather than letting system infrastructure handle such device enumeration tasks, they don't fully conform to the Linux driver model. In particular, when such drivers are built as modules, they can't be “hotplugged”.

Returns struct platform_device pointer on success, or ERR_PTR on error.

Name

platform_device_register_data — add a platform-level device with platform-specific data

Synopsis

```
struct platform_device * platform_device_register_data (struct device
* parent, const char * name, int id, const void * data, size_t size);
```

Arguments

parent parent device for the device we're adding

name base name of the device we're adding

id instance id

data platform specific data for this platform device

size size of platform specific data

Description

This function creates a simple platform device that requires minimal resource and memory management. Canned release function freeing memory allocated for the device allows drivers using such devices to be unloaded without waiting for the last reference to the device to be dropped.

Returns struct platform_device pointer on success, or ERR_PTR on error.

Name

platform_get_resource — get a resource for a device

Synopsis

```
struct resource * platform_get_resource (struct platform_device * dev,
unsigned int type, unsigned int num);
```

Arguments

dev platform device

type resource type

num resource index

Name

platform_get_irq — get an IRQ for a device

Synopsis

```
int platform_get_irq (struct platform_device * dev, unsigned int num);
```

Arguments

dev platform device

num IRQ number index

Name

platform_get_resource_byname — get a resource for a device by name

Synopsis

```
struct resource * platform_get_resource_byname (struct platform_device
* dev, unsigned int type, const char * name);
```

Arguments

dev platform device

type resource type

name resource name

Name

platform_get_irq_byname — get an IRQ for a device by name

Synopsis

```
int platform_get_irq_byname (struct platform_device * dev, const char
* name);
```

Arguments

dev platform device

name IRQ name

Name

platform_add_devices — add a numbers of platform devices

Synopsis

```
int platform_add_devices (struct platform_device ** devs, int num);
```

Arguments

devs array of platform devices to add

num number of platform devices in array

Name

platform_device_put — destroy a platform device

Synopsis

```
void platform_device_put (struct platform_device * pdev);
```

Arguments

pdev platform device to free

Description

Free all memory associated with a platform device. This function must _only_ be externally called in error cases. All other usage is a bug.

Name

platform_device_alloc — create a platform device

Synopsis

```
struct platform_device * platform_device_alloc (const char * name, int id);
```

Arguments

name base name of the device we're adding

id instance id

Description

Create a platform device object which can have other objects attached to it, and which will have attached objects freed when it is released.

Name

platform_device_add_resources — add resources to a platform device

Synopsis

```
int platform_device_add_resources (struct platform_device * pdev, const
struct resource * res, unsigned int num);
```

Arguments

pdev platform device allocated by platform_device_alloc to add resources to

res set of resources that needs to be allocated for the device

num number of resources

Description

Add a copy of the resources to the platform device. The memory associated with the resources will be freed when the platform device is released.

Name

platform_device_add_data — add platform-specific data to a platform device

Synopsis

```
int platform_device_add_data (struct platform_device * pdev, const void
* data, size_t size);
```

Arguments

pdev platform device allocated by platform_device_alloc to add resources to

data platform specific data for this platform device

size size of platform specific data

Description

Add a copy of platform specific data to the platform device's platform_data pointer. The memory associated with the platform data will be freed when the platform device is released.

Name

platform_device_add — add a platform device to device hierarchy

Synopsis

```
int platform_device_add (struct platform_device * pdev);
```

Arguments

pdev platform device we're adding

Description

This is part 2 of `platform_device_register`, though may be called separately _iff_ pdev was allocated by `platform_device_alloc`.

Name

platform_device_del — remove a platform-level device

Synopsis

```
void platform_device_del (struct platform_device * pdev);
```

Arguments

pdev platform device we're removing

Description

Note that this function will also release all memory- and port-based resources owned by the device (*dev*->resource). This function must _only_ be externally called in error cases. All other usage is a bug.

Name

platform_device_register — add a platform-level device

Synopsis

```
int platform_device_register (struct platform_device * pdev);
```

Arguments

pdev platform device we're adding

Name

platform_device_unregister — unregister a platform-level device

Synopsis

```
void platform_device_unregister (struct platform_device * pdev);
```

Arguments

pdev platform device we're unregistering

Description

Unregistration is done in 2 steps. First we release all resources and remove it from the subsystem, then we drop reference count by calling `platform_device_put`.

Name

platform_device_register_full — add a platform-level device with resources and platform-specific data

Synopsis

```
struct platform_device * platform_device_register_full (const struct
platform_device_info * pdevinfo);
```

Arguments

pdevinfo data used to create device

Description

Returns struct platform_device pointer on success, or ERR_PTR on error.

Name

__platform_driver_register — register a driver for platform-level devices

Synopsis

```
int __platform_driver_register (struct platform_driver * drv, struct
module * owner);
```

Arguments

drv platform driver structure

owner owning module/driver

Name

platform_driver_unregister — unregister a driver for platform-level devices

Synopsis

```
void platform_driver_unregister (struct platform_driver * drv);
```

Arguments

drv platform driver structure

Name

__platform_driver_probe — register driver for non-hotpluggable device

Synopsis

```
int __platform_driver_probe (struct platform_driver * drv, int (*probe)
(struct platform_device *), struct module * module);
```

Arguments

drv platform driver structure

probe the driver probe routine, probably from an __init section

module module which will be the owner of the driver

Description

Use this instead of `platform_driver_register` when you know the device is not hotpluggable and has already been registered, and you want to remove its run-once `probe` infrastructure from memory after the driver has bound to the device.

One typical use for this would be with drivers for controllers integrated into system-on-chip processors, where the controller devices have been configured as part of board setup.

Note that this is incompatible with deferred probing.

Returns zero if the driver registered and bound to a device, else returns a negative error code and with the driver not registered.

Name

__platform_create_bundle — register driver and create corresponding device

Synopsis

```
struct platform_device * __platform_create_bundle (struct platform_driver * driver, int (*probe) (struct platform_device *), struct resource * res, unsigned int n_res, const void * data, size_t size, struct module * module);
```

Arguments

driver platform driver structure

probe the driver probe routine, probably from an __init section

res set of resources that needs to be allocated for the device

n_res number of resources

data platform specific data for this platform device

size size of platform specific data

module module which will be the owner of the driver

Description

Use this in legacy-style modules that probe hardware directly and register a single platform device and corresponding platform driver.

Returns struct platform_device pointer on success, or ERR_PTR on error.

Name

__platform_register_drivers — register an array of platform drivers

Synopsis

```
int __platform_register_drivers (struct platform_driver *const * drivers, unsigned int count, struct module * owner);
```

Arguments

drivers an array of drivers to register

count the number of drivers to register

owner module owning the drivers

Description

Registers platform drivers specified by an array. On failure to register a driver, all previously registered drivers will be unregistered. Callers of this API should use `platform_unregister_drivers` to unregister drivers in the reverse order.

Returns

0 on success or a negative error code on failure.

Name

platform_unregister_drivers — unregister an array of platform drivers

Synopsis

```
void platform_unregister_drivers (struct platform_driver *const * drivers, unsigned int count);
```

Arguments

drivers an array of drivers to unregister

count the number of drivers to unregister

Description

Unegisters platform drivers specified by an array. This is typically used to complement an earlier call to `platform_register_drivers`. Drivers are unregistered in the reverse order in which they were registered.

Name

bus_for_each_dev — device iterator.

Synopsis

```
int bus_for_each_dev (struct bus_type * bus, struct device * start, void
* data, int (*fn) (struct device *, void *));
```

Arguments

bus bus type.

start device to start iterating from.

data data for the callback.

fn function to be called for each device.

Description

Iterate over *bus*'s list of devices, and call *fn* for each, passing it *data*. If *start* is not NULL, we use that device to begin iterating from.

We check the return of *fn* each time. If it returns anything other than 0, we break out and return that value.

NOTE

The device that returns a non-zero value is not retained in any way, nor is its refcount incremented. If the caller needs to retain this data, it should do so, and increment the reference count in the supplied callback.

Name

bus_find_device — device iterator for locating a particular device.

Synopsis

```
struct device * bus_find_device (struct bus_type * bus, struct device
* start, void * data, int (*match) (struct device *dev, void *data));
```

Arguments

bus bus type

start Device to begin with

data Data to pass to match function

match Callback function to check device

Description

This is similar to the `bus_for_each_dev` function above, but it returns a reference to a device that is 'found' for later use, as determined by the *match* callback.

The callback should return 0 if the device doesn't match and non-zero if it does. If the callback returns non-zero, this function will return to the caller and not iterate over any more devices.

Name

bus_find_device_by_name — device iterator for locating a particular device of a specific name

Synopsis

```
struct device * bus_find_device_by_name (struct bus_type * bus, struct
device * start, const char * name);
```

Arguments

bus bus type

start Device to begin with

name name of the device to match

Description

This is similar to the `bus_find_device` function above, but it handles searching by a name automatically, no need to write another strcmp matching function.

Name

subsys_find_device_by_id — find a device with a specific enumeration number

Synopsis

```
struct device * subsys_find_device_by_id (struct bus_type * subsys,
unsigned int id, struct device * hint);
```

Arguments

subsys subsystem

id index 'id' in struct device

hint device to check first

Description

Check the hint's next object and if it is a match return it directly, otherwise, fall back to a full list search. Either way a reference for the returned object is taken.

Name

bus_for_each_drv — driver iterator

Synopsis

```
int bus_for_each_drv (struct bus_type * bus, struct device_driver *
start, void * data, int (*fn) (struct device_driver *, void *));
```

Arguments

bus bus we're dealing with.

start driver to start iterating on.

data data to pass to the callback.

fn function to call for each driver.

Description

This is nearly identical to the device iterator above. We iterate over each driver that belongs to *bus*, and call *fn* for each. If *fn* returns anything but 0, we break out and return it. If *start* is not NULL, we use it as the head of the list.

NOTE

we don't return the driver that returns a non-zero value, nor do we leave the reference count incremented for that driver. If the caller needs to know that info, it must set it in the callback. It must also be sure to increment the refcount so it doesn't disappear before returning to the caller.

Name

bus_rescan_devices — rescan devices on the bus for possible drivers

Synopsis

```
int bus_rescan_devices (struct bus_type * bus);
```

Arguments

bus the bus to scan.

Description

This function will look for devices on the bus with no driver attached and rescan it against existing drivers to see if it matches any by calling `device_attach` for the unbound devices.

Name

device_reprobe — remove driver for a device and probe for a new driver

Synopsis

```
int device_reprobe (struct device * dev);
```

Arguments

dev the device to reprobe

Description

This function detaches the attached driver (if any) for the given device and restarts the driver probing process. It is intended to use if probing criteria changed during a devices lifetime and driver attachment should change accordingly.

Name

bus_register — register a driver-core subsystem

Synopsis

```
int bus_register (struct bus_type * bus);
```

Arguments

bus bus to register

Description

Once we have that, we register the bus with the kobject infrastructure, then register the children subsystems it has: the devices and drivers that belong to the subsystem.

Name

bus_unregister — remove a bus from the system

Synopsis

```
void bus_unregister (struct bus_type * bus);
```

Arguments

bus bus.

Description

Unregister the child subsystems and the bus itself. Finally, we call `bus_put` to release the refcount

Name

subsys_dev_iter_init — initialize subsys device iterator

Synopsis

```
void subsys_dev_iter_init (struct subsys_dev_iter * iter, struct bus_type * subsys, struct device * start, const struct device_type * type);
```

Arguments

iter subsys iterator to initialize

subsys the subsys we wanna iterate over

start the device to start iterating from, if any

type device_type of the devices to iterate over, NULL for all

Description

Initialize subsys iterator *iter* such that it iterates over devices of *subsys*. If *start* is set, the list iteration will start there, otherwise if it is NULL, the iteration starts at the beginning of the list.

Name

subsys_dev_iter_next — iterate to the next device

Synopsis

```
struct device * subsys_dev_iter_next (struct subsys_dev_iter * iter);
```

Arguments

iter subsys iterator to proceed

Description

Proceed *iter* to the next device and return it. Returns NULL if iteration is complete.

The returned device is referenced and won't be released till iterator is proceed to the next device or exited. The caller is free to do whatever it wants to do with the device including calling back into subsys code.

Name

subsys_dev_iter_exit — finish iteration

Synopsis

```
void subsys_dev_iter_exit (struct subsys_dev_iter * iter);
```

Arguments

iter subsys iterator to finish

Description

Finish an iteration. Always call this function after iteration is complete whether the iteration ran till the end or not.

Name

subsys_system_register — register a subsystem at /sys/devices/system/

Synopsis

```
int subsys_system_register (struct bus_type * subsys, const struct attribute_group ** groups);
```

Arguments

subsys system subsystem

groups default attributes for the root device

Description

All 'system' subsystems have a /sys/devices/system/<name> root device with the name of the subsystem. The root device can carry subsystem- wide attributes. All registered devices are below this single root device and are named after the subsystem with a simple enumeration number appended. The registered devices are not explicitly named; only 'id' in the device needs to be set.

Do not use this interface for anything new, it exists for compatibility with bad ideas only. New subsystems should use plain subsystems; and add the subsystem-wide attributes should be added to the subsystem directory itself and not some create fake root-device placed in /sys/devices/system/<name>.

Name

subsys_virtual_register — register a subsystem at /sys/devices/virtual/

Synopsis

```
int subsys_virtual_register (struct bus_type * subsys, const struct
attribute_group ** groups);
```

Arguments

subsys virtual subsystem

groups default attributes for the root device

Description

All 'virtual' subsystems have a /sys/devices/system/<name> root device with the name of the subystem. The root device can carry subsystem-wide attributes. All registered devices are below this single root device. There's no restriction on device naming. This is for kernel software constructs which need sysfs interface.

Device Drivers DMA Management

Name

dma_buf_export — Creates a new dma_buf, and associates an anon file with this buffer, so it can be exported. Also connect the allocator specific data and ops to the buffer. Additionally, provide a name string for exporter; useful in debugging.

Synopsis

```
struct dma_buf * dma_buf_export (const struct dma_buf_export_info *
exp_info);
```

Arguments

exp_info [in] holds all the export related information provided by the exporter. see struct dma_buf_export_info for further details.

Description

Returns, on success, a newly created dma_buf object, which wraps the supplied private data and operations for dma_buf_ops. On either missing ops, or error in allocating struct dma_buf, will return negative error.

Name

dma_buf_fd — returns a file descriptor for the given dma_buf

Synopsis

```
int dma_buf_fd (struct dma_buf * dmabuf, int flags);
```

Arguments

dmabuf [in] pointer to dma_buf for which fd is required.

flags [in] flags to give to fd

Description

On success, returns an associated 'fd'. Else, returns error.

Name

dma_buf_get — returns the dma_buf structure related to an fd

Synopsis

```
struct dma_buf * dma_buf_get (int fd);
```

Arguments

fd [in] fd associated with the dma_buf to be returned

Description

On success, returns the dma_buf structure associated with an fd; uses file's refcounting done by fget to increase refcount. returns ERR_PTR otherwise.

Name

dma_buf_put — decreases refcount of the buffer

Synopsis

```
void dma_buf_put (struct dma_buf * dmabuf);
```

Arguments

dmabuf [in] buffer to reduce refcount of

Description

Uses file's refcounting done implicitly by `fput`

Name

dma_buf_attach — Add the device to dma_buf's attachments list; optionally, calls `attach` of dma_buf_ops to allow device-specific attach functionality

Synopsis

```
struct dma_buf_attachment * dma_buf_attach (struct dma_buf * dmabuf,
struct device * dev);
```

Arguments

`dmabuf` [in] buffer to attach device to.

`dev` [in] device to be attached.

Description

Returns struct dma_buf_attachment * for this attachment; returns ERR_PTR on error.

Name

dma_buf_detach — Remove the given attachment from dmabuf's attachments list; optionally calls `detach` of dma_buf_ops for device-specific detach

Synopsis

```
void dma_buf_detach (struct dma_buf * dmabuf, struct dma_buf_attachment
* attach);
```

Arguments

`dmabuf` [in] buffer to detach from.

`attach` [in] attachment to be detached; is free'd after this call.

Name

dma_buf_map_attachment — Returns the scatterlist table of the attachment; mapped into _device_ address space. Is a wrapper for `map_dma_buf` of the dma_buf_ops.

Synopsis

```
struct sg_table * dma_buf_map_attachment (struct dma_buf_attachment *
attach, enum dma_data_direction direction);
```

Arguments

`attach` [in] attachment whose scatterlist is to be returned

`direction` [in] direction of DMA transfer

Description

Returns sg_table containing the scatterlist to be returned; returns ERR_PTR on error.

Name

dma_buf_unmap_attachment — unmaps and decreases usecount of the buffer;might deallocate the scatterlist associated. Is a wrapper for `unmap_dma_buf` of dma_buf_ops.

Synopsis

```
void dma_buf_unmap_attachment (struct dma_buf_attachment * attach,
struct sg_table * sg_table, enum dma_data_direction direction);
```

Arguments

`attach` [in] attachment to unmap buffer from

`sg_table` [in] scatterlist info of the buffer to unmap

`direction` [in] direction of DMA transfer

Name

dma_buf_begin_cpu_access — Must be called before accessing a dma_buf from the cpu in the kernel context. Calls begin_cpu_access to allow exporter-specific preparations. Coherency is only guaranteed in the specified range for the specified access direction.

Synopsis

```
int dma_buf_begin_cpu_access (struct dma_buf * dmabuf, size_t start,
size_t len, enum dma_data_direction direction);
```

Arguments

dmabuf [in] buffer to prepare cpu access for.

start [in] start of range for cpu access.

len [in] length of range for cpu access.

direction [in] length of range for cpu access.

Description

Can return negative error values, returns 0 on success.

Name

dma_buf_end_cpu_access — Must be called after accessing a dma_buf from the cpu in the kernel context. Calls end_cpu_access to allow exporter-specific actions. Coherency is only guaranteed in the specified range for the specified access direction.

Synopsis

```
void dma_buf_end_cpu_access (struct dma_buf * dmabuf, size_t start,
size_t len, enum dma_data_direction direction);
```

Arguments

dmabuf [in] buffer to complete cpu access for.

start [in] start of range for cpu access.

len [in] length of range for cpu access.

direction [in] length of range for cpu access.

Description

This call must always succeed.

Name

dma_buf_kmap_atomic — Map a page of the buffer object into kernel address space. The same restrictions as for kmap_atomic and friends apply.

Synopsis

```
void * dma_buf_kmap_atomic (struct dma_buf * dmabuf, unsigned long page_num);
```

Arguments

dmabuf [in] buffer to map page from.

page_num [in] page in PAGE_SIZE units to map.

Description

This call must always succeed, any necessary preparations that might fail need to be done in begin_cpu_access.

Name

dma_buf_kunmap_atomic — Unmap a page obtained by dma_buf_kmap_atomic.

Synopsis

```
void dma_buf_kunmap_atomic (struct dma_buf * dmabuf, unsigned long page_num, void * vaddr);
```

Arguments

dmabuf [in] buffer to unmap page from.

page_num [in] page in PAGE_SIZE units to unmap.

vaddr [in] kernel space pointer obtained from dma_buf_kmap_atomic.

Description

This call must always succeed.

Name

dma_buf_kmap — Map a page of the buffer object into kernel address space. The same restrictions as for kmap and friends apply.

Synopsis

```
void * dma_buf_kmap (struct dma_buf * dmabuf, unsigned long page_num);
```

Arguments

dmabuf [in] buffer to map page from.

page_num [in] page in PAGE_SIZE units to map.

Description

This call must always succeed, any necessary preparations that might fail need to be done in begin_cpu_access.

Name

dma_buf_kunmap — Unmap a page obtained by dma_buf_kmap.

Synopsis

```
void dma_buf_kunmap (struct dma_buf * dmabuf, unsigned long page_num,
void * vaddr);
```

Arguments

dmabuf [in] buffer to unmap page from.

page_num [in] page in PAGE_SIZE units to unmap.

vaddr [in] kernel space pointer obtained from dma_buf_kmap.

Description

This call must always succeed.

Name

dma_buf_mmap — Setup up a userspace mmap with the given vma

Synopsis

```
int dma_buf_mmap (struct dma_buf * dmabuf, struct vm_area_struct * vma,
unsigned long pgoff);
```

Arguments

dmabuf [in] buffer that should back the vma

vma [in] vma for the mmap

pgoff [in] offset in pages where this mmap should start within the dma-buf buffer.

Description

This function adjusts the passed in vma so that it points at the file of the dma_buf operation. It also adjusts the starting pgoff and does bounds checking on the size of the vma. Then it calls the exporters mmap function to set up the mapping.

Can return negative error values, returns 0 on success.

Name

dma_buf_vmap — Create virtual mapping for the buffer object into kernel address space. Same restrictions as for vmap and friends apply.

Synopsis

```
void * dma_buf_vmap (struct dma_buf * dmabuf);
```

Arguments

dmabuf [in] buffer to vmap

Description

This call may fail due to lack of virtual mapping address space. These calls are optional in drivers. The intended use for them is for mapping objects linear in kernel space for high use objects. Please attempt to use kmap/kunmap before thinking about these interfaces.

Returns NULL on error.

Name

dma_buf_vunmap — Unmap a vmap obtained by dma_buf_vmap.

Synopsis

```
void dma_buf_vunmap (struct dma_buf * dmabuf, void * vaddr);
```

Arguments

dmabuf [in] buffer to vunmap

vaddr [in] vmap to vunmap

Name

fence_context_alloc — allocate an array of fence contexts

Synopsis

```
unsigned fence_context_alloc (unsigned num);
```

Arguments

num [in] amount of contexts to allocate

Description

This function will return the first index of the number of fences allocated. The fence context is used for setting fence->context to a unique number.

Name

fence_signal_locked — signal completion of a fence

Synopsis

```
int fence_signal_locked (struct fence * fence);
```

Arguments

fence the fence to signal

Description

Signal completion for software callbacks on a fence, this will unblock `fence_wait` calls and run all the callbacks added with `fence_add_callback`. Can be called multiple times, but since a fence can only go from unsignaled to signaled state, it will only be effective the first time.

Unlike fence_signal, this function must be called with fence->lock held.

Name

fence_signal — signal completion of a fence

Synopsis

```
int fence_signal (struct fence * fence);
```

Arguments

fence the fence to signal

Description

Signal completion for software callbacks on a fence, this will unblock `fence_wait` calls and run all the callbacks added with `fence_add_callback`. Can be called multiple times, but since a fence can only go from unsignaled to signaled state, it will only be effective the first time.

Name

fence_wait_timeout — sleep until the fence gets signaled or until timeout elapses

Synopsis

```
signed long fence_wait_timeout (struct fence * fence, bool intr, signed long timeout);
```

Arguments

fence [in] the fence to wait on

intr [in] if true, do an interruptible wait

timeout [in] timeout value in jiffies, or MAX_SCHEDULE_TIMEOUT

Description

Returns -ERESTARTSYS if interrupted, 0 if the wait timed out, or the remaining timeout in jiffies on success. Other error values may be returned on custom implementations.

Performs a synchronous wait on this fence. It is assumed the caller directly or indirectly (buf-mgr between reservation and committing) holds a reference to the fence, otherwise the fence might be freed before return, resulting in undefined behavior.

Name

fence_enable_sw_signaling — enable signaling on fence

Synopsis

```
void fence_enable_sw_signaling (struct fence * fence);
```

Arguments

fence [in] the fence to enable

Description

this will request for sw signaling to be enabled, to make the fence complete as soon as possible

Name

fence_add_callback — add a callback to be called when the fence is signaled

Synopsis

```
int fence_add_callback (struct fence * fence, struct fence_cb * cb,
fence_func_t func);
```

Arguments

fence [in] the fence to wait on

cb [in] the callback to register

func [in] the function to call

Description

cb will be initialized by fence_add_callback, no initialization by the caller is required. Any number of callbacks can be registered to a fence, but a callback can only be registered to one fence at a time.

Note that the callback can be called from an atomic context. If fence is already signaled, this function will return -ENOENT (and *not* call the callback)

Add a software callback to the fence. Same restrictions apply to refcount as it does to fence_wait, however the caller doesn't need to

keep a refcount to fence afterwards

when software access is enabled, the creator of the fence is required to keep the fence alive until after it signals with fence_signal. The callback itself can be called from irq context.

Name

fence_remove_callback — remove a callback from the signaling list

Synopsis

```
bool fence_remove_callback (struct fence * fence, struct fence_cb * cb);
```

Arguments

fence [in] the fence to wait on

cb [in] the callback to remove

Description

Remove a previously queued callback from the fence. This function returns true if the callback is successfully removed, or false if the fence has already been signaled.

WARNING: Cancelling a callback should only be done if you really know what you're doing, since deadlocks and race conditions could occur all too easily. For this reason, it should only ever be done on hardware lockup recovery, with a reference held to the fence.

Name

fence_default_wait — default sleep until the fence gets signaled or until timeout elapses

Synopsis

```
signed long fence_default_wait (struct fence * fence, bool intr, signed long timeout);
```

Arguments

fence [in] the fence to wait on

intr [in] if true, do an interruptible wait

timeout [in] timeout value in jiffies, or MAX_SCHEDULE_TIMEOUT

Description

Returns -ERESTARTSYS if interrupted, 0 if the wait timed out, or the remaining timeout in jiffies on success.

Name

fence_wait_any_timeout — sleep until any fence gets signaled or until timeout elapses

Synopsis

```
signed long fence_wait_any_timeout (struct fence ** fences, uint32_t
count, bool intr, signed long timeout);
```

Arguments

fences [in] array of fences to wait on

count [in] number of fences to wait on

intr [in] if true, do an interruptible wait

timeout [in] timeout value in jiffies, or MAX_SCHEDULE_TIMEOUT

Description

Returns -EINVAL on custom fence wait implementation, -ERESTARTSYS if interrupted, 0 if the wait timed out, or the remaining timeout in jiffies on success.

Synchronous waits for the first fence in the array to be signaled. The caller needs to hold a reference to all fences in the array, otherwise a fence might be freed before return, resulting in undefined behavior.

Name

fence_init — Initialize a custom fence.

Synopsis

```
void fence_init (struct fence * fence, const struct fence_ops * ops,
spinlock_t * lock, unsigned context, unsigned seqno);
```

Arguments

fence	[in] the fence to initialize
ops	[in] the fence_ops for operations on this fence
lock	[in] the irqsafe spinlock to use for locking this fence
context	[in] the execution context this fence is run on
seqno	[in] a linear increasing sequence number for this context

Description

Initializes an allocated fence, the caller doesn't have to keep its refcount after committing with this fence, but it will need to hold a refcount again if fence_ops.enable_signaling gets called. This can be used for other implementing other types of fence.

context and seqno are used for easy comparison between fences, allowing to check which fence is later by simply using fence_later.

Name

drivers/dma-buf/seqno-fence.c — Document generation inconsistency

Oops

Warning

The template for this document tried to insert the structured comment from the file `drivers/dma-buf/seqno-fence.c` at this point, but none was found. This dummy section is inserted to allow generation to continue.

Name

struct fence — software synchronization primitive

Synopsis

```
struct fence {
  struct kref refcount;
  const struct fence_ops * ops;
  struct rcu_head rcu;
  struct list_head cb_list;
  spinlock_t * lock;
  unsigned context;
  unsigned seqno;
  unsigned long flags;
  ktime_t timestamp;
  int status;
};
```

Members

refcount	refcount for this fence
ops	fence_ops associated with this fence
rcu	used for releasing fence with kfree_rcu
cb_list	list of all callbacks to call
lock	spin_lock_irqsave used for locking
context	execution context this fence belongs to, returned by `fence_context_alloc`
seqno	the sequence number of this fence inside the execution context, can be compared to decide which fence would be signaled later.
flags	A mask of FENCE_FLAG_* defined below
timestamp	Timestamp when the fence was signaled.
status	Optional, only valid if < 0, must be set before calling fence_signal, indicates that the fence has completed with an error.

Description

the flags member must be manipulated and read using the appropriate atomic ops (bit_*), so taking the spinlock will not be needed most of the time.

FENCE_FLAG_SIGNALED_BIT - fence is already signaled FENCE_FLAG_ENABLE_SIGNAL_BIT - enable_signaling might have been called* FENCE_FLAG_USER_BITS - start of the unused bits, can be used by the implementer of the fence for its own purposes. Can be used in different ways by different fence implementers, so do not rely on this.

*) Since atomic bitops are used, this is not guaranteed to be the case. Particularly, if the bit was set, but fence_signal was called right before this bit was set, it would have been able to

set the FENCE_FLAG_SIGNALED_BIT, before enable_signaling was called. Adding a check for FENCE_FLAG_SIGNALED_BIT after setting FENCE_FLAG_ENABLE_SIGNAL_BIT closes this race, and makes sure that after fence_signal was called, any enable_signaling call will have either been completed, or never called at all.

Name

struct fence_cb — callback for fence_add_callback

Synopsis

```
struct fence_cb {
  struct list_head node;
  fence_func_t func;
};
```

Members

node used by fence_add_callback to append this struct to fence::cb_list

func fence_func_t to call

Description

This struct will be initialized by fence_add_callback, additional data can be passed along by embedding fence_cb in another struct.

Name

struct fence_ops — operations implemented for fence

Synopsis

```
struct fence_ops {
  const char * (* get_driver_name) (struct fence *fence);
  const char * (* get_timeline_name) (struct fence *fence);
  bool (* enable_signaling) (struct fence *fence);
  bool (* signaled) (struct fence *fence);
  signed long (* wait) (struct fence *fence, bool intr, signed long timeout);
  void (* release) (struct fence *fence);
  int (* fill_driver_data) (struct fence *fence, void *data, int size);
  void (* fence_value_str) (struct fence *fence, char *str, int size);
  void (* timeline_value_str) (struct fence *fence, char *str, int size);
};
```

Members

get_driver_name	returns the driver name.
get_timeline_name	return the name of the context this fence belongs to.
enable_signaling	enable software signaling of fence.
signaled	[optional] peek whether the fence is signaled, can be null.
wait	custom wait implementation, or fence_default_wait.
release	[optional] called on destruction of fence, can be null
fill_driver_data	[optional] callback to fill in free-form debug info Returns amount of bytes filled, or -errno.
fence_value_str	[optional] fills in the value of the fence as a string
timeline_value_str	[optional] fills in the current value of the timeline as a string

Notes on enable_signaling

For fence implementations that have the capability for hw->hw signaling, they can implement this op to enable the necessary irqs, or insert commands into cmdstream, etc. This is called in the first `wait` or `add_callback` path to let the fence implementation know that there is another driver waiting on the signal (ie. hw->sw case).

This function can be called called from atomic context, but not from irq context, so normal spinlocks can be used.

A return value of false indicates the fence already passed, or some failure occurred that made it impossible to enable signaling. True indicates successful enabling.

fence->status may be set in enable_signaling, but only when false is returned.

Calling fence_signal before enable_signaling is called allows for a tiny race window in which enable_signaling is called during, before, or after fence_signal. To fight this, it is recommended that before

enable_signaling returns true an extra reference is taken on the fence, to be released when the fence is signaled. This will mean fence_signal will still be called twice, but the second time will be a noop since it was already signaled.

Notes on signaled

May set fence->status if returning true.

Notes on wait

Must not be NULL, set to fence_default_wait for default implementation. the fence_default_wait implementation should work for any fence, as long as enable_signaling works correctly.

Must return -ERESTARTSYS if the wait is intr = true and the wait was interrupted, and remaining jiffies if fence has signaled, or 0 if wait timed out. Can also return other error values on custom implementations, which should be treated as if the fence is signaled. For example a hardware lockup could be reported like that.

Notes on release

Can be NULL, this function allows additional commands to run on destruction of the fence. Can be called from irq context. If pointer is set to NULL, kfree will get called instead.

Name

fence_get — increases refcount of the fence

Synopsis

```
struct fence * fence_get (struct fence * fence);
```

Arguments

fence [in] fence to increase refcount of

Description

Returns the same fence, with refcount increased by 1.

Name

fence_get_rcu — get a fence from a reservation_object_list with rcu read lock

Synopsis

```
struct fence * fence_get_rcu (struct fence * fence);
```

Arguments

fence [in] fence to increase refcount of

Description

Function returns NULL if no refcount could be obtained, or the fence.

Name

fence_put — decreases refcount of the fence

Synopsis

```
void fence_put (struct fence * fence);
```

Arguments

fence [in] fence to reduce refcount of

Name

fence_is_signaled_locked — Return an indication if the fence is signaled yet.

Synopsis

```
bool fence_is_signaled_locked (struct fence * fence);
```

Arguments

fence [in] the fence to check

Description

Returns true if the fence was already signaled, false if not. Since this function doesn't enable signaling, it is not guaranteed to ever return true if fence_add_callback, fence_wait or fence_enable_sw_signaling haven't been called before.

This function requires fence->lock to be held.

Name

fence_is_signaled — Return an indication if the fence is signaled yet.

Synopsis

```
bool fence_is_signaled (struct fence * fence);
```

Arguments

fence [in] the fence to check

Description

Returns true if the fence was already signaled, false if not. Since this function doesn't enable signaling, it is not guaranteed to ever return true if fence_add_callback, fence_wait or fence_enable_sw_signaling haven't been called before.

It's recommended for seqno fences to call fence_signal when the operation is complete, it makes it possible to prevent issues from wraparound between time of issue and time of use by checking the return value of this function before calling hardware-specific wait instructions.

Name

fence_is_later — return if f1 is chronologically later than f2

Synopsis

```
bool fence_is_later (struct fence * f1, struct fence * f2);
```

Arguments

f1 [in] the first fence from the same context

f2 [in] the second fence from the same context

Description

Returns true if f1 is chronologically later than f2. Both fences must be from the same context, since a seqno is not re-used across contexts.

Name

fence_later — return the chronologically later fence

Synopsis

```
struct fence * fence_later (struct fence * f1, struct fence * f2);
```

Arguments

f1 [in] the first fence from the same context

f2 [in] the second fence from the same context

Description

Returns NULL if both fences are signaled, otherwise the fence that would be signaled last. Both fences must be from the same context, since a seqno is not re-used across contexts.

Name

fence_wait — sleep until the fence gets signaled

Synopsis

```
signed long fence_wait (struct fence * fence, bool intr);
```

Arguments

fence [in] the fence to wait on

intr [in] if true, do an interruptible wait

Description

This function will return -ERESTARTSYS if interrupted by a signal, or 0 if the fence was signaled. Other error values may be returned on custom implementations.

Performs a synchronous wait on this fence. It is assumed the caller directly or indirectly holds a reference to the fence, otherwise the fence might be freed before return, resulting in undefined behavior.

Name

to_seqno_fence — cast a fence to a seqno_fence

Synopsis

```
struct seqno_fence * to_seqno_fence (struct fence * fence);
```

Arguments

fence fence to cast to a seqno_fence

Description

Returns NULL if the fence is not a seqno_fence, or the seqno_fence otherwise.

Name

seqno_fence_init — initialize a seqno fence

Synopsis

```
void seqno_fence_init (struct seqno_fence * fence, spinlock_t * lock,
struct dma_buf * sync_buf, uint32_t context, uint32_t seqno_ofs,
uint32_t seqno, enum seqno_fence_condition cond, const struct fence_ops
* ops);
```

Arguments

fence	seqno_fence to initialize
lock	pointer to spinlock to use for fence
sync_buf	buffer containing the memory location to signal on
context	the execution context this fence is a part of
seqno_ofs	the offset within *sync_buf*
seqno	the sequence # to signal on
cond	fence wait condition
ops	the fence_ops for operations on this seqno fence

Description

This function initializes a struct seqno_fence with passed parameters, and takes a reference on sync_buf which is released on fence destruction.

A seqno_fence is a dma_fence which can complete in software when enable_signaling is called, but it also completes when (s32)((sync_buf)[seqno_ofs] - seqno) >= 0 is true

The seqno_fence will take a refcount on the sync_buf until it's destroyed, but actual lifetime of sync_buf may be longer if one of the callers take a reference to it.

Certain hardware have instructions to insert this type of wait condition in the command stream, so no intervention from software would be needed. This type of fence can be destroyed before completed, however a reference on the sync_buf dma-buf can be taken. It is encouraged to re-use the same dma-buf for sync_buf, since mapping or unmapping the sync_buf to the device's vm can be expensive.

It is recommended for creators of seqno_fence to call fence_signal before destruction. This will prevent possible issues from wraparound at time of issue vs time of check, since users can check fence_is_signaled before submitting instructions for the hardware to wait on the fence. However, when ops.enable_signaling is not called, it doesn't have to be done as soon as possible, just before there's any real danger of seqno wraparound.

Name

drivers/dma-buf/reservation.c — Document generation inconsistency

Oops

Warning

The template for this document tried to insert the structured comment from the file `drivers/dma-buf/reservation.c` at this point, but none was found. This dummy section is inserted to allow generation to continue.

Name

include/linux/reservation.h — Document generation inconsistency

Oops

Warning

The template for this document tried to insert the structured comment from the file `include/linux/reservation.h` at this point, but none was found. This dummy section is inserted to allow generation to continue.

Name

dma_alloc_from_coherent — try to allocate memory from the per-device coherent area

Synopsis

```
int dma_alloc_from_coherent (struct device * dev, ssize_t size,
dma_addr_t * dma_handle, void ** ret);
```

Arguments

dev	device from which we allocate memory
size	size of requested memory area
dma_handle	This will be filled with the correct dma handle
ret	This pointer will be filled with the virtual address to allocated area.

Description

This function should be only called from per-arch `dma_alloc_coherent` to support allocation from per-device coherent memory pools.

Returns 0 if dma_alloc_coherent should continue with allocating from generic memory areas, or !0 if dma_alloc_coherent should return *ret*.

Name

dma_release_from_coherent — try to free the memory allocated from per-device coherent memory pool

Synopsis

```
int dma_release_from_coherent (struct device * dev, int order, void *
vaddr);
```

Arguments

dev device from which the memory was allocated

order the order of pages allocated

vaddr virtual address of allocated pages

Description

This checks whether the memory was allocated from the per-device coherent memory pool and if so, releases that memory.

Returns 1 if we correctly released the memory, or 0 if `dma_release_coherent` should proceed with releasing memory from generic pools.

Name

dma_mmap_from_coherent — try to mmap the memory allocated from per-device coherent memory pool to userspace

Synopsis

```
int dma_mmap_from_coherent (struct device * dev, struct vm_area_struct
* vma, void * vaddr, size_t size, int * ret);
```

Arguments

dev device from which the memory was allocated

vma vm_area for the userspace memory

vaddr cpu address returned by dma_alloc_from_coherent

size size of the memory buffer allocated by dma_alloc_from_coherent

ret result from `remap_pfn_range`

Description

This checks whether the memory was allocated from the per-device coherent memory pool and if so, maps that memory to the provided vma.

Returns 1 if we correctly mapped the memory, or 0 if the caller should proceed with mapping memory from generic pools.

Name

dmam_alloc_coherent — Managed `dma_alloc_coherent`

Synopsis

```
void * dmam_alloc_coherent (struct device * dev, size_t size, dma_addr_t
* dma_handle, gfp_t gfp);
```

Arguments

dev	Device to allocate coherent memory for
size	Size of allocation
dma_handle	Out argument for allocated DMA handle
gfp	Allocation flags

Description

Managed `dma_alloc_coherent`. Memory allocated using this function will be automatically released on driver detach.

RETURNS

Pointer to allocated memory on success, NULL on failure.

Name

dmam_free_coherent — Managed `dma_free_coherent`

Synopsis

```
void dmam_free_coherent (struct device * dev, size_t size, void * vaddr,
dma_addr_t dma_handle);
```

Arguments

dev	Device to free coherent memory for
size	Size of allocation
vaddr	Virtual address of the memory to free
dma_handle	DMA handle of the memory to free

Description

Managed `dma_free_coherent`.

Name

dmam_alloc_noncoherent — Managed `dma_alloc_noncoherent`

Synopsis

```
void * dmam_alloc_noncoherent (struct device * dev, size_t size,
dma_addr_t * dma_handle, gfp_t gfp);
```

Arguments

dev	Device to allocate non_coherent memory for
size	Size of allocation
dma_handle	Out argument for allocated DMA handle
gfp	Allocation flags

Description

Managed `dma_alloc_noncoherent`. Memory allocated using this function will be automatically released on driver detach.

RETURNS

Pointer to allocated memory on success, NULL on failure.

Name

dmam_free_noncoherent — Managed `dma_free_noncoherent`

Synopsis

```
void dmam_free_noncoherent (struct device * dev, size_t size, void *
vaddr, dma_addr_t dma_handle);
```

Arguments

dev	Device to free noncoherent memory for
size	Size of allocation
vaddr	Virtual address of the memory to free
dma_handle	DMA handle of the memory to free

Description

Managed `dma_free_noncoherent`.

Name

dmam_declare_coherent_memory — Managed `dma_declare_coherent_memory`

Synopsis

```
int dmam_declare_coherent_memory (struct device * dev, phys_addr_t
phys_addr, dma_addr_t device_addr, size_t size, int flags);
```

Arguments

dev	Device to declare coherent memory for
phys_addr	Physical address of coherent memory to be declared
device_addr	Device address of coherent memory to be declared
size	Size of coherent memory to be declared
flags	Flags

Description

Managed `dma_declare_coherent_memory`.

RETURNS

0 on success, -errno on failure.

Name

dmam_release_declared_memory — Managed `dma_release_declared_memory`.

Synopsis

```
void dmam_release_declared_memory (struct device * dev);
```

Arguments

dev Device to release declared coherent memory for

Description

Managed `dmam_release_declared_memory`.

Device Drivers Power Management

Name

dpm_resume_start — Execute “noirq” and “early” device callbacks.

Synopsis

```
void dpm_resume_start (pm_message_t state);
```

Arguments

state PM transition of the system being carried out.

Name

dpm_resume_end — Execute “resume” callbacks and complete system transition.

Synopsis

```
void dpm_resume_end (pm_message_t state);
```

Arguments

state PM transition of the system being carried out.

Description

Execute “resume” callbacks for all devices and complete the PM transition of the system.

Name

dpm_suspend_end — Execute “late” and “noirq” device suspend callbacks.

Synopsis

```
int dpm_suspend_end (pm_message_t state);
```

Arguments

state PM transition of the system being carried out.

Name

dpm_suspend_start — Prepare devices for PM transition and suspend them.

Synopsis

```
int dpm_suspend_start (pm_message_t state);
```

Arguments

state PM transition of the system being carried out.

Description

Prepare all non-sysdev devices for system PM transition and execute “suspend” callbacks for them.

Name

device_pm_wait_for_dev — Wait for suspend/resume of a device to complete.

Synopsis

```
int device_pm_wait_for_dev (struct device * subordinate, struct device
* dev);
```

Arguments

subordinate Device that needs to wait for *dev*.

dev Device to wait for.

Name

dpm_for_each_dev — device iterator.

Synopsis

```
void dpm_for_each_dev (void * data, void (*fn) (struct device *, void
*));
```

Arguments

data data for the callback.

fn function to be called for each device.

Description

Iterate over devices in dpm_list, and call *fn* for each device, passing it *data*.

Device Drivers ACPI Support

Name

acpi_bus_scan — Add ACPI device node objects in a given namespace scope.

Synopsis

```
int acpi_bus_scan (acpi_handle handle);
```

Arguments

handle Root of the namespace scope to scan.

Description

Scan a given ACPI tree (probably recently hot-plugged) and create and add found devices.

If no devices were found, -ENODEV is returned, but it does not mean that there has been a real error. There just have been no suitable ACPI objects in the table trunk from which the kernel could create a device and add an appropriate driver.

Must be called under acpi_scan_lock.

Name

acpi_bus_trim — Detach scan handlers and drivers from ACPI device objects.

Synopsis

```
void acpi_bus_trim (struct acpi_device * adev);
```

Arguments

adev Root of the ACPI namespace scope to walk.

Description

Must be called under acpi_scan_lock.

Name

acpi_scan_drop_device — Drop an ACPI device object.

Synopsis

```
void acpi_scan_drop_device (acpi_handle handle, void * context);
```

Arguments

handle Handle of an ACPI namespace node, not used.

context Address of the ACPI device object to drop.

Description

This is invoked by `acpi_ns_delete_node` during the removal of the ACPI namespace node the device object pointed to by *context* is attached to.

The unregistration is carried out asynchronously to avoid running `acpi_device_del` under the ACPICA's namespace mutex and the list is used to ensure the correct ordering (the device objects must be unregistered in the same order in which the corresponding namespace nodes are deleted).

Name

acpi_dma_supported — Check DMA support for the specified device.

Synopsis

```
bool acpi_dma_supported (struct acpi_device * adev);
```

Arguments

adev The pointer to acpi device

Description

Return false if DMA is not supported. Otherwise, return true

Name

acpi_get_dma_attr — Check the supported DMA attr for the specified device.

Synopsis

```
enum dev_dma_attr acpi_get_dma_attr (struct acpi_device * adev);
```

Arguments

adev The pointer to acpi device

Description

Return enum dev_dma_attr.

Device drivers PnP support

Name

pnp_register_protocol — adds a pnp protocol to the pnp layer

Synopsis

```
int pnp_register_protocol (struct pnp_protocol * protocol);
```

Arguments

protocol pointer to the corresponding pnp_protocol structure

Ex protocols

ISAPNP, PNPBIOS, etc

Name

pnp_unregister_protocol — removes a pnp protocol from the pnp layer

Synopsis

```
void pnp_unregister_protocol (struct pnp_protocol * protocol);
```

Arguments

protocol pointer to the corresponding pnp_protocol structure

Name

pnp_request_card_device — Searches for a PnP device under the specified card

Synopsis

```
struct pnp_dev * pnp_request_card_device (struct pnp_card_link * clink,
const char * id, struct pnp_dev * from);
```

Arguments

clink pointer to the card link, cannot be NULL

id pointer to a PnP ID structure that explains the rules for finding the device

from Starting place to search from. If NULL it will start from the beginning.

Name

pnp_release_card_device — call this when the driver no longer needs the device

Synopsis

```
void pnp_release_card_device (struct pnp_dev * dev);
```

Arguments

dev pointer to the PnP device structure

Name

pnp_register_card_driver — registers a PnP card driver with the PnP Layer

Synopsis

```
int pnp_register_card_driver (struct pnp_card_driver * drv);
```

Arguments

drv pointer to the driver to register

Name

pnp_unregister_card_driver — unregisters a PnP card driver from the PnP Layer

Synopsis

```
void pnp_unregister_card_driver (struct pnp_card_driver * drv);
```

Arguments

drv pointer to the driver to unregister

Name

pnp_add_id — adds an EISA id to the specified device

Synopsis

```
struct pnp_id * pnp_add_id (struct pnp_dev * dev, const char * id);
```

Arguments

dev pointer to the desired device

id pointer to an EISA id string

Name

pnp_start_dev — low-level start of the PnP device

Synopsis

```
int pnp_start_dev (struct pnp_dev * dev);
```

Arguments

dev pointer to the desired device

Description

assumes that resources have already been allocated

Name

pnp_stop_dev — low-level disable of the PnP device

Synopsis

```
int pnp_stop_dev (struct pnp_dev * dev);
```

Arguments

dev pointer to the desired device

Description

does not free resources

Name

pnp_activate_dev — activates a PnP device for use

Synopsis

```
int pnp_activate_dev (struct pnp_dev * dev);
```

Arguments

dev pointer to the desired device

Description

does not validate or set resources so be careful.

Name

pnp_disable_dev — disables device

Synopsis

```
int pnp_disable_dev (struct pnp_dev * dev);
```

Arguments

dev pointer to the desired device

Description

inform the correct pnp protocol so that resources can be used by other devices

Name

pnp_is_active — Determines if a device is active based on its current resources

Synopsis

```
int pnp_is_active (struct pnp_dev * dev);
```

Arguments

dev pointer to the desired PnP device

Userspace IO devices

Name

uio_event_notify — trigger an interrupt event

Synopsis

```
void uio_event_notify (struct uio_info * info);
```

Arguments

info UIO device capabilities

Name

__uio_register_device — register a new userspace IO device

Synopsis

```
int __uio_register_device (struct module * owner, struct device * parent,
struct uio_info * info);
```

Arguments

owner module that creates the new device

parent parent device

info UIO device capabilities

Description

returns zero on success or a negative error code.

Name

uio_unregister_device — unregister a industrial IO device

Synopsis

```
void uio_unregister_device (struct uio_info * info);
```

Arguments

info UIO device capabilities

Name

struct uio_mem — description of a UIO memory region

Synopsis

```
struct uio_mem {
  const char * name;
  phys_addr_t addr;
  resource_size_t size;
  int memtype;
  void __iomem * internal_addr;
  struct uio_map * map;
};
```

Members

name	name of the memory region for identification
addr	address of the device's memory (phys_addr is used since addr can be logical, virtual, or physical & phys_addr_t should always be large enough to handle any of the address types)
size	size of IO
memtype	type of memory addr points to
internal_addr	ioremap-ped version of addr, for driver internal use
map	for use by the UIO core only.

Name

struct uio_port — description of a UIO port region

Synopsis

```
struct uio_port {
  const char * name;
  unsigned long start;
  unsigned long size;
  int porttype;
  struct uio_portio * portio;
};
```

Members

name	name of the port region for identification
start	start of port region
size	size of port region
porttype	type of port (see UIO_PORT_* below)
portio	for use by the UIO core only.

Name

struct uio_info — UIO device capabilities

Synopsis

```
struct uio_info {
  struct uio_device * uio_dev;
  const char * name;
  const char * version;
  struct uio_mem mem[MAX_UIO_MAPS];
  struct uio_port port[MAX_UIO_PORT_REGIONS];
  long irq;
  unsigned long irq_flags;
  void * priv;
  irqreturn_t (* handler) (int irq, struct uio_info *dev_info);
  int (* mmap) (struct uio_info *info, struct vm_area_struct *vma);
  int (* open) (struct uio_info *info, struct inode *inode);
  int (* release) (struct uio_info *info, struct inode *inode);
  int (* irqcontrol) (struct uio_info *info, s32 irq_on);
};
```

Members

uio_dev	the UIO device this info belongs to
name	device name
version	device driver version
mem[MAX_UIO_MAPS]	list of mappable memory regions, size==0 for end of list
port[MAX_UIO_PORT_REGIONS]	list of port regions, size==0 for end of list
irq	interrupt number or UIO_IRQ_CUSTOM
irq_flags	flags for `request_irq`
priv	optional private data
handler	the device's irq handler
mmap	mmap operation for this uio device
open	open operation for this uio device
release	release operation for this uio device
irqcontrol	disable/enable irqs when 0/1 is written to /dev/uioX

Chapter 3. Parallel Port Devices

Name

parport_yield — relinquish a parallel port temporarily

Synopsis

```
int parport_yield (struct pardevice * dev);
```

Arguments

dev a device on the parallel port

Description

This function relinquishes the port if it would be helpful to other drivers to do so. Afterwards it tries to reclaim the port using `parport_claim`, and the return value is the same as for `parport_claim`. If it fails, the port is left unclaimed and it is the driver's responsibility to reclaim the port.

The `parport_yield` and `parport_yield_blocking` functions are for marking points in the driver at which other drivers may claim the port and use their devices. Yielding the port is similar to releasing it and reclaiming it, but is more efficient because no action is taken if there are no other devices needing the port. In fact, nothing is done even if there are other devices waiting but the current device is still within its “timeslice”. The default timeslice is half a second, but it can be adjusted via the /proc interface.

Name

parport_yield_blocking — relinquish a parallel port temporarily

Synopsis

```
int parport_yield_blocking (struct pardevice * dev);
```

Arguments

dev a device on the parallel port

Description

This function relinquishes the port if it would be helpful to other drivers to do so. Afterwards it tries to reclaim the port using `parport_claim_or_block`, and the return value is the same as for `parport_claim_or_block`.

Name

parport_wait_event — wait for an event on a parallel port

Synopsis

```
int parport_wait_event (struct parport * port, signed long timeout);
```

Arguments

port port to wait on

timeout time to wait (in jiffies)

Description

This function waits for up to *timeout* jiffies for an interrupt to occur on a parallel port. If the port timeout is set to zero, it returns immediately.

If an interrupt occurs before the timeout period elapses, this function returns zero immediately. If it times out, it returns one. An error code less than zero indicates an error (most likely a pending signal), and the calling code should finish what it's doing as soon as it can.

Name

parport_wait_peripheral — wait for status lines to change in 35ms

Synopsis

```
int parport_wait_peripheral (struct parport * port, unsigned char mask,
unsigned char result);
```

Arguments

port port to watch

mask status lines to watch

result desired values of chosen status lines

Description

This function waits until the masked status lines have the desired values, or until 35ms have elapsed (see IEEE 1284-1994 page 24 to 25 for why this value in particular is hardcoded). The *mask* and *result* parameters are bitmasks, with the bits defined by the constants in parport.h: PARPORT_STATUS_BUSY, and so on.

The port is polled quickly to start off with, in anticipation of a fast response from the peripheral. This fast polling time is configurable (using /proc), and defaults to 500usec. If the timeout for this port (see parport_set_timeout) is zero, the fast polling time is 35ms, and this function does not call schedule.

If the timeout for this port is non-zero, after the fast polling fails it uses parport_wait_event to wait for up to 10ms, waking up if an interrupt occurs.

Name

parport_negotiate — negotiate an IEEE 1284 mode

Synopsis

```
int parport_negotiate (struct parport * port, int mode);
```

Arguments

port port to use

mode mode to negotiate to

Description

Use this to negotiate to a particular IEEE 1284 transfer mode. The *mode* parameter should be one of the constants in parport.h starting `IEEE1284_MODE_xxx`.

The return value is 0 if the peripheral has accepted the negotiation to the mode specified, -1 if the peripheral is not IEEE 1284 compliant (or not present), or 1 if the peripheral has rejected the negotiation.

Name

parport_write — write a block of data to a parallel port

Synopsis

```
ssize_t parport_write (struct parport * port, const void * buffer,
size_t len);
```

Arguments

port	port to write to
buffer	data buffer (in kernel space)
len	number of bytes of data to transfer

Description

This will write up to *len* bytes of *buffer* to the port specified, using the IEEE 1284 transfer mode most recently negotiated to (using parport_negotiate), as long as that mode supports forward transfers (host to peripheral).

It is the caller's responsibility to ensure that the first *len* bytes of *buffer* are valid.

This function returns the number of bytes transferred (if zero or positive), or else an error code.

Name

parport_read — read a block of data from a parallel port

Synopsis

```
ssize_t parport_read (struct parport * port, void * buffer, size_t len);
```

Arguments

port	port to read from
buffer	data buffer (in kernel space)
len	number of bytes of data to transfer

Description

This will read up to *len* bytes of *buffer* to the port specified, using the IEEE 1284 transfer mode most recently negotiated to (using parport_negotiate), as long as that mode supports reverse transfers (peripheral to host).

It is the caller's responsibility to ensure that the first *len* bytes of *buffer* are available to write to.

This function returns the number of bytes transferred (if zero or positive), or else an error code.

Name

parport_set_timeout — set the inactivity timeout for a device

Synopsis

```
long parport_set_timeout (struct pardevice * dev, long inactivity);
```

Arguments

dev device on a port

inactivity inactivity timeout (in jiffies)

Description

This sets the inactivity timeout for a particular device on a port. This affects functions like `parport_wait_peripheral`. The special value 0 means not to call `schedule` while dealing with this device.

The return value is the previous inactivity timeout.

Any callers of `parport_wait_event` for this device are woken up.

Name

__parport_register_driver — register a parallel port device driver

Synopsis

```
int __parport_register_driver (struct parport_driver * drv, struct
module * owner, const char * mod_name);
```

Arguments

drv structure describing the driver

owner owner module of drv

mod_name module name string

Description

This can be called by a parallel port device driver in order to receive notifications about ports being found in the system, as well as ports no longer available.

If devmodel is true then the new device model is used for registration.

The *drv* structure is allocated by the caller and must not be deallocated until after calling `parport_unregister_driver`.

If using the non device model

The driver's `attach` function may block. The port that `attach` is given will be valid for the duration of the callback, but if the driver wants to take a copy of the pointer it must call `parport_get_port` to do so. Calling `parport_register_device` on that port will do this for you.

The driver's `detach` function may block. The port that `detach` is given will be valid for the duration of the callback, but if the driver wants to take a copy of the pointer it must call `parport_get_port` to do so.

Returns 0 on success. The non device model will always succeeds. but the new device model can fail and will return the error code.

Name

parport_unregister_driver — deregister a parallel port device driver

Synopsis

```
void parport_unregister_driver (struct parport_driver * drv);
```

Arguments

drv structure describing the driver that was given to `parport_register_driver`

Description

This should be called by a parallel port device driver that has registered itself using `parport_register_driver` when it is about to be unloaded.

When it returns, the driver's `attach` routine will no longer be called, and for each port that `attach` was called for, the `detach` routine will have been called.

All the driver's `attach` and `detach` calls are guaranteed to have finished by the time this function returns.

Name

parport_get_port — increment a port's reference count

Synopsis

```
struct parport * parport_get_port (struct parport * port);
```

Arguments

port the port

Description

This ensures that a struct parport pointer remains valid until the matching `parport_put_port` call.

Name

parport_put_port — decrement a port's reference count

Synopsis

```
void parport_put_port (struct parport * port);
```

Arguments

port the port

Description

This should be called once for each call to `parport_get_port`, once the port is no longer needed. When the reference count reaches zero (port is no longer used), free_port is called.

Name

parport_register_port — register a parallel port

Synopsis

```
struct parport * parport_register_port (unsigned long base, int irq,
int dma, struct parport_operations * ops);
```

Arguments

base base I/O address

irq IRQ line

dma DMA channel

ops pointer to the port driver's port operations structure

Description

When a parallel port (lowlevel) driver finds a port that should be made available to parallel port device drivers, it should call parport_register_port. The *base*, *irq*, and *dma* parameters are for the convenience of port drivers, and for ports where they aren't meaningful needn't be set to anything special. They can be altered afterwards by adjusting the relevant members of the parport structure that is returned and represents the port. They should not be tampered with after calling parport_announce_port, however.

If there are parallel port device drivers in the system that have registered themselves using parport_register_driver, they are not told about the port at this time; that is done by parport_announce_port.

The *ops* structure is allocated by the caller, and must not be deallocated before calling parport_remove_port.

If there is no memory to allocate a new parport structure, this function will return NULL.

Name

parport_announce_port — tell device drivers about a parallel port

Synopsis

```
void parport_announce_port (struct parport * port);
```

Arguments

port parallel port to announce

Description

After a port driver has registered a parallel port with parport_register_port, and performed any necessary initialisation or adjustments, it should call `parport_announce_port` in order to notify all device drivers that have called `parport_register_driver`. Their `attach` functions will be called, with *port* as the parameter.

Name

parport_remove_port — deregister a parallel port

Synopsis

```
void parport_remove_port (struct parport * port);
```

Arguments

port parallel port to deregister

Description

When a parallel port driver is forcibly unloaded, or a parallel port becomes inaccessible, the port driver must call this function in order to deal with device drivers that still want to use it.

The parport structure associated with the port has its operations structure replaced with one containing 'null' operations that return errors or just don't do anything.

Any drivers that have registered themselves using `parport_register_driver` are notified that the port is no longer accessible by having their `detach` routines called with *`port`* as the parameter.

Name

parport_register_device — register a device on a parallel port

Synopsis

```
struct pardevice * parport_register_device (struct parport * port, const
char * name, int (*pf) (void *), void (*kf) (void *), void (*irq_func)
(void *), int flags, void * handle);
```

Arguments

port	port to which the device is attached
name	a name to refer to the device
pf	preemption callback
kf	kick callback (wake-up)
irq_func	interrupt handler
flags	registration flags
handle	data for callback functions

Description

This function, called by parallel port device drivers, declares that a device is connected to a port, and tells the system all it needs to know.

The *name* is allocated by the caller and must not be deallocated until the caller calls *parport_unregister_device* for that device.

The preemption callback function, *pf*, is called when this device driver has claimed access to the port but another device driver wants to use it. It is given *handle* as its parameter, and should return zero if it is willing for the system to release the port to another driver on its behalf. If it wants to keep control of the port it should return non-zero, and no action will be taken. It is good manners for the driver to try to release the port at the earliest opportunity after its preemption callback rejects a preemption attempt. Note that if a preemption callback is happy for preemption to go ahead, there is no need to release the port; it is done automatically. This function may not block, as it may be called from interrupt context. If the device driver does not support preemption, *pf* can be NULL.

The wake-up ("kick") callback function, *kf*, is called when the port is available to be claimed for exclusive access; that is, parport_claim is guaranteed to succeed when called from inside the wake-up callback function. If the driver wants to claim the port it should do so; otherwise, it need not take any action. This function may not block, as it may be called from interrupt context. If the device driver does not want to be explicitly invited to claim the port in this way, *kf* can be NULL.

The interrupt handler, *irq_func*, is called when an interrupt arrives from the parallel port. Note that if a device driver wants to use interrupts it should use parport_enable_irq, and can also check the irq member of the parport structure representing the port.

The parallel port (lowlevel) driver is the one that has called request_irq and whose interrupt handler is called first. This handler does whatever needs to be done to the hardware to acknowledge the interrupt

(for PC-style ports there is nothing special to be done). It then tells the IEEE 1284 code about the interrupt, which may involve reacting to an IEEE 1284 event depending on the current IEEE 1284 phase. After this, it calls *irq_func*. Needless to say, *irq_func* will be called from interrupt context, and may not block.

The PARPORT_DEV_EXCL flag is for preventing port sharing, and so should only be used when sharing the port with other device drivers is impossible and would lead to incorrect behaviour. Use it sparingly! Normally, *flags* will be zero.

This function returns a pointer to a structure that represents the device on the port, or NULL if there is not enough memory to allocate space for that structure.

Name

parport_unregister_device — deregister a device on a parallel port

Synopsis

```
void parport_unregister_device (struct pardevice * dev);
```

Arguments

dev pointer to structure representing device

Description

This undoes the effect of `parport_register_device`.

Name

parport_find_number — find a parallel port by number

Synopsis

```
struct parport * parport_find_number (int number);
```

Arguments

number parallel port number

Description

This returns the parallel port with the specified number, or `NULL` if there is none.

There is an implicit `parport_get_port` done already; to throw away the reference to the port that `parport_find_number` gives you, use `parport_put_port`.

Name

parport_find_base — find a parallel port by base address

Synopsis

```
struct parport * parport_find_base (unsigned long base);
```

Arguments

base base I/O address

Description

This returns the parallel port with the specified base address, or `NULL` if there is none.

There is an implicit `parport_get_port` done already; to throw away the reference to the port that `parport_find_base` gives you, use `parport_put_port`.

Name

parport_claim — claim access to a parallel port device

Synopsis

```
int parport_claim (struct pardevice * dev);
```

Arguments

dev pointer to structure representing a device on the port

Description

This function will not block and so can be used from interrupt context. If `parport_claim` succeeds in claiming access to the port it returns zero and the port is available to use. It may fail (returning non-zero) if the port is in use by another driver and that driver is not willing to relinquish control of the port.

Name

parport_claim_or_block — claim access to a parallel port device

Synopsis

```
int parport_claim_or_block (struct pardevice * dev);
```

Arguments

dev pointer to structure representing a device on the port

Description

This behaves like `parport_claim`, but will block if necessary to wait for the port to be free. A return value of 1 indicates that it slept; 0 means that it succeeded without needing to sleep. A negative error code indicates failure.

Name

parport_release — give up access to a parallel port device

Synopsis

```
void parport_release (struct pardevice * dev);
```

Arguments

dev pointer to structure representing parallel port device

Description

This function cannot fail, but it should not be called without the port claimed. Similarly, if the port is already claimed you should not try claiming it again.

Name

parport_open — find a device by canonical device number

Synopsis

```
struct pardevice * parport_open (int devnum, const char * name);
```

Arguments

devnum canonical device number

name name to associate with the device

Description

This function is similar to `parport_register_device`, except that it locates a device by its number rather than by the port it is attached to.

All parameters except for *devnum* are the same as for `parport_register_device`. The return value is the same as for `parport_register_device`.

Name

parport_close — close a device opened with `parport_open`

Synopsis

```
void parport_close (struct pardevice * dev);
```

Arguments

`dev` device to close

Description

This is to `parport_open` as `parport_unregister_device` is to `parport_register_device`.

Chapter 4. Message-based devices

Fusion message devices

Name

mpt_register — Register protocol-specific main callback handler.

Synopsis

```
u8 mpt_register (MPT_CALLBACK cbfunc, MPT_DRIVER_CLASS dclass, char *
func_name);
```

Arguments

cbfunc callback function pointer

dclass Protocol driver's class (MPT_DRIVER_CLASS enum value)

func_name call function's name

Description

This routine is called by a protocol-specific driver (SCSI host, LAN, SCSI target) to register its reply callback routine. Each protocol-specific driver must do this before it will be able to use any IOC resources, such as obtaining request frames.

NOTES

The SCSI protocol driver currently calls this routine thrice in order to register separate callbacks; one for “normal” SCSI IO; one for MptScsiTaskMgmt requests; one for Scan/DV requests.

Returns u8 valued “handle” in the range (and S.O.D. order) {N,...,7,6,5,...,1} if successful. A return value of MPT_MAX_PROTOCOL_DRIVERS (including zero!) should be considered an error by the caller.

Name

mpt_deregister — Deregister a protocol drivers resources.

Synopsis

```
void mpt_deregister (u8 cb_idx);
```

Arguments

cb_idx previously registered callback handle

Description

Each protocol-specific driver should call this routine when its module is unloaded.

Name

mpt_event_register — Register protocol-specific event callback handler.

Synopsis

```
int mpt_event_register (u8 cb_idx, MPT_EVHANDLER ev_cbfunc);
```

Arguments

cb_idx previously registered (via mpt_register) callback handle

ev_cbfunc callback function

Description

This routine can be called by one or more protocol-specific drivers if/when they choose to be notified of MPT events.

Returns 0 for success.

Name

mpt_event_deregister — Deregister protocol-specific event callback handler

Synopsis

```
void mpt_event_deregister (u8 cb_idx);
```

Arguments

cb_idx previously registered callback handle

Description

Each protocol-specific driver should call this routine when it does not (or can no longer) handle events, or when its module is unloaded.

Name

mpt_reset_register — Register protocol-specific IOC reset handler.

Synopsis

```
int mpt_reset_register (u8 cb_idx, MPT_RESETHANDLER reset_func);
```

Arguments

cb_idx previously registered (via mpt_register) callback handle

reset_func reset function

Description

This routine can be called by one or more protocol-specific drivers if/when they choose to be notified of IOC resets.

Returns 0 for success.

Name

mpt_reset_deregister — Deregister protocol-specific IOC reset handler.

Synopsis

```
void mpt_reset_deregister (u8 cb_idx);
```

Arguments

cb_idx previously registered callback handle

Description

Each protocol-specific driver should call this routine when it does not (or can no longer) handle IOC reset handling, or when its module is unloaded.

Name

mpt_device_driver_register — Register device driver hooks

Synopsis

```
int mpt_device_driver_register (struct mpt_pci_driver * dd_cbfunc, u8
cb_idx);
```

Arguments

dd_cbfunc driver callbacks struct

cb_idx MPT protocol driver index

Name

mpt_device_driver_deregister — DeRegister device driver hooks

Synopsis

```
void mpt_device_driver_deregister (u8 cb_idx);
```

Arguments

cb_idx MPT protocol driver index

Name

mpt_get_msg_frame — Obtain an MPT request frame from the pool

Synopsis

```
MPT_FRAME_HDR* mpt_get_msg_frame (u8 cb_idx, MPT_ADAPTER * ioc);
```

Arguments

cb_idx Handle of registered MPT protocol driver

ioc Pointer to MPT adapter structure

Description

Obtain an MPT request frame from the pool (of 1024) that are allocated per MPT adapter.

Returns pointer to a MPT request frame or `NULL` if none are available or IOC is not active.

Name

mpt_put_msg_frame — Send a protocol-specific MPT request frame to an IOC

Synopsis

```
void mpt_put_msg_frame (u8 cb_idx, MPT_ADAPTER * ioc, MPT_FRAME_HDR *
mf);
```

Arguments

cb_idx Handle of registered MPT protocol driver

ioc Pointer to MPT adapter structure

mf Pointer to MPT request frame

Description

This routine posts an MPT request frame to the request post FIFO of a specific MPT adapter.

Name

mpt_put_msg_frame_hi_pri — Send a hi-pri protocol-specific MPT request frame

Synopsis

```
void mpt_put_msg_frame_hi_pri (u8 cb_idx, MPT_ADAPTER * ioc,
MPT_FRAME_HDR * mf);
```

Arguments

cb_idx Handle of registered MPT protocol driver

ioc Pointer to MPT adapter structure

mf Pointer to MPT request frame

Description

Send a protocol-specific MPT request frame to an IOC using hi-priority request queue.

This routine posts an MPT request frame to the request post FIFO of a specific MPT adapter.

Name

mpt_free_msg_frame — Place MPT request frame back on FreeQ.

Synopsis

```
void mpt_free_msg_frame (MPT_ADAPTER * ioc, MPT_FRAME_HDR * mf);
```

Arguments

ioc Pointer to MPT adapter structure

mf Pointer to MPT request frame

Description

This routine places a MPT request frame back on the MPT adapter's FreeQ.

Name

mpt_send_handshake_request — Send MPT request via doorbell handshake method.

Synopsis

```
int mpt_send_handshake_request (u8 cb_idx, MPT_ADAPTER * ioc, int reqBytes, u32 * req, int sleepFlag);
```

Arguments

cb_idx	Handle of registered MPT protocol driver
ioc	Pointer to MPT adapter structure
reqBytes	Size of the request in bytes
req	Pointer to MPT request frame
sleepFlag	Use schedule if CAN_SLEEP else use udelay.

Description

This routine is used exclusively to send MptScsiTaskMgmt requests since they are required to be sent via doorbell handshake.

NOTE

It is the callers responsibility to byte-swap fields in the request which are greater than 1 byte in size.

Returns 0 for success, non-zero for failure.

Name

mpt_verify_adapter — Given IOC identifier, set pointer to its adapter structure.

Synopsis

```
int mpt_verify_adapter (int iocid, MPT_ADAPTER ** iocpp);
```

Arguments

iocid IOC unique identifier (integer)

iocpp Pointer to pointer to IOC adapter

Description

Given a unique IOC identifier, set pointer to the associated MPT adapter structure.

Returns iocid and sets iocpp if iocid is found. Returns -1 if iocid is not found.

Name

mpt_attach — Install a PCI intelligent MPT adapter.

Synopsis

```
int mpt_attach (struct pci_dev * pdev, const struct pci_device_id * id);
```

Arguments

pdev Pointer to pci_dev structure

id PCI device ID information

Description

This routine performs all the steps necessary to bring the IOC of a MPT adapter to a OPERATIONAL state. This includes registering memory regions, registering the interrupt, and allocating request and reply memory pools.

This routine also pre-fetches the LAN MAC address of a Fibre Channel MPT adapter.

Returns 0 for success, non-zero for failure.

TODO

Add support for polled controllers

Name

mpt_detach — Remove a PCI intelligent MPT adapter.

Synopsis

```
void mpt_detach (struct pci_dev * pdev);
```

Arguments

pdev Pointer to pci_dev structure

Name

mpt_suspend — Fusion MPT base driver suspend routine.

Synopsis

```
int mpt_suspend (struct pci_dev * pdev, pm_message_t state);
```

Arguments

pdev Pointer to pci_dev structure

state new state to enter

Name

mpt_resume — Fusion MPT base driver resume routine.

Synopsis

```
int mpt_resume (struct pci_dev * pdev);
```

Arguments

pdev Pointer to pci_dev structure

Name

mpt_GetIocState — Get the current state of a MPT adapter.

Synopsis

```
u32 mpt_GetIocState (MPT_ADAPTER * ioc, int cooked);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

cooked Request raw or cooked IOC state

Description

Returns all IOC Doorbell register bits if cooked==0, else just the Doorbell bits in MPI_IOC_STATE_MASK.

Name

mpt_alloc_fw_memory — allocate firmware memory

Synopsis

```
int mpt_alloc_fw_memory (MPT_ADAPTER * ioc, int size);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

size total FW bytes

Description

If memory has already been allocated, the same (cached) value is returned.

Return 0 if successful, or non-zero for failure

Name

mpt_free_fw_memory — free firmware memory

Synopsis

```
void mpt_free_fw_memory (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Description

If alt_img is NULL, delete from ioc structure. Else, delete a secondary image in same format.

Name

mptbase_sas_persist_operation — Perform operation on SAS Persistent Table

Synopsis

```
int mptbase_sas_persist_operation (MPT_ADAPTER * ioc, u8 persist_opcode);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
persist_opcode	see below

Description

MPI_SAS_OP_CLEAR_NOT_PRESENT - Free all persist TargetID mappings for devices not currently present. MPI_SAS_OP_CLEAR_ALL_PERSISTENT - Clear al persist TargetID mappings

NOTE

Don't use not this function during interrupt time.

Returns 0 for success, non-zero error

Name

mpt_raid_phys_disk_pg0 — returns phys disk page zero

Synopsis

```
int mpt_raid_phys_disk_pg0 (MPT_ADAPTER * ioc, u8 phys_disk_num,
RaidPhysDiskPage0_t * phys_disk);
```

Arguments

ioc	Pointer to a Adapter Structure
phys_disk_num	io unit unique phys disk num generated by the ioc
phys_disk	requested payload data returned

Return

0 on success -EFAULT if read of config page header fails or data pointer not NULL -ENOMEM if pci_alloc failed

Name

mpt_raid_phys_disk_get_num_paths — returns number paths associated to this phys_num

Synopsis

```
int mpt_raid_phys_disk_get_num_paths (MPT_ADAPTER * ioc, u8 phys_disk_num);
```

Arguments

ioc	Pointer to a Adapter Structure
phys_disk_num	io unit unique phys disk num generated by the ioc

Return

returns number paths

Name

mpt_raid_phys_disk_pg1 — returns phys disk page 1

Synopsis

```
int mpt_raid_phys_disk_pg1 (MPT_ADAPTER * ioc, u8 phys_disk_num,
RaidPhysDiskPage1_t * phys_disk);
```

Arguments

ioc	Pointer to a Adapter Structure
phys_disk_num	io unit unique phys disk num generated by the ioc
phys_disk	requested payload data returned

Return

0 on success -EFAULT if read of config page header fails or data pointer not NULL -ENOMEM if pci_alloc failed

Name

mpt_findImVolumes — Identify IDs of hidden disks and RAID Volumes

Synopsis

```
int mpt_findImVolumes (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to a Adapter Strucutre

Return

0 on success -EFAULT if read of config page header fails or data pointer not NULL -ENOMEM if pci_alloc failed

Name

mpt_config — Generic function to issue config message

Synopsis

```
int mpt_config (MPT_ADAPTER * ioc, CONFIGPARMS * pCfg);
```

Arguments

ioc Pointer to an adapter structure

pCfg Pointer to a configuration structure. Struct contains action, page address, direction, physical address and pointer to a configuration page header Page header is updated.

Description

Returns 0 for success -EPERM if not allowed due to ISR context -EAGAIN if no msg frames currently available -EFAULT for non-successful reply or no reply (timeout)

Name

mpt_print_ioc_summary — Write ASCII summary of IOC to a buffer.

Synopsis

```
void mpt_print_ioc_summary (MPT_ADAPTER * ioc, char * buffer, int *
size, int len, int showlan);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
buffer	Pointer to buffer where IOC summary info should be written
size	Pointer to number of bytes we wrote (set by this routine)
len	Offset at which to start writing in buffer
showlan	Display LAN stuff?

Description

This routine writes (english readable) ASCII text, which represents a summary of IOC information, to a buffer.

Name

mpt_set_taskmgmt_in_progress_flag — set flags associated with task management

Synopsis

```
int mpt_set_taskmgmt_in_progress_flag (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Description

Returns 0 for SUCCESS or -1 if FAILED.

If -1 is return, then it was not possible to set the flags

Name

mpt_clear_taskmgmt_in_progress_flag — clear flags associated with task management

Synopsis

```
void mpt_clear_taskmgmt_in_progress_flag (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Name

mpt_halt_firmware — Halts the firmware if it is operational and panic the kernel

Synopsis

```
void mpt_halt_firmware (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Name

mpt_Soft_Hard_ResetHandler — Try less expensive reset

Synopsis

```
int mpt_Soft_Hard_ResetHandler (MPT_ADAPTER * ioc, int sleepFlag);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

sleepFlag Indicates if sleep or schedule must be called.

Description

Returns 0 for SUCCESS or -1 if FAILED. Try for softreset first, only if it fails go for expensive HardReset.

Name

mpt_HardResetHandler — Generic reset handler

Synopsis

```
int mpt_HardResetHandler (MPT_ADAPTER * ioc, int sleepFlag);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

sleepFlag Indicates if sleep or schedule must be called.

Description

Issues SCSI Task Management call based on input arg values. If TaskMgmt fails, returns associated SCSI request.

Remark

_HardResetHandler can be invoked from an interrupt thread (timer) or a non-interrupt thread. In the former, must not call `schedule`.

Note

A return of -1 is a FATAL error case, as it means a FW reload/initialization failed.

Returns 0 for SUCCESS or -1 if FAILED.

Name

mpt_get_cb_idx — obtain cb_idx for registered driver

Synopsis

```
u8 mpt_get_cb_idx (MPT_DRIVER_CLASS dclass);
```

Arguments

dclass class driver enum

Description

Returns cb_idx, or zero means it wasn't found

Name

mpt_is_discovery_complete — determine if discovery has completed

Synopsis

```
int mpt_is_discovery_complete (MPT_ADAPTER * ioc);
```

Arguments

ioc per adatper instance

Description

Returns 1 when discovery completed, else zero.

Name

mpt_remove_dead_ioc_func — kthread context to remove dead ioc

Synopsis

```
int mpt_remove_dead_ioc_func (void * arg);
```

Arguments

arg input argument, used to derive ioc

Description

Return 0 if controller is removed from pci subsystem. Return -1 for other case.

Name

mpt_fault_reset_work — work performed on workq after ioc fault

Synopsis

```
void mpt_fault_reset_work (struct work_struct * work);
```

Arguments

work input argument, used to derive ioc

Name

mpt_interrupt — MPT adapter (IOC) specific interrupt handler.

Synopsis

```
irqreturn_t mpt_interrupt (int irq, void * bus_id);
```

Arguments

irq irq number (not used)

bus_id bus identifier cookie == pointer to MPT_ADAPTER structure

Description

This routine is registered via the `request_irq` kernel API call, and handles all interrupts generated from a specific MPT adapter (also referred to as a IO Controller or IOC). This routine must clear the interrupt from the adapter and does so by reading the reply FIFO. Multiple replies may be processed per single call to this routine.

This routine handles register-level access of the adapter but dispatches (calls) a protocol-specific callback routine to handle the protocol-specific details of the MPT request completion.

Name

mptbase_reply — MPT base driver's callback routine

Synopsis

```
int mptbase_reply (MPT_ADAPTER * ioc, MPT_FRAME_HDR * req, MPT_FRAME_HDR
* reply);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

req Pointer to original MPT request frame

reply Pointer to MPT reply frame (NULL if TurboReply)

Description

MPT base driver's callback routine; all base driver “internal” request/reply processing is routed here. Currently used for EventNotification and EventAck handling.

Returns 1 indicating original alloc'd request frame ptr should be freed, or 0 if it shouldn't.

Name

mpt_add_sge — Place a simple 32 bit SGE at address pAddr.

Synopsis

```
void mpt_add_sge (void * pAddr, u32 flagslength, dma_addr_t dma_addr);
```

Arguments

pAddr	virtual address for SGE
flagslength	SGE flags and data transfer length
dma_addr	Physical address

Description

This routine places a MPT request frame back on the MPT adapter's FreeQ.

Name

mpt_add_sge_64bit — Place a simple 64 bit SGE at address pAddr.

Synopsis

```
void mpt_add_sge_64bit (void * pAddr, u32 flagslength, dma_addr_t
dma_addr);
```

Arguments

pAddr	virtual address for SGE
flagslength	SGE flags and data transfer length
dma_addr	Physical address

Description

This routine places a MPT request frame back on the MPT adapter's FreeQ.

Name

mpt_add_sge_64bit_1078 — Place a simple 64 bit SGE at address pAddr (1078 workaround).

Synopsis

```
void mpt_add_sge_64bit_1078 (void * pAddr, u32 flagslength, dma_addr_t
dma_addr);
```

Arguments

pAddr	virtual address for SGE
flagslength	SGE flags and data transfer length
dma_addr	Physical address

Description

This routine places a MPT request frame back on the MPT adapter's FreeQ.

Name

mpt_add_chain — Place a 32 bit chain SGE at address pAddr.

Synopsis

```
void mpt_add_chain (void * pAddr, u8 next, u16 length, dma_addr_t
dma_addr);
```

Arguments

pAddr	virtual address for SGE
next	nextChainOffset value (u32's)
length	length of next SGL segment
dma_addr	Physical address

Name

mpt_add_chain_64bit — Place a 64 bit chain SGE at address pAddr.

Synopsis

```
void mpt_add_chain_64bit (void * pAddr, u8 next, u16 length, dma_addr_t
dma_addr);
```

Arguments

pAddr	virtual address for SGE
next	nextChainOffset value (u32's)
length	length of next SGL segment
dma_addr	Physical address

Name

mpt_host_page_access_control — control the IOC's Host Page Buffer access

Synopsis

```
int mpt_host_page_access_control (MPT_ADAPTER * ioc, u8 access_control_value, int sleepFlag);
```

Arguments

ioc	Pointer to MPT adapter structure
access_control_value	define bits below
sleepFlag	Specifies whether the process can sleep

Description

Provides mechanism for the host driver to control the IOC's Host Page Buffer access.

Access Control Value - bits[15:12] 0h Reserved 1h Enable Access { MPI_DB_HPBAC_ENABLE_ACCESS } 2h Disable Access { MPI_DB_HPBAC_DISABLE_ACCESS } 3h Free Buffer { MPI_DB_HPBAC_FREE_BUFFER }

Returns 0 for success, non-zero for failure.

Name

mpt_host_page_alloc — allocate system memory for the fw

Synopsis

```
int mpt_host_page_alloc (MPT_ADAPTER * ioc, pIOCInit_t ioc_init);
```

Arguments

ioc Pointer to pointer to IOC adapter

ioc_init Pointer to ioc init config page

Description

If we already allocated memory in past, then resend the same pointer. Returns 0 for success, non-zero for failure.

Name

mpt_get_product_name — returns product string

Synopsis

```
const char* mpt_get_product_name (u16 vendor, u16 device, u8 revision);
```

Arguments

vendor pci vendor id

device pci device id

revision pci revision id

Description

Returns product string displayed when driver loads, in /proc/mpt/summary and /sysfs/class/scsi_host/host<X>/version_product

Name

mpt_mapresources — map in memory mapped io

Synopsis

```
int mpt_mapresources (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to pointer to IOC adapter

Name

mpt_do_ioc_recovery — Initialize or recover MPT adapter.

Synopsis

```
int mpt_do_ioc_recovery (MPT_ADAPTER * ioc, u32 reason, int sleepFlag);
```

Arguments

ioc	Pointer to MPT adapter structure
reason	Event word / reason
sleepFlag	Use schedule if CAN_SLEEP else use udelay.

Description

This routine performs all the steps necessary to bring the IOC to a OPERATIONAL state.

This routine also pre-fetches the LAN MAC address of a Fibre Channel MPT adapter.

Returns

0 for success -1 if failed to get board READY -2 if READY but IOCFacts Failed -3 if READY but PrimeIOCFifos Failed -4 if READY but IOCInit Failed -5 if failed to enable_device and/or request_selected_regions -6 if failed to upload firmware

Name

mpt_detect_bound_ports — Search for matching PCI bus/dev_function

Synopsis

```
void mpt_detect_bound_ports (MPT_ADAPTER * ioc, struct pci_dev * pdev);
```

Arguments

ioc Pointer to MPT adapter structure

pdev Pointer to (struct pci_dev) structure

Description

Search for PCI bus/dev_function which matches PCI bus/dev_function (+/-1) for newly discovered 929, 929X, 1030 or 1035.

If match on PCI dev_function +/-1 is found, bind the two MPT adapters using alt_ioc pointer fields in their MPT_ADAPTER structures.

Name

mpt_adapter_disable — Disable misbehaving MPT adapter.

Synopsis

```
void mpt_adapter_disable (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT adapter structure

Name

mpt_adapter_dispose — Free all resources associated with an MPT adapter

Synopsis

```
void mpt_adapter_dispose (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT adapter structure

Description

This routine unregisters h/w resources and frees all alloc'd memory associated with a MPT adapter structure.

Name

MptDisplayIocCapabilities — Disply IOC's capabilities.

Synopsis

```
void MptDisplayIocCapabilities (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT adapter structure

Name

MakeIocReady — Get IOC to a READY state, using KickStart if needed.

Synopsis

```
int MakeIocReady (MPT_ADAPTER * ioc, int force, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
force	Force hard KickStart of IOC
sleepFlag	Specifies whether the process can sleep

Returns

1 - DIAG reset and READY 0 - READY initially OR soft reset and READY -1 - Any failure on KickStart -2 - Msg Unit Reset Failed -3 - IO Unit Reset Failed -4 - IOC owned by a PEER

Name

GetIocFacts — Send IOCFacts request to MPT adapter.

Synopsis

```
int GetIocFacts (MPT_ADAPTER * ioc, int sleepFlag, int reason);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
sleepFlag	Specifies whether the process can sleep
reason	If recovery, only update facts.

Description

Returns 0 for success, non-zero for failure.

Name

GetPortFacts — Send PortFacts request to MPT adapter.

Synopsis

```
int GetPortFacts (MPT_ADAPTER * ioc, int portnum, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
portnum	Port number
sleepFlag	Specifies whether the process can sleep

Description

Returns 0 for success, non-zero for failure.

Name

SendIocInit — Send IOCInit request to MPT adapter.

Synopsis

```
int SendIocInit (MPT_ADAPTER * ioc, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
sleepFlag	Specifies whether the process can sleep

Description

Send IOCInit followed by PortEnable to bring IOC to OPERATIONAL state.

Returns 0 for success, non-zero for failure.

Name

SendPortEnable — Send PortEnable request to MPT adapter port.

Synopsis

```
int SendPortEnable (MPT_ADAPTER * ioc, int portnum, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
portnum	Port number to enable
sleepFlag	Specifies whether the process can sleep

Description

Send PortEnable to bring IOC to OPERATIONAL state.

Returns 0 for success, non-zero for failure.

Name

mpt_do_upload — Construct and Send FWUpload request to MPT adapter port.

Synopsis

```
int mpt_do_upload (MPT_ADAPTER * ioc, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
sleepFlag	Specifies whether the process can sleep

Description

Returns 0 for success, >0 for handshake failure <0 for fw upload failure.

Remark

If bound IOC and a successful FWUpload was performed on the bound IOC, the second image is discarded and memory is free'd. Both channels must upload to prevent IOC from running in degraded mode.

Name

mpt_downloadboot — DownloadBoot code

Synopsis

```
int mpt_downloadboot (MPT_ADAPTER * ioc, MpiFwHeader_t * pFwHeader, int
sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
pFwHeader	Pointer to firmware header info
sleepFlag	Specifies whether the process can sleep

Description

FwDownloadBoot requires Programmed IO access.

Returns 0 for success -1 FW Image size is 0 -2 No valid cached_fw Pointer <0 for fw upload failure.

Name

KickStart — Perform hard reset of MPT adapter.

Synopsis

```
int KickStart (MPT_ADAPTER * ioc, int force, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
force	Force hard reset
sleepFlag	Specifies whether the process can sleep

Description

This routine places MPT adapter in diagnostic mode via the WriteSequence register, and then performs a hard reset of adapter via the Diagnostic register.

Inputs

sleepflag - CAN_SLEEP (non-interrupt thread) or NO_SLEEP (interrupt thread, use mdelay) force - 1 if doorbell active, board fault state board operational, IOC_RECOVERY or IOC_BRINGUP and there is an alt_ioc. 0 else

Returns

1 - hard reset, READY 0 - no reset due to History bit, READY -1 - no reset due to History bit but not READY OR reset but failed to come READY -2 - no reset, could not enter DIAG mode -3 - reset but bad FW bit

Name

mpt_diag_reset — Perform hard reset of the adapter.

Synopsis

```
int mpt_diag_reset (MPT_ADAPTER * ioc, int ignore, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
ignore	Set if to honor and clear to ignore the reset history bit
sleepFlag	CAN_SLEEP if called in a non-interrupt thread, else set to NO_SLEEP (use mdelay instead)

Description

This routine places the adapter in diagnostic mode via the WriteSequence register and then performs a hard reset of adapter via the Diagnostic register. Adapter should be in ready state upon successful completion.

Returns

1 hard reset successful 0 no reset performed because reset history bit set -2 enabling diagnostic mode failed -3 diagnostic reset failed

Name

SendIocReset — Send IOCReset request to MPT adapter.

Synopsis

```
int SendIocReset (MPT_ADAPTER * ioc, u8 reset_type, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
reset_type	reset type, expected values are `MPI_FUNCTION_IOC_MESSAGE_UNIT_RESET` or `MPI_FUNCTION_IO_UNIT_RESET`
sleepFlag	Specifies whether the process can sleep

Description

Send IOCReset request to the MPT adapter.

Returns 0 for success, non-zero for failure.

Name

initChainBuffers — Allocate memory for and initialize chain buffers

Synopsis

```
int initChainBuffers (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Description

Allocates memory for and initializes chain buffers, chain buffer control arrays and spinlock.

Name

PrimeIocFifos — Initialize IOC request and reply FIFOs.

Synopsis

```
int PrimeIocFifos (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Description

This routine allocates memory for the MPT reply and request frame pools (if necessary), and primes the IOC reply FIFO with reply frames.

Returns 0 for success, non-zero for failure.

Name

mpt_handshake_req_reply_wait — Send MPT request to and receive reply from IOC via doorbell handshake method.

Synopsis

```
int mpt_handshake_req_reply_wait (MPT_ADAPTER * ioc, int reqBytes, u32
* req, int replyBytes, u16 * u16reply, int maxwait, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
reqBytes	Size of the request in bytes
req	Pointer to MPT request frame
replyBytes	Expected size of the reply in bytes
u16reply	Pointer to area where reply should be written
maxwait	Max wait time for a reply (in seconds)
sleepFlag	Specifies whether the process can sleep

NOTES

It is the callers responsibility to byte-swap fields in the request which are greater than 1 byte in size. It is also the callers responsibility to byte-swap response fields which are greater than 1 byte in size.

Returns 0 for success, non-zero for failure.

Name

WaitForDoorbellAck — Wait for IOC doorbell handshake acknowledge

Synopsis

```
int WaitForDoorbellAck (MPT_ADAPTER * ioc, int howlong, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
howlong	How long to wait (in seconds)
sleepFlag	Specifies whether the process can sleep

Description

This routine waits (up to ~2 seconds max) for IOC doorbell handshake ACKnowledge, indicated by the IOP_DOORBELL_STATUS bit in its IntStatus register being clear.

Returns a negative value on failure, else wait loop count.

Name

WaitForDoorbellInt — Wait for IOC to set its doorbell interrupt bit

Synopsis

```
int WaitForDoorbellInt (MPT_ADAPTER * ioc, int howlong, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
howlong	How long to wait (in seconds)
sleepFlag	Specifies whether the process can sleep

Description

This routine waits (up to ~2 seconds max) for IOC doorbell interrupt (MPI_HIS_DOORBELL_INTERRUPT) to be set in the IntStatus register.

Returns a negative value on failure, else wait loop count.

Name

WaitForDoorbellReply — Wait for and capture an IOC handshake reply.

Synopsis

```
int WaitForDoorbellReply (MPT_ADAPTER * ioc, int howlong, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
howlong	How long to wait (in seconds)
sleepFlag	Specifies whether the process can sleep

Description

This routine polls the IOC for a handshake reply, 16 bits at a time. Reply is cached to IOC private area large enough to hold a maximum of 128 bytes of reply data.

Returns a negative value on failure, else size of reply in WORDS.

Name

GetLanConfigPages — Fetch LANConfig pages.

Synopsis

```
int GetLanConfigPages (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Return

0 for success -ENOMEM if no memory available -EPERM if not allowed due to ISR context -EAGAIN if no msg frames currently available -EFAULT for non-successful reply or no reply (timeout)

Name

GetIoUnitPage2 — Retrieve BIOS version and boot order information.

Synopsis

```
int GetIoUnitPage2 (MPT_ADAPTER * ioc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

Returns

0 for success -ENOMEM if no memory available -EPERM if not allowed due to ISR context -EAGAIN if no msg frames currently available -EFAULT for non-successful reply or no reply (timeout)

Name

mpt_GetScsiPortSettings — read SCSI Port Page 0 and 2

Synopsis

```
int mpt_GetScsiPortSettings (MPT_ADAPTER * ioc, int portnum);
```

Arguments

ioc Pointer to a Adapter Strucutre

portnum IOC port number

Return

-EFAULT if read of config page header fails or if no nvram If read of SCSI Port Page 0 fails, NVRAM = MPT_HOST_NVRAM_INVALID (0xFFFFFFFF)

Adapter settings

async, narrow Return 1 If read of SCSI Port Page 2 fails, Adapter settings valid NVRAM = MPT_HOST_NVRAM_INVALID (0xFFFFFFFF) Return 1 Else Both valid Return 0 CHECK - what type of locking mechanisms should be used????

Name

mpt_readScsiDevicePageHeaders — save version and length of SDP1

Synopsis

```
int mpt_readScsiDevicePageHeaders (MPT_ADAPTER * ioc, int portnum);
```

Arguments

ioc Pointer to a Adapter Strucutre

portnum IOC port number

Return

-EFAULT if read of config page header fails or 0 if success.

Name

mpt_inactive_raid_list_free — This clears this link list.

Synopsis

```
void mpt_inactive_raid_list_free (MPT_ADAPTER * ioc);
```

Arguments

ioc pointer to per adapter structure

Name

mpt_inactive_raid_volumes — sets up link list of phy_disk_nums for devices belonging in an inactive volume

Synopsis

```
void mpt_inactive_raid_volumes (MPT_ADAPTER * ioc, u8 channel, u8 id);
```

Arguments

ioc	pointer to per adapter structure
channel	volume channel
id	volume target id

Name

SendEventNotification — Send EventNotification (on or off) request to adapter

Synopsis

```
int SendEventNotification (MPT_ADAPTER * ioc, u8 EvSwitch, int sleepFlag);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
EvSwitch	Event switch flags
sleepFlag	Specifies whether the process can sleep

Name

SendEventAck — Send EventAck request to MPT adapter.

Synopsis

```
int SendEventAck (MPT_ADAPTER * ioc, EventNotificationReply_t * evnp);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

evnp Pointer to original EventNotification request

Name

mpt_ioc_reset — Base cleanup for hard reset

Synopsis

```
int mpt_ioc_reset (MPT_ADAPTER * ioc, int reset_phase);
```

Arguments

ioc	Pointer to the adapter structure
reset_phase	Indicates pre- or post-reset functionality

Remark

Frees resources with internally generated commands.

Name

procmpt_create — Create `MPT_PROCFS_MPTBASEDIR` entries.

Synopsis

```
int procmpt_create ( void);
```

Arguments

`void` no arguments

Description

Returns 0 for success, non-zero for failure.

Name

procmpt_destroy — Tear down `MPT_PROCFS_MPTBASEDIR` entries.

Synopsis

```
void procmpt_destroy ( void);
```

Arguments

`void` no arguments

Description

Returns 0 for success, non-zero for failure.

Name

mpt_SoftResetHandler — Issues a less expensive reset

Synopsis

```
int mpt_SoftResetHandler (MPT_ADAPTER * ioc, int sleepFlag);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

sleepFlag Indicates if sleep or schedule must be called.

Description

Returns 0 for SUCCESS or -1 if FAILED.

Message Unit Reset - instructs the IOC to reset the Reply Post and Free FIFO's. All the Message Frames on Reply Free FIFO are discarded. All posted buffers are freed, and event notification is turned off. IOC doesn't reply to any outstanding request. This will transfer IOC to READY state.

Name

ProcessEventNotification — Route EventNotificationReply to all event handlers

Synopsis

```
int      ProcessEventNotification      (MPT_ADAPTER      *      ioc,
EventNotificationReply_t * pEventReply, int * evHandlers);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
pEventReply	Pointer to EventNotification reply frame
evHandlers	Pointer to integer, number of event handlers

Description

Routes a received EventNotificationReply to all currently registered event handlers. Returns sum of event handlers return values.

Name

mpt_fc_log_info — Log information returned from Fibre Channel IOC.

Synopsis

```
void mpt_fc_log_info (MPT_ADAPTER * ioc, u32 log_info);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

log_info U32 LogInfo reply word from the IOC

Description

Refer to lsi/mpi_log_fc.h.

Name

mpt_spi_log_info — Log information returned from SCSI Parallel IOC.

Synopsis

```
void mpt_spi_log_info (MPT_ADAPTER * ioc, u32 log_info);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

log_info U32 LogInfo word from the IOC

Description

Refer to lsi/sp_log.h.

Name

mpt_sas_log_info — Log information returned from SAS IOC.

Synopsis

```
void mpt_sas_log_info (MPT_ADAPTER * ioc, u32 log_info, u8 cb_idx);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
log_info	U32 LogInfo reply word from the IOC
cb_idx	callback function's handle

Description

Refer to lsi/mpi_log_sas.h.

Name

mpt_iocstatus_info_config — IOCSTATUS information for config pages

Synopsis

```
void mpt_iocstatus_info_config (MPT_ADAPTER * ioc, u32 ioc_status,
MPT_FRAME_HDR * mf);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
ioc_status	U32 IOCStatus word from IOC
mf	Pointer to MPT request frame

Description

Refer to lsi/mpi.h.

Name

mpt_iocstatus_info — IOCSTATUS information returned from IOC.

Synopsis

```
void mpt_iocstatus_info (MPT_ADAPTER * ioc, u32 ioc_status,
MPT_FRAME_HDR * mf);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
ioc_status	U32 IOCStatus word from IOC
mf	Pointer to MPT request frame

Description

Refer to lsi/mpi.h.

Name

fusion_init — Fusion MPT base driver initialization routine.

Synopsis

```
int fusion_init ( void);
```

Arguments

void no arguments

Description

Returns 0 for success, non-zero for failure.

Name

fusion_exit — Perform driver unload cleanup.

Synopsis

```
void __exit fusion_exit ( void);
```

Arguments

void no arguments

Description

This routine frees all resources associated with each MPT adapter and removes all `MPT_PROCFS_MPTBASEDIR` entries.

Name

mptscsih_info — Return information about MPT adapter

Synopsis

```
const char * mptscsih_info (struct Scsi_Host * SChost);
```

Arguments

SChost Pointer to Scsi_Host structure

Description

(linux scsi_host_template.info routine)

Returns pointer to buffer where information was written.

Name

mptscsih_qcmd — Primary Fusion MPT SCSI initiator IO start routine.

Synopsis

```
int mptscsih_qcmd (struct scsi_cmnd * SCpnt);
```

Arguments

SCpnt Pointer to scsi_cmnd structure

Description

(linux scsi_host_template.queuecommand routine) This is the primary SCSI IO start routine. Create a MPI SCSIIORequest from a linux scsi_cmnd request and send it to the IOC.

Returns 0. (rtn value discarded by linux scsi mid-layer)

Name

mptscsih_IssueTaskMgmt — Generic send Task Management function.

Synopsis

```
int mptscsih_IssueTaskMgmt (MPT_SCSI_HOST * hd, u8 type, u8 channel, u8
id, u64 lun, int ctx2abort, ulong timeout);
```

Arguments

hd	Pointer to MPT_SCSI_HOST structure
type	Task Management type
channel	channel number for task management
id	Logical Target ID for reset (if appropriate)
lun	Logical Unit for reset (if appropriate)
ctx2abort	Context for the task to be aborted (if appropriate)
timeout	timeout for task management control

Remark

_HardResetHandler can be invoked from an interrupt thread (timer) or a non-interrupt thread. In the former, must not call `schedule`.

Not all fields are meaningfull for all task types.

Returns 0 for SUCCESS, or FAILED.

Name

mptscsih_abort — Abort linux scsi_cmnd routine, new_eh variant

Synopsis

```
int mptscsih_abort (struct scsi_cmnd * SCpnt);
```

Arguments

SCpnt Pointer to scsi_cmnd structure, IO to be aborted

Description

(linux scsi_host_template.eh_abort_handler routine)

Returns SUCCESS or FAILED.

Name

mptscsih_dev_reset — Perform a SCSI TARGET_RESET! new_eh variant

Synopsis

```
int mptscsih_dev_reset (struct scsi_cmnd * SCpnt);
```

Arguments

SCpnt Pointer to scsi_cmnd structure, IO which reset is due to

Description

(linux scsi_host_template.eh_dev_reset_handler routine)

Returns SUCCESS or FAILED.

Name

mptscsih_bus_reset — Perform a SCSI BUS_RESET! new_eh variant

Synopsis

```
int mptscsih_bus_reset (struct scsi_cmnd * SCpnt);
```

Arguments

SCpnt Pointer to scsi_cmnd structure, IO which reset is due to

Description

(linux scsi_host_template.eh_bus_reset_handler routine)

Returns SUCCESS or FAILED.

Name

mptscsih_host_reset — Perform a SCSI host adapter RESET (new_eh variant)

Synopsis

```
int mptscsih_host_reset (struct scsi_cmnd * SCpnt);
```

Arguments

SCpnt Pointer to scsi_cmnd structure, IO which reset is due to

Description

(linux scsi_host_template.eh_host_reset_handler routine)

Returns SUCCESS or FAILED.

Name

mptscsih_taskmgmt_complete — Registered with Fusion MPT base driver

Synopsis

```
int mptscsih_taskmgmt_complete (MPT_ADAPTER * ioc, MPT_FRAME_HDR * mf,
MPT_FRAME_HDR * mr);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

mf Pointer to SCSI task mgmt request frame

mr Pointer to SCSI task mgmt reply frame

Description

This routine is called from mptbase.c::`mpt_interrupt` at the completion of any SCSI task management request. This routine is registered with the MPT (base) driver at driver load/init time via the `mpt_register` API call.

Returns 1 indicating alloc'd request frame ptr should be freed.

Name

mptscsih_get_scsi_lookup — retrieves scmd entry

Synopsis

```
struct scsi_cmnd * mptscsih_get_scsi_lookup (MPT_ADAPTER * ioc, int i);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

i index into the array

Description

Returns the scsi_cmd pointer

Name

mptscsih_info_scsiio — debug print info on reply frame

Synopsis

```
void mptscsih_info_scsiio (MPT_ADAPTER * ioc, struct scsi_cmnd * sc,
SCSIIOReply_t * pScsiReply);
```

Arguments

ioc	Pointer to MPT_ADAPTER structure
sc	original scsi cmnd pointer
pScsiReply	Pointer to MPT reply frame

Description

MPT_DEBUG_REPLY needs to be enabled to obtain this info

Refer to lsi/mpi.h.

Name

mptscsih_getclear_scsi_lookup — retrieves and clears scmd entry from ScsiLookup[] array list

Synopsis

```
struct scsi_cmnd * mptscsih_getclear_scsi_lookup (MPT_ADAPTER * ioc,
int i);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

i index into the array

Description

Returns the scsi_cmd pointer

Name

mptscsih_set_scsi_lookup — write a scmd entry into the ScsiLookup[] array list

Synopsis

```
void mptscsih_set_scsi_lookup (MPT_ADAPTER * ioc, int i, struct scsi_cmnd * scmd);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

i index into the array

scmd scsi_cmnd pointer

Name

SCPNT_TO_LOOKUP_IDX — searches for a given scmd in the ScsiLookup[] array list

Synopsis

```
int SCPNT_TO_LOOKUP_IDX (MPT_ADAPTER * ioc, struct scsi_cmnd * sc);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

sc scsi_cmnd pointer

Name

mptscsih_get_completion_code — get completion code from MPT request

Synopsis

```
int mptscsih_get_completion_code (MPT_ADAPTER * ioc, MPT_FRAME_HDR *
req, MPT_FRAME_HDR * reply);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

req Pointer to original MPT request frame

reply Pointer to MPT reply frame (NULL if TurboReply)

Name

mptscsih_do_cmd — Do internal command.

Synopsis

```
int mptscsih_do_cmd (MPT_SCSI_HOST * hd, INTERNAL_CMD * io);
```

Arguments

hd MPT_SCSI_HOST pointer

io INTERNAL_CMD pointer.

Description

Issue the specified internally generated command and do command specific cleanup. For bus scan / DV only.

NOTES

If command is Inquiry and status is good, initialize a target structure, save the data

Remark

Single threaded access only.

Return

< 0 if an illegal command or no resources

0 if good

> 0 if command complete but some type of completion error.

Name

mptscsih_synchronize_cache — Send SYNCHRONIZE_CACHE to all disks.

Synopsis

```
void mptscsih_synchronize_cache (MPT_SCSI_HOST * hd, VirtDevice * vdevice);
```

Arguments

hd Pointer to a SCSI HOST structure

vdevice virtual target device

Description

Uses the ISR, but with special processing. MUST be single-threaded.

Name

mptctl_syscall_down — Down the MPT adapter syscall semaphore.

Synopsis

```
int mptctl_syscall_down (MPT_ADAPTER * ioc, int nonblock);
```

Arguments

ioc Pointer to MPT adapter

nonblock boolean, non-zero if O_NONBLOCK is set

Description

All of the ioctl commands can potentially sleep, which is illegal with a spinlock held, thus we perform mutual exclusion here.

Returns negative errno on error, or zero for success.

Name

mptspi_setTargetNegoParms — Update the target negotiation parameters

Synopsis

```
void mptspi_setTargetNegoParms (MPT_SCSI_HOST * hd, VirtTarget * target,
struct scsi_device * sdev);
```

Arguments

hd Pointer to a SCSI Host Structure

target per target private data

sdev SCSI device

Description

Update the target negotiation parameters based on the the Inquiry data, adapter capabilities, and NVRAM settings.

Name

mptspi_writeIOCPage4 — write IOC Page 4

Synopsis

```
int mptspi_writeIOCPage4 (MPT_SCSI_HOST * hd, u8 channel, u8 id);
```

Arguments

hd	Pointer to a SCSI Host Structure
channel	channel number
id	write IOC Page4 for this ID & Bus

Return

-EAGAIN if unable to obtain a Message Frame or 0 if success.

Remark

We do not wait for a return, write pages sequentially.

Name

mptspi_initTarget — Target, LUN alloc/free functionality.

Synopsis

```
void mptspi_initTarget (MPT_SCSI_HOST * hd, VirtTarget * vtarget, struct
scsi_device * sdev);
```

Arguments

hd	Pointer to MPT_SCSI_HOST structure
vtarget	per target private data
sdev	SCSI device

NOTE

It's only SAFE to call this routine if data points to sane & valid STANDARD INQUIRY data!

Allocate and initialize memory for this target. Save inquiry data.

Name

mptspi_is_raid — Determines whether target is belonging to volume

Synopsis

```
int mptspi_is_raid (struct _MPT_SCSI_HOST * hd, u32 id);
```

Arguments

hd Pointer to a SCSI HOST structure

id target device id

Return

non-zero = true zero = false

Name

mptspi_print_write_nego — negotiation parameters debug info that is being sent

Synopsis

```
void mptspi_print_write_nego (struct _MPT_SCSI_HOST * hd, struct
scsi_target * starget, u32 ii);
```

Arguments

hd Pointer to a SCSI HOST structure

starget SCSI target

ii negotiation parameters

Name

mptspi_print_read_nego — negotiation parameters debug info that is being read

Synopsis

```
void mptspi_print_read_nego (struct _MPT_SCSI_HOST * hd, struct
scsi_target * starget, u32 ii);
```

Arguments

hd Pointer to a SCSI HOST structure

starget SCSI target

ii negotiation parameters

Name

mptspi_init — Register MPT adapter(s) as SCSI host(s) with SCSI mid-layer.

Synopsis

```
int mptspi_init ( void);
```

Arguments

void no arguments

Description

Returns 0 for success, non-zero for failure.

Name

mptspi_exit — Unregisters MPT adapter(s)

Synopsis

```
void __exit mptspi_exit ( void);
```

Arguments

void no arguments

Name

mptfc_init — Register MPT adapter(s) as SCSI host(s) with SCSI mid-layer.

Synopsis

```
int mptfc_init ( void);
```

Arguments

void no arguments

Description

Returns 0 for success, non-zero for failure.

Name

mptfc_remove — Remove fc infrastructure for devices

Synopsis

```
void mptfc_remove (struct pci_dev * pdev);
```

Arguments

pdev Pointer to pci_dev structure

Name

mptfc_exit — Unregisters MPT adapter(s)

Synopsis

```
void __exit mptfc_exit ( void);
```

Arguments

void no arguments

Name

lan_reply — Handle all data sent from the hardware.

Synopsis

```
int lan_reply (MPT_ADAPTER * ioc, MPT_FRAME_HDR * mf, MPT_FRAME_HDR *
reply);
```

Arguments

ioc Pointer to MPT_ADAPTER structure

mf Pointer to original MPT request frame (NULL if TurboReply)

reply Pointer to MPT reply frame

Description

Returns 1 indicating original alloc'd request frame ptr should be freed, or 0 if it shouldn't.

Chapter 5. Sound Devices

Name

snd_printk — printk wrapper

Synopsis

```
snd_printk ( fmt, args...);
```

Arguments

fmt format string

args... variable arguments

Description

Works like `printk` but prints the file and the line of the caller when configured with CONFIG_SND_VERBOSE_PRINTK.

Name

snd_printd — debug printk

Synopsis

```
snd_printd ( fmt, args...);
```

Arguments

fmt format string

args... variable arguments

Description

Works like `snd_printk` for debugging purposes. Ignored when CONFIG_SND_DEBUG is not set.

Name

snd_BUG — give a BUG warning message and stack trace

Synopsis

```
snd_BUG (void);
```

Arguments

None

Description

Calls `WARN` if CONFIG_SND_DEBUG is set. Ignored when CONFIG_SND_DEBUG is not set.

Name

snd_printd_ratelimit —

Synopsis

```
snd_printd_ratelimit (void);
```

Arguments

None

Name

snd_BUG_ON — debugging check macro

Synopsis

```
snd_BUG_ON ( cond);
```

Arguments

cond condition to evaluate

Description

Has the same behavior as WARN_ON when CONFIG_SND_DEBUG is set, otherwise just evaluates the conditional and returns the value.

Name

snd_printdd — debug printk

Synopsis

```
snd_printdd ( format, args...);
```

Arguments

format format string

args... variable arguments

Description

Works like `snd_printk` for debugging purposes. Ignored when CONFIG_SND_DEBUG_VERBOSE is not set.

Name

register_sound_special_device — register a special sound node

Synopsis

```
int register_sound_special_device (const struct file_operations * fops,
int unit, struct device * dev);
```

Arguments

fops File operations for the driver

unit Unit number to allocate

dev device pointer

Description

Allocate a special sound device by minor number from the sound subsystem.

Return

The allocated number is returned on success. On failure, a negative error code is returned.

Name

register_sound_mixer — register a mixer device

Synopsis

```
int register_sound_mixer (const struct file_operations * fops, int dev);
```

Arguments

fops File operations for the driver

dev Unit number to allocate

Description

Allocate a mixer device. Unit is the number of the mixer requested. Pass -1 to request the next free mixer unit.

Return

On success, the allocated number is returned. On failure, a negative error code is returned.

Name

register_sound_midi — register a midi device

Synopsis

```
int register_sound_midi (const struct file_operations * fops, int dev);
```

Arguments

fops File operations for the driver

dev Unit number to allocate

Description

Allocate a midi device. Unit is the number of the midi device requested. Pass -1 to request the next free midi unit.

Return

On success, the allocated number is returned. On failure, a negative error code is returned.

Name

register_sound_dsp — register a DSP device

Synopsis

```
int register_sound_dsp (const struct file_operations * fops, int dev);
```

Arguments

fops File operations for the driver

dev Unit number to allocate

Description

Allocate a DSP device. Unit is the number of the DSP requested. Pass -1 to request the next free DSP unit.

This function allocates both the audio and dsp device entries together and will always allocate them as a matching pair - eg dsp3/audio3

Return

On success, the allocated number is returned. On failure, a negative error code is returned.

Name

unregister_sound_special — unregister a special sound device

Synopsis

```
void unregister_sound_special (int unit);
```

Arguments

unit unit number to allocate

Description

Release a sound device that was allocated with `register_sound_special`. The unit passed is the return value from the register function.

Name

unregister_sound_mixer — unregister a mixer

Synopsis

```
void unregister_sound_mixer (int unit);
```

Arguments

unit unit number to allocate

Description

Release a sound device that was allocated with `register_sound_mixer`. The unit passed is the return value from the register function.

Name

unregister_sound_midi — unregister a midi device

Synopsis

```
void unregister_sound_midi (int unit);
```

Arguments

unit unit number to allocate

Description

Release a sound device that was allocated with `register_sound_midi`. The unit passed is the return value from the register function.

Name

unregister_sound_dsp — unregister a DSP device

Synopsis

```
void unregister_sound_dsp (int unit);
```

Arguments

unit unit number to allocate

Description

Release a sound device that was allocated with `register_sound_dsp`. The unit passed is the return value from the register function.

Both of the allocated units are released together automatically.

Name

snd_pcm_stream_linked — Check whether the substream is linked with others

Synopsis

```
int snd_pcm_stream_linked (struct snd_pcm_substream * substream);
```

Arguments

substream substream to check

Description

Returns true if the given substream is being linked with others.

Name

snd_pcm_stream_lock_irqsave — Lock the PCM stream

Synopsis

```
snd_pcm_stream_lock_irqsave ( substream, flags);
```

Arguments

substream PCM substream

flags irq flags

Description

This locks the PCM stream like `snd_pcm_stream_lock` but with the local IRQ (only when nonatomic is false). In nonatomic case, this is identical as `snd_pcm_stream_lock`.

Name

snd_pcm_group_for_each_entry — iterate over the linked substreams

Synopsis

```
snd_pcm_group_for_each_entry ( s, substream);
```

Arguments

s	the iterator
substream	the substream

Description

Iterate over the all linked substreams to the given *substream*. When *substream* isn't linked with any others, this gives returns *substream* itself once.

Name

snd_pcm_running — Check whether the substream is in a running state

Synopsis

```
int snd_pcm_running (struct snd_pcm_substream * substream);
```

Arguments

substream substream to check

Description

Returns true if the given substream is in the state RUNNING, or in the state DRAINING for playback.

Name

bytes_to_samples — Unit conversion of the size from bytes to samples

Synopsis

```
ssize_t bytes_to_samples (struct snd_pcm_runtime * runtime, ssize_t size);
```

Arguments

runtime PCM runtime instance

size size in bytes

Name

bytes_to_frames — Unit conversion of the size from bytes to frames

Synopsis

```
snd_pcm_sframes_t bytes_to_frames (struct snd_pcm_runtime * runtime,
ssize_t size);
```

Arguments

runtime PCM runtime instance

size size in bytes

Name

samples_to_bytes — Unit conversion of the size from samples to bytes

Synopsis

```
ssize_t samples_to_bytes (struct snd_pcm_runtime * runtime, ssize_t size);
```

Arguments

runtime PCM runtime instance

size size in samples

Name

frames_to_bytes — Unit conversion of the size from frames to bytes

Synopsis

```
ssize_t frames_to_bytes (struct snd_pcm_runtime * runtime,
snd_pcm_sframes_t size);
```

Arguments

runtime PCM runtime instance

size size in frames

Name

frame_aligned — Check whether the byte size is aligned to frames

Synopsis

```
int frame_aligned (struct snd_pcm_runtime * runtime, ssize_t bytes);
```

Arguments

runtime PCM runtime instance

bytes size in bytes

Name

snd_pcm_lib_buffer_bytes — Get the buffer size of the current PCM in bytes

Synopsis

```
size_t snd_pcm_lib_buffer_bytes (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Name

snd_pcm_lib_period_bytes — Get the period size of the current PCM in bytes

Synopsis

```
size_t snd_pcm_lib_period_bytes (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Name

snd_pcm_playback_avail — Get the available (writable) space for playback

Synopsis

```
snd_pcm_uframes_t snd_pcm_playback_avail (struct snd_pcm_runtime * runtime);
```

Arguments

runtime PCM runtime instance

Description

Result is between 0 ... (boundary - 1)

Name

snd_pcm_capture_avail — Get the available (readable) space for capture

Synopsis

```
snd_pcm_uframes_t snd_pcm_capture_avail (struct snd_pcm_runtime * runtime);
```

Arguments

runtime PCM runtime instance

Description

Result is between 0 ... (boundary - 1)

Name

snd_pcm_playback_hw_avail — Get the queued space for playback

Synopsis

```
snd_pcm_sframes_t snd_pcm_playback_hw_avail (struct snd_pcm_runtime *
runtime);
```

Arguments

runtime PCM runtime instance

Name

snd_pcm_capture_hw_avail — Get the free space for capture

Synopsis

```
snd_pcm_sframes_t snd_pcm_capture_hw_avail (struct snd_pcm_runtime *
runtime);
```

Arguments

runtime PCM runtime instance

Name

snd_pcm_playback_ready — check whether the playback buffer is available

Synopsis

```
int snd_pcm_playback_ready (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

Checks whether enough free space is available on the playback buffer.

Return

Non-zero if available, or zero if not.

Name

snd_pcm_capture_ready — check whether the capture buffer is available

Synopsis

```
int snd_pcm_capture_ready (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

Checks whether enough capture data is available on the capture buffer.

Return

Non-zero if available, or zero if not.

Name

snd_pcm_playback_data — check whether any data exists on the playback buffer

Synopsis

```
int snd_pcm_playback_data (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

Checks whether any data exists on the playback buffer.

Return

Non-zero if any data exists, or zero if not. If stop_threshold is bigger or equal to boundary, then this function returns always non-zero.

Name

snd_pcm_playback_empty — check whether the playback buffer is empty

Synopsis

```
int snd_pcm_playback_empty (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

Checks whether the playback buffer is empty.

Return

Non-zero if empty, or zero if not.

Name

snd_pcm_capture_empty — check whether the capture buffer is empty

Synopsis

```
int snd_pcm_capture_empty (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

Checks whether the capture buffer is empty.

Return

Non-zero if empty, or zero if not.

Name

snd_pcm_trigger_done — Mark the master substream

Synopsis

```
void snd_pcm_trigger_done (struct snd_pcm_substream * substream, struct
snd_pcm_substream * master);
```

Arguments

substream the pcm substream instance

master the linked master substream

Description

When multiple substreams of the same card are linked and the hardware supports the single-shot operation, the driver calls this in the loop in `snd_pcm_group_for_each_entry` for marking the substream as “done”. Then most of trigger operations are performed only to the given master substream.

The trigger_master mark is cleared at timestamp updates at the end of trigger operations.

Name

params_channels — Get the number of channels from the hw params

Synopsis

```
unsigned int params_channels (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

params_rate — Get the sample rate from the hw params

Synopsis

```
unsigned int params_rate (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

params_period_size — Get the period size (in frames) from the hw params

Synopsis

```
unsigned int params_period_size (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

params_periods — Get the number of periods from the hw params

Synopsis

```
unsigned int params_periods (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

params_buffer_size — Get the buffer size (in frames) from the hw params

Synopsis

```
unsigned int params_buffer_size (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

params_buffer_bytes — Get the buffer size (in bytes) from the hw params

Synopsis

```
unsigned int params_buffer_bytes (const struct snd_pcm_hw_params * p);
```

Arguments

p hw params

Name

snd_pcm_hw_constraint_single — Constrain parameter to a single value

Synopsis

```
int snd_pcm_hw_constraint_single (struct snd_pcm_runtime * runtime,
snd_pcm_hw_param_t var, unsigned int val);
```

Arguments

runtime PCM runtime instance

var The hw_params variable to constrain

val The value to constrain to

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_pcm_format_cpu_endian — Check the PCM format is CPU-endian

Synopsis

```
int snd_pcm_format_cpu_endian (snd_pcm_format_t format);
```

Arguments

format the format to check

Return

1 if the given PCM format is CPU-endian, 0 if opposite, or a negative error code if endian not specified.

Name

snd_pcm_set_runtime_buffer — Set the PCM runtime buffer

Synopsis

```
void snd_pcm_set_runtime_buffer (struct snd_pcm_substream * substream,
struct snd_dma_buffer * bufp);
```

Arguments

substream PCM substream to set

bufp the buffer information, NULL to clear

Description

Copy the buffer information to runtime->dma_buffer when *bufp* is non-NULL. Otherwise it clears the current buffer information.

Name

snd_pcm_gettime — Fill the timespec depending on the timestamp mode

Synopsis

```
void snd_pcm_gettime (struct snd_pcm_runtime * runtime, struct timespec
* tv);
```

Arguments

runtime PCM runtime instance

tv timespec to fill

Name

snd_pcm_lib_alloc_vmalloc_buffer — allocate virtual DMA buffer

Synopsis

```
int snd_pcm_lib_alloc_vmalloc_buffer (struct snd_pcm_substream * substream, size_t size);
```

Arguments

substream the substream to allocate the buffer to

size the requested buffer size, in bytes

Description

Allocates the PCM substream buffer using `vmalloc`, i.e., the memory is contiguous in kernel virtual space, but not in physical memory. Use this if the buffer is accessed by kernel code but not by device DMA.

Return

1 if the buffer was changed, 0 if not changed, or a negative error code.

Name

snd_pcm_lib_alloc_vmalloc_32_buffer — allocate 32-bit-addressable buffer

Synopsis

```
int snd_pcm_lib_alloc_vmalloc_32_buffer (struct snd_pcm_substream * substream, size_t size);
```

Arguments

substream the substream to allocate the buffer to

size the requested buffer size, in bytes

Description

This function works like `snd_pcm_lib_alloc_vmalloc_buffer`, but uses `vmalloc_32`, i.e., the pages are allocated from 32-bit-addressable memory.

Return

1 if the buffer was changed, 0 if not changed, or a negative error code.

Name

snd_pcm_sgbuf_get_addr — Get the DMA address at the corresponding offset

Synopsis

```
dma_addr_t snd_pcm_sgbuf_get_addr (struct snd_pcm_substream * substream, unsigned int ofs);
```

Arguments

substream PCM substream

ofs byte offset

Name

snd_pcm_sgbuf_get_ptr — Get the virtual address at the corresponding offset

Synopsis

```
void * snd_pcm_sgbuf_get_ptr (struct snd_pcm_substream * substream,
unsigned int ofs);
```

Arguments

substream PCM substream

ofs byte offset

Name

snd_pcm_sgbuf_get_chunk_size — Compute the max size that fits within the contig. page from the given size

Synopsis

```
unsigned int snd_pcm_sgbuf_get_chunk_size (struct snd_pcm_substream *
substream, unsigned int ofs, unsigned int size);
```

Arguments

substream PCM substream

ofs byte offset

size byte size to examine

Name

snd_pcm_mmap_data_open — increase the mmap counter

Synopsis

```
void snd_pcm_mmap_data_open (struct vm_area_struct * area);
```

Arguments

area VMA

Description

PCM mmap callback should handle this counter properly

Name

snd_pcm_mmap_data_close — decrease the mmap counter

Synopsis

```
void snd_pcm_mmap_data_close (struct vm_area_struct * area);
```

Arguments

area VMA

Description

PCM mmap callback should handle this counter properly

Name

snd_pcm_limit_isa_dma_size — Get the max size fitting with ISA DMA transfer

Synopsis

```
void snd_pcm_limit_isa_dma_size (int dma, size_t * max);
```

Arguments

dma DMA number

max pointer to store the max size

Name

snd_pcm_stream_str — Get a string naming the direction of a stream

Synopsis

```
const char * snd_pcm_stream_str (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Return

A string naming the direction of the stream.

Name

snd_pcm_chmap_substream — get the PCM substream assigned to the given chmap info

Synopsis

```
struct snd_pcm_substream * snd_pcm_chmap_substream (struct
snd_pcm_chmap * info, unsigned int idx);
```

Arguments

info chmap information

idx the substream number index

Name

pcm_format_to_bits — Strong-typed conversion of pcm_format to bitwise

Synopsis

```
u64 pcm_format_to_bits (snd_pcm_format_t pcm_format);
```

Arguments

pcm_format PCM format

Name

snd_pcm_format_name — Return a name string for the given PCM format

Synopsis

```
const char * snd_pcm_format_name (snd_pcm_format_t format);
```

Arguments

format PCM format

Name

snd_pcm_new_stream — create a new PCM stream

Synopsis

```
int snd_pcm_new_stream (struct snd_pcm * pcm, int stream, int substream_count);
```

Arguments

pcm	the pcm instance
stream	the stream direction, SNDRV_PCM_STREAM_XXX
substream_count	the number of substreams

Description

Creates a new stream for the pcm. The corresponding stream on the pcm must have been empty before calling this, i.e. zero must be given to the argument of snd_pcm_new.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_new — create a new PCM instance

Synopsis

```
int snd_pcm_new (struct snd_card * card, const char * id, int device,
int playback_count, int capture_count, struct snd_pcm ** rpcm);
```

Arguments

card	the card instance
id	the id string
device	the device index (zero based)
playback_count	the number of substreams for playback
capture_count	the number of substreams for capture
rpcm	the pointer to store the new pcm instance

Description

Creates a new PCM instance.

The pcm operators have to be set afterwards to the new instance via snd_pcm_set_ops.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_new_internal — create a new internal PCM instance

Synopsis

```
int snd_pcm_new_internal (struct snd_card * card, const char * id, int
device, int playback_count, int capture_count, struct snd_pcm ** rpcm);
```

Arguments

card	the card instance
id	the id string
device	the device index (zero based - shared with normal PCMs)
playback_count	the number of substreams for playback
capture_count	the number of substreams for capture
rpcm	the pointer to store the new pcm instance

Description

Creates a new internal PCM instance with no userspace device or procfs entries. This is used by ASoC Back End PCMs in order to create a PCM that will only be used internally by kernel drivers. i.e. it cannot be opened by userspace. It provides existing ASoC components drivers with a substream and access to any private data.

The pcm operators have to be set afterwards to the new instance via `snd_pcm_set_ops`.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_notify — Add/remove the notify list

Synopsis

```
int snd_pcm_notify (struct snd_pcm_notify * notify, int nfree);
```

Arguments

notify PCM notify list

nfree 0 = register, 1 = unregister

Description

This adds the given notifier to the global list so that the callback is called for each registered PCM devices. This exists only for PCM OSS emulation, so far.

Name

snd_device_new — create an ALSA device component

Synopsis

```
int snd_device_new (struct snd_card * card, enum snd_device_type type,
void * device_data, struct snd_device_ops * ops);
```

Arguments

card	the card instance
type	the device type, SNDRV_DEV_XXX
device_data	the data pointer of this device
ops	the operator table

Description

Creates a new device component for the given data pointer. The device will be assigned to the card and managed together by the card.

The data pointer plays a role as the identifier, too, so the pointer address must be unique and unchanged.

Return

Zero if successful, or a negative error code on failure.

Name

snd_device_disconnect — disconnect the device

Synopsis

```
void snd_device_disconnect (struct snd_card * card, void * device_data);
```

Arguments

card the card instance

device_data the data pointer to disconnect

Description

Turns the device into the disconnection state, invoking dev_disconnect callback, if the device was already registered.

Usually called from `snd_card_disconnect`.

Return

Zero if successful, or a negative error code on failure or if the device not found.

Name

snd_device_free — release the device from the card

Synopsis

```
void snd_device_free (struct snd_card * card, void * device_data);
```

Arguments

card the card instance

device_data the data pointer to release

Description

Removes the device from the list on the card and invokes the callbacks, dev_disconnect and dev_free, corresponding to the state. Then release the device.

Name

snd_device_register — register the device

Synopsis

```
int snd_device_register (struct snd_card * card, void * device_data);
```

Arguments

card the card instance

device_data the data pointer to register

Description

Registers the device which was already created via `snd_device_new`. Usually this is called from `snd_card_register`, but it can be called later if any new devices are created after invocation of `snd_card_register`.

Return

Zero if successful, or a negative error code on failure or if the device not found.

Name

snd_info_get_line — read one line from the procfs buffer

Synopsis

```
int snd_info_get_line (struct snd_info_buffer * buffer, char * line,
int len);
```

Arguments

buffer the procfs buffer

line the buffer to store

len the max. buffer size

Description

Reads one line from the buffer and stores the string.

Return

Zero if successful, or 1 if error or EOF.

Name

snd_info_get_str — parse a string token

Synopsis

```
const char * snd_info_get_str (char * dest, const char * src, int len);
```

Arguments

dest the buffer to store the string token

src the original string

len the max. length of token - 1

Description

Parses the original string and copy a token to the given string buffer.

Return

The updated pointer of the original string so that it can be used for the next call.

Name

snd_info_create_module_entry — create an info entry for the given module

Synopsis

```
struct snd_info_entry * snd_info_create_module_entry (struct module *
module, const char * name, struct snd_info_entry * parent);
```

Arguments

module the module pointer

name the file name

parent the parent directory

Description

Creates a new info entry and assigns it to the given module.

Return

The pointer of the new instance, or NULL on failure.

Name

snd_info_create_card_entry — create an info entry for the given card

Synopsis

```
struct snd_info_entry * snd_info_create_card_entry (struct snd_card *
card, const char * name, struct snd_info_entry * parent);
```

Arguments

card the card instance

name the file name

parent the parent directory

Description

Creates a new info entry and assigns it to the given card.

Return

The pointer of the new instance, or NULL on failure.

Name

snd_info_free_entry — release the info entry

Synopsis

```
void snd_info_free_entry (struct snd_info_entry * entry);
```

Arguments

entry the info entry

Description

Releases the info entry.

Name

snd_info_register — register the info entry

Synopsis

```
int snd_info_register (struct snd_info_entry * entry);
```

Arguments

entry the info entry

Description

Registers the proc info entry.

Return

Zero if successful, or a negative error code on failure.

Name

snd_rawmidi_receive — receive the input data from the device

Synopsis

```
int snd_rawmidi_receive (struct snd_rawmidi_substream * substream, const
unsigned char * buffer, int count);
```

Arguments

substream	the rawmidi substream
buffer	the buffer pointer
count	the data size to read

Description

Reads the data from the internal buffer.

Return

The size of read data, or a negative error code on failure.

Name

snd_rawmidi_transmit_empty — check whether the output buffer is empty

Synopsis

```
int snd_rawmidi_transmit_empty (struct snd_rawmidi_substream * substream);
```

Arguments

substream the rawmidi substream

Return

1 if the internal output buffer is empty, 0 if not.

Name

__snd_rawmidi_transmit_peek — copy data from the internal buffer

Synopsis

```
int __snd_rawmidi_transmit_peek (struct snd_rawmidi_substream * substream, unsigned char * buffer, int count);
```

Arguments

substream	the rawmidi substream
buffer	the buffer pointer
count	data size to transfer

Description

This is a variant of `snd_rawmidi_transmit_peek` without spinlock.

Name

snd_rawmidi_transmit_peek — copy data from the internal buffer

Synopsis

```
int snd_rawmidi_transmit_peek (struct snd_rawmidi_substream * substream, unsigned char * buffer, int count);
```

Arguments

substream the rawmidi substream

buffer the buffer pointer

count data size to transfer

Description

Copies data from the internal output buffer to the given buffer.

Call this in the interrupt handler when the midi output is ready, and call `snd_rawmidi_transmit_ack` after the transmission is finished.

Return

The size of copied data, or a negative error code on failure.

Name

__snd_rawmidi_transmit_ack — acknowledge the transmission

Synopsis

```
int __snd_rawmidi_transmit_ack (struct snd_rawmidi_substream *
substream, int count);
```

Arguments

substream the rawmidi substream

count the transferred count

Description

This is a variant of `__snd_rawmidi_transmit_ack` without spinlock.

Name

snd_rawmidi_transmit_ack — acknowledge the transmission

Synopsis

```
int snd_rawmidi_transmit_ack (struct snd_rawmidi_substream * substream,
int count);
```

Arguments

substream the rawmidi substream

count the transferred count

Description

Advances the hardware pointer for the internal output buffer with the given size and updates the condition. Call after the transmission is finished.

Return

The advanced size if successful, or a negative error code on failure.

Name

snd_rawmidi_transmit — copy from the buffer to the device

Synopsis

```
int snd_rawmidi_transmit (struct snd_rawmidi_substream * substream,
unsigned char * buffer, int count);
```

Arguments

substream	the rawmidi substream
buffer	the buffer pointer
count	the data size to transfer

Description

Copies data from the buffer to the device and advances the pointer.

Return

The copied size if successful, or a negative error code on failure.

Name

snd_rawmidi_new — create a rawmidi instance

Synopsis

```
int snd_rawmidi_new (struct snd_card * card, char * id, int device, int
output_count, int input_count, struct snd_rawmidi ** rrawmidi);
```

Arguments

card	the card instance
id	the id string
device	the device index
output_count	the number of output streams
input_count	the number of input streams
rrawmidi	the pointer to store the new rawmidi instance

Description

Creates a new rawmidi instance. Use `snd_rawmidi_set_ops` to set the operators to the new instance.

Return

Zero if successful, or a negative error code on failure.

Name

snd_rawmidi_set_ops — set the rawmidi operators

Synopsis

```
void snd_rawmidi_set_ops (struct snd_rawmidi * rmidi, int stream, struct
snd_rawmidi_ops * ops);
```

Arguments

rmidi the rawmidi instance

stream the stream direction, SNDRV_RAWMIDI_STREAM_XXX

ops the operator table

Description

Sets the rawmidi operators for the given stream direction.

Name

snd_request_card — try to load the card module

Synopsis

```
void snd_request_card (int card);
```

Arguments

card the card number

Description

Tries to load the module “snd-card-X” for the given card number via request_module. Returns immediately if already loaded.

Name

snd_lookup_minor_data — get user data of a registered device

Synopsis

```
void * snd_lookup_minor_data (unsigned int minor, int type);
```

Arguments

minor the minor number

type device type (SNDRV_DEVICE_TYPE_XXX)

Description

Checks that a minor device with the specified type is registered, and returns its user data pointer.

This function increments the reference counter of the card instance if an associated instance with the given minor number and type is found. The caller must call `snd_card_unref` appropriately later.

Return

The user data pointer if the specified device is found. `NULL` otherwise.

Name

snd_register_device — Register the ALSA device file for the card

Synopsis

```
int snd_register_device (int type, struct snd_card * card, int dev,
const struct file_operations * f_ops, void * private_data, struct device
* device);
```

Arguments

type	the device type, SNDRV_DEVICE_TYPE_XXX
card	the card instance
dev	the device index
f_ops	the file operations
private_data	user pointer for f_ops->open
device	the device to register

Description

Registers an ALSA device file for the given card. The operators have to be set in reg parameter.

Return

Zero if successful, or a negative error code on failure.

Name

snd_unregister_device — unregister the device on the given card

Synopsis

```
int snd_unregister_device (struct device * dev);
```

Arguments

dev the device instance

Description

Unregisters the device file already registered via `snd_register_device`.

Return

Zero if successful, or a negative error code on failure.

Name

copy_to_user_fromio — copy data from mmio-space to user-space

Synopsis

```
int copy_to_user_fromio (void __user * dst, const volatile void __iomem
* src, size_t count);
```

Arguments

dst the destination pointer on user-space

src the source pointer on mmio

count the data size to copy in bytes

Description

Copies the data from mmio-space to user-space.

Return

Zero if successful, or non-zero on failure.

Name

copy_from_user_toio — copy data from user-space to mmio-space

Synopsis

```
int copy_from_user_toio (volatile void __iomem * dst, const void __user
* src, size_t count);
```

Arguments

dst the destination pointer on mmio-space

src the source pointer on user-space

count the data size to copy in bytes

Description

Copies the data from user-space to mmio-space.

Return

Zero if successful, or non-zero on failure.

Name

snd_pcm_lib_preallocate_free_for_all — release all pre-allocated buffers on the pcm

Synopsis

```
int snd_pcm_lib_preallocate_free_for_all (struct snd_pcm * pcm);
```

Arguments

pcm the pcm instance

Description

Releases all the pre-allocated buffers on the given pcm.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_lib_preallocate_pages — pre-allocation for the given DMA type

Synopsis

```
int snd_pcm_lib_preallocate_pages (struct snd_pcm_substream * substream, int type, struct device * data, size_t size, size_t max);
```

Arguments

substream	the pcm substream instance
type	DMA type (SNDRV_DMA_TYPE_*)
data	DMA type dependent data
size	the requested pre-allocation size in bytes
max	the max. allowed pre-allocation size

Description

Do pre-allocation for the given DMA buffer type.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_lib_preallocate_pages_for_all — pre-allocation for continuous memory type (all substreams)

Synopsis

```
int snd_pcm_lib_preallocate_pages_for_all (struct snd_pcm * pcm, int type, void * data, size_t size, size_t max);
```

Arguments

pcm the pcm instance

type DMA type (SNDRV_DMA_TYPE_*)

data DMA type dependent data

size the requested pre-allocation size in bytes

max the max. allowed pre-allocation size

Description

Do pre-allocation to all substreams of the given pcm for the specified DMA type.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_sgbuf_ops_page — get the page struct at the given offset

Synopsis

```
struct page * snd_pcm_sgbuf_ops_page (struct snd_pcm_substream *
substream, unsigned long offset);
```

Arguments

substream the pcm substream instance

offset the buffer offset

Description

Used as the page callback of PCM ops.

Return

The page struct at the given buffer offset. NULL on failure.

Name

snd_pcm_lib_malloc_pages — allocate the DMA buffer

Synopsis

```
int snd_pcm_lib_malloc_pages (struct snd_pcm_substream * substream,
size_t size);
```

Arguments

substream the substream to allocate the DMA buffer to

size the requested buffer size in bytes

Description

Allocates the DMA buffer on the BUS type given earlier to `snd_pcm_lib_preallocate_xxx_pages`.

Return

1 if the buffer is changed, 0 if not changed, or a negative code on failure.

Name

snd_pcm_lib_free_pages — release the allocated DMA buffer.

Synopsis

```
int snd_pcm_lib_free_pages (struct snd_pcm_substream * substream);
```

Arguments

substream the substream to release the DMA buffer

Description

Releases the DMA buffer allocated via `snd_pcm_lib_malloc_pages`.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_lib_free_vmalloc_buffer — free vmalloc buffer

Synopsis

```
int snd_pcm_lib_free_vmalloc_buffer (struct snd_pcm_substream * substream);
```

Arguments

substream the substream with a buffer allocated by `snd_pcm_lib_alloc_vmalloc_buffer`

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_lib_get_vmalloc_page — map vmalloc buffer offset to page struct

Synopsis

```
struct page * snd_pcm_lib_get_vmalloc_page (struct snd_pcm_substream *
substream, unsigned long offset);
```

Arguments

substream the substream with a buffer allocated by `snd_pcm_lib_alloc_vmalloc_buffer`

offset offset in the buffer

Description

This function is to be used as the page callback in the PCM ops.

Return

The page struct, or `NULL` on failure.

Name

snd_device_initialize — Initialize struct device for sound devices

Synopsis

```
void snd_device_initialize (struct device * dev, struct snd_card * card);
```

Arguments

dev device to initialize

card card to assign, optional

Name

snd_card_new — create and initialize a soundcard structure

Synopsis

```
int snd_card_new (struct device * parent, int idx, const char * xid,
struct module * module, int extra_size, struct snd_card ** card_ret);
```

Arguments

parent	the parent device object
idx	card index (address) [0 ... (SNDRV_CARDS-1)]
xid	card identification (ASCII string)
module	top level module for locking
extra_size	allocate this extra size after the main soundcard structure
card_ret	the pointer to store the created card instance

Description

Creates and initializes a soundcard structure.

The function allocates snd_card instance via kzalloc with the given space for the driver to use freely. The allocated struct is stored in the given card_ret pointer.

Return

Zero if successful or a negative error code.

Name

snd_card_disconnect — disconnect all APIs from the file-operations (user space)

Synopsis

```
int snd_card_disconnect (struct snd_card * card);
```

Arguments

card soundcard structure

Description

Disconnects all APIs from the file-operations (user space).

Return

Zero, otherwise a negative error code.

Note

The current implementation replaces all active file->f_op with special dummy file operations (they do nothing except release).

Name

snd_card_free_when_closed — Disconnect the card, free it later eventually

Synopsis

```
int snd_card_free_when_closed (struct snd_card * card);
```

Arguments

card soundcard structure

Description

Unlike `snd_card_free`, this function doesn't try to release the card resource immediately, but tries to disconnect at first. When the card is still in use, the function returns before freeing the resources. The card resources will be freed when the refcount gets to zero.

Name

snd_card_free — frees given soundcard structure

Synopsis

```
int snd_card_free (struct snd_card * card);
```

Arguments

card soundcard structure

Description

This function releases the soundcard structure and the all assigned devices automatically. That is, you don't have to release the devices by yourself.

This function waits until the all resources are properly released.

Return

Zero. Frees all associated devices and frees the control interface associated to given soundcard.

Name

snd_card_set_id — set card identification name

Synopsis

```
void snd_card_set_id (struct snd_card * card, const char * nid);
```

Arguments

card soundcard structure

nid new identification string

Description

This function sets the card identification and checks for name collisions.

Name

snd_card_add_dev_attr — Append a new sysfs attribute group to card

Synopsis

```
int snd_card_add_dev_attr (struct snd_card * card, const struct
attribute_group * group);
```

Arguments

card card instance

group attribute group to append

Name

snd_card_register — register the soundcard

Synopsis

```
int snd_card_register (struct snd_card * card);
```

Arguments

card soundcard structure

Description

This function registers all the devices assigned to the soundcard. Until calling this, the ALSA control interface is blocked from the external accesses. Thus, you should call this function at the end of the initialization of the card.

Return

Zero otherwise a negative error code if the registration failed.

Name

snd_component_add — add a component string

Synopsis

```
int snd_component_add (struct snd_card * card, const char * component);
```

Arguments

card soundcard structure

component the component id string

Description

This function adds the component id string to the supported list. The component can be referred from the alsa-lib.

Return

Zero otherwise a negative error code.

Name

snd_card_file_add — add the file to the file list of the card

Synopsis

```
int snd_card_file_add (struct snd_card * card, struct file * file);
```

Arguments

card soundcard structure

file file pointer

Description

This function adds the file to the file linked-list of the card. This linked-list is used to keep tracking the connection state, and to avoid the release of busy resources by hotplug.

Return

zero or a negative error code.

Name

snd_card_file_remove — remove the file from the file list

Synopsis

```
int snd_card_file_remove (struct snd_card * card, struct file * file);
```

Arguments

card soundcard structure

file file pointer

Description

This function removes the file formerly added to the card via `snd_card_file_add` function. If all files are removed and `snd_card_free_when_closed` was called beforehand, it processes the pending release of resources.

Return

Zero or a negative error code.

Name

snd_power_wait — wait until the power-state is changed.

Synopsis

```
int snd_power_wait (struct snd_card * card, unsigned int power_state);
```

Arguments

card	soundcard structure
power_state	expected power state

Description

Waits until the power-state is changed.

Return

Zero if successful, or a negative error code.

Note

the power lock must be active before call.

Name

snd_dma_program — program an ISA DMA transfer

Synopsis

```
void snd_dma_program (unsigned long dma, unsigned long addr, unsigned int size, unsigned short mode);
```

Arguments

dma the dma number

addr the physical address of the buffer

size the DMA transfer size

mode the DMA transfer mode, DMA_MODE_XXX

Description

Programs an ISA DMA transfer for the given buffer.

Name

snd_dma_disable — stop the ISA DMA transfer

Synopsis

```
void snd_dma_disable (unsigned long dma);
```

Arguments

dma the dma number

Description

Stops the ISA DMA transfer.

Name

snd_dma_pointer — return the current pointer to DMA transfer buffer in bytes

Synopsis

```
unsigned int snd_dma_pointer (unsigned long dma, unsigned int size);
```

Arguments

dma the dma number

size the dma transfer size

Return

The current pointer in DMA transfer buffer in bytes.

Name

snd_ctl_notify — Send notification to user-space for a control change

Synopsis

```
void snd_ctl_notify (struct snd_card * card, unsigned int mask, struct
snd_ctl_elem_id * id);
```

Arguments

card the card to send notification

mask the event mask, SNDRV_CTL_EVENT_*

id the ctl element id to send notification

Description

This function adds an event record with the given id and mask, appends to the list and wakes up the user-space for notification. This can be called in the atomic context.

Name

snd_ctl_new1 — create a control instance from the template

Synopsis

```
struct snd_kcontrol * snd_ctl_new1 (const struct snd_kcontrol_new *
ncontrol, void * private_data);
```

Arguments

ncontrol the initialization record

private_data the private data to set

Description

Allocates a new struct snd_kcontrol instance and initialize from the given template. When the access field of ncontrol is 0, it's assumed as READWRITE access. When the count field is 0, it's assumes as one.

Return

The pointer of the newly generated instance, or NULL on failure.

Name

snd_ctl_free_one — release the control instance

Synopsis

```
void snd_ctl_free_one (struct snd_kcontrol * kcontrol);
```

Arguments

kcontrol the control instance

Description

Releases the control instance created via snd_ctl_new or snd_ctl_new1. Don't call this after the control was added to the card.

Name

snd_ctl_add — add the control instance to the card

Synopsis

```
int snd_ctl_add (struct snd_card * card, struct snd_kcontrol * kcontrol);
```

Arguments

card the card instance

kcontrol the control instance to add

Description

Adds the control instance created via `snd_ctl_new` or `snd_ctl_new1` to the given card. Assigns also an unique numid used for fast search.

It frees automatically the control which cannot be added.

Return

Zero if successful, or a negative error code on failure.

Name

snd_ctl_replace — replace the control instance of the card

Synopsis

```
int snd_ctl_replace (struct snd_card * card, struct snd_kcontrol *
kcontrol, bool add_on_replace);
```

Arguments

card	the card instance
kcontrol	the control instance to replace
add_on_replace	add the control if not already added

Description

Replaces the given control. If the given control does not exist and the add_on_replace flag is set, the control is added. If the control exists, it is destroyed first.

It frees automatically the control which cannot be added or replaced.

Return

Zero if successful, or a negative error code on failure.

Name

snd_ctl_remove — remove the control from the card and release it

Synopsis

```
int snd_ctl_remove (struct snd_card * card, struct snd_kcontrol * kcontrol);
```

Arguments

card the card instance

kcontrol the control instance to remove

Description

Removes the control from the card and then releases the instance. You don't need to call snd_ctl_free_one. You must be in the write lock - down_write(card->controls_rwsem).

Return

0 if successful, or a negative error code on failure.

Name

snd_ctl_remove_id — remove the control of the given id and release it

Synopsis

```
int snd_ctl_remove_id (struct snd_card * card, struct snd_ctl_elem_id
* id);
```

Arguments

card the card instance

id the control id to remove

Description

Finds the control instance with the given id, removes it from the card list and releases it.

Return

0 if successful, or a negative error code on failure.

Name

snd_ctl_activate_id — activate/inactivate the control of the given id

Synopsis

```
int snd_ctl_activate_id (struct snd_card * card, struct snd_ctl_elem_id
* id, int active);
```

Arguments

card the card instance

id the control id to activate/inactivate

active non-zero to activate

Description

Finds the control instance with the given id, and activate or inactivate the control together with notification, if changed. The given ID data is filled with full information.

Return

0 if unchanged, 1 if changed, or a negative error code on failure.

Name

snd_ctl_rename_id — replace the id of a control on the card

Synopsis

```
int snd_ctl_rename_id (struct snd_card * card, struct snd_ctl_elem_id
* src_id, struct snd_ctl_elem_id * dst_id);
```

Arguments

card the card instance

src_id the old id

dst_id the new id

Description

Finds the control with the old id from the card, and replaces the id with the new one.

Return

Zero if successful, or a negative error code on failure.

Name

snd_ctl_find_numid — find the control instance with the given number-id

Synopsis

```
struct snd_kcontrol * snd_ctl_find_numid (struct snd_card * card,
unsigned int numid);
```

Arguments

card the card instance

numid the number-id to search

Description

Finds the control instance with the given number-id from the card.

The caller must down card->controls_rwsem before calling this function (if the race condition can happen).

Return

The pointer of the instance if found, or NULL if not.

Name

snd_ctl_find_id — find the control instance with the given id

Synopsis

```
struct snd_kcontrol * snd_ctl_find_id (struct snd_card * card, struct
snd_ctl_elem_id * id);
```

Arguments

card the card instance

id the id to search

Description

Finds the control instance with the given id from the card.

The caller must down card->controls_rwsem before calling this function (if the race condition can happen).

Return

The pointer of the instance if found, or NULL if not.

Name

snd_ctl_register_ioctl — register the device-specific control-ioctls

Synopsis

```
int snd_ctl_register_ioctl (snd_kctl_ioctl_func_t fcn);
```

Arguments

fcn ioctl callback function

Description

called from each device manager like pcm.c, hwdep.c, etc.

Name

snd_ctl_register_ioctl_compat — register the device-specific 32bit compat control-ioctls

Synopsis

```
int snd_ctl_register_ioctl_compat (snd_kctl_ioctl_func_t fcn);
```

Arguments

fcn ioctl callback function

Name

snd_ctl_unregister_ioctl — de-register the device-specific control-ioctls

Synopsis

```
int snd_ctl_unregister_ioctl (snd_kctl_ioctl_func_t fcn);
```

Arguments

fcn ioctl callback function to unregister

Name

snd_ctl_unregister_ioctl_compat — de-register the device-specific compat 32bit control-ioctls

Synopsis

```
int snd_ctl_unregister_ioctl_compat (snd_kctl_ioctl_func_t fcn);
```

Arguments

fcn ioctl callback function to unregister

Name

snd_ctl_boolean_mono_info — Helper function for a standard boolean info callback with a mono channel

Synopsis

```
int snd_ctl_boolean_mono_info (struct snd_kcontrol * kcontrol, struct
snd_ctl_elem_info * uinfo);
```

Arguments

kcontrol the kcontrol instance

uinfo info to store

Description

This is a function that can be used as info callback for a standard boolean control with a single mono channel.

Name

snd_ctl_boolean_stereo_info — Helper function for a standard boolean info callback with stereo two channels

Synopsis

```
int snd_ctl_boolean_stereo_info (struct snd_kcontrol * kcontrol, struct snd_ctl_elem_info * uinfo);
```

Arguments

kcontrol the kcontrol instance

uinfo info to store

Description

This is a function that can be used as info callback for a standard boolean control with stereo two channels.

Name

snd_ctl_enum_info — fills the info structure for an enumerated control

Synopsis

```
int snd_ctl_enum_info (struct snd_ctl_elem_info * info, unsigned int channels, unsigned int items, const char *const names[]);
```

Arguments

info	the structure to be filled
channels	the number of the control's channels; often one
items	the number of control values; also the size of *names*
names[]	an array containing the names of all control values

Description

Sets all required fields in *info* to their appropriate values. If the control's accessibility is not the default (readable and writable), the caller has to fill *info*->access.

Return

Zero.

Name

snd_pcm_set_ops — set the PCM operators

Synopsis

```
void snd_pcm_set_ops (struct snd_pcm * pcm, int direction, const struct
snd_pcm_ops * ops);
```

Arguments

pcm	the pcm instance
direction	stream direction, SNDRV_PCM_STREAM_XXX
ops	the operator table

Description

Sets the given PCM operators to the pcm instance.

Name

snd_pcm_set_sync — set the PCM sync id

Synopsis

```
void snd_pcm_set_sync (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream

Description

Sets the PCM sync identifier for the card.

Name

snd_interval_refine — refine the interval value of configurator

Synopsis

```
int snd_interval_refine (struct snd_interval * i, const struct snd_interval * v);
```

Arguments

i the interval value to refine

v the interval value to refer to

Description

Refines the interval value with the reference value. The interval is changed to the range satisfying both intervals. The interval status (min, max, integer, etc.) are evaluated.

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_interval_ratnum — refine the interval value

Synopsis

```
int snd_interval_ratnum (struct snd_interval * i, unsigned int rats_count, const struct snd_ratnum * rats, unsigned int * nump, unsigned int * denp);
```

Arguments

i	interval to refine
rats_count	number of ratnum_t
rats	ratnum_t array
nump	pointer to store the resultant numerator
denp	pointer to store the resultant denominator

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_interval_list — refine the interval value from the list

Synopsis

```
int snd_interval_list (struct snd_interval * i, unsigned int count,
const unsigned int * list, unsigned int mask);
```

Arguments

i the interval value to refine

count the number of elements in the list

list the value list

mask the bit-mask to evaluate

Description

Refines the interval value from the list. When mask is non-zero, only the elements corresponding to bit 1 are evaluated.

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_interval_ranges — refine the interval value from the list of ranges

Synopsis

```
int snd_interval_ranges (struct snd_interval * i, unsigned int count,
const struct snd_interval * ranges, unsigned int mask);
```

Arguments

i	the interval value to refine
count	the number of elements in the list of ranges
ranges	the ranges list
mask	the bit-mask to evaluate

Description

Refines the interval value from the list of ranges. When mask is non-zero, only the elements corresponding to bit 1 are evaluated.

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_pcm_hw_rule_add — add the hw-constraint rule

Synopsis

```
int snd_pcm_hw_rule_add (struct snd_pcm_runtime * runtime, unsigned int cond, int var, snd_pcm_hw_rule_func_t func, void * private, int dep, ...);
```

Arguments

runtime	the pcm runtime instance
cond	condition bits
var	the variable to evaluate
func	the evaluation function
private	the private data pointer passed to function
dep	the dependent variables
...	variable arguments

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_mask64 — apply the given bitmap mask constraint

Synopsis

```
int snd_pcm_hw_constraint_mask64 (struct snd_pcm_runtime * runtime,
snd_pcm_hw_param_t var, u_int64_t mask);
```

Arguments

runtime PCM runtime instance

var hw_params variable to apply the mask

mask the 64bit bitmap mask

Description

Apply the constraint of the given bitmap mask to a 64-bit mask parameter.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_integer — apply an integer constraint to an interval

Synopsis

```
int snd_pcm_hw_constraint_integer (struct snd_pcm_runtime * runtime,
snd_pcm_hw_param_t var);
```

Arguments

runtime PCM runtime instance

var hw_params variable to apply the integer constraint

Description

Apply the constraint of integer to an interval parameter.

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_pcm_hw_constraint_minmax — apply a min/max range constraint to an interval

Synopsis

```
int snd_pcm_hw_constraint_minmax (struct snd_pcm_runtime * runtime,
snd_pcm_hw_param_t var, unsigned int min, unsigned int max);
```

Arguments

runtime PCM runtime instance

var hw_params variable to apply the range

min the minimal value

max the maximal value

Description

Apply the min/max range constraint to an interval parameter.

Return

Positive if the value is changed, zero if it's not changed, or a negative error code.

Name

snd_pcm_hw_constraint_list — apply a list of constraints to a parameter

Synopsis

```
int snd_pcm_hw_constraint_list (struct snd_pcm_runtime * runtime, unsigned int cond, snd_pcm_hw_param_t var, const struct snd_pcm_hw_constraint_list * l);
```

Arguments

runtime	PCM runtime instance
cond	condition bits
var	hw_params variable to apply the list constraint
l	list

Description

Apply the list of constraints to an interval parameter.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_ranges — apply list of range constraints to a parameter

Synopsis

```
int snd_pcm_hw_constraint_ranges (struct snd_pcm_runtime * runtime, unsigned int cond, snd_pcm_hw_param_t var, const struct snd_pcm_hw_constraint_ranges * r);
```

Arguments

runtime PCM runtime instance

cond condition bits

var hw_params variable to apply the list of range constraints

r ranges

Description

Apply the list of range constraints to an interval parameter.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_ratnums — apply ratnums constraint to a parameter

Synopsis

```
int snd_pcm_hw_constraint_ratnums (struct snd_pcm_runtime * runtime, unsigned int cond, snd_pcm_hw_param_t var, const struct snd_pcm_hw_constraint_ratnums * r);
```

Arguments

runtime PCM runtime instance

cond condition bits

var hw_params variable to apply the ratnums constraint

r struct snd_ratnums constriants

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_ratdens — apply ratdens constraint to a parameter

Synopsis

```
int snd_pcm_hw_constraint_ratdens (struct snd_pcm_runtime * runtime, unsigned int cond, snd_pcm_hw_param_t var, const struct snd_pcm_hw_constraint_ratdens * r);
```

Arguments

runtime PCM runtime instance

cond condition bits

var hw_params variable to apply the ratdens constraint

r struct snd_ratdens constriants

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_msbits — add a hw constraint msbits rule

Synopsis

```
int snd_pcm_hw_constraint_msbits (struct snd_pcm_runtime * runtime,
unsigned int cond, unsigned int width, unsigned int msbits);
```

Arguments

runtime PCM runtime instance

cond condition bits

width sample bits width

msbits msbits width

Description

This constraint will set the number of most significant bits (msbits) if a sample format with the specified width has been select. If width is set to 0 the msbits will be set for any sample format with a width larger than the specified msbits.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_step — add a hw constraint step rule

Synopsis

```
int snd_pcm_hw_constraint_step (struct snd_pcm_runtime * runtime,
unsigned int cond, snd_pcm_hw_param_t var, unsigned long step);
```

Arguments

runtime PCM runtime instance

cond condition bits

var hw_params variable to apply the step constraint

step step size

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_constraint_pow2 — add a hw constraint power-of-2 rule

Synopsis

```
int snd_pcm_hw_constraint_pow2 (struct snd_pcm_runtime * runtime,
unsigned int cond, snd_pcm_hw_param_t var);
```

Arguments

runtime PCM runtime instance

cond condition bits

var hw_params variable to apply the power-of-2 constraint

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_rule_noresample — add a rule to allow disabling hw resampling

Synopsis

```
int snd_pcm_hw_rule_noresample (struct snd_pcm_runtime * runtime,
unsigned int base_rate);
```

Arguments

runtime PCM runtime instance

base_rate the rate at which the hardware does not resample

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_hw_param_value — return *params* field *var* value

Synopsis

```
int snd_pcm_hw_param_value (const struct snd_pcm_hw_params * params,
snd_pcm_hw_param_t var, int * dir);
```

Arguments

params the hw_params instance

var parameter to retrieve

dir pointer to the direction (-1,0,1) or NULL

Return

The value for field *var* if it's fixed in configuration space defined by *params*. -EINVAL otherwise.

Name

snd_pcm_hw_param_first — refine config space and return minimum value

Synopsis

```
int snd_pcm_hw_param_first (struct snd_pcm_substream * pcm, struct snd_pcm_hw_params * params, snd_pcm_hw_param_t var, int * dir);
```

Arguments

pcm	PCM instance
params	the hw_params instance
var	parameter to retrieve
dir	pointer to the direction (-1,0,1) or NULL

Description

Inside configuration space defined by *params* remove from *var* all values > minimum. Reduce configuration space accordingly.

Return

The minimum, or a negative error code on failure.

Name

snd_pcm_hw_param_last — refine config space and return maximum value

Synopsis

```
int snd_pcm_hw_param_last (struct snd_pcm_substream * pcm, struct snd_pcm_hw_params * params, snd_pcm_hw_param_t var, int * dir);
```

Arguments

pcm PCM instance

params the hw_params instance

var parameter to retrieve

dir pointer to the direction (-1,0,1) or NULL

Description

Inside configuration space defined by *params* remove from *var* all values < maximum. Reduce configuration space accordingly.

Return

The maximum, or a negative error code on failure.

Name

snd_pcm_lib_ioctl — a generic PCM ioctl callback

Synopsis

```
int snd_pcm_lib_ioctl (struct snd_pcm_substream * substream, unsigned
int cmd, void * arg);
```

Arguments

substream	the pcm substream instance
cmd	ioctl command
arg	ioctl argument

Description

Processes the generic ioctl commands for PCM. Can be passed as the ioctl callback for PCM ops.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_period_elapsed — update the pcm status for the next period

Synopsis

```
void snd_pcm_period_elapsed (struct snd_pcm_substream * substream);
```

Arguments

substream the pcm substream instance

Description

This function is called from the interrupt handler when the PCM has processed the period size. It will update the current pointer, wake up sleepers, etc.

Even if more than one periods have elapsed since the last call, you have to call this only once.

Name

snd_pcm_add_chmap_ctls — create channel-mapping control elements

Synopsis

```
int snd_pcm_add_chmap_ctls (struct snd_pcm * pcm, int stream, const
struct snd_pcm_chmap_elem * chmap, int max_channels, unsigned long
private_value, struct snd_pcm_chmap ** info_ret);
```

Arguments

pcm	the assigned PCM instance
stream	stream direction
chmap	channel map elements (for query)
max_channels	the max number of channels for the stream
private_value	the value passed to each kcontrol's private_value field
info_ret	store struct snd_pcm_chmap instance if non-NULL

Description

Create channel-mapping control elements assigned to the given PCM stream(s).

Return

Zero if successful, or a negative error value.

Name

snd_hwdep_new — create a new hwdep instance

Synopsis

```
int snd_hwdep_new (struct snd_card * card, char * id, int device, struct
snd_hwdep ** rhwdep);
```

Arguments

card the card instance

id the id string

device the device index (zero-based)

rhwdep the pointer to store the new hwdep instance

Description

Creates a new hwdep instance with the given index on the card. The callbacks (hwdep->ops) must be set on the returned instance after this call manually by the caller.

Return

Zero if successful, or a negative error code on failure.

Name

snd_pcm_stream_lock — Lock the PCM stream

Synopsis

```
void snd_pcm_stream_lock (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Description

This locks the PCM stream's spinlock or mutex depending on the nonatomic flag of the given substream. This also takes the global link rw lock (or rw sem), too, for avoiding the race with linked streams.

Name

snd_pcm_stream_unlock — Unlock the PCM stream

Synopsis

```
void snd_pcm_stream_unlock (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Description

This unlocks the PCM stream that has been locked via `snd_pcm_stream_lock`.

Name

snd_pcm_stream_lock_irq — Lock the PCM stream

Synopsis

```
void snd_pcm_stream_lock_irq (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Description

This locks the PCM stream like `snd_pcm_stream_lock` and disables the local IRQ (only when nonatomic is false). In nonatomic case, this is identical as `snd_pcm_stream_lock`.

Name

snd_pcm_stream_unlock_irq — Unlock the PCM stream

Synopsis

```
void snd_pcm_stream_unlock_irq (struct snd_pcm_substream * substream);
```

Arguments

substream PCM substream

Description

This is a counter-part of `snd_pcm_stream_lock_irq`.

Name

snd_pcm_stream_unlock_irqrestore — Unlock the PCM stream

Synopsis

```
void snd_pcm_stream_unlock_irqrestore (struct snd_pcm_substream * substream, unsigned long flags);
```

Arguments

substream PCM substream

flags irq flags

Description

This is a counter-part of `snd_pcm_stream_lock_irqsave`.

Name

snd_pcm_stop — try to stop all running streams in the substream group

Synopsis

```
int snd_pcm_stop (struct snd_pcm_substream * substream, snd_pcm_state_t state);
```

Arguments

substream the PCM substream instance

state PCM state after stopping the stream

Description

The state of each stream is then changed to the given state unconditionally.

Return

Zero if successful, or a negative error code.

Name

snd_pcm_stop_xrun — stop the running streams as XRUN

Synopsis

```
int snd_pcm_stop_xrun (struct snd_pcm_substream * substream);
```

Arguments

substream the PCM substream instance

Description

This stops the given running substream (and all linked substreams) as XRUN. Unlike `snd_pcm_stop`, this function takes the substream lock by itself.

Return

Zero if successful, or a negative error code.

Name

snd_pcm_suspend — trigger SUSPEND to all linked streams

Synopsis

```
int snd_pcm_suspend (struct snd_pcm_substream * substream);
```

Arguments

substream the PCM substream

Description

After this call, all streams are changed to SUSPENDED state.

Return

Zero if successful (or *substream* is NULL), or a negative error code.

Name

snd_pcm_suspend_all — trigger SUSPEND to all substreams in the given pcm

Synopsis

```
int snd_pcm_suspend_all (struct snd_pcm * pcm);
```

Arguments

pcm the PCM instance

Description

After this call, all streams are changed to SUSPENDED state.

Return

Zero if successful (or *pcm* is NULL), or a negative error code.

Name

snd_pcm_lib_default_mmap — Default PCM data mmap function

Synopsis

```
int snd_pcm_lib_default_mmap (struct snd_pcm_substream * substream,
struct vm_area_struct * area);
```

Arguments

substream PCM substream

area VMA

Description

This is the default mmap handler for PCM data. When mmap pcm_ops is NULL, this function is invoked implicitly.

Name

snd_pcm_lib_mmap_iomem — Default PCM data mmap function for I/O mem

Synopsis

```
int snd_pcm_lib_mmap_iomem (struct snd_pcm_substream * substream, struct
vm_area_struct * area);
```

Arguments

substream PCM substream

area VMA

Description

When your hardware uses the iomapped pages as the hardware buffer and wants to mmap it, pass this function as mmap pcm_ops. Note that this is supposed to work only on limited architectures.

Name

snd_malloc_pages — allocate pages with the given size

Synopsis

```
void * snd_malloc_pages (size_t size, gfp_t gfp_flags);
```

Arguments

size	the size to allocate in bytes
gfp_flags	the allocation conditions, GFP_XXX

Description

Allocates the physically contiguous pages with the given size.

Return

The pointer of the buffer, or NULL if no enough memory.

Name

snd_free_pages — release the pages

Synopsis

```
void snd_free_pages (void * ptr, size_t size);
```

Arguments

ptr the buffer pointer to release

size the allocated buffer size

Description

Releases the buffer allocated via `snd_malloc_pages`.

Name

snd_dma_alloc_pages — allocate the buffer area according to the given type

Synopsis

```
int snd_dma_alloc_pages (int type, struct device * device, size_t size,
struct snd_dma_buffer * dmab);
```

Arguments

type the DMA buffer type

device the device pointer

size the buffer size to allocate

dmab buffer allocation record to store the allocated data

Description

Calls the memory-allocator function for the corresponding buffer type.

Return

Zero if the buffer with the given size is allocated successfully, otherwise a negative value on error.

Name

snd_dma_alloc_pages_fallback — allocate the buffer area according to the given type with fallback

Synopsis

```
int snd_dma_alloc_pages_fallback (int type, struct device * device,
size_t size, struct snd_dma_buffer * dmab);
```

Arguments

type the DMA buffer type

device the device pointer

size the buffer size to allocate

dmab buffer allocation record to store the allocated data

Description

Calls the memory-allocator function for the corresponding buffer type. When no space is left, this function reduces the size and tries to allocate again. The size actually allocated is stored in res_size argument.

Return

Zero if the buffer with the given size is allocated successfully, otherwise a negative value on error.

Name

snd_dma_free_pages — release the allocated buffer

Synopsis

```
void snd_dma_free_pages (struct snd_dma_buffer * dmab);
```

Arguments

dmab the buffer allocation record to release

Description

Releases the allocated buffer via `snd_dma_alloc_pages`.

Chapter 6. Media Devices

Video2Linux devices

Name

enum tuner_mode — Mode of the tuner

Synopsis

```
enum tuner_mode {
  T_RADIO,
  T_ANALOG_TV
};
```

Constants

T_RADIO	Tuner core will work in radio mode
T_ANALOG_TV	Tuner core will work in analog TV mode

Description

Older boards only had a single tuner device, but some devices have a separate tuner for radio. In any case, the tuner-core needs to know if the tuner chip(s) will be used in radio mode or analog TV mode, as, on radio mode, frequencies are specified on a different range than on TV mode. This enum is used by the tuner core in order to work with the proper tuner range and eventually use a different tuner chip while in radio mode.

Name

struct tuner_setup — setup the tuner chipsets

Synopsis

```
struct tuner_setup {
  unsigned short addr;
  unsigned int type;
  unsigned int mode_mask;
  void * config;
  int (* tuner_callback) (void *dev, int component, int cmd, int arg);
};
```

Members

addr — I2C address used to control the tuner device/chipset

type — Type of the tuner, as defined at the TUNER_* macros. Each different tuner model should have an unique identifier.

mode_mask — Mask with the allowed tuner modes: V4L2_TUNER_RADIO, V4L2_TUNER_ANALOG_TV and/or V4L2_TUNER_DIGITAL_TV, describing if the tuner should be used to support Radio, analog TV and/or digital TV.

config — Used to send tuner-specific configuration for complex tuners that require extra parameters to be set. Only a very few tuners require it and its usage on newer tuners should be avoided.

tuner_callback — Some tuners require to call back the bridge driver, in order to do some tasks like rising a GPIO at the bridge chipset, in order to do things like resetting the device.

Description

Older boards only had a single tuner device. Nowadays multiple tuner devices may be present on a single board. Using TUNER_SET_TYPE_ADDR to pass the tuner_setup structure it is possible to setup each tuner device in turn.

Since multiple devices may be present it is no longer sufficient to send a command to a single i2c device. Instead you should broadcast the command to all i2c devices.

By setting the mode_mask correctly you can select which commands are accepted by a specific tuner device. For example, set mode_mask to T_RADIO if the device is a radio-only tuner. That specific tuner will only accept commands when the tuner is in radio mode and ignore them when the tuner is set to TV mode.

Name

enum param_type — type of the tuner pameters

Synopsis

```
enum param_type {
  TUNER_PARAM_TYPE_RADIO,
  TUNER_PARAM_TYPE_PAL,
  TUNER_PARAM_TYPE_SECAM,
  TUNER_PARAM_TYPE_NTSC,
  TUNER_PARAM_TYPE_DIGITAL
};
```

Constants

TUNER_PARAM_TYPE_RADIO	Tuner params are for FM and/or AM radio
TUNER_PARAM_TYPE_PAL	Tuner params are for PAL color TV standard
TUNER_PARAM_TYPE_SECAM	Tuner params are for SECAM color TV standard
TUNER_PARAM_TYPE_NTSC	Tuner params are for NTSC color TV standard
TUNER_PARAM_TYPE_DIGITAL	Tuner params are for digital TV

Name

struct tuner_range — define the frequencies supported by the tuner

Synopsis

```
struct tuner_range {
  unsigned short limit;
  unsigned char config;
  unsigned char cb;
};
```

Members

limit — Max frequency supported by that range, in 62.5 kHz (TV) or 62.5 Hz (Radio), as defined by V4L2_TUNER_CAP_LOW.

config — Value of the band switch byte (BB) to setup this mode.

cb — Value of the CB byte to setup this mode.

Description

Please notice that digital tuners like xc3028/xc4000/xc5000 don't use those ranges, as they're defined inside the driver. This is used by analog tuners that are compatible with the “Philips way” to setup the tuners. On those devices, the tuner set is done via 4 bytes: divider byte1 (DB1), divider byte 2 (DB2), Control byte (CB) and band switch byte (BB). Some tuners also have an additional optional Auxiliary byte (AB).

Name

struct tuner_params — Parameters to be used to setup the tuner. Those are used by drivers/media/tuners/tuner-types.c in order to specify the tuner properties. Most of the parameters are for tuners based on tda9887 IF-PLL multi-standard analog TV/Radio demodulator, with is very common on legacy analog tuners.

Synopsis

```
struct tuner_params {
  enum param_type type;
  unsigned int cb_first_if_lower_freq:1;
  unsigned int has_tda9887:1;
  unsigned int port1_fm_high_sensitivity:1;
  unsigned int port2_fm_high_sensitivity:1;
  unsigned int fm_gain_normal:1;
  unsigned int intercarrier_mode:1;
  unsigned int port1_active:1;
  unsigned int port2_active:1;
  unsigned int port1_invert_for_secam_lc:1;
  unsigned int port2_invert_for_secam_lc:1;
  unsigned int port1_set_for_fm_mono:1;
  unsigned int default_pll_gating_18:1;
  unsigned int radio_if:2;
  signed int default_top_low:5;
  signed int default_top_mid:5;
  signed int default_top_high:5;
  signed int default_top_secam_low:5;
  signed int default_top_secam_mid:5;
  signed int default_top_secam_high:5;
  u16 iffreq;
  unsigned int count;
  struct tuner_range * ranges;
};
```

Members

type
: Type of the tuner parameters, as defined at enum param_type. If the tuner supports multiple standards, an array should be used, with one row per different standard.

cb_first_if_lower_freq
: Many Philips-based tuners have a comment in their datasheet like “For channel selection involving band switching, and to ensure smooth tuning to the desired channel without causing unnecessary charge pump action, it is recommended to consider the difference between wanted channel frequency and the current channel frequency. Unnecessary charge pump action will result in very low tuning voltage which may drive the oscillator to extreme conditions”. Set cb_first_if_lower_freq to 1, if this check is required for this tuner. I tested this for PAL by first setting the TV frequency to 203 MHz and then switching to 96.6 MHz FM radio. The result was static unless the control byte was sent first.

has_tda9887
: Set to 1 if this tuner uses a tda9887

port1_fm_high_sensitivity	Many Philips tuners use tda9887 PORT1 to select the FM radio sensitivity. If this setting is 1, then set PORT1 to 1 to get proper FM reception.
port2_fm_high_sensitivity	Some Philips tuners use tda9887 PORT2 to select the FM radio sensitivity. If this setting is 1, then set PORT2 to 1 to get proper FM reception.
fm_gain_normal	Some Philips tuners use tda9887 cGainNormal to select the FM radio sensitivity. If this setting is 1, e register will use cGainNormal instead of cGainLow.
intercarrier_mode	Most tuners with a tda9887 use QSS mode. Some (cheaper) tuners use Intercarrier mode. If this setting is 1, then the tuner needs to be set to intercarrier mode.
port1_active	This setting sets the default value for PORT1. 0 means inactive, 1 means active. Note: the actual bit value written to the tda9887 is inverted. So a 0 here means a 1 in the B6 bit.
port2_active	This setting sets the default value for PORT2. 0 means inactive, 1 means active. Note: the actual bit value written to the tda9887 is inverted. So a 0 here means a 1 in the B7 bit.
port1_invert_for_secam_lc	Sometimes PORT1 is inverted when the SECAM-L' standard is selected. Set this bit to 1 if this is needed.
port2_invert_for_secam_lc	Sometimes PORT2 is inverted when the SECAM-L' standard is selected. Set this bit to 1 if this is needed.
port1_set_for_fm_mono	Some cards require PORT1 to be 1 for mono Radio FM and 0 for stereo.
default_pll_gating_18	Select 18% (or according to datasheet 0%) L standard PLL gating, vs the driver default of 36%.
radio_if	IF to use in radio mode. Tuners with a separate radio IF filter seem to use 10.7, while those without use 33.3 for PAL/SECAM tuners and 41.3 for NTSC tuners. 0 = 10.7, 1 = 33.3, 2 = 41.3
default_top_low	Default tda9887 TOP value in dB for the low band. Default is 0. Range: -16:+15
default_top_mid	Default tda9887 TOP value in dB for the mid band. Default is 0. Range: -16:+15
default_top_high	Default tda9887 TOP value in dB for the high band. Default is 0. Range: -16:+15
default_top_secam_low	Default tda9887 TOP value in dB for SECAM-L/L' for the low band. Default is 0. Several tuners require a different TOP value for the SECAM-L/L' standards. Range: -16:+15
default_top_secam_mid	Default tda9887 TOP value in dB for SECAM-L/L' for the mid band. Default is 0. Several tuners require a different TOP value for the SECAM-L/L' standards. Range: -16:+15

default_top_secam_high	Default tda9887 TOP value in dB for SECAM-L/L' for the high band. Default is 0. Several tuners require a different TOP value for the SECAM-L/L' standards. Range: -16:+15
iffreq	Intermediate frequency (IF) used by the tuner on digital mode.
count	Size of the ranges array.
ranges	Array with the frequency ranges supported by the tuner.

Name

enum tveeprom_audio_processor — Specifies the type of audio processor used on a Hauppauge device.

Synopsis

```
enum tveeprom_audio_processor {
  TVEEPROM_AUDPROC_NONE,
  TVEEPROM_AUDPROC_INTERNAL,
  TVEEPROM_AUDPROC_MSP,
  TVEEPROM_AUDPROC_OTHER
};
```

Constants

TVEEPROM_AUDPROC_NONE	No audio processor present
TVEEPROM_AUDPROC_INTERNAL	The audio processor is internal to the video processor
TVEEPROM_AUDPROC_MSP	The audio processor is a MSPXXXX device
TVEEPROM_AUDPROC_OTHER	The audio processor is another device

Name

struct tveeprom — Contains the fields parsed from Hauppauge eeproms

Synopsis

```
struct tveeprom {
  u32 has_radio;
  u32 has_ir;
  u32 has_MAC_address;
  u32 tuner_type;
  u32 tuner_formats;
  u32 tuner_hauppauge_model;
  u32 tuner2_type;
  u32 tuner2_formats;
  u32 tuner2_hauppauge_model;
  u32 audio_processor;
  u32 decoder_processor;
  u32 model;
  u32 revision;
  u32 serial_number;
  char rev_str[5];
  u8 MAC_address[ETH_ALEN];
};
```

Members

has_radio	1 if the device has radio; 0 otherwise.
has_ir	If has_ir == 0, then it is unknown what the IR capabilities are. Otherwise: bit 0) 1 (= IR capabilities are known); bit 1) IR receiver present; bit 2) IR transmitter (blaster) present.
has_MAC_address	0: no MAC, 1: MAC present, 2: unknown.
tuner_type	type of the tuner (TUNER_*, as defined at include/media/tuner.h).
tuner_formats	Supported analog TV standards (V4L2_STD_*).
tuner_hauppauge_model	Hauppauge's code for the device model number.
tuner2_type	type of the second tuner (TUNER_*, as defined at include/media/tuner.h).
tuner2_formats	Tuner 2 supported analog TV standards (V4L2_STD_*).
tuner2_hauppauge_model	tuner 2 Hauppauge's code for the device model number.
audio_processor	analog audio decoder, as defined by enum tveeprom_audio_processor.
decoder_processor	Hauppauge's code for the decoder chipset. Unused by the drivers, as they probe the decoder based on the PCI or USB ID.
model	Hauppauge's model number
revision	Card revision number

serial_number	Card's serial number
rev_str[5]	Card revision converted to number
MAC_address[ETH_ALEN]	MAC address for the network interface

Name

tveeprom_hauppauge_analog — Fill struct tveeprom using the contents of the eeprom previously filled at *eeprom_data* field.

Synopsis

```
void tveeprom_hauppauge_analog (struct i2c_client * c, struct tveeprom
* tvee, unsigned char * eeprom_data);
```

Arguments

c	I2C client struct
tvee	Struct to where the eeprom parsed data will be filled;
eeprom_data	Array with the contents of the eeprom_data. It should contain 256 bytes filled with the contents of the eeprom read from the Hauppauge device.

Name

tveeprom_read — Reads the contents of the eeprom found at the Hauppauge devices.

Synopsis

```
int tveeprom_read (struct i2c_client * c, unsigned char * eedata, int len);
```

Arguments

c I2C client struct

eedata Array where the eeprom content will be stored.

len Size of *eedata* array. If the eeprom content will be latter be parsed by `tveeprom_hauppauge_analog`, len should be, at least, 256.

Name

struct v4l2_async_subdev — sub-device descriptor, as known to a bridge

Synopsis

```
struct v4l2_async_subdev {
  enum v4l2_async_match_type match_type;
  union match;
  struct list_head list;
};
```

Members

match_type	type of match that will be used
match	union of per-bus type matching data sets
list	used to link struct v4l2_async_subdev objects, waiting to be probed, to a notifier->waiting list

Name

struct v4l2_async_notifier — v4l2_device notifier data

Synopsis

```
struct v4l2_async_notifier {
  unsigned int num_subdevs;
  struct v4l2_async_subdev ** subdevs;
  struct v4l2_device * v4l2_dev;
  struct list_head waiting;
  struct list_head done;
  struct list_head list;
  int (* bound) (struct v4l2_async_notifier *notifier,struct v4l2_subdev *subdev,s
  int (* complete) (struct v4l2_async_notifier *notifier);
  void (* unbind) (struct v4l2_async_notifier *notifier,struct v4l2_subdev *subdev
};
```

Members

num_subdevs	number of subdevices
subdevs	array of pointers to subdevice descriptors
v4l2_dev	pointer to struct v4l2_device
waiting	list of struct v4l2_async_subdev, waiting for their drivers
done	list of struct v4l2_subdev, already probed
list	member in a global list of notifiers
bound	a subdevice driver has successfully probed one of subdevices
complete	all subdevices have been probed successfully
unbind	a subdevice is leaving

Name

union v4l2_ctrl_ptr — A pointer to a control value.

Synopsis

```
union v4l2_ctrl_ptr {
  s32 * p_s32;
  s64 * p_s64;
  u8 * p_u8;
  u16 * p_u16;
  u32 * p_u32;
  char * p_char;
  void * p;
};
```

Members

p_s32 Pointer to a 32-bit signed value.

p_s64 Pointer to a 64-bit signed value.

p_u8 Pointer to a 8-bit unsigned value.

p_u16 Pointer to a 16-bit unsigned value.

p_u32 Pointer to a 32-bit unsigned value.

p_char Pointer to a string.

p Pointer to a compound value.

Name

struct v4l2_ctrl_ops — The control operations that the driver has to provide.

Synopsis

```
struct v4l2_ctrl_ops {
  int (* g_volatile_ctrl) (struct v4l2_ctrl *ctrl);
  int (* try_ctrl) (struct v4l2_ctrl *ctrl);
  int (* s_ctrl) (struct v4l2_ctrl *ctrl);
};
```

Members

g_volatile_ctrl	Get a new value for this control. Generally only relevant for volatile (and usually read-only) controls such as a control that returns the current signal strength which changes continuously. If not set, then the currently cached value will be returned.
try_ctrl	Test whether the control's value is valid. Only relevant when the usual min/max/step checks are not sufficient.
s_ctrl	Actually set the new control value. s_ctrl is compulsory. The ctrl->handler->lock is held when these ops are called, so no one else can access controls owned by that handler.

Name

struct v4l2_ctrl_type_ops — The control type operations that the driver has to provide.

Synopsis

```
struct v4l2_ctrl_type_ops {
  bool (* equal) (const struct v4l2_ctrl *ctrl, u32 idx,union v4l2_ctrl_ptr ptr1,u
  void (* init) (const struct v4l2_ctrl *ctrl, u32 idx,union v4l2_ctrl_ptr ptr);
  void (* log) (const struct v4l2_ctrl *ctrl);
  int (* validate) (const struct v4l2_ctrl *ctrl, u32 idx,union v4l2_ctrl_ptr ptr)
};
```

Members

equal	return true if both values are equal.
init	initialize the value.
log	log the value.
validate	validate the value. Return 0 on success and a negative value otherwise.

Name

struct v4l2_ctrl — The control structure.

Synopsis

```
struct v4l2_ctrl {
  struct list_head node;
  struct list_head ev_subs;
  struct v4l2_ctrl_handler * handler;
  struct v4l2_ctrl ** cluster;
  unsigned ncontrols;
  unsigned int done:1;
  unsigned int is_new:1;
  unsigned int has_changed:1;
  unsigned int is_private:1;
  unsigned int is_auto:1;
  unsigned int is_int:1;
  unsigned int is_string:1;
  unsigned int is_ptr:1;
  unsigned int is_array:1;
  unsigned int has_volatiles:1;
  unsigned int call_notify:1;
  unsigned int manual_mode_value:8;
  const struct v4l2_ctrl_ops * ops;
  const struct v4l2_ctrl_type_ops * type_ops;
  u32 id;
  const char * name;
  enum v4l2_ctrl_type type;
  s64 minimum;
  s64 maximum;
  s64 default_value;
  u32 elems;
  u32 elem_size;
  u32 dims[V4L2_CTRL_MAX_DIMS];
  u32 nr_of_dims;
  union cur;
  union v4l2_ctrl_ptr p_new;
  union v4l2_ctrl_ptr p_cur;
};
```

Members

node	The list node.
ev_subs	The list of control event subscriptions.
handler	The handler that owns the control.
cluster	Point to start of cluster array.
ncontrols	Number of controls in cluster array.
done	Internal flag: set for each processed control.

is_new	Set when the user specified a new value for this control. It is also set when called from v4l2_ctrl_handler_setup. Drivers should never set this flag.
has_changed	Set when the current value differs from the new value. Drivers should never use this flag.
is_private	If set, then this control is private to its handler and it will not be added to any other handlers. Drivers can set this flag.
is_auto	If set, then this control selects whether the other cluster members are in 'automatic' mode or 'manual' mode. This is used for autogain/ gain type clusters. Drivers should never set this flag directly.
is_int	If set, then this control has a simple integer value (i.e. it uses ctrl->val).
is_string	If set, then this control has type V4L2_CTRL_TYPE_STRING.
is_ptr	If set, then this control is an array and/or has type >= V4L2_CTRL_COMPOUND_TYPES and/or has type V4L2_CTRL_TYPE_STRING. In other words, struct v4l2_ext_control uses field p to point to the data.
is_array	If set, then this control contains an N-dimensional array.
has_volatiles	If set, then one or more members of the cluster are volatile. Drivers should never touch this flag.
call_notify	If set, then call the handler's notify function whenever the control's value changes.
manual_mode_value	If the is_auto flag is set, then this is the value of the auto control that determines if that control is in manual mode. So if the value of the auto control equals this value, then the whole cluster is in manual mode. Drivers should never set this flag directly.
ops	The control ops.
type_ops	The control type ops.
id	The control ID.
name	The control name.
type	The control type.
minimum	The control's minimum value.
maximum	The control's maximum value.
default_value	The control's default value.
elems	The number of elements in the N-dimensional array.
elem_size	The size in bytes of the control.
dims[V4L2_CTRL_MAX_DIMS]	The size of each dimension.

nr_of_dims	The number of dimensions in *dims*.
cur	The control's current value.
p_new	The control's new value represented via an union with provides a standard way of accessing control types through a pointer.
p_cur	The control's current value represented via an union with provides a standard way of accessing control types through a pointer.

Name

struct v4l2_ctrl_ref — The control reference.

Synopsis

```
struct v4l2_ctrl_ref {
  struct list_head node;
  struct v4l2_ctrl_ref * next;
  struct v4l2_ctrl * ctrl;
  struct v4l2_ctrl_helper * helper;
};
```

Members

node — List node for the sorted list.

next — Single-link list node for the hash.

ctrl — The actual control information.

helper — Pointer to helper struct. Used internally in `prepare_ext_ctrls`.

Description

Each control handler has a list of these refs. The list_head is used to keep a sorted-by-control-ID list of all controls, while the next pointer is used to link the control in the hash's bucket.

Name

struct v4l2_ctrl_handler — The control handler keeps track of all the

Synopsis

```
struct v4l2_ctrl_handler {
  struct mutex _lock;
  struct mutex * lock;
  struct list_head ctrls;
  struct list_head ctrl_refs;
  struct v4l2_ctrl_ref * cached;
  struct v4l2_ctrl_ref ** buckets;
  v4l2_ctrl_notify_fnc notify;
  void * notify_priv;
  u16 nr_of_buckets;
  int error;
};
```

Members

_lock	Default for “lock”.
lock	Lock to control access to this handler and its controls. May be replaced by the user right after init.
ctrls	The list of controls owned by this handler.
ctrl_refs	The list of control references.
cached	The last found control reference. It is common that the same control is needed multiple times, so this is a simple optimization.
buckets	Buckets for the hashing. Allows for quick control lookup.
notify	A notify callback that is called whenever the control changes value. Note that the handler's lock is held when the notify function is called!
notify_priv	Passed as argument to the v4l2_ctrl notify callback.
nr_of_buckets	Total number of buckets in the array.
error	The error code of the first failed control addition.

controls

both the controls owned by the handler and those inherited from other handlers.

Name

struct v4l2_ctrl_config — Control configuration structure.

Synopsis

```
struct v4l2_ctrl_config {
  const struct v4l2_ctrl_ops * ops;
  const struct v4l2_ctrl_type_ops * type_ops;
  u32 id;
  const char * name;
  enum v4l2_ctrl_type type;
  s64 min;
  s64 max;
  u64 step;
  s64 def;
  u32 dims[V4L2_CTRL_MAX_DIMS];
  u32 elem_size;
  u32 flags;
  u64 menu_skip_mask;
  const char *const * qmenu;
  const s64 * qmenu_int;
  unsigned int is_private:1;
};
```

Members

ops	The control ops.
type_ops	The control type ops. Only needed for compound controls.
id	The control ID.
name	The control name.
type	The control type.
min	The control's minimum value.
max	The control's maximum value.
step	The control's step value for non-menu controls.
def	The control's default value.
dims[V4L2_CTRL_MAX_DIMS]	The size of each dimension.
elem_size	The size in bytes of the control.
flags	The control's flags.
menu_skip_mask	The control's skip mask for menu controls. This makes it easy to skip menu items that are not valid. If bit X is set, then menu item X is skipped. Of course, this only works for menus with <= 64 menu items. There are no menus that come close to that number, so this is

	OK. Should we ever need more, then this will have to be extended to a bit array.
qmenu	A const char * array for all menu items. Array entries that are empty strings ("") correspond to non-existing menu items (this is in addition to the menu_skip_mask above). The last entry must be NULL.
qmenu_int	A const s64 integer array for all menu items of the type V4L2_CTRL_TYPE_INTEGER_MENU.
is_private	If set, then this control is private to its handler and it will not be added to any other handlers.

Name

v4l2_ctrl_handler_init_class — Initialize the control handler.

Synopsis

```
int v4l2_ctrl_handler_init_class (struct v4l2_ctrl_handler * hdl, unsigned nr_of_controls_hint, struct lock_class_key * key, const char * name);
```

Arguments

hdl	The control handler.
nr_of_controls_hint	A hint of how many controls this handler is expected to refer to. This is the total number, so including any inherited controls. It doesn't have to be precise, but if it is way off, then you either waste memory (too many buckets are allocated) or the control lookup becomes slower (not enough buckets are allocated, so there are more slow list lookups). It will always work, though.
key	Used by the lock validator if CONFIG_LOCKDEP is set.
name	Used by the lock validator if CONFIG_LOCKDEP is set.

Description

Returns an error if the buckets could not be allocated. This error will also be stored in *hdl*->error.

Never use this call directly, always use the v4l2_ctrl_handler_init macro that hides the *key* and *name* arguments.

Name

v4l2_ctrl_handler_free — Free all controls owned by the handler and free the control list.

Synopsis

```
void v4l2_ctrl_handler_free (struct v4l2_ctrl_handler * hdl);
```

Arguments

hdl The control handler.

Description

Does nothing if *hdl* == NULL.

Name

v4l2_ctrl_lock — Helper function to lock the handler associated with the control.

Synopsis

```
void v4l2_ctrl_lock (struct v4l2_ctrl * ctrl);
```

Arguments

ctrl The control to lock.

Name

v4l2_ctrl_unlock — Helper function to unlock the handler associated with the control.

Synopsis

```
void v4l2_ctrl_unlock (struct v4l2_ctrl * ctrl);
```

Arguments

ctrl The control to unlock.

Name

v4l2_ctrl_handler_setup — Call the s_ctrl op for all controls belonging to the handler to initialize the hardware to the current control values.

Synopsis

```
int v4l2_ctrl_handler_setup (struct v4l2_ctrl_handler * hdl);
```

Arguments

hdl The control handler.

Description

Button controls will be skipped, as are read-only controls.

If *hdl* == NULL, then this just returns 0.

Name

v4l2_ctrl_handler_log_status — Log all controls owned by the handler.

Synopsis

```
void v4l2_ctrl_handler_log_status (struct v4l2_ctrl_handler * hdl, const
char * prefix);
```

Arguments

hdl The control handler.

prefix The prefix to use when logging the control values. If the prefix does not end with a space, then ": " will be added after the prefix. If *prefix* == NULL, then no prefix will be used.

Description

For use with VIDIOC_LOG_STATUS.

Does nothing if *hdl* == NULL.

Name

v4l2_ctrl_new_custom — Allocate and initialize a new custom V4L2 control.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_new_custom (struct v4l2_ctrl_handler * hdl,
const struct v4l2_ctrl_config * cfg, void * priv);
```

Arguments

hdl The control handler.

cfg The control's configuration data.

priv The control's driver-specific private data.

Description

If the v4l2_ctrl struct could not be allocated then NULL is returned and *hdl*->error is set to the error code (if it wasn't set already).

Name

v4l2_ctrl_new_std — Allocate and initialize a new standard V4L2 non-menu control.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_new_std (struct v4l2_ctrl_handler * hdl,
const struct v4l2_ctrl_ops * ops, u32 id, s64 min, s64 max, u64 step,
s64 def);
```

Arguments

hdl The control handler.

ops The control ops.

id The control ID.

min The control's minimum value.

max The control's maximum value.

step The control's step value

def The control's default value.

Description

If the v4l2_ctrl struct could not be allocated, or the control ID is not known, then NULL is returned and *hdl*->error is set to the appropriate error code (if it wasn't set already).

If *id* refers to a menu control, then this function will return NULL.

Use `v4l2_ctrl_new_std_menu` when adding menu controls.

Name

v4l2_ctrl_new_std_menu — Allocate and initialize a new standard V4L2 menu control.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_new_std_menu (struct v4l2_ctrl_handler *
hdl, const struct v4l2_ctrl_ops * ops, u32 id, u8 max, u64 mask, u8 def);
```

Arguments

hdl The control handler.

ops The control ops.

id The control ID.

max The control's maximum value.

mask The control's skip mask for menu controls. This makes it easy to skip menu items that are not valid. If bit X is set, then menu item X is skipped. Of course, this only works for menus with <= 64 menu items. There are no menus that come close to that number, so this is OK. Should we ever need more, then this will have to be extended to a bit array.

def The control's default value.

Description

Same as v4l2_ctrl_new_std, but *min* is set to 0 and the *mask* value determines which menu items are to be skipped.

If *id* refers to a non-menu control, then this function will return NULL.

Name

v4l2_ctrl_new_std_menu_items — Create a new standard V4L2 menu control with driver specific menu.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_new_std_menu_items (struct v4l2_ctrl_handler * hdl, const struct v4l2_ctrl_ops * ops, u32 id, u8 max, u64 mask, u8 def, const char *const * qmenu);
```

Arguments

hdl The control handler.

ops The control ops.

id The control ID.

max The control's maximum value.

mask The control's skip mask for menu controls. This makes it easy to skip menu items that are not valid. If bit X is set, then menu item X is skipped. Of course, this only works for menus with <= 64 menu items. There are no menus that come close to that number, so this is OK. Should we ever need more, then this will have to be extended to a bit array.

def The control's default value.

qmenu The new menu.

Description

Same as `v4l2_ctrl_new_std_menu`, but *qmenu* will be the driver specific menu of this control.

Name

v4l2_ctrl_new_int_menu — Create a new standard V4L2 integer menu control.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_new_int_menu (struct v4l2_ctrl_handler *
hdl, const struct v4l2_ctrl_ops * ops, u32 id, u8 max, u8 def, const
s64 * qmenu_int);
```

Arguments

hdl	The control handler.
ops	The control ops.
id	The control ID.
max	The control's maximum value.
def	The control's default value.
qmenu_int	The control's menu entries.

Description

Same as `v4l2_ctrl_new_std_menu`, but *mask* is set to 0 and it additionaly takes as an argument an array of integers determining the menu items.

If *id* refers to a non-integer-menu control, then this function will return NULL.

Name

v4l2_ctrl_add_ctrl — Add a control from another handler to this handler.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_add_ctrl (struct v4l2_ctrl_handler * hdl,
struct v4l2_ctrl * ctrl);
```

Arguments

hdl The control handler.

ctrl The control to add.

Description

It will return NULL if it was unable to add the control reference. If the control already belonged to the handler, then it will do nothing and just return *ctrl*.

Name

v4l2_ctrl_add_handler — Add all controls from handler *add* to handler *hdl*.

Synopsis

```
int v4l2_ctrl_add_handler (struct v4l2_ctrl_handler * hdl, struct
v4l2_ctrl_handler * add, bool (*filter) (const struct v4l2_ctrl *ctrl));
```

Arguments

hdl The control handler.

add The control handler whose controls you want to add to the *hdl* control handler.

filter This function will filter which controls should be added.

Description

Does nothing if either of the two handlers is a NULL pointer. If *filter* is NULL, then all controls are added. Otherwise only those controls for which *filter* returns true will be added. In case of an error *hdl*->error will be set to the error code (if it wasn't set already).

Name

v4l2_ctrl_radio_filter — Standard filter for radio controls.

Synopsis

```
bool v4l2_ctrl_radio_filter (const struct v4l2_ctrl * ctrl);
```

Arguments

ctrl The control that is filtered.

Description

This will return true for any controls that are valid for radio device nodes. Those are all of the V4L2_CID_AUDIO_* user controls and all FM transmitter class controls.

This function is to be used with `v4l2_ctrl_add_handler`.

Name

v4l2_ctrl_cluster — Mark all controls in the cluster as belonging to that cluster.

Synopsis

```
void v4l2_ctrl_cluster (unsigned ncontrols, struct v4l2_ctrl ** controls);
```

Arguments

`ncontrols` The number of controls in this cluster.

`controls` The cluster control array of size *`ncontrols`*.

Name

v4l2_ctrl_auto_cluster — Mark all controls in the cluster as belonging to that cluster and set it up for autofoo/foo-type handling.

Synopsis

```
void v4l2_ctrl_auto_cluster (unsigned ncontrols, struct v4l2_ctrl ** controls, u8 manual_val, bool set_volatile);
```

Arguments

ncontrols	The number of controls in this cluster.
controls	The cluster control array of size *ncontrols*. The first control must be the 'auto' control (e.g. autogain, autoexposure, etc.)
manual_val	The value for the first control in the cluster that equals the manual setting.
set_volatile	If true, then all controls except the first auto control will be volatile.

Description

Use for control groups where one control selects some automatic feature and the other controls are only active whenever the automatic feature is turned off (manual mode). Typical examples: autogain vs gain, auto-whitebalance vs red and blue balance, etc.

The behavior of such controls is as follows

When the autofoo control is set to automatic, then any manual controls are set to inactive and any reads will call g_volatile_ctrl (if the control was marked volatile).

When the autofoo control is set to manual, then any manual controls will be marked active, and any reads will just return the current value without going through g_volatile_ctrl.

In addition, this function will set the V4L2_CTRL_FLAG_UPDATE flag on the autofoo control and V4L2_CTRL_FLAG_INACTIVE on the foo control(s) if autofoo is in auto mode.

Name

v4l2_ctrl_find — Find a control with the given ID.

Synopsis

```
struct v4l2_ctrl * v4l2_ctrl_find (struct v4l2_ctrl_handler * hdl, u32 id);
```

Arguments

hdl The control handler.

id The control ID to find.

Description

If *hdl* == NULL this will return NULL as well. Will lock the handler so do not use from inside v4l2_ctrl_ops.

Name

v4l2_ctrl_activate — Make the control active or inactive.

Synopsis

```
void v4l2_ctrl_activate (struct v4l2_ctrl * ctrl, bool active);
```

Arguments

ctrl The control to (de)activate.

active True if the control should become active.

Description

This sets or clears the V4L2_CTRL_FLAG_INACTIVE flag atomically. Does nothing if *ctrl* == NULL. This will usually be called from within the s_ctrl op. The V4L2_EVENT_CTRL event will be generated afterwards.

This function assumes that the control handler is locked.

Name

v4l2_ctrl_grab — Mark the control as grabbed or not grabbed.

Synopsis

```
void v4l2_ctrl_grab (struct v4l2_ctrl * ctrl, bool grabbed);
```

Arguments

ctrl The control to (de)activate.

grabbed True if the control should become grabbed.

Description

This sets or clears the V4L2_CTRL_FLAG_GRABBED flag atomically. Does nothing if *ctrl* == NULL. The V4L2_EVENT_CTRL event will be generated afterwards. This will usually be called when starting or stopping streaming in the driver.

This function assumes that the control handler is not locked and will take the lock itself.

Name

__v4l2_ctrl_modify_range — Unlocked variant of `v4l2_ctrl_modify_range`

Synopsis

```
int __v4l2_ctrl_modify_range (struct v4l2_ctrl * ctrl, s64 min, s64 max,
u64 step, s64 def);
```

Arguments

`ctrl` The control to update.

`min` The control's minimum value.

`max` The control's maximum value.

`step` The control's step value

`def` The control's default value.

Description

Update the range of a control on the fly. This works for control types INTEGER, BOOLEAN, MENU, INTEGER MENU and BITMASK. For menu controls the *`step`* value is interpreted as a menu_skip_mask.

An error is returned if one of the range arguments is invalid for this control type.

This function assumes that the control handler is not locked and will take the lock itself.

Name

v4l2_ctrl_modify_range — Update the range of a control.

Synopsis

```
int v4l2_ctrl_modify_range (struct v4l2_ctrl * ctrl, s64 min, s64 max,
u64 step, s64 def);
```

Arguments

ctrl The control to update.

min The control's minimum value.

max The control's maximum value.

step The control's step value

def The control's default value.

Description

Update the range of a control on the fly. This works for control types INTEGER, BOOLEAN, MENU, INTEGER MENU and BITMASK. For menu controls the *step* value is interpreted as a menu_skip_mask.

An error is returned if one of the range arguments is invalid for this control type.

This function assumes that the control handler is not locked and will take the lock itself.

Name

v4l2_ctrl_notify — Function to set a notify callback for a control.

Synopsis

```
void v4l2_ctrl_notify (struct v4l2_ctrl * ctrl, v4l2_ctrl_notify_fnc notify, void * priv);
```

Arguments

ctrl The control.

notify The callback function.

priv The callback private handle, passed as argument to the callback.

Description

This function sets a callback function for the control. If *ctrl* is NULL, then it will do nothing. If *notify* is NULL, then the notify callback will be removed.

There can be only one notify. If another already exists, then a WARN_ON will be issued and the function will do nothing.

Name

v4l2_ctrl_get_name — Get the name of the control

Synopsis

```
const char * v4l2_ctrl_get_name (u32 id);
```

Arguments

id The control ID.

Description

This function returns the name of the given control ID or NULL if it isn't a known control.

Name

v4l2_ctrl_get_menu — Get the menu string array of the control

Synopsis

```
const char * const * v4l2_ctrl_get_menu (u32 id);
```

Arguments

id The control ID.

Description

This function returns the NULL-terminated menu string array name of the given control ID or NULL if it isn't a known menu control.

Name

v4l2_ctrl_get_int_menu — Get the integer menu array of the control

Synopsis

```
const s64 * v4l2_ctrl_get_int_menu (u32 id, u32 * len);
```

Arguments

id The control ID.

len The size of the integer array.

Description

This function returns the integer array of the given control ID or NULL if it if it isn't a known integer menu control.

Name

v4l2_ctrl_g_ctrl — Helper function to get the control's value from within a driver.

Synopsis

```
s32 v4l2_ctrl_g_ctrl (struct v4l2_ctrl * ctrl);
```

Arguments

ctrl The control.

Description

This returns the control's value safely by going through the control framework. This function will lock the control's handler, so it cannot be used from within the v4l2_ctrl_ops functions.

This function is for integer type controls only.

Name

__v4l2_ctrl_s_ctrl — Unlocked variant of `v4l2_ctrl_s_ctrl`.

Synopsis

```
int __v4l2_ctrl_s_ctrl (struct v4l2_ctrl * ctrl, s32 val);
```

Arguments

`ctrl` The control.

`val` The new value.

Description

This set the control's new value safely by going through the control framework. This function will lock the control's handler, so it cannot be used from within the v4l2_ctrl_ops functions.

This function is for integer type controls only.

Name

v4l2_ctrl_g_ctrl_int64 — Helper function to get a 64-bit control's value from within a driver.

Synopsis

```
s64 v4l2_ctrl_g_ctrl_int64 (struct v4l2_ctrl * ctrl);
```

Arguments

ctrl The control.

Description

This returns the control's value safely by going through the control framework. This function will lock the control's handler, so it cannot be used from within the v4l2_ctrl_ops functions.

This function is for 64-bit integer type controls only.

Name

__v4l2_ctrl_s_ctrl_int64 — Unlocked variant of `v4l2_ctrl_s_ctrl_int64`.

Synopsis

```
int __v4l2_ctrl_s_ctrl_int64 (struct v4l2_ctrl * ctrl, s64 val);
```

Arguments

`ctrl` The control.

`val` The new value.

Description

This set the control's new value safely by going through the control framework. This function will lock the control's handler, so it cannot be used from within the v4l2_ctrl_ops functions.

This function is for 64-bit integer type controls only.

Name

v4l2_check_dv_timings_fnc — timings check callback

Synopsis

```
typedef bool v4l2_check_dv_timings_fnc (const struct v4l2_dv_timings *
t, void * handle);
```

Arguments

t the v4l2_dv_timings struct.

handle a handle from the driver.

Description

Returns true if the given timings are valid.

Name

v4l2_valid_dv_timings — are these timings valid?

Synopsis

```
bool v4l2_valid_dv_timings (const struct v4l2_dv_timings * t, const
struct v4l2_dv_timings_cap * cap, v4l2_check_dv_timings_fnc fnc, void
* fnc_handle);
```

Arguments

t	the v4l2_dv_timings struct.
cap	the v4l2_dv_timings_cap capabilities.
fnc	callback to check if this timing is OK. May be NULL.
fnc_handle	a handle that is passed on to *fnc*.

Description

Returns true if the given dv_timings struct is supported by the hardware capabilities and the callback function (if non-NULL), returns false otherwise.

Name

v4l2_enum_dv_timings_cap — Helper function to enumerate possible DV timings based on capabilities

Synopsis

```
int v4l2_enum_dv_timings_cap (struct v4l2_enum_dv_timings * t, const
struct v4l2_dv_timings_cap * cap, v4l2_check_dv_timings_fnc fnc, void
* fnc_handle);
```

Arguments

t	the v4l2_enum_dv_timings struct.
cap	the v4l2_dv_timings_cap capabilities.
fnc	callback to check if this timing is OK. May be NULL.
fnc_handle	a handle that is passed on to *fnc*.

Description

This enumerates dv_timings using the full list of possible CEA-861 and DMT timings, filtering out any timings that are not supported based on the hardware capabilities and the callback function (if non-NULL).

If a valid timing for the given index is found, it will fill in *t* and return 0, otherwise it returns -EINVAL.

Name

v4l2_find_dv_timings_cap — Find the closest timings struct

Synopsis

```
bool v4l2_find_dv_timings_cap (struct v4l2_dv_timings * t,
const struct v4l2_dv_timings_cap * cap, unsigned pclock_delta,
v4l2_check_dv_timings_fnc fnc, void * fnc_handle);
```

Arguments

t	the v4l2_enum_dv_timings struct.
cap	the v4l2_dv_timings_cap capabilities.
pclock_delta	maximum delta between t->pixelclock and the timing struct under consideration.
fnc	callback to check if a given timings struct is OK. May be NULL.
fnc_handle	a handle that is passed on to *fnc*.

Description

This function tries to map the given timings to an entry in the full list of possible CEA-861 and DMT timings, filtering out any timings that are not supported based on the hardware capabilities and the callback function (if non-NULL).

On success it will fill in *t* with the found timings and it returns true. On failure it will return false.

Name

v4l2_match_dv_timings — do two timings match?

Synopsis

```
bool v4l2_match_dv_timings (const struct v4l2_dv_timings * measured,
const struct v4l2_dv_timings * standard, unsigned pclock_delta);
```

Arguments

measured	the measured timings data.
standard	the timings according to the standard.
pclock_delta	maximum delta in Hz between standard->pixelclock and the measured timings.

Description

Returns true if the two timings match, returns false otherwise.

Name

v4l2_print_dv_timings — log the contents of a dv_timings struct

Synopsis

```
void v4l2_print_dv_timings (const char * dev_prefix, const char * prefix,
const struct v4l2_dv_timings * t, bool detailed);
```

Arguments

dev_prefix	device prefix for each log line.
prefix	additional prefix for each log line, may be NULL.
t	the timings data.
detailed	if true, give a detailed log.

Name

v4l2_detect_cvt — detect if the given timings follow the CVT standard

Synopsis

```
bool v4l2_detect_cvt (unsigned frame_height, unsigned hfreq, unsigned vsync, unsigned active_width, u32 polarities, bool interlaced, struct v4l2_dv_timings * fmt);
```

Arguments

frame_height	the total height of the frame (including blanking) in lines.
hfreq	the horizontal frequency in Hz.
vsync	the height of the vertical sync in lines.
active_width	active width of image (does not include blanking). This information is needed only in case of version 2 of reduced blanking. In other cases, this parameter does not have any effect on timings.
polarities	the horizontal and vertical polarities (same as struct v4l2_bt_timings polarities).
interlaced	if this flag is true, it indicates interlaced format
fmt	the resulting timings.

Description

This function will attempt to detect if the given values correspond to a valid CVT format. If so, then it will return true, and fmt will be filled in with the found CVT timings.

Name

v4l2_detect_gtf — detect if the given timings follow the GTF standard

Synopsis

```
bool v4l2_detect_gtf (unsigned frame_height, unsigned hfreq, unsigned
vsync, u32 polarities, bool interlaced, struct v4l2_fract aspect, struct
v4l2_dv_timings * fmt);
```

Arguments

frame_height	the total height of the frame (including blanking) in lines.
hfreq	the horizontal frequency in Hz.
vsync	the height of the vertical sync in lines.
polarities	the horizontal and vertical polarities (same as struct v4l2_bt_timings polarities).
interlaced	if this flag is true, it indicates interlaced format
aspect	preferred aspect ratio. GTF has no method of determining the aspect ratio in order to derive the image width from the image height, so it has to be passed explicitly. Usually the native screen aspect ratio is used for this. If it is not filled in correctly, then 16:9 will be assumed.
fmt	the resulting timings.

Description

This function will attempt to detect if the given values correspond to a valid GTF format. If so, then it will return true, and fmt will be filled in with the found GTF timings.

Name

v4l2_calc_aspect_ratio — calculate the aspect ratio based on bytes 0x15 and 0x16 from the EDID.

Synopsis

```
struct v4l2_fract v4l2_calc_aspect_ratio (u8 hor_landscape, u8 vert_portrait);
```

Arguments

hor_landscape byte 0x15 from the EDID.

vert_portrait byte 0x16 from the EDID.

Description

Determines the aspect ratio from the EDID. See VESA Enhanced EDID standard, release A, rev 2, section 3.6.2: “Horizontal and Vertical Screen Size or Aspect Ratio”

Name

struct v4l2_kevent — Internal kernel event struct.

Synopsis

```
struct v4l2_kevent {
  struct list_head list;
  struct v4l2_subscribed_event * sev;
  struct v4l2_event event;
};
```

Members

list List node for the v4l2_fh->available list.

sev Pointer to parent v4l2_subscribed_event.

event The event itself.

Name

struct v4l2_subscribed_event — Internal struct representing a subscribed event.

Synopsis

```
struct v4l2_subscribed_event {
  struct list_head list;
  u32 type;
  u32 id;
  u32 flags;
  struct v4l2_fh * fh;
  struct list_head node;
  const struct v4l2_subscribed_event_ops * ops;
  unsigned elems;
  unsigned first;
  unsigned in_use;
  struct v4l2_kevent events[];
};
```

Members

list	List node for the v4l2_fh->subscribed list.
type	Event type.
id	Associated object ID (e.g. control ID). 0 if there isn't any.
flags	Copy of v4l2_event_subscription->flags.
fh	Filehandle that subscribed to this event.
node	List node that hooks into the object's event list (if there is one).
ops	v4l2_subscribed_event_ops
elems	The number of elements in the events array.
first	The index of the events containing the oldest available event.
in_use	The number of queued events.
events[]	An array of *elems* events.

Name

struct v4l2_flash_config — V4L2 Flash sub-device initialization data

Synopsis

```
struct v4l2_flash_config {
  char dev_name[32];
  struct led_flash_setting torch_intensity;
  struct led_flash_setting indicator_intensity;
  u32 flash_faults;
  unsigned int has_external_strobe:1;
};
```

Members

dev_name[32]	the name of the media entity, unique in the system
torch_intensity	constraints for the LED in torch mode
indicator_intensity	constraints for the indicator LED
flash_faults	bitmask of flash faults that the LED flash class device can report; corresponding LED_FAULT* bit definitions are available in the header file <linux/led-class-flash.h>
has_external_strobe	external strobe capability

Name

struct v4l2_flash — Flash sub-device context

Synopsis

```
struct v4l2_flash {
  struct led_classdev_flash * fled_cdev;
  struct led_classdev_flash * iled_cdev;
  const struct v4l2_flash_ops * ops;
  struct v4l2_subdev sd;
  struct v4l2_ctrl_handler hdl;
  struct v4l2_ctrl ** ctrls;
};
```

Members

fled_cdev	LED flash class device controlled by this sub-device
iled_cdev	LED class device representing indicator LED associated with the LED flash class device
ops	V4L2 specific flash ops
sd	V4L2 sub-device
hdl	flash controls handler
ctrls	array of pointers to controls, whose values define the sub-device state

Name

v4l2_flash_init — initialize V4L2 flash led sub-device

Synopsis

```
struct v4l2_flash * v4l2_flash_init (struct device * dev, struct device_node * of_node, struct led_classdev_flash * fled_cdev, struct led_classdev_flash * iled_cdev, const struct v4l2_flash_ops * ops, struct v4l2_flash_config * config);
```

Arguments

dev	flash device, e.g. an I2C device
of_node	of_node of the LED, may be NULL if the same as device's
fled_cdev	LED flash class device to wrap
iled_cdev	LED flash class device representing indicator LED associated with fled_cdev, may be NULL
ops	V4L2 Flash device ops
config	initialization data for V4L2 Flash sub-device

Description

Create V4L2 Flash sub-device wrapping given LED subsystem device.

Returns

A valid pointer, or, when an error occurs, the return value is encoded using ERR_PTR. Use IS_ERR to check and PTR_ERR to obtain the numeric return value.

Name

v4l2_flash_release — release V4L2 Flash sub-device

Synopsis

```
void v4l2_flash_release (struct v4l2_flash * v4l2_flash);
```

Arguments

v4l2_flash the V4L2 Flash sub-device to release

Description

Release V4L2 Flash sub-device.

Name

enum v4l2_mbus_type — media bus type

Synopsis

```
enum v4l2_mbus_type {
  V4L2_MBUS_PARALLEL,
  V4L2_MBUS_BT656,
  V4L2_MBUS_CSI2
};
```

Constants

V4L2_MBUS_PARALLEL	parallel interface with hsync and vsync
V4L2_MBUS_BT656	parallel interface with embedded synchronisation, can also be used for BT.1120
V4L2_MBUS_CSI2	MIPI CSI-2 serial interface

Name

struct v4l2_mbus_config — media bus configuration

Synopsis

```
struct v4l2_mbus_config {
  enum v4l2_mbus_type type;
  unsigned int flags;
};
```

Members

type in: interface type

flags in / out: configuration flags, depending on *`type`*

Name

struct v4l2_m2m_ops — mem-to-mem device driver callbacks

Synopsis

```
struct v4l2_m2m_ops {
  void (* device_run) (void *priv);
  int (* job_ready) (void *priv);
  void (* job_abort) (void *priv);
  void (* lock) (void *priv);
  void (* unlock) (void *priv);
};
```

Members

device_run — required. Begin the actual job (transaction) inside this callback. The job does NOT have to end before this callback returns (and it will be the usual case). When the job finishes, `v4l2_m2m_job_finish` has to be called.

job_ready — optional. Should return 0 if the driver does not have a job fully prepared to run yet (i.e. it will not be able to finish a transaction without sleeping). If not provided, it will be assumed that one source and one destination buffer are all that is required for the driver to perform one full transaction. This method may not sleep.

job_abort — required. Informs the driver that it has to abort the currently running transaction as soon as possible (i.e. as soon as it can stop the device safely; e.g. in the next interrupt handler), even if the transaction would not have been finished by then. After the driver performs the necessary steps, it has to call `v4l2_m2m_job_finish` (as if the transaction ended normally). This function does not have to (and will usually not) wait until the device enters a state when it can be stopped.

lock — optional. Define a driver's own lock callback, instead of using m2m_ctx->q_lock.

unlock — optional. Define a driver's own unlock callback, instead of using m2m_ctx->q_lock.

Name

v4l2_m2m_num_src_bufs_ready — return the number of source buffers ready for use

Synopsis

```
unsigned int v4l2_m2m_num_src_bufs_ready (struct v4l2_m2m_ctx *
m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_num_dst_bufs_ready — return the number of destination buffers ready for use

Synopsis

```
unsigned int v4l2_m2m_num_dst_bufs_ready (struct v4l2_m2m_ctx *
m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_next_src_buf — return next source buffer from the list of ready buffers

Synopsis

```
void * v4l2_m2m_next_src_buf (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_next_dst_buf — return next destination buffer from the list of ready buffers

Synopsis

```
void * v4l2_m2m_next_dst_buf (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_get_src_vq — return vb2_queue for source buffers

Synopsis

```
struct vb2_queue * v4l2_m2m_get_src_vq (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_get_dst_vq — return vb2_queue for destination buffers

Synopsis

```
struct vb2_queue * v4l2_m2m_get_dst_vq (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_src_buf_remove — take off a source buffer from the list of ready buffers and return it

Synopsis

```
void * v4l2_m2m_src_buf_remove (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

v4l2_m2m_dst_buf_remove — take off a destination buffer from the list of ready buffers and return it

Synopsis

```
void * v4l2_m2m_dst_buf_remove (struct v4l2_m2m_ctx * m2m_ctx);
```

Arguments

m2m_ctx pointer to struct v4l2_m2m_ctx

Name

struct v4l2_of_bus_mipi_csi2 — MIPI CSI-2 bus data structure

Synopsis

```
struct v4l2_of_bus_mipi_csi2 {
  unsigned int flags;
  unsigned char data_lanes[4];
  unsigned char clock_lane;
  unsigned short num_data_lanes;
  bool lane_polarities[5];
};
```

Members

flags	media bus (V4L2_MBUS_*) flags
data_lanes[4]	an array of physical data lane indexes
clock_lane	physical lane index of the clock lane
num_data_lanes	number of data lanes
lane_polarities[5]	polarity of the lanes. The order is the same of the physical lanes.

Name

struct v4l2_of_bus_parallel — parallel data bus data structure

Synopsis

```
struct v4l2_of_bus_parallel {
  unsigned int flags;
  unsigned char bus_width;
  unsigned char data_shift;
};
```

Members

flags	media bus (V4L2_MBUS_*) flags
bus_width	bus width in bits
data_shift	data shift in bits

Name

struct v4l2_of_endpoint — the endpoint data structure

Synopsis

```
struct v4l2_of_endpoint {
  struct of_endpoint base;
  enum v4l2_mbus_type bus_type;
  union bus;
  u64 * link_frequencies;
  unsigned int nr_of_link_frequencies;
};
```

Members

base	struct of_endpoint containing port, id, and local of_node
bus_type	bus type
bus	bus configuration data structure
link_frequencies	array of supported link frequencies
nr_of_link_frequencies	number of elements in link_frequenccies array

Name

struct v4l2_of_link — a link between two endpoints

Synopsis

```
struct v4l2_of_link {
  struct device_node * local_node;
  unsigned int local_port;
  struct device_node * remote_node;
  unsigned int remote_port;
};
```

Members

local_node	pointer to device_node of this endpoint
local_port	identifier of the port this endpoint belongs to
remote_node	pointer to device_node of the remote endpoint
remote_port	identifier of the port the remote endpoint belongs to

Name

struct v4l2_subdev_core_ops — Define core ops callbacks for subdevs

Synopsis

```
struct v4l2_subdev_core_ops {
  int (* log_status) (struct v4l2_subdev *sd);
  int (* s_io_pin_config) (struct v4l2_subdev *sd, size_t n,struct v4l2_subdev_io_
  int (* init) (struct v4l2_subdev *sd, u32 val);
  int (* load_fw) (struct v4l2_subdev *sd);
  int (* reset) (struct v4l2_subdev *sd, u32 val);
  int (* s_gpio) (struct v4l2_subdev *sd, u32 val);
  int (* queryctrl) (struct v4l2_subdev *sd, struct v4l2_queryctrl *qc);
  int (* g_ctrl) (struct v4l2_subdev *sd, struct v4l2_control *ctrl);
  int (* s_ctrl) (struct v4l2_subdev *sd, struct v4l2_control *ctrl);
  int (* g_ext_ctrls) (struct v4l2_subdev *sd, struct v4l2_ext_controls *ctrls);
  int (* s_ext_ctrls) (struct v4l2_subdev *sd, struct v4l2_ext_controls *ctrls);
  int (* try_ext_ctrls) (struct v4l2_subdev *sd, struct v4l2_ext_controls *ctrls);
  int (* querymenu) (struct v4l2_subdev *sd, struct v4l2_querymenu *qm);
  long (* ioctl) (struct v4l2_subdev *sd, unsigned int cmd, void *arg);
#ifdef CONFIG_COMPAT
  long (* compat_ioctl32) (struct v4l2_subdev *sd, unsigned int cmd,unsigned long
#endif
#ifdef CONFIG_VIDEO_ADV_DEBUG
  int (* g_register) (struct v4l2_subdev *sd, struct v4l2_dbg_register *reg);
  int (* s_register) (struct v4l2_subdev *sd, const struct v4l2_dbg_register *reg)
#endif
  int (* s_power) (struct v4l2_subdev *sd, int on);
  int (* interrupt_service_routine) (struct v4l2_subdev *sd,u32 status, bool *hand
  int (* subscribe_event) (struct v4l2_subdev *sd, struct v4l2_fh *fh,struct v4l2_
  int (* unsubscribe_event) (struct v4l2_subdev *sd, struct v4l2_fh *fh,struct v4l
};
```

Members

log_status — callback for VIDIOC_LOG_STATUS ioctl handler code.

s_io_pin_config — configure one or more chip I/O pins for chips that multiplex different internal signal pads out to IO pins. This function takes a pointer to an array of 'n' pin configuration entries, one for each pin being configured. This function could be called at times other than just subdevice initialization.

init — initialize the sensor registers to some sort of reasonable default values. Do not use for new drivers and should be removed in existing drivers.

load_fw — load firmware.

reset — generic reset command. The argument selects which subsystems to reset. Passing 0 will always reset the whole chip. Do not use for new drivers without discussing this first on the linux-media mailinglist. There should be no reason normally to reset a device.

s_gpio	set GPIO pins. Very simple right now, might need to be extended with a direction argument if needed.
queryctrl	callback for VIDIOC_QUERYCTL ioctl handler code.
g_ctrl	callback for VIDIOC_G_CTRL ioctl handler code.
s_ctrl	callback for VIDIOC_S_CTRL ioctl handler code.
g_ext_ctrls	callback for VIDIOC_G_EXT_CTRLS ioctl handler code.
s_ext_ctrls	callback for VIDIOC_S_EXT_CTRLS ioctl handler code.
try_ext_ctrls	callback for VIDIOC_TRY_EXT_CTRLS ioctl handler code.
querymenu	callback for VIDIOC_QUERYMENU ioctl handler code.
ioctl	called at the end of `ioctl` syscall handler at the V4L2 core. used to provide support for private ioctls used on the driver.
compat_ioctl32	called when a 32 bits application uses a 64 bits Kernel, in order to fix data passed from/to userspace.
g_register	callback for VIDIOC_G_REGISTER ioctl handler code.
s_register	callback for VIDIOC_G_REGISTER ioctl handler code.
s_power	puts subdevice in power saving mode (on == 0) or normal operation mode (on == 1).
interrupt_service_routine	Called by the bridge chip's interrupt service handler, when an interrupt status has be raised due to this subdev, so that this subdev can handle the details. It may schedule work to be performed later. It must not sleep. *Called from an IRQ context*.
subscribe_event	used by the drivers to request the control framework that for it to be warned when the value of a control changes.
unsubscribe_event	remove event subscription from the control framework.

Name

struct v4l2_subdev_tuner_ops — Callbacks used when v4l device was opened in radio mode.

Synopsis

```
struct v4l2_subdev_tuner_ops {
  int (* s_radio) (struct v4l2_subdev *sd);
  int (* s_frequency) (struct v4l2_subdev *sd, const struct v4l2_frequency *freq);
  int (* g_frequency) (struct v4l2_subdev *sd, struct v4l2_frequency *freq);
  int (* enum_freq_bands) (struct v4l2_subdev *sd, struct v4l2_frequency_band *ban
  int (* g_tuner) (struct v4l2_subdev *sd, struct v4l2_tuner *vt);
  int (* s_tuner) (struct v4l2_subdev *sd, const struct v4l2_tuner *vt);
  int (* g_modulator) (struct v4l2_subdev *sd, struct v4l2_modulator *vm);
  int (* s_modulator) (struct v4l2_subdev *sd, const struct v4l2_modulator *vm);
  int (* s_type_addr) (struct v4l2_subdev *sd, struct tuner_setup *type);
  int (* s_config) (struct v4l2_subdev *sd, const struct v4l2_priv_tun_config *con
};
```

Members

s_radio	callback for VIDIOC_S_RADIO ioctl handler code.
s_frequency	callback for VIDIOC_S_FREQUENCY ioctl handler code.
g_frequency	callback for VIDIOC_G_FREQUENCY ioctl handler code. freq->type must be filled in. Normally done by video_ioctl2 or the bridge driver.
enum_freq_bands	callback for VIDIOC_ENUM_FREQ_BANDS ioctl handler code.
g_tuner	callback for VIDIOC_G_TUNER ioctl handler code.
s_tuner	callback for VIDIOC_S_TUNER ioctl handler code. vt->type must be filled in. Normally done by video_ioctl2 or the bridge driver.
g_modulator	callback for VIDIOC_G_MODULATOR ioctl handler code.
s_modulator	callback for VIDIOC_S_MODULATOR ioctl handler code.
s_type_addr	sets tuner type and its I2C addr.
s_config	sets tda9887 specific stuff, like port1, port2 and qss

Name

struct v4l2_subdev_audio_ops — Callbacks used for audio-related settings

Synopsis

```
struct v4l2_subdev_audio_ops {
  int (* s_clock_freq) (struct v4l2_subdev *sd, u32 freq);
  int (* s_i2s_clock_freq) (struct v4l2_subdev *sd, u32 freq);
  int (* s_routing) (struct v4l2_subdev *sd, u32 input, u32 output, u32 config);
  int (* s_stream) (struct v4l2_subdev *sd, int enable);
};
```

Members

s_clock_freq — set the frequency (in Hz) of the audio clock output. Used to slave an audio processor to the video decoder, ensuring that audio and video remain synchronized. Usual values for the frequency are 48000, 44100 or 32000 Hz. If the frequency is not supported, then -EINVAL is returned.

s_i2s_clock_freq — sets I2S speed in bps. This is used to provide a standard way to select I2S clock used by driving digital audio streams at some board designs. Usual values for the frequency are 1024000 and 2048000. If the frequency is not supported, then -EINVAL is returned.

s_routing — used to define the input and/or output pins of an audio chip, and any additional configuration data. Never attempt to use user-level input IDs (e.g. Composite, S-Video, Tuner) at this level. An i2c device shouldn't know about whether an input pin is connected to a Composite connector, become on another board or platform it might be connected to something else entirely. The calling driver is responsible for mapping a user-level input to the right pins on the i2c device.

s_stream — used to notify the audio code that stream will start or has stopped.

Name

struct v4l2_mbus_frame_desc_entry — media bus frame description structure

Synopsis

```
struct v4l2_mbus_frame_desc_entry {
  u16 flags;
  u32 pixelcode;
  u32 length;
};
```

Members

flags	V4L2_MBUS_FRAME_DESC_FL_* flags
pixelcode	media bus pixel code, valid if FRAME_DESC_FL_BLOB is not set
length	number of octets per frame, valid if V4L2_MBUS_FRAME_DESC_FL_BLOB is set

Name

struct v4l2_mbus_frame_desc — media bus data frame description

Synopsis

```
struct v4l2_mbus_frame_desc {
  struct v4l2_mbus_frame_desc_entry entry[V4L2_FRAME_DESC_ENTRY_MAX];
  unsigned short num_entries;
};
```

Members

entry[V4L2_FRAME_DESC_ENTRY_MAX] — frame descriptors array

num_entries — number of entries in *entry* array

Name

struct v4l2_subdev_video_ops — Callbacks used when v4l device was opened in video mode.

Synopsis

```
struct v4l2_subdev_video_ops {
  int (* s_routing) (struct v4l2_subdev *sd, u32 input, u32 output, u32 config);
  int (* s_crystal_freq) (struct v4l2_subdev *sd, u32 freq, u32 flags);
  int (* g_std) (struct v4l2_subdev *sd, v4l2_std_id *norm);
  int (* s_std) (struct v4l2_subdev *sd, v4l2_std_id norm);
  int (* s_std_output) (struct v4l2_subdev *sd, v4l2_std_id std);
  int (* g_std_output) (struct v4l2_subdev *sd, v4l2_std_id *std);
  int (* querystd) (struct v4l2_subdev *sd, v4l2_std_id *std);
  int (* g_tvnorms) (struct v4l2_subdev *sd, v4l2_std_id *std);
  int (* g_tvnorms_output) (struct v4l2_subdev *sd, v4l2_std_id *std);
  int (* g_input_status) (struct v4l2_subdev *sd, u32 *status);
  int (* s_stream) (struct v4l2_subdev *sd, int enable);
  int (* cropcap) (struct v4l2_subdev *sd, struct v4l2_cropcap *cc);
  int (* g_crop) (struct v4l2_subdev *sd, struct v4l2_crop *crop);
  int (* s_crop) (struct v4l2_subdev *sd, const struct v4l2_crop *crop);
  int (* g_parm) (struct v4l2_subdev *sd, struct v4l2_streamparm *param);
  int (* s_parm) (struct v4l2_subdev *sd, struct v4l2_streamparm *param);
  int (* g_frame_interval) (struct v4l2_subdev *sd,struct v4l2_subdev_frame_interv
  int (* s_frame_interval) (struct v4l2_subdev *sd,struct v4l2_subdev_frame_interv
  int (* s_dv_timings) (struct v4l2_subdev *sd,struct v4l2_dv_timings *timings);
  int (* g_dv_timings) (struct v4l2_subdev *sd,struct v4l2_dv_timings *timings);
  int (* query_dv_timings) (struct v4l2_subdev *sd,struct v4l2_dv_timings *timings
  int (* g_mbus_config) (struct v4l2_subdev *sd,struct v4l2_mbus_config *cfg);
  int (* s_mbus_config) (struct v4l2_subdev *sd,const struct v4l2_mbus_config *cfg
  int (* s_rx_buffer) (struct v4l2_subdev *sd, void *buf,unsigned int *size);
};
```

Members

s_routing — see s_routing in audio_ops, except this version is for video devices.

s_crystal_freq — sets the frequency of the crystal used to generate the clocks in Hz. An extra flags field allows device specific configuration regarding clock frequency dividers, etc. If not used, then set flags to 0. If the frequency is not supported, then -EINVAL is returned.

g_std — callback for VIDIOC_G_STD ioctl handler code.

s_std — callback for VIDIOC_S_STD ioctl handler code.

s_std_output — set v4l2_std_id for video OUTPUT devices. This is ignored by video input devices.

g_std_output — get current standard for video OUTPUT devices. This is ignored by video input devices.

querystd — callback for VIDIOC_QUERYSTD ioctl handler code.

g_tvnorms	get v4l2_std_id with all standards supported by the video CAPTURE device. This is ignored by video output devices.
g_tvnorms_output	get v4l2_std_id with all standards supported by the video OUTPUT device. This is ignored by video capture devices.
g_input_status	get input status. Same as the status field in the v4l2_input struct.
s_stream	used to notify the driver that a video stream will start or has stopped.
cropcap	callback for VIDIOC_CROPCAP ioctl handler code.
g_crop	callback for VIDIOC_G_CROP ioctl handler code.
s_crop	callback for VIDIOC_S_CROP ioctl handler code.
g_parm	callback for VIDIOC_G_PARM ioctl handler code.
s_parm	callback for VIDIOC_S_PARM ioctl handler code.
g_frame_interval	callback for VIDIOC_G_FRAMEINTERVAL ioctl handler code.
s_frame_interval	callback for VIDIOC_S_FRAMEINTERVAL ioctl handler code.
s_dv_timings	Set custom dv timings in the sub device. This is used when sub device is capable of setting detailed timing information in the hardware to generate/detect the video signal.
g_dv_timings	Get custom dv timings in the sub device.
query_dv_timings	callback for VIDIOC_QUERY_DV_TIMINGS ioctl handler code.
g_mbus_config	get supported mediabus configurations
s_mbus_config	set a certain mediabus configuration. This operation is added for compatibility with soc-camera drivers and should not be used by new software.
s_rx_buffer	set a host allocated memory buffer for the subdev. The subdev can adjust *`size`* to a lower value and must not write more data to the buffer starting at *`data`* than the original value of *`size`*.

Name

struct v4l2_subdev_vbi_ops — Callbacks used when v4l device was opened in video mode via the vbi device node.

Synopsis

```
struct v4l2_subdev_vbi_ops {
  int (* decode_vbi_line) (struct v4l2_subdev *sd, struct v4l2_decode_vbi_line *vb
  int (* s_vbi_data) (struct v4l2_subdev *sd, const struct v4l2_sliced_vbi_data *v
  int (* g_vbi_data) (struct v4l2_subdev *sd, struct v4l2_sliced_vbi_data *vbi_dat
  int (* g_sliced_vbi_cap) (struct v4l2_subdev *sd, struct v4l2_sliced_vbi_cap *ca
  int (* s_raw_fmt) (struct v4l2_subdev *sd, struct v4l2_vbi_format *fmt);
  int (* g_sliced_fmt) (struct v4l2_subdev *sd, struct v4l2_sliced_vbi_format *fmt
  int (* s_sliced_fmt) (struct v4l2_subdev *sd, struct v4l2_sliced_vbi_format *fmt
};
```

Members

decode_vbi_line — video decoders that support sliced VBI need to implement this ioctl. Field p of the v4l2_sliced_vbi_line struct is set to the start of the VBI data that was generated by the decoder. The driver then parses the sliced VBI data and sets the other fields in the struct accordingly. The pointer p is updated to point to the start of the payload which can be copied verbatim into the data field of the v4l2_sliced_vbi_data struct. If no valid VBI data was found, then the type field is set to 0 on return.

s_vbi_data — used to generate VBI signals on a video signal. v4l2_sliced_vbi_data is filled with the data packets that should be output. Note that if you set the line field to 0, then that VBI signal is disabled. If no valid VBI data was found, then the type field is set to 0 on return.

g_vbi_data — used to obtain the sliced VBI packet from a readback register. Not all video decoders support this. If no data is available because the readback register contains invalid or erroneous data -EIO is returned. Note that you must fill in the 'id' member and the 'field' member (to determine whether CC data from the first or second field should be obtained).

g_sliced_vbi_cap — callback for VIDIOC_SLICED_VBI_CAP ioctl handler code.

s_raw_fmt — setup the video encoder/decoder for raw VBI.

g_sliced_fmt — retrieve the current sliced VBI settings.

s_sliced_fmt — setup the sliced VBI settings.

Name

struct v4l2_subdev_sensor_ops — v4l2-subdev sensor operations

Synopsis

```
struct v4l2_subdev_sensor_ops {
  int (* g_skip_top_lines) (struct v4l2_subdev *sd, u32 *lines);
  int (* g_skip_frames) (struct v4l2_subdev *sd, u32 *frames);
};
```

Members

g_skip_top_lines — number of lines at the top of the image to be skipped. This is needed for some sensors, which always corrupt several top lines of the output image, or which send their metadata in them.

g_skip_frames — number of frames to skip at stream start. This is needed for buggy sensors that generate faulty frames when they are turned on.

Name

struct v4l2_subdev_pad_ops — v4l2-subdev pad level operations

Synopsis

```
struct v4l2_subdev_pad_ops {
  int (* enum_mbus_code) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *cf
  int (* enum_frame_size) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *c
  int (* enum_frame_interval) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_confi
  int (* get_fmt) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *cfg,struc
  int (* set_fmt) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *cfg,struc
  int (* get_selection) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *cfg
  int (* set_selection) (struct v4l2_subdev *sd,struct v4l2_subdev_pad_config *cfg
  int (* get_edid) (struct v4l2_subdev *sd, struct v4l2_edid *edid);
  int (* set_edid) (struct v4l2_subdev *sd, struct v4l2_edid *edid);
  int (* dv_timings_cap) (struct v4l2_subdev *sd,struct v4l2_dv_timings_cap *cap);
  int (* enum_dv_timings) (struct v4l2_subdev *sd,struct v4l2_enum_dv_timings *tim
#ifdef CONFIG_MEDIA_CONTROLLER
  int (* link_validate) (struct v4l2_subdev *sd, struct media_link *link,struct v4
#endif
  int (* get_frame_desc) (struct v4l2_subdev *sd, unsigned int pad,struct v4l2_mbu
  int (* set_frame_desc) (struct v4l2_subdev *sd, unsigned int pad,struct v4l2_mbu
};
```

Members

enum_mbus_code	callback for VIDIOC_SUBDEV_ENUM_MBUS_CODE ioctl handler code.
enum_frame_size	callback for VIDIOC_SUBDEV_ENUM_FRAME_SIZE ioctl handler code.
enum_frame_interval	callback for VIDIOC_SUBDEV_ENUM_FRAME_INTERVAL ioctl handler code.
get_fmt	callback for VIDIOC_SUBDEV_G_FMT ioctl handler code.
set_fmt	callback for VIDIOC_SUBDEV_S_FMT ioctl handler code.
get_selection	callback for VIDIOC_SUBDEV_G_SELECTION ioctl handler code.
set_selection	callback for VIDIOC_SUBDEV_S_SELECTION ioctl handler code.
get_edid	callback for VIDIOC_SUBDEV_G_EDID ioctl handler code.
set_edid	callback for VIDIOC_SUBDEV_S_EDID ioctl handler code.
dv_timings_cap	callback for VIDIOC_SUBDEV_DV_TIMINGS_CAP ioctl handler code.
enum_dv_timings	callback for VIDIOC_SUBDEV_ENUM_DV_TIMINGS ioctl handler code.
link_validate	used by the media controller code to check if the links that belongs to a pipeline can be used for stream.

get_frame_desc	get the current low level media bus frame parameters.
set_frame_desc	set the low level media bus frame parameters, *fd* array may be adjusted by the subdev driver to device capabilities.

Name

struct vb2_mem_ops — memory handling/memory allocator operations

Synopsis

```
struct vb2_mem_ops {
  void *(* alloc) (void *alloc_ctx, unsigned long size,enum dma_data_direction dma
  void (* put) (void *buf_priv);
  struct dma_buf *(* get_dmabuf) (void *buf_priv, unsigned long flags);
  void *(* get_userptr) (void *alloc_ctx, unsigned long vaddr,unsigned long size,e
  void (* put_userptr) (void *buf_priv);
  void (* prepare) (void *buf_priv);
  void (* finish) (void *buf_priv);
  void *(* attach_dmabuf) (void *alloc_ctx, struct dma_buf *dbuf,unsigned long siz
  void (* detach_dmabuf) (void *buf_priv);
  int (* map_dmabuf) (void *buf_priv);
  void (* unmap_dmabuf) (void *buf_priv);
  void *(* vaddr) (void *buf_priv);
  void *(* cookie) (void *buf_priv);
  unsigned int (* num_users) (void *buf_priv);
  int (* mmap) (void *buf_priv, struct vm_area_struct *vma);
};
```

Members

alloc
: allocate video memory and, optionally, allocator private data, return NULL on failure or a pointer to allocator private, per-buffer data on success; the returned private structure will then be passed as buf_priv argument to other ops in this structure. Additional gfp_flags to use when allocating the are also passed to this operation. These flags are from the gfp_flags field of vb2_queue.

put
: inform the allocator that the buffer will no longer be used; usually will result in the allocator freeing the buffer (if no other users of this buffer are present); the buf_priv argument is the allocator private per-buffer structure previously returned from the alloc callback.

get_dmabuf
: acquire userspace memory for a hardware operation; used for DMABUF memory types.

get_userptr
: acquire userspace memory for a hardware operation; used for USERPTR memory types; vaddr is the address passed to the videobuf layer when queuing a video buffer of USERPTR type; should return an allocator private per-buffer structure associated with the buffer on success, NULL on failure; the returned private structure will then be passed as buf_priv argument to other ops in this structure.

put_userptr
: inform the allocator that a USERPTR buffer will no longer be used.

prepare
: called every time the buffer is passed from userspace to the driver, useful for cache synchronisation, optional.

finish
: called every time the buffer is passed back from the driver to the userspace, also optional.

attach_dmabuf	attach a shared struct dma_buf for a hardware operation; used for DMABUF memory types; alloc_ctx is the alloc context dbuf is the shared dma_buf; returns NULL on failure; allocator private per-buffer structure on success; this needs to be used for further accesses to the buffer.
detach_dmabuf	inform the exporter of the buffer that the current DMABUF buffer is no longer used; the buf_priv argument is the allocator private per-buffer structure previously returned from the attach_dmabuf callback.
map_dmabuf	request for access to the dmabuf from allocator; the allocator of dmabuf is informed that this driver is going to use the dmabuf.
unmap_dmabuf	releases access control to the dmabuf - allocator is notified that this driver is done using the dmabuf for now.
vaddr	return a kernel virtual address to a given memory buffer associated with the passed private structure or NULL if no such mapping exists.
cookie	return allocator specific cookie for a given memory buffer associated with the passed private structure or NULL if not available.
num_users	return the current number of users of a memory buffer; return 1 if the videobuf layer (or actually the driver using it) is the only user.
mmap	setup a userspace mapping for a given memory buffer under the provided virtual memory region.

Required ops for USERPTR types

get_userptr, put_userptr.

Required ops for MMAP types

alloc, put, num_users, mmap. Required ops for read/write access types: alloc, put, num_users, vaddr.

Required ops for DMABUF types

attach_dmabuf, detach_dmabuf, map_dmabuf, unmap_dmabuf.

Name

struct vb2_plane — plane information

Synopsis

```
struct vb2_plane {
  void * mem_priv;
  struct dma_buf * dbuf;
  unsigned int dbuf_mapped;
  unsigned int bytesused;
  unsigned int length;
  union m;
  unsigned int data_offset;
};
```

Members

mem_priv	private data with this plane
dbuf	dma_buf - shared buffer object
dbuf_mapped	flag to show whether dbuf is mapped or not
bytesused	number of bytes occupied by data in the plane (payload)
length	size of this plane (NOT the payload) in bytes
m	Union with memtype-specific data (*offset*, *userptr* or *fd*).
data_offset	offset in the plane to the start of data; usually 0, unless there is a header in front of the data Should contain enough information to be able to cover all the fields of struct v4l2_plane at videodev2.h

Name

enum vb2_io_modes — queue access methods

Synopsis

```
enum vb2_io_modes {
  VB2_MMAP,
  VB2_USERPTR,
  VB2_READ,
  VB2_WRITE,
  VB2_DMABUF
};
```

Constants

VB2_MMAP	driver supports MMAP with streaming API
VB2_USERPTR	driver supports USERPTR with streaming API
VB2_READ	driver supports `read` style access
VB2_WRITE	driver supports `write` style access
VB2_DMABUF	driver supports DMABUF with streaming API

Name

enum vb2_buffer_state — current video buffer state

Synopsis

```
enum vb2_buffer_state {
  VB2_BUF_STATE_DEQUEUED,
  VB2_BUF_STATE_PREPARING,
  VB2_BUF_STATE_PREPARED,
  VB2_BUF_STATE_QUEUED,
  VB2_BUF_STATE_REQUEUEING,
  VB2_BUF_STATE_ACTIVE,
  VB2_BUF_STATE_DONE,
  VB2_BUF_STATE_ERROR
};
```

Constants

VB2_BUF_STATE_DEQUEUED	buffer under userspace control
VB2_BUF_STATE_PREPARING	buffer is being prepared in videobuf
VB2_BUF_STATE_PREPARED	buffer prepared in videobuf and by the driver
VB2_BUF_STATE_QUEUED	buffer queued in videobuf, but not in driver
VB2_BUF_STATE_REQUEUEING	re-queue a buffer to the driver
VB2_BUF_STATE_ACTIVE	buffer queued in driver and possibly used in a hardware operation
VB2_BUF_STATE_DONE	buffer returned from driver to videobuf, but not yet dequeued to userspace
VB2_BUF_STATE_ERROR	same as above, but the operation on the buffer has ended with an error, which will be reported to the userspace when it is dequeued

Name

struct vb2_buffer — represents a video buffer

Synopsis

```
struct vb2_buffer {
  struct vb2_queue * vb2_queue;
  unsigned int index;
  unsigned int type;
  unsigned int memory;
  unsigned int num_planes;
  struct vb2_plane planes[VB2_MAX_PLANES];
};
```

Members

vb2_queue	the queue to which this driver belongs
index	id number of the buffer
type	buffer type
memory	the method, in which the actual data is passed
num_planes	number of planes in the buffer on an internal driver queue
planes[VB2_MAX_PLANES]	private per-plane information; do not change

Name

struct vb2_ops — driver-specific callbacks

Synopsis

```
struct vb2_ops {
  int (* queue_setup) (struct vb2_queue *q, const void *parg,unsigned int *num_buf
  void (* wait_prepare) (struct vb2_queue *q);
  void (* wait_finish) (struct vb2_queue *q);
  int (* buf_init) (struct vb2_buffer *vb);
  int (* buf_prepare) (struct vb2_buffer *vb);
  void (* buf_finish) (struct vb2_buffer *vb);
  void (* buf_cleanup) (struct vb2_buffer *vb);
  int (* start_streaming) (struct vb2_queue *q, unsigned int count);
  void (* stop_streaming) (struct vb2_queue *q);
  void (* buf_queue) (struct vb2_buffer *vb);
};
```

Members

queue_setup — called from VIDIOC_REQBUFS and VIDIOC_CREATE_BUFS handlers before memory allocation, or, if *num_planes != 0, after the allocation to verify a smaller number of buffers. Driver should return the required number of buffers in *num_buffers, the required number of planes per buffer in *num_planes; the size of each plane should be set in the sizes[] array and optional per-plane allocator specific context in the alloc_ctxs[] array. When called from VIDIOC_REQBUFS, fmt == NULL, the driver has to use the currently configured format and *num_buffers is the total number of buffers, that are being allocated. When called from VIDIOC_CREATE_BUFS, fmt != NULL and it describes the target frame format (if the format isn't valid the callback must return -EINVAL). In this case *num_buffers are being allocated additionally to q->num_buffers.

wait_prepare — release any locks taken while calling vb2 functions; it is called before an ioctl needs to wait for a new buffer to arrive; required to avoid a deadlock in blocking access type.

wait_finish — reacquire all locks released in the previous callback; required to continue operation after sleeping while waiting for a new buffer to arrive.

buf_init — called once after allocating a buffer (in MMAP case) or after acquiring a new USERPTR buffer; drivers may perform additional buffer-related initialization; initialization failure (return != 0) will prevent queue setup from completing successfully; optional.

buf_prepare — called every time the buffer is queued from userspace and from the VIDIOC_PREPARE_BUF ioctl; drivers may perform any initialization required before each hardware operation in this callback; drivers can access/modify the buffer here as it is still synced for the CPU; drivers that support VIDIOC_CREATE_BUFS must also validate the buffer size; if an error is returned, the buffer will not be queued in driver; optional.

buf_finish — called before every dequeue of the buffer back to userspace; the buffer is synced for the CPU, so drivers can access/modify the buffer contents; drivers may

perform any operations required before userspace accesses the buffer; optional. The buffer state can be

buf_cleanup — called once before the buffer is freed; drivers may perform any additional cleanup; optional.

start_streaming — called once to enter 'streaming' state; the driver may receive buffers with *buf_queue* callback before *start_streaming* is called; the driver gets the number of already queued buffers in count parameter; driver can return an error if hardware fails, in that case all buffers that have been already given by the *buf_queue* callback are to be returned by the driver by calling *vb2_buffer_done*(VB2_BUF_STATE_QUEUED). If you need a minimum number of buffers before you can start streaming, then set *min_buffers_needed* in the vb2_queue structure. If that is non-zero then start_streaming won't be called until at least that many buffers have been queued up by userspace.

stop_streaming — called when 'streaming' state must be disabled; driver should stop any DMA transactions or wait until they finish and give back all buffers it got from `buf_queue` callback by calling *vb2_buffer_done*() with either VB2_BUF_STATE_DONE or VB2_BUF_STATE_ERROR; may use `vb2_wait_for_all_buffers` function

buf_queue — passes buffer vb to the driver; driver may start hardware operation on this buffer; driver should give the buffer back by calling `vb2_buffer_done` function; it is allways called after calling STREAMON ioctl; might be called before start_streaming callback if user pre-queued buffers before calling STREAMON.

one of the following

DONE and ERROR occur while streaming is in progress, and the PREPARED state occurs when the queue has been canceled and all pending buffers are being returned to their default DEQUEUED state. Typically you only have to do something if the state is VB2_BUF_STATE_DONE, since in all other cases the buffer contents will be ignored anyway.

Name

struct vb2_queue — a videobuf queue

Synopsis

```
struct vb2_queue {
  unsigned int type;
  unsigned int io_modes;
  unsigned fileio_read_once:1;
  unsigned fileio_write_immediately:1;
  unsigned allow_zero_bytesused:1;
  struct mutex * lock;
  void * owner;
  const struct vb2_ops * ops;
  const struct vb2_mem_ops * mem_ops;
  const struct vb2_buf_ops * buf_ops;
  void * drv_priv;
  unsigned int buf_struct_size;
  u32 timestamp_flags;
  gfp_t gfp_flags;
  u32 min_buffers_needed;
};
```

Members

type	private buffer type whose content is defined by the vb2-core caller. For example, for V4L2, it should match the V4L2_BUF_TYPE_* in include/uapi/linux/videodev2.h
io_modes	supported io methods (see vb2_io_modes enum)
fileio_read_once	report EOF after reading the first buffer
fileio_write_immediately	queue buffer after each `write` call
allow_zero_bytesused	allow bytesused == 0 to be passed to the driver
lock	pointer to a mutex that protects the vb2_queue struct. The driver can set this to a mutex to let the v4l2 core serialize the queuing ioctls. If the driver wants to handle locking itself, then this should be set to NULL. This lock is not used by the videobuf2 core API.
owner	The filehandle that 'owns' the buffers, i.e. the filehandle that called reqbufs, create_buffers or started fileio. This field is not used by the videobuf2 core API, but it allows drivers to easily associate an owner filehandle with the queue.
ops	driver-specific callbacks
mem_ops	memory allocator specific callbacks
buf_ops	callbacks to deliver buffer information between user-space and kernel-space

drv_priv	driver private data
buf_struct_size	size of the driver-specific buffer structure; “0” indicates the driver doesn't want to use a custom buffer structure type. for example, sizeof(struct vb2_v4l2_buffer) will be used for v4l2.
timestamp_flags	Timestamp flags; V4L2_BUF_FLAG_TIMESTAMP_* and V4L2_BUF_FLAG_TSTAMP_SRC_*
gfp_flags	additional gfp flags used when allocating the buffers. Typically this is 0, but it may be e.g. GFP_DMA or __GFP_DMA32 to force the buffer allocation to a specific memory zone.
min_buffers_needed	the minimum number of buffers needed before `start_streaming` can be called. Used when a DMA engine cannot be started unless at least this number of buffers have been queued into the driver.

Name

vb2_is_streaming — return streaming status of the queue

Synopsis

```
bool vb2_is_streaming (struct vb2_queue * q);
```

Arguments

q videobuf queue

Name

vb2_fileio_is_active — return true if fileio is active.

Synopsis

```
bool vb2_fileio_is_active (struct vb2_queue * q);
```

Arguments

q videobuf queue

Description

This returns true if `read` or `write` is used to stream the data as opposed to stream I/O. This is almost never an important distinction, except in rare cases. One such case is that using `read` or `write` to stream a format using V4L2_FIELD_ALTERNATE is not allowed since there is no way you can pass the field information of each buffer to/from userspace. A driver that supports this field format should check for this in the queue_setup op and reject it if this function returns true.

Name

vb2_is_busy — return busy status of the queue

Synopsis

```
bool vb2_is_busy (struct vb2_queue * q);
```

Arguments

q videobuf queue

Description

This function checks if queue has any buffers allocated.

Name

vb2_get_drv_priv — return driver private data associated with the queue

Synopsis

```
void * vb2_get_drv_priv (struct vb2_queue * q);
```

Arguments

q videobuf queue

Name

vb2_set_plane_payload — set bytesused for the plane plane_no

Synopsis

```
void vb2_set_plane_payload (struct vb2_buffer * vb, unsigned int plane_no, unsigned long size);
```

Arguments

vb	buffer for which plane payload should be set
plane_no	plane number for which payload should be set
size	payload in bytes

Name

vb2_get_plane_payload — get bytesused for the plane plane_no

Synopsis

```
unsigned long vb2_get_plane_payload (struct vb2_buffer * vb, unsigned
int plane_no);
```

Arguments

vb buffer for which plane payload should be set

plane_no plane number for which payload should be set

Name

vb2_plane_size — return plane size in bytes

Synopsis

```
unsigned long vb2_plane_size (struct vb2_buffer * vb, unsigned int plane_no);
```

Arguments

vb buffer for which plane size should be returned

plane_no plane number for which size should be returned

Name

vb2_start_streaming_called — return streaming status of driver

Synopsis

```
bool vb2_start_streaming_called (struct vb2_queue * q);
```

Arguments

q videobuf queue

Name

vb2_clear_last_buffer_dequeued — clear last buffer dequeued flag of queue

Synopsis

```
void vb2_clear_last_buffer_dequeued (struct vb2_queue * q);
```

Arguments

q videobuf queue

Name

struct vb2_v4l2_buffer — video buffer information for v4l2

Synopsis

```
struct vb2_v4l2_buffer {
  struct vb2_buffer vb2_buf;
  __u32 flags;
  __u32 field;
  struct timeval timestamp;
  struct v4l2_timecode timecode;
  __u32 sequence;
};
```

Members

vb2_buf	video buffer 2
flags	buffer informational flags
field	enum v4l2_field; field order of the image in the buffer
timestamp	frame timestamp
timecode	frame timecode
sequence	sequence count of this frame Should contain enough information to be able to cover all the fields of struct v4l2_buffer at videodev2.h

Name

vb2_thread_start — start a thread for the given queue.

Synopsis

```
int vb2_thread_start (struct vb2_queue * q, vb2_thread_fnc fnc, void *
priv, const char * thread_name);
```

Arguments

q	videobuf queue
fnc	callback function
priv	priv pointer passed to the callback function
thread_name	the name of the thread. This will be prefixed with “vb2-”.

Description

This starts a thread that will queue and dequeue until an error occurs or *vb2_thread_stop* is called.

This function should not be used for anything else but the videobuf2-dvb support. If you think you have another good use-case for this, then please contact the linux-media mailinglist first.

Name

vb2_thread_stop — stop the thread for the given queue.

Synopsis

```
int vb2_thread_stop (struct vb2_queue * q);
```

Arguments

q videobuf queue

Name

struct vb2_vmarea_handler — common vma refcount tracking handler

Synopsis

```
struct vb2_vmarea_handler {
  atomic_t * refcount;
  void (* put) (void *arg);
  void * arg;
};
```

Members

refcount	pointer to refcount entry in the buffer
put	callback to function that decreases buffer refcount
arg	argument for *put* callback

Digital TV (DVB) devices

Name

struct dvb_ca_en50221 — Structure describing a CA interface

Synopsis

```
struct dvb_ca_en50221 {
  struct module * owner;
  int (* read_attribute_mem) (struct dvb_ca_en50221 *ca,int slot, int address);
  int (* write_attribute_mem) (struct dvb_ca_en50221 *ca,int slot, int address, u8
  int (* read_cam_control) (struct dvb_ca_en50221 *ca,int slot, u8 address);
  int (* write_cam_control) (struct dvb_ca_en50221 *ca,int slot, u8 address, u8 va
  int (* slot_reset) (struct dvb_ca_en50221 *ca, int slot);
  int (* slot_shutdown) (struct dvb_ca_en50221 *ca, int slot);
  int (* slot_ts_enable) (struct dvb_ca_en50221 *ca, int slot);
  int (* poll_slot_status) (struct dvb_ca_en50221 *ca, int slot, int open);
  void * data;
  void * private;
};
```

Members

owner	the module owning this structure
read_attribute_mem	function for reading attribute memory on the CAM
write_attribute_mem	function for writing attribute memory on the CAM
read_cam_control	function for reading the control interface on the CAM
write_cam_control	function for reading the control interface on the CAM
slot_reset	function to reset the CAM slot
slot_shutdown	function to shutdown a CAM slot
slot_ts_enable	function to enable the Transport Stream on a CAM slot
poll_slot_status	function to poll slot status. Only necessary if DVB_CA_FLAG_EN50221_IRQ_CAMCHANGE is not set.
data	private data, used by caller.
private	Opaque data used by the dvb_ca core. Do not modify!

NOTE

the read_*, write_* and poll_slot_status functions will be called for different slots concurrently and need to use locks where and if appropriate. There will be no concurrent access to one slot.

Name

dvb_ca_en50221_camchange_irq — A CAMCHANGE IRQ has occurred.

Synopsis

```
void dvb_ca_en50221_camchange_irq (struct dvb_ca_en50221 * pubca, int slot, int change_type);
```

Arguments

pubca	CA instance.
slot	Slot concerned.
change_type	One of the DVB_CA_CAMCHANGE_* values

Name

dvb_ca_en50221_camready_irq — A CAMREADY IRQ has occurred.

Synopsis

```
void dvb_ca_en50221_camready_irq (struct dvb_ca_en50221 * pubca, int slot);
```

Arguments

pubca CA instance.

slot Slot concerned.

Name

dvb_ca_en50221_frda_irq — An FR or a DA IRQ has occurred.

Synopsis

```
void dvb_ca_en50221_frda_irq (struct dvb_ca_en50221 * ca, int slot);
```

Arguments

ca CA instance.

slot Slot concerned.

Name

dvb_ca_en50221_init — Initialise a new DVB CA device.

Synopsis

```
int dvb_ca_en50221_init (struct dvb_adapter * dvb_adapter, struct
dvb_ca_en50221 * ca, int flags, int slot_count);
```

Arguments

dvb_adapter	DVB adapter to attach the new CA device to.
ca	The dvb_ca instance.
flags	Flags describing the CA device (DVB_CA_EN50221_FLAG_*).
slot_count	Number of slots supported.

Description

return 0 on success, nonzero on failure

Name

dvb_ca_en50221_release — Release a DVB CA device.

Synopsis

```
void dvb_ca_en50221_release (struct dvb_ca_en50221 * ca);
```

Arguments

ca The associated dvb_ca instance.

Name

struct dvb_frontend_tune_settings — parameters to adjust frontend tuning

Synopsis

```
struct dvb_frontend_tune_settings {
  int min_delay_ms;
  int step_size;
  int max_drift;
};
```

Members

min_delay_ms	minimum delay for tuning, in ms
step_size	step size between two consecutive frequencies
max_drift	maximum drift

NOTE

step_size is in Hz, for terrestrial/cable or kHz for satellite

Name

struct dvb_tuner_info — Frontend name and min/max ranges/bandwidths

Synopsis

```
struct dvb_tuner_info {
  char name[128];
  u32 frequency_min;
  u32 frequency_max;
  u32 frequency_step;
  u32 bandwidth_min;
  u32 bandwidth_max;
  u32 bandwidth_step;
};
```

Members

name[128]	name of the Frontend
frequency_min	minimal frequency supported
frequency_max	maximum frequency supported
frequency_step	frequency step
bandwidth_min	minimal frontend bandwidth supported
bandwidth_max	maximum frontend bandwidth supported
bandwidth_step	frontend bandwidth step

NOTE

frequency parameters are in Hz, for terrestrial/cable or kHz for satellite.

Name

struct analog_parameters — Parameters to tune into an analog/radio channel

Synopsis

```
struct analog_parameters {
  unsigned int frequency;
  unsigned int mode;
  unsigned int audmode;
  u64 std;
};
```

Members

frequency	Frequency used by analog TV tuner (either in 62.5 kHz step, for TV, or 62.5 Hz for radio)
mode	Tuner mode, as defined on enum v4l2_tuner_type
audmode	Audio mode as defined for the rxsubchans field at videodev2.h, e. g. V4L2_TUNER_MODE_*
std	TV standard bitmap as defined at videodev2.h, e. g. V4L2_STD_*

Description

Hybrid tuners should be supported by both V4L2 and DVB APIs. This struct contains the data that are used by the V4L2 side. To avoid dependencies from V4L2 headers, all enums here are declared as integers.

Name

enum dvbfe_algo — defines the algorithm used to tune into a channel

Synopsis

```
enum dvbfe_algo {
  DVBFE_ALGO_HW,
  DVBFE_ALGO_SW,
  DVBFE_ALGO_CUSTOM,
  DVBFE_ALGO_RECOVERY
};
```

Constants

DVBFE_ALGO_HW	Hardware Algorithm - Devices that support this algorithm do everything in hardware and no software support is needed to handle them. Requesting these devices to LOCK is the only thing required, device is supposed to do everything in the hardware.
DVBFE_ALGO_SW	Software Algorithm - These are dumb devices, that require software to do everything
DVBFE_ALGO_CUSTOM	Customizable Agorithm - Devices having this algorithm can be customized to have specific algorithms in the frontend driver, rather than simply doing a software zig-zag. In this case the zigzag maybe hardware assisted or it maybe completely done in hardware. In all cases, usage of this algorithm, in conjunction with the search and track callbacks, utilizes the driver specific algorithm.
DVBFE_ALGO_RECOVERY	Recovery Algorithm - These devices have AUTO recovery capabilities from LOCK failure

Name

enum dvbfe_search — search callback possible return status

Synopsis

```
enum dvbfe_search {
  DVBFE_ALGO_SEARCH_SUCCESS,
  DVBFE_ALGO_SEARCH_ASLEEP,
  DVBFE_ALGO_SEARCH_FAILED,
  DVBFE_ALGO_SEARCH_INVALID,
  DVBFE_ALGO_SEARCH_AGAIN,
  DVBFE_ALGO_SEARCH_ERROR
};
```

Constants

DVBFE_ALGO_SEARCH_SUCCESS	The frontend search algorithm completed and returned successfully
DVBFE_ALGO_SEARCH_ASLEEP	The frontend search algorithm is sleeping
DVBFE_ALGO_SEARCH_FAILED	The frontend search for a signal failed
DVBFE_ALGO_SEARCH_INVALID	The frontend search algorith was probably supplied with invalid parameters and the search is an invalid one
DVBFE_ALGO_SEARCH_AGAIN	The frontend search algorithm was requested to search again
DVBFE_ALGO_SEARCH_ERROR	The frontend search algorithm failed due to some error

Name

struct dvb_tuner_ops — Tuner information and callbacks

Synopsis

```
struct dvb_tuner_ops {
  struct dvb_tuner_info info;
  int (* release) (struct dvb_frontend *fe);
  int (* init) (struct dvb_frontend *fe);
  int (* sleep) (struct dvb_frontend *fe);
  int (* suspend) (struct dvb_frontend *fe);
  int (* resume) (struct dvb_frontend *fe);
  int (* set_params) (struct dvb_frontend *fe);
  int (* set_analog_params) (struct dvb_frontend *fe, struct analog_parameters *p)
  int (* calc_regs) (struct dvb_frontend *fe, u8 *buf, int buf_len);
  int (* set_config) (struct dvb_frontend *fe, void *priv_cfg);
  int (* get_frequency) (struct dvb_frontend *fe, u32 *frequency);
  int (* get_bandwidth) (struct dvb_frontend *fe, u32 *bandwidth);
  int (* get_if_frequency) (struct dvb_frontend *fe, u32 *frequency);
#define TUNER_STATUS_LOCKED 1
#define TUNER_STATUS_STEREO 2
  int (* get_status) (struct dvb_frontend *fe, u32 *status);
  int (* get_rf_strength) (struct dvb_frontend *fe, u16 *strength);
  int (* get_afc) (struct dvb_frontend *fe, s32 *afc);
  int (* set_frequency) (struct dvb_frontend *fe, u32 frequency);
  int (* set_bandwidth) (struct dvb_frontend *fe, u32 bandwidth);
  int (* set_state) (struct dvb_frontend *fe, enum tuner_param param, struct tuner
  int (* get_state) (struct dvb_frontend *fe, enum tuner_param param, struct tuner
};
```

Members

info	embedded struct dvb_tuner_info with tuner properties
release	callback function called when frontend is dettached. drivers should free any allocated memory.
init	callback function used to initialize the tuner device.
sleep	callback function used to put the tuner to sleep.
suspend	callback function used to inform that the Kernel will suspend.
resume	callback function used to inform that the Kernel is resuming from suspend.
set_params	callback function used to inform the tuner to tune into a digital TV channel. The properties to be used are stored at *dvb_frontend*.dtv_property_cache;. The tuner demod can change the parameters to reflect the changes needed for the channel to be tuned, and update statistics.
set_analog_params	callback function used to tune into an analog TV channel on hybrid tuners. It passes *analog_parameters*; to the driver.
calc_regs	callback function used to pass register data settings for simple tuners.

set_config	callback function used to send some tuner-specific parameters.
get_frequency	get the actual tuned frequency
get_bandwidth	get the bandwitdh used by the low pass filters
get_if_frequency	get the Intermediate Frequency, in Hz. For baseband, should return 0.
get_status	returns the frontend lock status
get_rf_strength	returns the RF signal strengh. Used mostly to support analog TV and radio. Digital TV should report, instead, via DVBv5 API (*dvb_frontend*.dtv_property_cache;).
get_afc	Used only by analog TV core. Reports the frequency drift due to AFC.
set_frequency	Set a new frequency. Please notice that using set_params is preferred.
set_bandwidth	Set a new frequency. Please notice that using set_params is preferred.
set_state	callback function used on some legacy drivers that don't implement set_params in order to set properties. Shouldn't be used on new drivers.
get_state	callback function used to get properties by some legacy drivers that don't implement set_params. Shouldn't be used on new drivers.

NOTE

frequencies used on get_frequency and set_frequency are in Hz for terrestrial/cable or kHz for satellite.

Name

struct analog_demod_info — Information struct for analog TV part of the demod

Synopsis

```
struct analog_demod_info {
  char * name;
};
```

Members

name Name of the analog TV demodulator

Name

struct analog_demod_ops — Demodulation information and callbacks for analog TV and radio

Synopsis

```
struct analog_demod_ops {
  struct analog_demod_info info;
  void (* set_params) (struct dvb_frontend *fe,struct analog_parameters *params);
  int (* has_signal) (struct dvb_frontend *fe, u16 *signal);
  int (* get_afc) (struct dvb_frontend *fe, s32 *afc);
  void (* tuner_status) (struct dvb_frontend *fe);
  void (* standby) (struct dvb_frontend *fe);
  void (* release) (struct dvb_frontend *fe);
  int (* i2c_gate_ctrl) (struct dvb_frontend *fe, int enable);
  int (* set_config) (struct dvb_frontend *fe, void *priv_cfg);
};
```

Members

info	pointer to struct analog_demod_info
set_params	callback function used to inform the demod to set the demodulator parameters needed to decode an analog or radio channel. The properties are passed via struct *analog_params*;.
has_signal	returns 0xffff if has signal, or 0 if it doesn't.
get_afc	Used only by analog TV core. Reports the frequency drift due to AFC.
tuner_status	callback function that returns tuner status bits, e. g. TUNER_STATUS_LOCKED and TUNER_STATUS_STEREO.
standby	set the tuner to standby mode.
release	callback function called when frontend is dettached. drivers should free any allocated memory.
i2c_gate_ctrl	controls the I2C gate. Newer drivers should use I2C mux support instead.
set_config	callback function used to send some tuner-specific parameters.

Name

struct dvb_frontend_ops — Demodulation information and callbacks for ditialt TV

Synopsis

```
struct dvb_frontend_ops {
  struct dvb_frontend_info info;
  u8 delsys[MAX_DELSYS];
  void (* release) (struct dvb_frontend* fe);
  void (* release_sec) (struct dvb_frontend* fe);
  int (* init) (struct dvb_frontend* fe);
  int (* sleep) (struct dvb_frontend* fe);
  int (* write) (struct dvb_frontend* fe, const u8 buf[], int len);
  int (* tune) (struct dvb_frontend* fe,bool re_tune,unsigned int mode_flags,unsig
  enum dvbfe_algo (* get_frontend_algo) (struct dvb_frontend *fe);
  int (* set_frontend) (struct dvb_frontend *fe);
  int (* get_tune_settings) (struct dvb_frontend* fe, struct dvb_frontend_tune_set
  int (* get_frontend) (struct dvb_frontend *fe);
  int (* read_status) (struct dvb_frontend *fe, enum fe_status *status);
  int (* read_ber) (struct dvb_frontend* fe, u32* ber);
  int (* read_signal_strength) (struct dvb_frontend* fe, u16* strength);
  int (* read_snr) (struct dvb_frontend* fe, u16* snr);
  int (* read_ucblocks) (struct dvb_frontend* fe, u32* ucblocks);
  int (* diseqc_reset_overload) (struct dvb_frontend* fe);
  int (* diseqc_send_master_cmd) (struct dvb_frontend* fe, struct dvb_diseqc_maste
  int (* diseqc_recv_slave_reply) (struct dvb_frontend* fe, struct dvb_diseqc_slav
  int (* diseqc_send_burst) (struct dvb_frontend *fe,enum fe_sec_mini_cmd minicmd)
  int (* set_tone) (struct dvb_frontend *fe, enum fe_sec_tone_mode tone);
  int (* set_voltage) (struct dvb_frontend *fe,enum fe_sec_voltage voltage);
  int (* enable_high_lnb_voltage) (struct dvb_frontend* fe, long arg);
  int (* dishnetwork_send_legacy_command) (struct dvb_frontend* fe, unsigned long
  int (* i2c_gate_ctrl) (struct dvb_frontend* fe, int enable);
  int (* ts_bus_ctrl) (struct dvb_frontend* fe, int acquire);
  int (* set_lna) (struct dvb_frontend *);
  enum dvbfe_search (* search) (struct dvb_frontend *fe);
  struct dvb_tuner_ops tuner_ops;
  struct analog_demod_ops analog_ops;
  int (* set_property) (struct dvb_frontend* fe, struct dtv_property* tvp);
  int (* get_property) (struct dvb_frontend* fe, struct dtv_property* tvp);
};
```

Members

info	embedded struct dvb_tuner_info with tuner properties
delsys[MAX_DELSYS]	Delivery systems supported by the frontend
release	callback function called when frontend is dettached. drivers should free any allocated memory.
release_sec	callback function requesting that the Satelite Equipment Control (SEC) driver to release and free any memory allocated by the driver.

init	callback function used to initialize the tuner device.
sleep	callback function used to put the tuner to sleep.
write	callback function used by some demod legacy drivers to allow other drivers to write data into their registers. Should not be used on new drivers.
tune	callback function used by demod drivers that use *DVBFE_ALGO_HW*; to tune into a frequency.
get_frontend_algo	returns the desired hardware algorithm.
set_frontend	callback function used to inform the demod to set the parameters for demodulating a digital TV channel. The properties to be used are stored at *dvb_frontend*.dtv_property_cache;. The demod can change the parameters to reflect the changes needed for the channel to be decoded, and update statistics.
get_tune_settings	callback function
get_frontend	callback function used to inform the parameters actuall in use. The properties to be used are stored at *dvb_frontend*.dtv_property_cache; and update statistics. Please notice that it should not return an error code if the statistics are not available because the demog is not locked.
read_status	returns the locking status of the frontend.
read_ber	legacy callback function to return the bit error rate. Newer drivers should provide such info via DVBv5 API, e. g. *set_frontend*;/*get_frontend*;, implementing this callback only if DVBv3 API compatibility is wanted.
read_signal_strength	legacy callback function to return the signal strength. Newer drivers should provide such info via DVBv5 API, e. g. *set_frontend*;/*get_frontend*;, implementing this callback only if DVBv3 API compatibility is wanted.
read_snr	legacy callback function to return the Signal/Noise rate. Newer drivers should provide such info via DVBv5 API, e. g. *set_frontend*;/*get_frontend*;, implementing this callback only if DVBv3 API compatibility is wanted.
read_ucblocks	legacy callback function to return the Uncorrected Error Blocks. Newer drivers should provide such info via DVBv5 API, e. g. *set_frontend*;/*get_frontend*;, implementing this callback only if DVBv3 API compatibility is wanted.
diseqc_reset_overload	callback function to implement the FE_DISEQC_RESET_OVERLOAD ioctl (only Satellite)
diseqc_send_master_cmd	callback function to implement the FE_DISEQC_SEND_MASTER_CMD ioctl (only Satellite).
diseqc_recv_slave_reply	callback function to implement the FE_DISEQC_RECV_SLAVE_REPLY ioctl (only Satellite)

diseqc_send_burst	callback function to implement the FE_DISEQC_SEND_BURST ioctl (only Satellite).
set_tone	callback function to implement the FE_SET_TONE ioctl (only Satellite).
set_voltage	callback function to implement the FE_SET_VOLTAGE ioctl (only Satellite).
enable_high_lnb_voltage	callback function to implement the FE_ENABLE_HIGH_LNB_VOLTAGE ioctl (only Satellite).
dishnetwork_send_legacy_command	callback function to implement the FE_DISHNETWORK_SEND_LEGACY_CMD ioctl (only Satellite).
i2c_gate_ctrl	controls the I2C gate. Newer drivers should use I2C mux support instead.
ts_bus_ctrl	callback function used to take control of the TS bus.
set_lna	callback function to power on/off/auto the LNA.
search	callback function used on some custom algo search algos.
tuner_ops	pointer to struct dvb_tuner_ops
analog_ops	pointer to struct analog_demod_ops
set_property	callback function to allow the frontend to validade incoming properties. Should not be used on new drivers.
get_property	callback function to allow the frontend to override outcoming properties. Should not be used on new drivers.

Name

struct dtv_frontend_properties — contains a list of properties that are specific to a digital TV standard.

Synopsis

```
struct dtv_frontend_properties {
  u32 frequency;
  enum fe_modulation modulation;
  enum fe_sec_voltage voltage;
  enum fe_sec_tone_mode sectone;
  enum fe_spectral_inversion inversion;
  enum fe_code_rate fec_inner;
  enum fe_transmit_mode transmission_mode;
  u32 bandwidth_hz;
  enum fe_guard_interval guard_interval;
  enum fe_hierarchy hierarchy;
  u32 symbol_rate;
  enum fe_code_rate code_rate_HP;
  enum fe_code_rate code_rate_LP;
  enum fe_pilot pilot;
  enum fe_rolloff rolloff;
  enum fe_delivery_system delivery_system;
  enum fe_interleaving interleaving;
  u8 isdbt_partial_reception;
  u8 isdbt_sb_mode;
  u8 isdbt_sb_subchannel;
  u32 isdbt_sb_segment_idx;
  u32 isdbt_sb_segment_count;
  u8 isdbt_layer_enabled;
  struct layer[3];
  u32 stream_id;
  u8 atscmh_fic_ver;
  u8 atscmh_parade_id;
  u8 atscmh_nog;
  u8 atscmh_tnog;
  u8 atscmh_sgn;
  u8 atscmh_prc;
  u8 atscmh_rs_frame_mode;
  u8 atscmh_rs_frame_ensemble;
  u8 atscmh_rs_code_mode_pri;
  u8 atscmh_rs_code_mode_sec;
  u8 atscmh_sccc_block_mode;
  u8 atscmh_sccc_code_mode_a;
  u8 atscmh_sccc_code_mode_b;
  u8 atscmh_sccc_code_mode_c;
  u8 atscmh_sccc_code_mode_d;
  u32 lna;
  struct dtv_fe_stats strength;
  struct dtv_fe_stats cnr;
  struct dtv_fe_stats pre_bit_error;
  struct dtv_fe_stats pre_bit_count;
  struct dtv_fe_stats post_bit_error;
```

```
  struct dtv_fe_stats post_bit_count;
  struct dtv_fe_stats block_error;
  struct dtv_fe_stats block_count;
};
```

Members

frequency	frequency in Hz for terrestrial/cable or in kHz for Satellite
modulation	Frontend modulation type
voltage	SEC voltage (only Satellite)
sectone	SEC tone mode (only Satellite)
inversion	Spectral inversion
fec_inner	Forward error correction inner Code Rate
transmission_mode	Transmission Mode
bandwidth_hz	Bandwidth, in Hz. A zero value means that userspace wants to autodetect.
guard_interval	Guard Interval
hierarchy	Hierarchy
symbol_rate	Symbol Rate
code_rate_HP	high priority stream code rate
code_rate_LP	low priority stream code rate
pilot	Enable/disable/autodetect pilot tones
rolloff	Rolloff factor (alpha)
delivery_system	FE delivery system (e. g. digital TV standard)
interleaving	interleaving
isdbt_partial_reception	ISDB-T partial reception (only ISDB standard)
isdbt_sb_mode	ISDB-T Sound Broadcast (SB) mode (only ISDB standard)
isdbt_sb_subchannel	ISDB-T SB subchannel (only ISDB standard)
isdbt_sb_segment_idx	ISDB-T SB segment index (only ISDB standard)
isdbt_sb_segment_count	ISDB-T SB segment count (only ISDB standard)
isdbt_layer_enabled	ISDB Layer enabled (only ISDB standard)
layer[3]	ISDB per-layer data (only ISDB standard) *layer*.segment_count: Segment Count; *layer*.fec: per layer code rate; *layer*.modulation: per layer modulation; *layer*.interleaving: per layer interleaving.

stream_id	If different than zero, enable substream filtering, if hardware supports (DVB-S2 and DVB-T2).
atscmh_fic_ver	Version number of the FIC (Fast Information Channel) signaling data (only ATSC-M/H)
atscmh_parade_id	Parade identification number (only ATSC-M/H)
atscmh_nog	Number of MH groups per MH subframe for a designated parade (only ATSC-M/H)
atscmh_tnog	Total number of MH groups including all MH groups belonging to all MH parades in one MH subframe (only ATSC-M/H)
atscmh_sgn	Start group number (only ATSC-M/H)
atscmh_prc	Parade repetition cycle (only ATSC-M/H)
atscmh_rs_frame_mode	Reed Solomon (RS) frame mode (only ATSC-M/H)
atscmh_rs_frame_ensemble	RS frame ensemble (only ATSC-M/H)
atscmh_rs_code_mode_pri	RS code mode pri (only ATSC-M/H)
atscmh_rs_code_mode_sec	RS code mode sec (only ATSC-M/H)
atscmh_sccc_block_mode	Series Concatenated Convolutional Code (SCCC) Block Mode (only ATSC-M/H)
atscmh_sccc_code_mode_a	SCCC code mode A (only ATSC-M/H)
atscmh_sccc_code_mode_b	SCCC code mode B (only ATSC-M/H)
atscmh_sccc_code_mode_c	SCCC code mode C (only ATSC-M/H)
atscmh_sccc_code_mode_d	SCCC code mode D (only ATSC-M/H)
lna	Power ON/OFF/AUTO the Linear Now-noise Amplifier (LNA)
strength	DVBv5 API statistics: Signal Strength
cnr	DVBv5 API statistics: Signal to Noise ratio of the (main) carrier
pre_bit_error	DVBv5 API statistics: pre-Viterbi bit error count
pre_bit_count	DVBv5 API statistics: pre-Viterbi bit count
post_bit_error	DVBv5 API statistics: post-Viterbi bit error count
post_bit_count	DVBv5 API statistics: post-Viterbi bit count
block_error	DVBv5 API statistics: block error count
block_count	DVBv5 API statistics: block count

NOTE

derivated statistics like Uncorrected Error blocks (UCE) are calculated on userspace.

Only a subset of the properties are needed for a given delivery system. For more info, consult the media_api.html with the documentation of the Userspace API.

Name

struct dvb_frontend — Frontend structure to be used on drivers.

Synopsis

```
struct dvb_frontend {
  struct dvb_frontend_ops ops;
  struct dvb_adapter * dvb;
  void * demodulator_priv;
  void * tuner_priv;
  void * frontend_priv;
  void * sec_priv;
  void * analog_demod_priv;
  struct dtv_frontend_properties dtv_property_cache;
#define DVB_FRONTEND_COMPONENT_TUNER 0
#define DVB_FRONTEND_COMPONENT_DEMOD 1
  int (* callback) (void *adapter_priv, int component, int cmd, int arg);
  int id;
  unsigned int exit;
};
```

Members

ops	embedded struct dvb_frontend_ops
dvb	pointer to struct dvb_adapter
demodulator_priv	demod private data
tuner_priv	tuner private data
frontend_priv	frontend private data
sec_priv	SEC private data
analog_demod_priv	Analog demod private data
dtv_property_cache	embedded struct dtv_frontend_properties
callback	callback function used on some drivers to call either the tuner or the demodulator.
id	Frontend ID
exit	Used to inform the DVB core that the frontend thread should exit (usually, means that the hardware got disconnected.

Name

intlog2 — computes log2 of a value; the result is shifted left by 24 bits

Synopsis

```
unsigned int intlog2 (u32 value);
```

Arguments

value The value (must be != 0)

to use rational values you can use the following method

intlog2(value) = intlog2(value * 2^x) - x * 2^24

Some usecase examples

```
intlog2(8) will give 3 << 24 = 3 * 2^24
intlog2(9) will give 3 << 24 + ... = 3.16... * 2^24
intlog2(1.5) = intlog2(3) - 2^24 = 0.584... * 2^24
```

return

log2(value) * 2^24

Name

intlog10 — computes log10 of a value; the result is shifted left by 24 bits

Synopsis

```
unsigned int intlog10 (u32 value);
```

Arguments

value The value (must be != 0)

to use rational values you can use the following method

intlog10(value) = intlog10(value * 10^x) - x * 2^24

An usecase example

```
intlog10(1000) will give 3 << 24 = 3 * 2^24
 due to the implementation intlog10(1000) might be not exactly 3 * 2^24

look at intlog2 for similar examples
```

return

log10(value) * 2^24

Name

dvb_ringbuffer_pkt_write — Write a packet into the ringbuffer.

Synopsis

```
ssize_t dvb_ringbuffer_pkt_write (struct dvb_ringbuffer * rbuf, u8 *
buf, size_t len);
```

Arguments

rbuf Ringbuffer to write to.

buf Buffer to write.

len Length of buffer (currently limited to 65535 bytes max). returns Number of bytes written, or -EFAULT, -ENOMEM, -EVINAL.

Name

dvb_ringbuffer_pkt_read_user — Read from a packet in the ringbuffer.

Synopsis

```
ssize_t dvb_ringbuffer_pkt_read_user (struct dvb_ringbuffer * rbuf,
size_t idx, int offset, u8 __user * buf, size_t len);
```

Arguments

rbuf Ringbuffer concerned.

idx Packet index as returned by `dvb_ringbuffer_pkt_next`.

offset Offset into packet to read from.

buf Destination buffer for data.

len Size of destination buffer.

Note

unlike `dvb_ringbuffer_read`, this does NOT update the read pointer in the ringbuffer. You must use `dvb_ringbuffer_pkt_dispose` to mark a packet as no longer required.

Description

returns Number of bytes read, or -EFAULT.

Name

dvb_ringbuffer_pkt_read — Read from a packet in the ringbuffer.

Synopsis

```
ssize_t dvb_ringbuffer_pkt_read (struct dvb_ringbuffer * rbuf, size_t
idx, int offset, u8 * buf, size_t len);
```

Arguments

rbuf Ringbuffer concerned.

idx Packet index as returned by `dvb_ringbuffer_pkt_next`.

offset Offset into packet to read from.

buf Destination buffer for data.

len Size of destination buffer.

Note

unlike `dvb_ringbuffer_read_user`, this DOES update the read pointer in the ringbuffer.

Description

returns Number of bytes read, or -EFAULT.

Name

dvb_ringbuffer_pkt_dispose — Dispose of a packet in the ring buffer.

Synopsis

```
void dvb_ringbuffer_pkt_dispose (struct dvb_ringbuffer * rbuf, size_t
idx);
```

Arguments

rbuf Ring buffer concerned.

idx Packet index as returned by `dvb_ringbuffer_pkt_next`.

Name

dvb_ringbuffer_pkt_next — Get the index of the next packet in a ringbuffer.

Synopsis

```
ssize_t dvb_ringbuffer_pkt_next (struct dvb_ringbuffer * rbuf, size_t
idx, size_t * pktlen);
```

Arguments

rbuf Ringbuffer concerned.

idx Previous packet index, or -1 to return the first packet index.

pktlen On success, will be updated to contain the length of the packet in bytes. returns Packet index (if >=0), or -1 if no packets available.

Name

struct dvb_adapter — represents a Digital TV adapter using Linux DVB API

Synopsis

```
struct dvb_adapter {
  int num;
  struct list_head list_head;
  struct list_head device_list;
  const char * name;
  u8 proposed_mac[6];
  void * priv;
  struct device * device;
  struct module * module;
  int mfe_shared;
  struct dvb_device * mfe_dvbdev;
  struct mutex mfe_lock;
#if defined(CONFIG_MEDIA_CONTROLLER_DVB)
  struct media_device * mdev;
#endif
};
```

Members

num	Number of the adapter
list_head	List with the DVB adapters
device_list	List with the DVB devices
name	Name of the adapter
proposed_mac[6]	proposed MAC address for the adapter
priv	private data
device	pointer to struct device
module	pointer to struct module
mfe_shared	mfe shared: indicates mutually exclusive frontends Thie usage of this flag is currently deprecated
mfe_dvbdev	Frontend device in use, in the case of MFE
mfe_lock	Lock to prevent using the other frontends when MFE is used.
mdev	pointer to struct media_device, used when the media controller is used.

Name

struct dvb_device — represents a DVB device node

Synopsis

```
struct dvb_device {
  struct list_head list_head;
  const struct file_operations * fops;
  struct dvb_adapter * adapter;
  int type;
  int minor;
  u32 id;
  int readers;
  int writers;
  int users;
  wait_queue_head_t wait_queue;
  int (* kernel_ioctl) (struct file *file, unsigned int cmd, void *arg);
#if defined(CONFIG_MEDIA_CONTROLLER_DVB)
  const char * name;
  struct media_entity * entity;
  struct media_pad * pads;
#endif
  void * priv;
};
```

Members

list_head	List head with all DVB devices
fops	pointer to struct file_operations
adapter	pointer to the adapter that holds this device node
type	type of the device: DVB_DEVICE_SEC, DVB_DEVICE_FRONTEND, DVB_DEVICE_DEMUX, DVB_DEVICE_DVR, DVB_DEVICE_CA, DVB_DEVICE_NET
minor	devnode minor number. Major number is always DVB_MAJOR.
id	device ID number, inside the adapter
readers	Initialized by the caller. Each call to `open` in Read Only mode decreases this counter by one.
writers	Initialized by the caller. Each call to `open` in Read/Write mode decreases this counter by one.
users	Initialized by the caller. Each call to `open` in any mode decreases this counter by one.
wait_queue	wait queue, used to wait for certain events inside one of the DVB API callers
kernel_ioctl	callback function used to handle ioctl calls from userspace.
name	Name to be used for the device at the Media Controller

entity	pointer to struct media_entity associated with the device node
pads	pointer to struct media_pad associated with *entity*;
priv	private data

Description

This structure is used by the DVB core (frontend, CA, net, demux) in order to create the device nodes. Usually, driver should not initialize this struct diretly.

Name

dvb_register_adapter — Registers a new DVB adapter

Synopsis

```
int dvb_register_adapter (struct dvb_adapter * adap, const char * name,
struct module * module, struct device * device, short * adapter_nums);
```

Arguments

adap	pointer to struct dvb_adapter
name	Adapter's name
module	initialized with THIS_MODULE at the caller
device	pointer to struct device that corresponds to the device driver
adapter_nums	Array with a list of the numbers for *dvb_register_adapter*; to select among them. Typically, initialized with: DVB_DEFINE_MOD_OPT_ADAPTER_NR(adapter_nums)

Name

dvb_unregister_adapter — Unregisters a DVB adapter

Synopsis

```
int dvb_unregister_adapter (struct dvb_adapter * adap);
```

Arguments

adap pointer to struct dvb_adapter

Name

dvb_register_device — Registers a new DVB device

Synopsis

```
int dvb_register_device (struct dvb_adapter * adap, struct dvb_device
** pdvbdev, const struct dvb_device * template, void * priv, int type);
```

Arguments

adap	pointer to struct dvb_adapter
pdvbdev	pointer to the place where the new struct dvb_device will be stored
template	Template used to create pdvbdev;
priv	private data
type	type of the device: DVB_DEVICE_SEC, DVB_DEVICE_FRONTEND, DVB_DEVICE_DEMUX, DVB_DEVICE_DVR, DVB_DEVICE_CA, DVB_DEVICE_NET

Name

dvb_unregister_device — Unregisters a DVB device

Synopsis

```
void dvb_unregister_device (struct dvb_device * dvbdev);
```

Arguments

dvbdev pointer to struct dvb_device

Digital TV Demux API

The kernel demux API defines a driver-internal interface for registering low-level, hardware specific driver to a hardware independent demux layer. It is only of interest for Digital TV device driver writers. The header file for this API is named `demux.h` and located in `drivers/media/dvb-core`.

The demux API should be implemented for each demux in the system. It is used to select the TS source of a demux and to manage the demux resources. When the demux client allocates a resource via the demux API, it receives a pointer to the API of that resource.

Each demux receives its TS input from a DVB front-end or from memory, as set via this demux API. In a system with more than one front-end, the API can be used to select one of the DVB front-ends as a TS source for a demux, unless this is fixed in the HW platform. The demux API only controls front-ends regarding to their connections with demuxes; the APIs used to set the other front-end parameters, such as tuning, are not defined in this document.

The functions that implement the abstract interface demux should be defined static or module private and registered to the Demux core for external access. It is not necessary to implement every function in the struct `dmx_demux`. For example, a demux interface might support Section filtering, but not PES filtering. The API client is expected to check the value of any function pointer before calling the function: the value of NULL means that the “function is not available”.

Whenever the functions of the demux API modify shared data, the possibilities of lost update and race condition problems should be addressed, e.g. by protecting parts of code with mutexes.

Note that functions called from a bottom half context must not sleep. Even a simple memory allocation without using GFP_ATOMIC can result in a kernel thread being put to sleep if swapping is needed. For example, the Linux kernel calls the functions of a network device interface from a bottom half context. Thus, if a demux API function is called from network device code, the function must not sleep.

Demux Callback API

This kernel-space API comprises the callback functions that deliver filtered data to the demux client. Unlike the other DVB kABIs, these functions are provided by the client and called from the demux code.

The function pointers of this abstract interface are not packed into a structure as in the other demux APIs, because the callback functions are registered and used independent of each other. As an example, it is possible for the API client to provide several callback functions for receiving TS packets and no callbacks for PES packets or sections.

The functions that implement the callback API need not be re-entrant: when a demux driver calls one of these functions, the driver is not allowed to call the function again before the original call returns. If a

callback is triggered by a hardware interrupt, it is recommended to use the Linux “bottom half” mechanism or start a tasklet instead of making the callback function call directly from a hardware interrupt.

This mechanism is implemented by dmx_ts_cb() and dmx_section_cb().

Name

enum ts_filter_type — filter type bitmap for dmx_ts_feed.set

Synopsis

```
enum ts_filter_type {
  TS_PACKET,
  TS_PAYLOAD_ONLY,
  TS_DECODER,
  TS_DEMUX
};
```

Constants

TS_PACKET	Send TS packets (188 bytes) to callback (default).
TS_PAYLOAD_ONLY	In case TS_PACKET is set, only send the TS payload (<=184 bytes per packet) to callback
TS_DECODER	Send stream to built-in decoder (if present).
TS_DEMUX	In case TS_PACKET is set, send the TS to the demux device, not to the dvr device

Name

struct dmx_ts_feed — Structure that contains a TS feed filter

Synopsis

```
struct dmx_ts_feed {
  int is_filtering;
  struct dmx_demux * parent;
  void * priv;
  int (* set) (struct dmx_ts_feed *feed,u16 pid,int type,enum dmx_ts_pes pes_type,
  int (* start_filtering) (struct dmx_ts_feed *feed);
  int (* stop_filtering) (struct dmx_ts_feed *feed);
};
```

Members

is_filtering	Set to non-zero when filtering in progress
parent	pointer to struct dmx_demux
priv	pointer to private data of the API client
set	sets the TS filter
start_filtering	starts TS filtering
stop_filtering	stops TS filtering

Description

A TS feed is typically mapped to a hardware PID filter on the demux chip. Using this API, the client can set the filtering properties to start/stop filtering TS packets on a particular TS feed.

Name

struct dmx_section_filter — Structure that describes a section filter

Synopsis

```
struct dmx_section_filter {
  u8 filter_value[DMX_MAX_FILTER_SIZE];
  u8 filter_mask[DMX_MAX_FILTER_SIZE];
  u8 filter_mode[DMX_MAX_FILTER_SIZE];
  struct dmx_section_feed * parent;
  void * priv;
};
```

Members

filter_value[DMX_MAX_FILTER_SIZE] — Contains up to 16 bytes (128 bits) of the TS section header that will be matched by the section filter

filter_mask[DMX_MAX_FILTER_SIZE] — Contains a 16 bytes (128 bits) filter mask with the bits specified by *filter_value* that will be used on the filter match logic.

filter_mode[DMX_MAX_FILTER_SIZE] — Contains a 16 bytes (128 bits) filter mode.

parent — Pointer to struct dmx_section_feed.

priv — Pointer to private data of the API client.

Description

The *filter_mask* controls which bits of *filter_value* are compared with the section headers/ payload. On a binary value of 1 in filter_mask, the corresponding bits are compared. The filter only accepts sections that are equal to filter_value in all the tested bit positions.

Name

struct dmx_section_feed — Structure that contains a section feed filter

Synopsis

```
struct dmx_section_feed {
  int is_filtering;
  struct dmx_demux * parent;
  void * priv;
  int check_crc;
  int (* set) (struct dmx_section_feed *feed,u16 pid,size_t circular_buffer_size,i
  int (* allocate_filter) (struct dmx_section_feed *feed,struct dmx_section_filter
  int (* release_filter) (struct dmx_section_feed *feed,struct dmx_section_filter
  int (* start_filtering) (struct dmx_section_feed *feed);
  int (* stop_filtering) (struct dmx_section_feed *feed);
};
```

Members

is_filtering	Set to non-zero when filtering in progress
parent	pointer to struct dmx_demux
priv	pointer to private data of the API client
check_crc	If non-zero, check the CRC values of filtered sections.
set	sets the section filter
allocate_filter	This function is used to allocate a section filter on the demux. It should only be called when no filtering is in progress on this section feed. If a filter cannot be allocated, the function fails with -ENOSPC.
release_filter	This function releases all the resources of a previously allocated section filter. The function should not be called while filtering is in progress on this section feed. After calling this function, the caller should not try to dereference the filter pointer.
start_filtering	starts section filtering
stop_filtering	stops section filtering

Description

A TS feed is typically mapped to a hardware PID filter on the demux chip. Using this API, the client can set the filtering properties to start/stop filtering TS packets on a particular TS feed.

Name

dmx_ts_cb — DVB demux TS filter callback function prototype

Synopsis

```
int dmx_ts_cb (const u8 * buffer1, size_t buffer1_length, const u8 *
buffer2, size_t buffer2_length, struct dmx_ts_feed * source);
```

Arguments

buffer1	Pointer to the start of the filtered TS packets.
buffer1_length	Length of the TS data in buffer1.
buffer2	Pointer to the tail of the filtered TS packets, or NULL.
buffer2_length	Length of the TS data in buffer2.
source	Indicates which TS feed is the source of the callback.

Description

This function callback prototype, provided by the client of the demux API, is called from the demux code. The function is only called when filtering on ae TS feed has been enabled using the `start_filtering` function at the dmx_demux. Any TS packets that match the filter settings are copied to a circular buffer. The filtered TS packets are delivered to the client using this callback function. The size of the circular buffer is controlled by the circular_buffer_size parameter of the dmx_ts_feed.*set* function. It is expected that the *buffer1* and *buffer2* callback parameters point to addresses within the circular buffer, but other implementations are also possible. Note that the called party should not try to free the memory the *buffer1* and *buffer2* parameters point to.

When this function is called, the *buffer1* parameter typically points to the start of the first undelivered TS packet within a circular buffer. The *buffer2* buffer parameter is normally NULL, except when the received TS packets have crossed the last address of the circular buffer and ”wrapped” to the beginning of the buffer. In the latter case the *buffer1* parameter would contain an address within the circular buffer, while the *buffer2* parameter would contain the first address of the circular buffer. The number of bytes delivered with this function (i.e. *buffer1_length* + *buffer2_length*) is usually equal to the value of callback_length parameter given in the `set` function, with one exception: if a timeout occurs before receiving callback_length bytes of TS data, any undelivered packets are immediately delivered to the client by calling this function. The timeout duration is controlled by the `set` function in the TS Feed API.

If a TS packet is received with errors that could not be fixed by the TS-level forward error correction (FEC), the Transport_error_indicator flag of the TS packet header should be set. The TS packet should not be discarded, as the error can possibly be corrected by a higher layer protocol. If the called party is slow in processing the callback, it is possible that the circular buffer eventually fills up. If this happens, the demux driver should discard any TS packets received while the buffer is full and return -EOVERFLOW.

The type of data returned to the callback can be selected by the dmx_ts_feed.*set* function. The type parameter decides if the raw TS packet (TS_PACKET) or just the payload (TS_PACKET| TS_PAYLOAD_ONLY) should be returned. If additionally the TS_DECODER bit is set the stream will also be sent to the hardware MPEG decoder.

Return

0, on success; -EOVERFLOW, on buffer overflow.

Name

dmx_section_cb — DVB demux TS filter callback function prototype

Synopsis

```
int dmx_section_cb (const u8 * buffer1, size_t buffer1_len, const u8 *
buffer2, size_t buffer2_len, struct dmx_section_filter * source);
```

Arguments

buffer1 Pointer to the start of the filtered section, e.g. within the circular buffer of the demux driver.

buffer1_len Length of the filtered section data in *buffer1*, including headers and CRC.

buffer2 Pointer to the tail of the filtered section data, or NULL. Useful to handle the wrapping of a circular buffer.

buffer2_len Length of the filtered section data in *buffer2*, including headers and CRC.

source Indicates which section feed is the source of the callback.

Description

This function callback prototype, provided by the client of the demux API, is called from the demux code. The function is only called when filtering of sections has been enabled using the function dmx_ts_feed.*start_filtering*. When the demux driver has received a complete section that matches at least one section filter, the client is notified via this callback function. Normally this function is called for each received section; however, it is also possible to deliver multiple sections with one callback, for example when the system load is high. If an error occurs while receiving a section, this function should be called with the corresponding error type set in the success field, whether or not there is data to deliver. The Section Feed implementation should maintain a circular buffer for received sections. However, this is not necessary if the Section Feed API is implemented as a client of the TS Feed API, because the TS Feed implementation then buffers the received data. The size of the circular buffer can be configured using the dmx_ts_feed.*set* function in the Section Feed API. If there is no room in the circular buffer when a new section is received, the section must be discarded. If this happens, the value of the success parameter should be DMX_OVERRUN_ERROR on the next callback.

Name

enum dmx_frontend_source — Used to identify the type of frontend

Synopsis

```
enum dmx_frontend_source {
  DMX_MEMORY_FE,
  DMX_FRONTEND_0
};
```

Constants

DMX_MEMORY_FE The source of the demux is memory. It means that the MPEG-TS to be filtered comes from userspace, via `write` syscall.

DMX_FRONTEND_0 The source of the demux is a frontend connected to the demux.

Name

struct dmx_frontend — Structure that lists the frontends associated with a demux

Synopsis

```
struct dmx_frontend {
  struct list_head connectivity_list;
  enum dmx_frontend_source source;
};
```

Members

connectivity_list	List of front-ends that can be connected to a particular demux;
source	Type of the frontend.

FIXME

this structure should likely be replaced soon by some media-controller based logic.

Name

enum dmx_demux_caps — MPEG-2 TS Demux capabilities bitmap

Synopsis

```
enum dmx_demux_caps {
  DMX_TS_FILTERING,
  DMX_SECTION_FILTERING,
  DMX_MEMORY_BASED_FILTERING
};
```

Constants

DMX_TS_FILTERING	set if TS filtering is supported;
DMX_SECTION_FILTERING	set if section filtering is supported;
DMX_MEMORY_BASED_FILTERING	set if `write` available.

Description

Those flags are OR'ed in the dmx_demux.capabilities field

Name

struct dmx_demux — Structure that contains the demux capabilities and callbacks.

Synopsis

```
struct dmx_demux {
  enum dmx_demux_caps capabilities;
  struct dmx_frontend * frontend;
  void * priv;
  int (* open) (struct dmx_demux *demux);
  int (* close) (struct dmx_demux *demux);
  int (* write) (struct dmx_demux *demux, const char __user *buf,size_t count);
  int (* allocate_ts_feed) (struct dmx_demux *demux,struct dmx_ts_feed **feed,dmx_
  int (* release_ts_feed) (struct dmx_demux *demux,struct dmx_ts_feed *feed);
  int (* allocate_section_feed) (struct dmx_demux *demux,struct dmx_section_feed *
  int (* release_section_feed) (struct dmx_demux *demux,struct dmx_section_feed *f
  int (* add_frontend) (struct dmx_demux *demux,struct dmx_frontend *frontend);
  int (* remove_frontend) (struct dmx_demux *demux,struct dmx_frontend *frontend);
  struct list_head *(* get_frontends) (struct dmx_demux *demux);
  int (* connect_frontend) (struct dmx_demux *demux,struct dmx_frontend *frontend)
  int (* disconnect_frontend) (struct dmx_demux *demux);
  int (* get_pes_pids) (struct dmx_demux *demux, u16 *pids);
};
```

Members

capabilities — Bitfield of capability flags.

frontend — Front-end connected to the demux

priv — Pointer to private data of the API client

open — This function reserves the demux for use by the caller and, if necessary, initializes the demux. When the demux is no longer needed, the function *close* should be called. It should be possible for multiple clients to access the demux at the same time. Thus, the function implementation should increment the demux usage count when *open* is called and decrement it when *close* is called. The *demux* function parameter contains a pointer to the demux API and instance data. It returns 0 on success; -EUSERS, if maximum usage count was reached; -EINVAL, on bad parameter.

close — This function reserves the demux for use by the caller and, if necessary, initializes the demux. When the demux is no longer needed, the function *close* should be called. It should be possible for multiple clients to access the demux at the same time. Thus, the function implementation should increment the demux usage count when *open* is called and decrement it when *close* is called. The *demux* function parameter contains a pointer to the demux API and instance data. It returns 0 on success; -ENODEV, if demux was not in use (e. g. no users); -EINVAL, on bad parameter.

write — This function provides the demux driver with a memory buffer containing TS packets. Instead of receiving TS packets from the DVB

	front-end, the demux driver software will read packets from memory. Any clients of this demux with active TS, PES or Section filters will receive filtered data via the Demux callback API (see 0). The function returns when all the data in the buffer has been consumed by the demux. Demux hardware typically cannot read TS from memory. If this is the case, memory-based filtering has to be implemented entirely in software. The *demux* function parameter contains a pointer to the demux API and instance data. The *buf* function parameter contains a pointer to the TS data in kernel-space memory. The *count* function parameter contains the length of the TS data. It returns 0 on success; -ERESTARTSYS, if mutex lock was interrupted; -EINTR, if a signal handling is pending; -ENODEV, if demux was removed; -EINVAL, on bad parameter.
allocate_ts_feed	Allocates a new TS feed, which is used to filter the TS packets carrying a certain PID. The TS feed normally corresponds to a hardware PID filter on the demux chip. The *demux* function parameter contains a pointer to the demux API and instance data. The *feed* function parameter contains a pointer to the TS feed API and instance data. The *callback* function parameter contains a pointer to the callback function for passing received TS packet. It returns 0 on success; -ERESTARTSYS, if mutex lock was interrupted; -EBUSY, if no more TS feeds is available; -EINVAL, on bad parameter.
release_ts_feed	Releases the resources allocated with *allocate_ts_feed*. Any filtering in progress on the TS feed should be stopped before calling this function. The *demux* function parameter contains a pointer to the demux API and instance data. The *feed* function parameter contains a pointer to the TS feed API and instance data. It returns 0 on success; -EINVAL on bad parameter.
allocate_section_feed	Allocates a new section feed, i.e. a demux resource for filtering and receiving sections. On platforms with hardware support for section filtering, a section feed is directly mapped to the demux HW. On other platforms, TS packets are first PID filtered in hardware and a hardware section filter then emulated in software. The caller obtains an API pointer of type dmx_section_feed_t as an out parameter. Using this API the caller can set filtering parameters and start receiving sections. The *demux* function parameter contains a pointer to the demux API and instance data. The *feed* function parameter contains a pointer to the TS feed API and instance data. The *callback* function parameter contains a pointer to the callback function for passing received TS packet. It returns 0 on success; -EBUSY, if no more TS feeds is available; -EINVAL, on bad parameter.
release_section_feed	Releases the resources allocated with *allocate_section_feed*, including allocated filters. Any filtering in progress on the section feed should be stopped before calling this function. The *demux* function parameter contains a pointer to the demux API and instance data. The *feed* function parameter contains a pointer to the TS feed API and instance data. It returns 0 on success; -EINVAL, on bad parameter.
add_frontend	Registers a connectivity between a demux and a front-end, i.e., indicates that the demux can be connected via a call to *connect_frontend* to use the given front-end as a TS source. The client of this function

	has to allocate dynamic or static memory for the frontend structure and initialize its fields before calling this function. This function is normally called during the driver initialization. The caller must not free the memory of the frontend struct before successfully calling *remove_frontend*. The *demux* function parameter contains a pointer to the demux API and instance data. The *frontend* function parameter contains a pointer to the front-end instance data. It returns 0 on success; -EINVAL, on bad parameter.
remove_frontend	Indicates that the given front-end, registered by a call to *add_frontend*, can no longer be connected as a TS source by this demux. The function should be called when a front-end driver or a demux driver is removed from the system. If the front-end is in use, the function fails with the return value of -EBUSY. After successfully calling this function, the caller can free the memory of the frontend struct if it was dynamically allocated before the *add_frontend* operation. The *demux* function parameter contains a pointer to the demux API and instance data. The *frontend* function parameter contains a pointer to the front-end instance data. It returns 0 on success; -ENODEV, if the front-end was not found, -EINVAL, on bad parameter.
get_frontends	Provides the APIs of the front-ends that have been registered for this demux. Any of the front-ends obtained with this call can be used as a parameter for *connect_frontend*. The include file demux.h contains the macro DMX_FE_ENTRY for converting an element of the generic type struct list_head * to the type struct dmx_frontend *. The caller must not free the memory of any of the elements obtained via this function call. The *demux* function parameter contains a pointer to the demux API and instance data. It returns a struct list_head pointer to the list of front-end interfaces, or NULL in the case of an empty list.
connect_frontend	Connects the TS output of the front-end to the input of the demux. A demux can only be connected to a front-end registered to the demux with the function *add_frontend*. It may or may not be possible to connect multiple demuxes to the same front-end, depending on the capabilities of the HW platform. When not used, the front-end should be released by calling *disconnect_frontend*. The *demux* function parameter contains a pointer to the demux API and instance data. The *frontend* function parameter contains a pointer to the front-end instance data. It returns 0 on success; -EINVAL, on bad parameter.
disconnect_frontend	Disconnects the demux and a front-end previously connected by a *connect_frontend* call. The *demux* function parameter contains a pointer to the demux API and instance data. It returns 0 on success; -EINVAL on bad parameter.
get_pes_pids	Get the PIDs for DMX_PES_AUDIO0, DMX_PES_VIDEO0, DMX_PES_TELETEXT0, DMX_PES_SUBTITLE0 and DMX_PES_PCR0. The *demux* function parameter contains a pointer to the demux API and instance data. The *pids* function parameter contains an array with five u16 elements where the PIDs will be stored. It returns 0 on success; -EINVAL on bad parameter.

Remote Controller devices

Name

struct rc_scancode_filter — Filter scan codes.

Synopsis

```
struct rc_scancode_filter {
  u32 data;
  u32 mask;
};
```

Members

data Scancode data to match.

mask Mask of bits of scancode to compare.

Name

enum rc_filter_type — Filter type constants.

Synopsis

```
enum rc_filter_type {
  RC_FILTER_NORMAL,
  RC_FILTER_WAKEUP,
  RC_FILTER_MAX
};
```

Constants

RC_FILTER_NORMAL	Filter for normal operation.
RC_FILTER_WAKEUP	Filter for waking from suspend.
RC_FILTER_MAX	Number of filter types.

Name

struct rc_dev — represents a remote control device

Synopsis

```
struct rc_dev {
  struct device dev;
  const struct attribute_group * sysfs_groups[5];
  const char * input_name;
  const char * input_phys;
  struct input_id input_id;
  char * driver_name;
  const char * map_name;
  struct rc_map rc_map;
  struct mutex lock;
  unsigned int minor;
  struct ir_raw_event_ctrl * raw;
  struct input_dev * input_dev;
  enum rc_driver_type driver_type;
  bool idle;
  u64 allowed_protocols;
  u64 enabled_protocols;
  u64 allowed_wakeup_protocols;
  u64 enabled_wakeup_protocols;
  struct rc_scancode_filter scancode_filter;
  struct rc_scancode_filter scancode_wakeup_filter;
  u32 scancode_mask;
  u32 users;
  void * priv;
  spinlock_t keylock;
  bool keypressed;
  unsigned long keyup_jiffies;
  struct timer_list timer_keyup;
  u32 last_keycode;
  enum rc_type last_protocol;
  u32 last_scancode;
  u8 last_toggle;
  u32 timeout;
  u32 min_timeout;
  u32 max_timeout;
  u32 rx_resolution;
  u32 tx_resolution;
  int (* change_protocol) (struct rc_dev *dev, u64 *rc_type);
  int (* change_wakeup_protocol) (struct rc_dev *dev, u64 *rc_type);
  int (* open) (struct rc_dev *dev);
  void (* close) (struct rc_dev *dev);
  int (* s_tx_mask) (struct rc_dev *dev, u32 mask);
  int (* s_tx_carrier) (struct rc_dev *dev, u32 carrier);
  int (* s_tx_duty_cycle) (struct rc_dev *dev, u32 duty_cycle);
  int (* s_rx_carrier_range) (struct rc_dev *dev, u32 min, u32 max);
  int (* tx_ir) (struct rc_dev *dev, unsigned *txbuf, unsigned n);
  void (* s_idle) (struct rc_dev *dev, bool enable);
```

```
  int (* s_learning_mode) (struct rc_dev *dev, int enable);
  int (* s_carrier_report) (struct rc_dev *dev, int enable);
  int (* s_filter) (struct rc_dev *dev,struct rc_scancode_filter *filter);
  int (* s_wakeup_filter) (struct rc_dev *dev,struct rc_scancode_filter *filter);
};
```

Members

dev	driver model's view of this device
sysfs_groups[5]	sysfs attribute groups
input_name	name of the input child device
input_phys	physical path to the input child device
input_id	id of the input child device (struct input_id)
driver_name	name of the hardware driver which registered this device
map_name	name of the default keymap
rc_map	current scan/key table
lock	used to ensure we've filled in all protocol details before anyone can call show_protocols or store_protocols
minor	unique minor remote control device number
raw	additional data for raw pulse/space devices
input_dev	the input child device used to communicate events to userspace
driver_type	specifies if protocol decoding is done in hardware or software
idle	used to keep track of RX state
allowed_protocols	bitmask with the supported RC_BIT_* protocols
enabled_protocols	bitmask with the enabled RC_BIT_* protocols
allowed_wakeup_protocols	bitmask with the supported RC_BIT_* wakeup protocols
enabled_wakeup_protocols	bitmask with the enabled RC_BIT_* wakeup protocols
scancode_filter	scancode filter
scancode_wakeup_filter	scancode wakeup filters
scancode_mask	some hardware decoders are not capable of providing the full scancode to the application. As this is a hardware limit, we can't do anything with it. Yet, as the same keycode table can be used with other devices, a mask is provided to allow its usage. Drivers should generally leave this field in blank
users	number of current users of the device
priv	driver-specific data

keylock	protects the remaining members of the struct
keypressed	whether a key is currently pressed
keyup_jiffies	time (in jiffies) when the current keypress should be released
timer_keyup	timer for releasing a keypress
last_keycode	keycode of last keypress
last_protocol	protocol of last keypress
last_scancode	scancode of last keypress
last_toggle	toggle value of last command
timeout	optional time after which device stops sending data
min_timeout	minimum timeout supported by device
max_timeout	maximum timeout supported by device
rx_resolution	resolution (in ns) of input sampler
tx_resolution	resolution (in ns) of output sampler
change_protocol	allow changing the protocol used on hardware decoders
change_wakeup_protocol	allow changing the protocol used for wakeup filtering
open	callback to allow drivers to enable polling/irq when IR input device is opened.
close	callback to allow drivers to disable polling/irq when IR input device is opened.
s_tx_mask	set transmitter mask (for devices with multiple tx outputs)
s_tx_carrier	set transmit carrier frequency
s_tx_duty_cycle	set transmit duty cycle (0% - 100%)
s_rx_carrier_range	inform driver about carrier it is expected to handle
tx_ir	transmit IR
s_idle	enable/disable hardware idle mode, upon which, device doesn't interrupt host until it sees IR pulses
s_learning_mode	enable wide band receiver used for learning
s_carrier_report	enable carrier reports
s_filter	set the scancode filter
s_wakeup_filter	set the wakeup scancode filter

Name

struct lirc_driver — Defines the parameters on a LIRC driver

Synopsis

```
struct lirc_driver {
  char name[40];
  int minor;
  __u32 code_length;
  unsigned int buffer_size;
  int sample_rate;
  __u32 features;
  unsigned int chunk_size;
  void * data;
  int min_timeout;
  int max_timeout;
  int (* add_to_buf) (void *data, struct lirc_buffer *buf);
  struct lirc_buffer * rbuf;
  int (* set_use_inc) (void *data);
  void (* set_use_dec) (void *data);
  struct rc_dev * rdev;
  const struct file_operations * fops;
  struct device * dev;
  struct module * owner;
};
```

Members

name[40] — this string will be used for logs

minor — indicates minor device (/dev/lirc) number for registered driver if caller fills it with negative value, then the first free minor number will be used (if available).

code_length — length of the remote control key code expressed in bits.

buffer_size — Number of FIFO buffers with *chunk_size* size. If zero, creates a buffer with BUFLEN size (16 bytes).

sample_rate — if zero, the device will wait for an event with a new code to be parsed. Otherwise, specifies the sample rate for polling. Value should be between 0 and HZ. If equal to HZ, it would mean one polling per second.

features — lirc compatible hardware features, like LIRC_MODE_RAW, LIRC_CAN_*, as defined at include/media/lirc.h.

chunk_size — Size of each FIFO buffer.

data — it may point to any driver data and this pointer will be passed to all callback functions.

min_timeout — Minimum timeout for record. Valid only if LIRC_CAN_SET_REC_TIMEOUT is defined.

max_timeout — Maximum timeout for record. Valid only if LIRC_CAN_SET_REC_TIMEOUT is defined.

add_to_buf	add_to_buf will be called after specified period of the time or triggered by the external event, this behavior depends on value of the sample_rate this function will be called in user context. This routine should return 0 if data was added to the buffer and -ENODATA if none was available. This should add some number of bits evenly divisible by code_length to the buffer.
rbuf	if not NULL, it will be used as a read buffer, you will have to write to the buffer by other means, like irq's (see also lirc_serial.c).
set_use_inc	set_use_inc will be called after device is opened
set_use_dec	set_use_dec will be called after device is closed
rdev	Pointed to struct rc_dev associated with the LIRC device.
fops	file_operations for drivers which don't fit the current driver model. Some ioctl's can be directly handled by lirc_dev if the driver's ioctl function is NULL or if it returns -ENOIOCTLCMD (see also lirc_serial.c).
dev	pointer to the struct device associated with the LIRC device.
owner	the module owning this struct

Media Controller devices

Name

struct media_device — Media device

Synopsis

```
struct media_device {
  struct device * dev;
  struct media_devnode devnode;
  char model[32];
  char serial[40];
  char bus_info[32];
  u32 hw_revision;
  u32 driver_version;
  u32 entity_id;
  struct list_head entities;
  spinlock_t lock;
  struct mutex graph_mutex;
  int (* link_notify) (struct media_link *link, u32 flags,unsigned int notificatio
};
```

Members

dev	Parent device
devnode	Media device node
model[32]	Device model name
serial[40]	Device serial number (optional)
bus_info[32]	Unique and stable device location identifier
hw_revision	Hardware device revision
driver_version	Device driver version
entity_id	ID of the next entity to be registered
entities	List of registered entities
lock	Entities list lock
graph_mutex	Entities graph operation lock
link_notify	Link state change notification callback

Description

This structure represents an abstract high-level media device. It allows easy access to entities and provides basic media device-level support. The structure can be allocated directly or embedded in a larger structure.

The parent *dev* is a physical device. It must be set before registering the media device.

model is a descriptive model name exported through sysfs. It doesn't have to be unique.

Name

struct media_devnode — Media device node

Synopsis

```
struct media_devnode {
  const struct media_file_operations * fops;
  struct device dev;
  struct cdev cdev;
  struct device * parent;
  int minor;
  unsigned long flags;
  void (* release) (struct media_devnode *mdev);
};
```

Members

fops	pointer to struct media_file_operations with media device ops
dev	struct device pointer for the media controller device
cdev	struct cdev pointer character device
parent	parent device
minor	device node minor number
flags	flags, combination of the MEDIA_FLAG_* constants
release	release callback called at the end of `media_devnode_release`

Description

This structure represents a media-related device node.

The *`parent`* is a physical device. It must be set by core or device drivers before registering the node.

Name

struct media_entity_operations — Media entity operations

Synopsis

```
struct media_entity_operations {
  int (* link_setup) (struct media_entity *entity,const struct media_pad *local,co
  int (* link_validate) (struct media_link *link);
};
```

Members

link_setup — Notify the entity of link changes. The operation can return an error, in which case link setup will be cancelled. Optional.

link_validate — Return whether a link is valid from the entity point of view. The `media_entity_pipeline_start` function validates all links by calling this operation. Optional.

Chapter 7. 16x50 UART Driver

Name

uart_update_timeout — update per-port FIFO timeout.

Synopsis

```
void uart_update_timeout (struct uart_port * port, unsigned int cflag,
unsigned int baud);
```

Arguments

port uart_port structure describing the port

cflag termios cflag value

baud speed of the port

Description

Set the port FIFO timeout value. The *cflag* value should reflect the actual hardware settings.

Name

uart_get_baud_rate — return baud rate for a particular port

Synopsis

```
unsigned int uart_get_baud_rate (struct uart_port * port, struct ktermios * termios, struct ktermios * old, unsigned int min, unsigned int max);
```

Arguments

port uart_port structure describing the port in question.

termios desired termios settings.

old old termios (or NULL)

min minimum acceptable baud rate

max maximum acceptable baud rate

Description

Decode the termios structure into a numeric baud rate, taking account of the magic 38400 baud rate (with spd_* flags), and mapping the `B0` rate to 9600 baud.

If the new baud rate is invalid, try the old termios setting. If it's still invalid, we try 9600 baud.

Update the *termios* structure to reflect the baud rate we're actually going to be using. Don't do this for the case where B0 is requested (“hang up”).

Name

uart_get_divisor — return uart clock divisor

Synopsis

```
unsigned int uart_get_divisor (struct uart_port * port, unsigned int baud);
```

Arguments

port uart_port structure describing the port.

baud desired baud rate

Description

Calculate the uart clock divisor for the port.

Name

uart_console_write — write a console message to a serial port

Synopsis

```
void uart_console_write (struct uart_port * port, const char * s,
unsigned int count, void (*putchar) (struct uart_port *, int));
```

Arguments

port	the port to write the message
s	array of characters
count	number of characters in string to write
putchar	function to write character to port

Name

uart_parse_earlycon — Parse earlycon options

Synopsis

```
int uart_parse_earlycon (char * p, unsigned char * iotype, unsigned long
* addr, char ** options);
```

Arguments

p	ptr to 2nd field (ie., just beyond '<name>,')
iotype	ptr for decoded iotype (out)
addr	ptr for decoded mapbase/iobase (out)
options	ptr for <options> field; NULL if not present (out)

Description

Decodes earlycon kernel command line parameters of the form earlycon=<name>,io|mmio|mmio32|mmio32be|mmio32native,<addr>,<options> console=<name>,io|mmio|mmio32|mmio32be|mmio32native,<addr>,<options>

The optional form earlycon=<name>,0x<addr>,<options> console=<name>,0x<addr>,<options> is also accepted; the returned *iotype* will be UPIO_MEM.

Returns 0 on success or -EINVAL on failure

Name

uart_parse_options — Parse serial port baud/parity/bits/flow control.

Synopsis

```
void uart_parse_options (char * options, int * baud, int * parity, int
* bits, int * flow);
```

Arguments

options	pointer to option string
baud	pointer to an 'int' variable for the baud rate.
parity	pointer to an 'int' variable for the parity.
bits	pointer to an 'int' variable for the number of data bits.
flow	pointer to an 'int' variable for the flow control character.

Description

uart_parse_options decodes a string containing the serial console options. The format of the string is <baud><parity><bits><flow>,

eg

115200n8r

Name

uart_set_options — setup the serial console parameters

Synopsis

```
int uart_set_options (struct uart_port * port, struct console * co, int baud, int parity, int bits, int flow);
```

Arguments

port	pointer to the serial ports uart_port structure
co	console pointer
baud	baud rate
parity	parity character - 'n' (none), 'o' (odd), 'e' (even)
bits	number of data bits
flow	flow control character - 'r' (rts)

Name

uart_register_driver — register a driver with the uart core layer

Synopsis

```
int uart_register_driver (struct uart_driver * drv);
```

Arguments

drv low level driver structure

Description

Register a uart driver with the core driver. We in turn register with the tty layer, and initialise the core driver per-port state.

We have a proc file in /proc/tty/driver which is named after the normal driver.

drv->port should be NULL, and the per-port structures should be registered using uart_add_one_port after this call has succeeded.

Name

uart_unregister_driver — remove a driver from the uart core layer

Synopsis

```
void uart_unregister_driver (struct uart_driver * drv);
```

Arguments

drv low level driver structure

Description

Remove all references to a driver from the core driver. The low level driver must have removed all its ports via the `uart_remove_one_port` if it registered them with `uart_add_one_port`. (ie, drv->port == NULL)

Name

uart_add_one_port — attach a driver-defined port structure

Synopsis

```
int uart_add_one_port (struct uart_driver * drv, struct uart_port *
uport);
```

Arguments

drv pointer to the uart low level driver structure for this port

uport uart port structure to use for this port.

Description

This allows the driver to register its own uart_port structure with the core driver. The main purpose is to allow the low level uart drivers to expand uart_port, rather than having yet more levels of structures.

Name

uart_remove_one_port — detach a driver defined port structure

Synopsis

```
int uart_remove_one_port (struct uart_driver * drv, struct uart_port
* uport);
```

Arguments

drv pointer to the uart low level driver structure for this port

uport uart port structure for this port

Description

This unhooks (and hangs up) the specified port structure from the core driver. No further calls will be made to the low-level code for this port.

Name

uart_handle_dcd_change — handle a change of carrier detect state

Synopsis

```
void uart_handle_dcd_change (struct uart_port * uport, unsigned int status);
```

Arguments

uport uart_port structure for the open port

status new carrier detect status, nonzero if active

Description

Caller must hold uport->lock

Name

uart_handle_cts_change — handle a change of clear-to-send state

Synopsis

```
void uart_handle_cts_change (struct uart_port * uport, unsigned int status);
```

Arguments

uport uart_port structure for the open port

status new clear to send status, nonzero if active

Description

Caller must hold uport->lock

Name

uart_insert_char — push a char to the uart layer

Synopsis

```
void uart_insert_char (struct uart_port * port, unsigned int status,
unsigned int overrun, unsigned int ch, unsigned int flag);
```

Arguments

port	corresponding port
status	state of the serial port RX buffer (LSR for 8250)
overrun	mask of overrun bits in *status*
ch	character to push
flag	flag for the character (see TTY_NORMAL and friends)

Description

User is responsible to call tty_flip_buffer_push when they are done with insertion.

Name

serial8250_get_port — retrieve struct uart_8250_port

Synopsis

```
struct uart_8250_port * serial8250_get_port (int line);
```

Arguments

line serial line number

Description

This function retrieves struct uart_8250_port for the specific line. This struct *must* *not* be used to perform a 8250 or serial core operation which is not accessible otherwise. Its only purpose is to make the struct accessible to the runtime-pm callbacks for context suspend/restore. The lock assumption made here is none because runtime-pm suspend/resume callbacks should not be invoked if there is any operation performed on the port.

Name

serial8250_suspend_port — suspend one serial port

Synopsis

```
void serial8250_suspend_port (int line);
```

Arguments

line serial line number

Description

Suspend one serial port.

Name

serial8250_resume_port — resume one serial port

Synopsis

```
void serial8250_resume_port (int line);
```

Arguments

line serial line number

Description

Resume one serial port.

Name

serial8250_register_8250_port — register a serial port

Synopsis

```
int serial8250_register_8250_port (struct uart_8250_port * up);
```

Arguments

up serial port template

Description

Configure the serial port specified by the request. If the port exists and is in use, it is hung up and unregistered first.

The port is then probed and if necessary the IRQ is autodetected If this fails an error is returned.

On success the port is ready to use and the line number is returned.

Name

serial8250_unregister_port — remove a 16x50 serial port at runtime

Synopsis

```
void serial8250_unregister_port (int line);
```

Arguments

line serial line number

Description

Remove one serial port. This may not be called from interrupt context. We hand the port back to the our control.

Chapter 8. Frame Buffer Library

The frame buffer drivers depend heavily on four data structures. These structures are declared in include/linux/fb.h. They are fb_info, fb_var_screeninfo, fb_fix_screeninfo and fb_monospecs. The last three can be made available to and from userland.

fb_info defines the current state of a particular video card. Inside fb_info, there exists a fb_ops structure which is a collection of needed functions to make fbdev and fbcon work. fb_info is only visible to the kernel.

fb_var_screeninfo is used to describe the features of a video card that are user defined. With fb_var_screeninfo, things such as depth and the resolution may be defined.

The next structure is fb_fix_screeninfo. This defines the properties of a card that are created when a mode is set and can't be changed otherwise. A good example of this is the start of the frame buffer memory. This "locks" the address of the frame buffer memory, so that it cannot be changed or moved.

The last structure is fb_monospecs. In the old API, there was little importance for fb_monospecs. This allowed for forbidden things such as setting a mode of 800x600 on a fix frequency monitor. With the new API, fb_monospecs prevents such things, and if used correctly, can prevent a monitor from being cooked. fb_monospecs will not be useful until kernels 2.5.x.

Frame Buffer Memory

Name

register_framebuffer — registers a frame buffer device

Synopsis

```
int register_framebuffer (struct fb_info * fb_info);
```

Arguments

fb_info frame buffer info structure

Description

Registers a frame buffer device *fb_info*.

Returns negative errno on error, or zero for success.

Name

unregister_framebuffer — releases a frame buffer device

Synopsis

```
int unregister_framebuffer (struct fb_info * fb_info);
```

Arguments

fb_info frame buffer info structure

Description

Unregisters a frame buffer device *fb_info*.

Returns negative errno on error, or zero for success.

This function will also notify the framebuffer console to release the driver.

This is meant to be called within a driver's `module_exit` function. If this is called outside `module_exit`, ensure that the driver implements `fb_open` and `fb_release` to check that no processes are using the device.

Name

fb_set_suspend — low level driver signals suspend

Synopsis

```
void fb_set_suspend (struct fb_info * info, int state);
```

Arguments

info framebuffer affected

state 0 = resuming, !=0 = suspending

Description

This is meant to be used by low level drivers to signal suspend/resume to the core & clients. It must be called with the console semaphore held

Frame Buffer Colormap

Name

fb_dealloc_cmap — deallocate a colormap

Synopsis

```
void fb_dealloc_cmap (struct fb_cmap * cmap);
```

Arguments

cmap frame buffer colormap structure

Description

Deallocates a colormap that was previously allocated with `fb_alloc_cmap`.

Name

fb_copy_cmap — copy a colormap

Synopsis

```
int fb_copy_cmap (const struct fb_cmap * from, struct fb_cmap * to);
```

Arguments

from frame buffer colormap structure

to frame buffer colormap structure

Description

Copy contents of colormap from *from* to *to*.

Name

fb_set_cmap — set the colormap

Synopsis

```
int fb_set_cmap (struct fb_cmap * cmap, struct fb_info * info);
```

Arguments

cmap frame buffer colormap structure

info frame buffer info structure

Description

Sets the colormap *cmap* for a screen of device *info*.

Returns negative errno on error, or zero on success.

Name

fb_default_cmap — get default colormap

Synopsis

```
const struct fb_cmap * fb_default_cmap (int len);
```

Arguments

len size of palette for a depth

Description

Gets the default colormap for a specific screen depth. *len* is the size of the palette for a particular screen depth.

Returns pointer to a frame buffer colormap structure.

Name

fb_invert_cmaps — invert all defaults colormaps

Synopsis

```
void fb_invert_cmaps ( void);
```

Arguments

void no arguments

Description

Invert all default colormaps.

Frame Buffer Video Mode Database

Name

fb_try_mode — test a video mode

Synopsis

```
int fb_try_mode (struct fb_var_screeninfo * var, struct fb_info * info,
const struct fb_videomode * mode, unsigned int bpp);
```

Arguments

var frame buffer user defined part of display

info frame buffer info structure

mode frame buffer video mode structure

bpp color depth in bits per pixel

Description

Tries a video mode to test it's validity for device *info*.

Returns 1 on success.

Name

fb_delete_videomode — removed videomode entry from modelist

Synopsis

```
void fb_delete_videomode (const struct fb_videomode * mode, struct
list_head * head);
```

Arguments

mode videomode to remove

head struct list_head of modelist

NOTES

Will remove all matching mode entries

Name

fb_find_mode — finds a valid video mode

Synopsis

```
int fb_find_mode (struct fb_var_screeninfo * var, struct fb_info * info,
const char * mode_option, const struct fb_videomode * db, unsigned
int dbsize, const struct fb_videomode * default_mode, unsigned int
default_bpp);
```

Arguments

var	frame buffer user defined part of display
info	frame buffer info structure
mode_option	string video mode to find
db	video mode database
dbsize	size of *db*
default_mode	default video mode to fall back to
default_bpp	default color depth in bits per pixel

Description

Finds a suitable video mode, starting with the specified mode in *mode_option* with fallback to *default_mode*. If *default_mode* fails, all modes in the video mode database will be tried.

Valid mode specifiers for *mode_option*:

<xres>x<yres>[M][R][-<bpp>][@<refresh>][i][m] or <name>[-<bpp>][@<refresh>]

with <xres>, <yres>, <bpp> and <refresh> decimal numbers and <name> a string.

If 'M' is present after yres (and before refresh/bpp if present), the function will compute the timings using VESA(tm) Coordinated Video Timings (CVT). If 'R' is present after 'M', will compute with reduced blanking (for flatpanels). If 'i' is present, compute interlaced mode. If 'm' is present, add margins equal to 1.8% of xres rounded down to 8 pixels, and 1.8% of yres. The char 'i' and 'm' must be after 'M' and 'R'. Example:

1024x768MR-8*60m* - Reduced blank with margins at 60Hz.

NOTE

The passed struct *var* is _not_ cleared! This allows you to supply values for e.g. the grayscale and accel_flags fields.

Returns zero for failure, 1 if using specified *mode_option*, 2 if using specified *mode_option* with an ignored refresh rate, 3 if default mode is used, 4 if fall back to any valid mode.

Name

fb_var_to_videomode — convert fb_var_screeninfo to fb_videomode

Synopsis

```
void fb_var_to_videomode (struct fb_videomode * mode, const struct
fb_var_screeninfo * var);
```

Arguments

mode pointer to struct fb_videomode

var pointer to struct fb_var_screeninfo

Name

fb_videomode_to_var — convert fb_videomode to fb_var_screeninfo

Synopsis

```
void fb_videomode_to_var (struct fb_var_screeninfo * var, const struct
fb_videomode * mode);
```

Arguments

var pointer to struct fb_var_screeninfo

mode pointer to struct fb_videomode

Name

fb_mode_is_equal — compare 2 videomodes

Synopsis

```
int fb_mode_is_equal (const struct fb_videomode * mode1, const struct
fb_videomode * mode2);
```

Arguments

mode1 first videomode

mode2 second videomode

RETURNS

1 if equal, 0 if not

Name

fb_find_best_mode — find best matching videomode

Synopsis

```
const struct fb_videomode * fb_find_best_mode (const struct
fb_var_screeninfo * var, struct list_head * head);
```

Arguments

var pointer to struct fb_var_screeninfo

head pointer to struct list_head of modelist

RETURNS

struct fb_videomode, NULL if none found

IMPORTANT

This function assumes that all modelist entries in info->modelist are valid.

NOTES

Finds best matching videomode which has an equal or greater dimension than var->xres and var->yres. If more than 1 videomode is found, will return the videomode with the highest refresh rate

Name

fb_find_nearest_mode — find closest videomode

Synopsis

```
const struct fb_videomode * fb_find_nearest_mode (const struct fb_videomode * mode, struct list_head * head);
```

Arguments

mode pointer to struct fb_videomode

head pointer to modelist

Description

Finds best matching videomode, smaller or greater in dimension. If more than 1 videomode is found, will return the videomode with the closest refresh rate.

Name

fb_match_mode — find a videomode which exactly matches the timings in var

Synopsis

```
const struct fb_videomode * fb_match_mode (const struct
fb_var_screeninfo * var, struct list_head * head);
```

Arguments

var pointer to struct fb_var_screeninfo

head pointer to struct list_head of modelist

RETURNS

struct fb_videomode, NULL if none found

Name

fb_add_videomode — adds videomode entry to modelist

Synopsis

```
int fb_add_videomode (const struct fb_videomode * mode, struct list_head
* head);
```

Arguments

mode videomode to add

head struct list_head of modelist

NOTES

Will only add unmatched mode entries

Name

fb_destroy_modelist — destroy modelist

Synopsis

```
void fb_destroy_modelist (struct list_head * head);
```

Arguments

head struct list_head of modelist

Name

fb_videomode_to_modelist — convert mode array to mode list

Synopsis

```
void fb_videomode_to_modelist (const struct fb_videomode * modedb, int
num, struct list_head * head);
```

Arguments

modedb array of struct fb_videomode

num number of entries in array

head struct list_head of modelist

Frame Buffer Macintosh Video Mode Database

Name

mac_vmode_to_var — converts vmode/cmode pair to var structure

Synopsis

```
int mac_vmode_to_var (int vmode, int cmode, struct fb_var_screeninfo
* var);
```

Arguments

vmode MacOS video mode

cmode MacOS color mode

var frame buffer video mode structure

Description

Converts a MacOS vmode/cmode pair to a frame buffer video mode structure.

Returns negative errno on error, or zero for success.

Name

mac_map_monitor_sense — Convert monitor sense to vmode

Synopsis

```
int mac_map_monitor_sense (int sense);
```

Arguments

sense Macintosh monitor sense number

Description

Converts a Macintosh monitor sense number to a MacOS vmode number.

Returns MacOS vmode video mode number.

Name

mac_find_mode — find a video mode

Synopsis

```
int mac_find_mode (struct fb_var_screeninfo * var, struct fb_info *
info, const char * mode_option, unsigned int default_bpp);
```

Arguments

var	frame buffer user defined part of display
info	frame buffer info structure
mode_option	video mode name (see mac_modedb[])
default_bpp	default color depth in bits per pixel

Description

Finds a suitable video mode. Tries to set mode specified by *mode_option*. If the name of the wanted mode begins with 'mac', the Mac video mode database will be used, otherwise it will fall back to the standard video mode database.

Note

Function marked as __init and can only be used during system boot.

Returns error code from fb_find_mode (see fb_find_mode function).

Frame Buffer Fonts

Refer to the file lib/fonts/fonts.c for more information.

Chapter 9. Input Subsystem

Input core

Name

struct input_value — input value representation

Synopsis

```
struct input_value {
  __u16 type;
  __u16 code;
  __s32 value;
};
```

Members

type — type of value (EV_KEY, EV_ABS, etc)

code — the value code

value — the value

Name

struct input_dev — represents an input device

Synopsis

```
struct input_dev {
  const char * name;
  const char * phys;
  const char * uniq;
  struct input_id id;
  unsigned long propbit[BITS_TO_LONGS(INPUT_PROP_CNT)];
  unsigned long evbit[BITS_TO_LONGS(EV_CNT)];
  unsigned long keybit[BITS_TO_LONGS(KEY_CNT)];
  unsigned long relbit[BITS_TO_LONGS(REL_CNT)];
  unsigned long absbit[BITS_TO_LONGS(ABS_CNT)];
  unsigned long mscbit[BITS_TO_LONGS(MSC_CNT)];
  unsigned long ledbit[BITS_TO_LONGS(LED_CNT)];
  unsigned long sndbit[BITS_TO_LONGS(SND_CNT)];
  unsigned long ffbit[BITS_TO_LONGS(FF_CNT)];
  unsigned long swbit[BITS_TO_LONGS(SW_CNT)];
  unsigned int hint_events_per_packet;
  unsigned int keycodemax;
  unsigned int keycodesize;
  void * keycode;
  int (* setkeycode) (struct input_dev *dev,const struct input_keymap_entry *ke,un
  int (* getkeycode) (struct input_dev *dev,struct input_keymap_entry *ke);
  struct ff_device * ff;
  unsigned int repeat_key;
  struct timer_list timer;
  int rep[REP_CNT];
  struct input_mt * mt;
  struct input_absinfo * absinfo;
  unsigned long key[BITS_TO_LONGS(KEY_CNT)];
  unsigned long led[BITS_TO_LONGS(LED_CNT)];
  unsigned long snd[BITS_TO_LONGS(SND_CNT)];
  unsigned long sw[BITS_TO_LONGS(SW_CNT)];
  int (* open) (struct input_dev *dev);
  void (* close) (struct input_dev *dev);
  int (* flush) (struct input_dev *dev, struct file *file);
  int (* event) (struct input_dev *dev, unsigned int type, unsigned int code, int
  struct input_handle __rcu * grab;
  spinlock_t event_lock;
  struct mutex mutex;
  unsigned int users;
  bool going_away;
  struct device dev;
  struct list_head h_list;
  struct list_head node;
  unsigned int num_vals;
  unsigned int max_vals;
  struct input_value * vals;
  bool devres_managed;
```

```
};
```

Members

name	name of the device
phys	physical path to the device in the system hierarchy
uniq	unique identification code for the device (if device has it)
id	id of the device (struct input_id)
propbit[BITS_TO_LONGS(INPUT_PROP_CNT)]	bitmap of device properties and quirks
evbit[BITS_TO_LONGS(EV_CNT)]	bitmap of types of events supported by the device (EV_KEY, EV_REL, etc.)
keybit[BITS_TO_LONGS(KEY_CNT)]	bitmap of keys/buttons this device has
relbit[BITS_TO_LONGS(REL_CNT)]	bitmap of relative axes for the device
absbit[BITS_TO_LONGS(ABS_CNT)]	bitmap of absolute axes for the device
mscbit[BITS_TO_LONGS(MSC_CNT)]	bitmap of miscellaneous events supported by the device
ledbit[BITS_TO_LONGS(LED_CNT)]	bitmap of leds present on the device
sndbit[BITS_TO_LONGS(SND_CNT)]	bitmap of sound effects supported by the device
ffbit[BITS_TO_LONGS(FF_CNT)]	bitmap of force feedback effects supported by the device
swbit[BITS_TO_LONGS(SW_CNT)]	bitmap of switches present on the device
hint_events_per_packet	average number of events generated by the device in a packet (between EV_SYN/SYN_REPORT events). Used by event handlers to estimate size of the buffer needed to hold events.
keycodemax	size of keycode table
keycodesize	size of elements in keycode table
keycode	map of scancodes to keycodes for this device
setkeycode	optional method to alter current keymap, used to implement sparse keymaps. If not supplied default mechanism will be used. The method is being called while holding event_lock and thus must not sleep
getkeycode	optional legacy method to retrieve current keymap.
ff	force feedback structure associated with the device if device supports force feedback effects
repeat_key	stores key code of the last key pressed; used to implement software autorepeat
timer	timer for software autorepeat

rep[REP_CNT]	current values for autorepeat parameters (delay, rate)
mt	pointer to multitouch state
absinfo	array of struct input_absinfo elements holding information about absolute axes (current value, min, max, flat, fuzz, resolution)
key[BITS_TO_LONGS(KEY_CNT)]	reflects current state of device's keys/buttons
led[BITS_TO_LONGS(LED_CNT)]	reflects current state of device's LEDs
snd[BITS_TO_LONGS(SND_CNT)]	reflects current state of sound effects
sw[BITS_TO_LONGS(SW_CNT)]	reflects current state of device's switches
open	this method is called when the very first user calls `input_open_device`. The driver must prepare the device to start generating events (start polling thread, request an IRQ, submit URB, etc.)
close	this method is called when the very last user calls `input_close_device`.
flush	purges the device. Most commonly used to get rid of force feedback effects loaded into the device when disconnecting from it
event	event handler for events sent _to_ the device, like EV_LED or EV_SND. The device is expected to carry out the requested action (turn on a LED, play sound, etc.) The call is protected by *`event_lock`* and must not sleep
grab	input handle that currently has the device grabbed (via EVIOCGRAB ioctl). When a handle grabs a device it becomes sole recipient for all input events coming from the device
event_lock	this spinlock is is taken when input core receives and processes a new event for the device (in `input_event`). Code that accesses and/or modifies parameters of a device (such as keymap or absmin, absmax, absfuzz, etc.) after device has been registered with input core must take this lock.
mutex	serializes calls to `open`, `close` and `flush` methods
users	stores number of users (input handlers) that opened this device. It is used by `input_open_device` and `input_close_device` to make sure that dev->`open` is only called when the first user opens device and dev->`close` is called when the very last user closes the device
going_away	marks devices that are in a middle of unregistering and causes input_open_device*() fail with -ENODEV.
dev	driver model's view of this device
h_list	list of input handles associated with the device. When accessing the list dev->mutex must be held

node	used to place the device onto input_dev_list
num_vals	number of values queued in the current frame
max_vals	maximum number of values queued in a frame
vals	array of values queued in the current frame
devres_managed	indicates that devices is managed with devres framework and needs not be explicitly unregistered or freed.

Name

struct input_handler — implements one of interfaces for input devices

Synopsis

```
struct input_handler {
  void * private;
  void (* event) (struct input_handle *handle, unsigned int type, unsigned int cod
  void (* events) (struct input_handle *handle,const struct input_value *vals, uns
  bool (* filter) (struct input_handle *handle, unsigned int type, unsigned int co
  bool (* match) (struct input_handler *handler, struct input_dev *dev);
  int (* connect) (struct input_handler *handler, struct input_dev *dev, const str
  void (* disconnect) (struct input_handle *handle);
  void (* start) (struct input_handle *handle);
  bool legacy_minors;
  int minor;
  const char * name;
  const struct input_device_id * id_table;
  struct list_head h_list;
  struct list_head node;
};
```

Members

private	driver-specific data
event	event handler. This method is being called by input core with interrupts disabled and dev->event_lock spinlock held and so it may not sleep
events	event sequence handler. This method is being called by input core with interrupts disabled and dev->event_lock spinlock held and so it may not sleep
filter	similar to *event*; separates normal event handlers from “filters”.
match	called after comparing device's id with handler's id_table to perform fine-grained matching between device and handler
connect	called when attaching a handler to an input device
disconnect	disconnects a handler from input device
start	starts handler for given handle. This function is called by input core right after `connect` method and also when a process that “grabbed” a device releases it
legacy_minors	set to `true` by drivers using legacy minor ranges
minor	beginning of range of 32 legacy minors for devices this driver can provide
name	name of the handler, to be shown in /proc/bus/input/handlers
id_table	pointer to a table of input_device_ids this driver can handle
h_list	list of input handles associated with the handler
node	for placing the driver onto input_handler_list

Description

Input handlers attach to input devices and create input handles. There are likely several handlers attached to any given input device at the same time. All of them will get their copy of input event generated by the device.

The very same structure is used to implement input filters. Input core allows filters to run first and will not pass event to regular handlers if any of the filters indicate that the event should be filtered (by returning `true` from their `filter` method).

Note that input core serializes calls to `connect` and `disconnect` methods.

Name

struct input_handle — links input device with an input handler

Synopsis

```
struct input_handle {
  void * private;
  int open;
  const char * name;
  struct input_dev * dev;
  struct input_handler * handler;
  struct list_head d_node;
  struct list_head h_node;
};
```

Members

private	handler-specific data
open	counter showing whether the handle is 'open', i.e. should deliver events from its device
name	name given to the handle by handler that created it
dev	input device the handle is attached to
handler	handler that works with the device through this handle
d_node	used to put the handle on device's list of attached handles
h_node	used to put the handle on handler's list of handles from which it gets events

Name

input_set_events_per_packet — tell handlers about the driver event rate

Synopsis

```
void input_set_events_per_packet (struct input_dev * dev, int n_events);
```

Arguments

dev the input device used by the driver

n_events the average number of events between calls to `input_sync`

Description

If the event rate sent from a device is unusually large, use this function to set the expected event rate. This will allow handlers to set up an appropriate buffer size for the event stream, in order to minimize information loss.

Name

struct ff_device — force-feedback part of an input device

Synopsis

```
struct ff_device {
  int (* upload) (struct input_dev *dev, struct ff_effect *effect,struct ff_effect
  int (* erase) (struct input_dev *dev, int effect_id);
  int (* playback) (struct input_dev *dev, int effect_id, int value);
  void (* set_gain) (struct input_dev *dev, u16 gain);
  void (* set_autocenter) (struct input_dev *dev, u16 magnitude);
  void (* destroy) (struct ff_device *);
  void * private;
  unsigned long ffbit[BITS_TO_LONGS(FF_CNT)];
  struct mutex mutex;
  int max_effects;
  struct ff_effect * effects;
  struct file * effect_owners[];
};
```

Members

upload	Called to upload an new effect into device
erase	Called to erase an effect from device
playback	Called to request device to start playing specified effect
set_gain	Called to set specified gain
set_autocenter	Called to auto-center device
destroy	called by input core when parent input device is being destroyed
private	driver-specific data, will be freed automatically
ffbit[BITS_TO_LONGS(FF_CNT)]	bitmap of force feedback capabilities truly supported by device (not emulated like ones in input_dev->ffbit)
mutex	mutex for serializing access to the device
max_effects	maximum number of effects supported by device
effects	pointer to an array of effects currently loaded into device
effect_owners[]	array of effect owners; when file handle owning an effect gets closed the effect is automatically erased

Description

Every force-feedback device must implement `upload` and `playback` methods; `erase` is optional. `set_gain` and `set_autocenter` need only be implemented if driver sets up FF_GAIN and FF_AUTOCENTER bits.

Note that `playback`, `set_gain` and `set_autocenter` are called with dev->event_lock spinlock held and interrupts off and thus may not sleep.

Name

input_event — report new input event

Synopsis

```
void input_event (struct input_dev * dev, unsigned int type, unsigned int code, int value);
```

Arguments

dev device that generated the event

type type of the event

code event code

value value of the event

Description

This function should be used by drivers implementing various input devices to report input events. See also `input_inject_event`.

NOTE

`input_event` may be safely used right after input device was allocated with `input_allocate_device`, even before it is registered with `input_register_device`, but the event will not reach any of the input handlers. Such early invocation of `input_event` may be used to 'seed' initial state of a switch or initial position of absolute axis, etc.

Name

input_inject_event — send input event from input handler

Synopsis

```
void input_inject_event (struct input_handle * handle, unsigned int type, unsigned int code, int value);
```

Arguments

handle input handle to send event through

type type of the event

code event code

value value of the event

Description

Similar to `input_event` but will ignore event if device is “grabbed” and handle injecting event is not the one that owns the device.

Name

input_alloc_absinfo — allocates array of input_absinfo structs

Synopsis

```
void input_alloc_absinfo (struct input_dev * dev);
```

Arguments

dev the input device emitting absolute events

Description

If the absinfo struct the caller asked for is already allocated, this functions will not do anything.

Name

input_grab_device — grabs device for exclusive use

Synopsis

```
int input_grab_device (struct input_handle * handle);
```

Arguments

handle input handle that wants to own the device

Description

When a device is grabbed by an input handle all events generated by the device are delivered only to this handle. Also events injected by other input handles are ignored while device is grabbed.

Name

input_release_device — release previously grabbed device

Synopsis

```
void input_release_device (struct input_handle * handle);
```

Arguments

handle input handle that owns the device

Description

Releases previously grabbed device so that other input handles can start receiving input events. Upon release all handlers attached to the device have their `start` method called so they have a change to synchronize device state with the rest of the system.

Name

input_open_device — open input device

Synopsis

```
int input_open_device (struct input_handle * handle);
```

Arguments

handle handle through which device is being accessed

Description

This function should be called by input handlers when they want to start receive events from given input device.

Name

input_close_device — close input device

Synopsis

```
void input_close_device (struct input_handle * handle);
```

Arguments

handle handle through which device is being accessed

Description

This function should be called by input handlers when they want to stop receive events from given input device.

Name

input_scancode_to_scalar — converts scancode in struct input_keymap_entry

Synopsis

```
int input_scancode_to_scalar (const struct input_keymap_entry * ke,
unsigned int * scancode);
```

Arguments

ke keymap entry containing scancode to be converted.

scancode pointer to the location where converted scancode should be stored.

Description

This function is used to convert scancode stored in struct keymap_entry into scalar form understood by legacy keymap handling methods. These methods expect scancodes to be represented as 'unsigned int'.

Name

input_get_keycode — retrieve keycode currently mapped to a given scancode

Synopsis

```
int input_get_keycode (struct input_dev * dev, struct input_keymap_entry
* ke);
```

Arguments

dev input device which keymap is being queried

ke keymap entry

Description

This function should be called by anyone interested in retrieving current keymap. Presently evdev handlers use it.

Name

input_set_keycode — attribute a keycode to a given scancode

Synopsis

```
int input_set_keycode (struct input_dev * dev, const struct
input_keymap_entry * ke);
```

Arguments

dev input device which keymap is being updated

ke new keymap entry

Description

This function should be called by anyone needing to update current keymap. Presently keyboard and evdev handlers use it.

Name

input_reset_device — reset/restore the state of input device

Synopsis

```
void input_reset_device (struct input_dev * dev);
```

Arguments

dev input device whose state needs to be reset

Description

This function tries to reset the state of an opened input device and bring internal state and state if the hardware in sync with each other. We mark all keys as released, restore LED state, repeat rate, etc.

Name

input_allocate_device — allocate memory for new input device

Synopsis

```
struct input_dev * input_allocate_device ( void);
```

Arguments

void no arguments

Description

Returns prepared struct input_dev or `NULL`.

NOTE

Use `input_free_device` to free devices that have not been registered; `input_unregister_device` should be used for already registered devices.

Name

devm_input_allocate_device — allocate managed input device

Synopsis

```
struct input_dev * devm_input_allocate_device (struct device * dev);
```

Arguments

dev device owning the input device being created

Description

Returns prepared struct input_dev or NULL.

Managed input devices do not need to be explicitly unregistered or freed as it will be done automatically when owner device unbinds from its driver (or binding fails). Once managed input device is allocated, it is ready to be set up and registered in the same fashion as regular input device. There are no special devm_input_device_[un]register variants, regular ones work with both managed and unmanaged devices, should you need them. In most cases however, managed input device need not be explicitly unregistered or freed.

NOTE

the owner device is set up as parent of input device and users should not override it.

Name

input_free_device — free memory occupied by input_dev structure

Synopsis

```
void input_free_device (struct input_dev * dev);
```

Arguments

dev input device to free

Description

This function should only be used if `input_register_device` was not called yet or if it failed. Once device was registered use `input_unregister_device` and memory will be freed once last reference to the device is dropped.

Device should be allocated by `input_allocate_device`.

NOTE

If there are references to the input device then memory will not be freed until last reference is dropped.

Name

input_set_capability — mark device as capable of a certain event

Synopsis

```
void input_set_capability (struct input_dev * dev, unsigned int type,
unsigned int code);
```

Arguments

dev device that is capable of emitting or accepting event

type type of the event (EV_KEY, EV_REL, etc...)

code event code

Description

In addition to setting up corresponding bit in appropriate capability bitmap the function also adjusts dev->evbit.

Name

input_enable_softrepeat — enable software autorepeat

Synopsis

```
void input_enable_softrepeat (struct input_dev * dev, int delay, int
period);
```

Arguments

dev input device

delay repeat delay

period repeat period

Description

Enable software autorepeat on the input device.

Name

input_register_device — register device with input core

Synopsis

```
int input_register_device (struct input_dev * dev);
```

Arguments

dev device to be registered

Description

This function registers device with input core. The device must be allocated with `input_allocate_device` and all it's capabilities set up before registering. If function fails the device must be freed with `input_free_device`. Once device has been successfully registered it can be unregistered with `input_unregister_device`; `input_free_device` should not be called in this case.

Note that this function is also used to register managed input devices (ones allocated with `devm_input_allocate_device`). Such managed input devices need not be explicitly unregistered or freed, their tear down is controlled by the devres infrastructure. It is also worth noting that tear down of managed input devices is internally a 2-step process: registered managed input device is first unregistered, but stays in memory and can still handle `input_event` calls (although events will not be delivered anywhere). The freeing of managed input device will happen later, when devres stack is unwound to the point where device allocation was made.

Name

input_unregister_device — unregister previously registered device

Synopsis

```
void input_unregister_device (struct input_dev * dev);
```

Arguments

dev device to be unregistered

Description

This function unregisters an input device. Once device is unregistered the caller should not try to access it as it may get freed at any moment.

Name

input_register_handler — register a new input handler

Synopsis

```
int input_register_handler (struct input_handler * handler);
```

Arguments

handler handler to be registered

Description

This function registers a new input handler (interface) for input devices in the system and attaches it to all input devices that are compatible with the handler.

Name

input_unregister_handler — unregisters an input handler

Synopsis

```
void input_unregister_handler (struct input_handler * handler);
```

Arguments

handler handler to be unregistered

Description

This function disconnects a handler from its input devices and removes it from lists of known handlers.

Name

input_handler_for_each_handle — handle iterator

Synopsis

```
int input_handler_for_each_handle (struct input_handler * handler, void
* data, int (*fn) (struct input_handle *, void *));
```

Arguments

handler	input handler to iterate
data	data for the callback
fn	function to be called for each handle

Description

Iterate over *bus*'s list of devices, and call *fn* for each, passing it *data* and stop when *fn* returns a non-zero value. The function is using RCU to traverse the list and therefore may be using in atomic contexts. The *fn* callback is invoked from RCU critical section and thus must not sleep.

Name

input_register_handle — register a new input handle

Synopsis

```
int input_register_handle (struct input_handle * handle);
```

Arguments

handle handle to register

Description

This function puts a new input handle onto device's and handler's lists so that events can flow through it once it is opened using `input_open_device`.

This function is supposed to be called from handler's `connect` method.

Name

input_unregister_handle — unregister an input handle

Synopsis

```
void input_unregister_handle (struct input_handle * handle);
```

Arguments

handle handle to unregister

Description

This function removes input handle from device's and handler's lists.

This function is supposed to be called from handler's `disconnect` method.

Name

input_get_new_minor — allocates a new input minor number

Synopsis

```
int input_get_new_minor (int legacy_base, unsigned int legacy_num, bool
allow_dynamic);
```

Arguments

legacy_base	beginning or the legacy range to be searched
legacy_num	size of legacy range
allow_dynamic	whether we can also take ID from the dynamic range

Description

This function allocates a new device minor for from input major namespace. Caller can request legacy minor by specifying *legacy_base* and *legacy_num* parameters and whether ID can be allocated from dynamic range if there are no free IDs in legacy range.

Name

input_free_minor — release previously allocated minor

Synopsis

```
void input_free_minor (unsigned int minor);
```

Arguments

minor minor to be released

Description

This function releases previously allocated input minor so that it can be reused later.

Name

input_ff_upload — upload effect into force-feedback device

Synopsis

```
int input_ff_upload (struct input_dev * dev, struct ff_effect * effect,
struct file * file);
```

Arguments

dev input device

effect effect to be uploaded

file owner of the effect

Name

input_ff_erase — erase a force-feedback effect from device

Synopsis

```
int input_ff_erase (struct input_dev * dev, int effect_id, struct file
* file);
```

Arguments

dev	input device to erase effect from
effect_id	id of the effect to be erased
file	purported owner of the request

Description

This function erases a force-feedback effect from specified device. The effect will only be erased if it was uploaded through the same file handle that is requesting erase.

Name

input_ff_event — generic handler for force-feedback events

Synopsis

```
int input_ff_event (struct input_dev * dev, unsigned int type, unsigned
int code, int value);
```

Arguments

dev input device to send the effect to

type event type (anything but EV_FF is ignored)

code event code

value event value

Name

input_ff_create — create force-feedback device

Synopsis

```
int input_ff_create (struct input_dev * dev, unsigned int max_effects);
```

Arguments

dev	input device supporting force-feedback
max_effects	maximum number of effects supported by the device

Description

This function allocates all necessary memory for a force feedback portion of an input device and installs all default handlers. *dev*->ffbit should be already set up before calling this function. Once ff device is created you need to setup its upload, erase, playback and other handlers before registering input device

Name

input_ff_destroy — frees force feedback portion of input device

Synopsis

```
void input_ff_destroy (struct input_dev * dev);
```

Arguments

dev input device supporting force feedback

Description

This function is only needed in error path as input core will automatically free force feedback structures when device is destroyed.

Name

input_ff_create_memless — create memoryless force-feedback device

Synopsis

```
int input_ff_create_memless (struct input_dev * dev, void * data, int
(*play_effect) (struct input_dev *, void *, struct ff_effect *));
```

Arguments

dev	input device supporting force-feedback
data	driver-specific data to be passed into *play_effect*
play_effect	driver-specific method for playing FF effect

Multitouch Library

Name

struct input_mt_slot — represents the state of an input MT slot

Synopsis

```
struct input_mt_slot {
  int abs[ABS_MT_LAST - ABS_MT_FIRST + 1];
  unsigned int frame;
  unsigned int key;
};
```

Members

abs[ABS_MT_LAST - ABS_MT_FIRST + 1]	holds current values of ABS_MT axes for this slot
frame	last frame at which `input_mt_report_slot_state` was called
key	optional driver designation of this slot

Name

struct input_mt — state of tracked contacts

Synopsis

```
struct input_mt {
  int trkid;
  int num_slots;
  int slot;
  unsigned int flags;
  unsigned int frame;
  int * red;
  struct input_mt_slot slots[];
};
```

Members

trkid	stores MT tracking ID for the next contact
num_slots	number of MT slots the device uses
slot	MT slot currently being transmitted
flags	input_mt operation flags
frame	increases every time `input_mt_sync_frame` is called
red	reduced cost matrix for in-kernel tracking
slots[]	array of slots holding current values of tracked contacts

Name

struct input_mt_pos — contact position

Synopsis

```
struct input_mt_pos {
  s16 x;
  s16 y;
};
```

Members

x horizontal coordinate

y vertical coordinate

Name

input_mt_init_slots — initialize MT input slots

Synopsis

```
int input_mt_init_slots (struct input_dev * dev, unsigned int num_slots,
unsigned int flags);
```

Arguments

dev	input device supporting MT events and finger tracking
num_slots	number of slots used by the device
flags	mt tasks to handle in core

Description

This function allocates all necessary memory for MT slot handling in the input device, prepares the ABS_MT_SLOT and ABS_MT_TRACKING_ID events for use and sets up appropriate buffers. Depending on the flags set, it also performs pointer emulation and frame synchronization.

May be called repeatedly. Returns -EINVAL if attempting to reinitialize with a different number of slots.

Name

input_mt_destroy_slots — frees the MT slots of the input device

Synopsis

```
void input_mt_destroy_slots (struct input_dev * dev);
```

Arguments

dev input device with allocated MT slots

Description

This function is only needed in error path as the input core will automatically free the MT slots when the device is destroyed.

Name

input_mt_report_slot_state — report contact state

Synopsis

```
void input_mt_report_slot_state (struct input_dev * dev, unsigned int tool_type, bool active);
```

Arguments

dev	input device with allocated MT slots
tool_type	the tool type to use in this slot
active	true if contact is active, false otherwise

Description

Reports a contact via ABS_MT_TRACKING_ID, and optionally ABS_MT_TOOL_TYPE. If active is true and the slot is currently inactive, or if the tool type is changed, a new tracking id is assigned to the slot. The tool type is only reported if the corresponding absbit field is set.

Name

input_mt_report_finger_count — report contact count

Synopsis

```
void input_mt_report_finger_count (struct input_dev * dev, int count);
```

Arguments

dev input device with allocated MT slots

count the number of contacts

Description

Reports the contact count via BTN_TOOL_FINGER, BTN_TOOL_DOUBLETAP, BTN_TOOL_TRIPLETAP and BTN_TOOL_QUADTAP.

The input core ensures only the KEY events already setup for this device will produce output.

Name

input_mt_report_pointer_emulation — common pointer emulation

Synopsis

```
void input_mt_report_pointer_emulation (struct input_dev * dev, bool use_count);
```

Arguments

dev input device with allocated MT slots

use_count report number of active contacts as finger count

Description

Performs legacy pointer emulation via BTN_TOUCH, ABS_X, ABS_Y and ABS_PRESSURE. Touchpad finger count is emulated if use_count is true.

The input core ensures only the KEY and ABS axes already setup for this device will produce output.

Name

input_mt_drop_unused — Inactivate slots not seen in this frame

Synopsis

```
void input_mt_drop_unused (struct input_dev * dev);
```

Arguments

dev input device with allocated MT slots

Description

Lift all slots not seen since the last call to this function.

Name

input_mt_sync_frame — synchronize mt frame

Synopsis

```
void input_mt_sync_frame (struct input_dev * dev);
```

Arguments

dev input device with allocated MT slots

Description

Close the frame and prepare the internal state for a new one. Depending on the flags, marks unused slots as inactive and performs pointer emulation.

Name

input_mt_assign_slots — perform a best-match assignment

Synopsis

```
int input_mt_assign_slots (struct input_dev * dev, int * slots, const
struct input_mt_pos * pos, int num_pos, int dmax);
```

Arguments

dev	input device with allocated MT slots
slots	the slot assignment to be filled
pos	the position array to match
num_pos	number of positions
dmax	maximum ABS_MT_POSITION displacement (zero for infinite)

Description

Performs a best match against the current contacts and returns the slot assignment list. New contacts are assigned to unused slots.

The assignments are balanced so that all coordinate displacements are below the euclidian distance dmax. If no such assignment can be found, some contacts are assigned to unused slots.

Returns zero on success, or negative error in case of failure.

Name

input_mt_get_slot_by_key — return slot matching key

Synopsis

```
int input_mt_get_slot_by_key (struct input_dev * dev, int key);
```

Arguments

dev input device with allocated MT slots

key the key of the sought slot

Description

Returns the slot of the given key, if it exists, otherwise set the key on the first unused slot and return.

If no available slot can be found, -1 is returned. Note that for this function to work properly, `input_mt_sync_frame` has to be called at each frame.

Polled input devices

Name

struct input_polled_dev — simple polled input device

Synopsis

```
struct input_polled_dev {
  void * private;
  void (* open) (struct input_polled_dev *dev);
  void (* close) (struct input_polled_dev *dev);
  void (* poll) (struct input_polled_dev *dev);
  unsigned int poll_interval;
  unsigned int poll_interval_max;
  unsigned int poll_interval_min;
  struct input_dev * input;
};
```

Members

private	private driver data.
open	driver-supplied method that prepares device for polling (enabled the device and maybe flushes device state).
close	driver-supplied method that is called when device is no longer being polled. Used to put device into low power mode.
poll	driver-supplied method that polls the device and posts input events (mandatory).
poll_interval	specifies how often the `poll` method should be called. Defaults to 500 msec unless overridden when registering the device.
poll_interval_max	specifies upper bound for the poll interval. Defaults to the initial value of *`poll_interval`*.
poll_interval_min	specifies lower bound for the poll interval. Defaults to 0.
input	input device structure associated with the polled device. Must be properly initialized by the driver (id, name, phys, bits).

Description

Polled input device provides a skeleton for supporting simple input devices that do not raise interrupts but have to be periodically scanned or polled to detect changes in their state.

Name

input_allocate_polled_device — allocate memory for polled device

Synopsis

```
struct input_polled_dev * input_allocate_polled_device ( void);
```

Arguments

void no arguments

Description

The function allocates memory for a polled device and also for an input device associated with this polled device.

Name

devm_input_allocate_polled_device — allocate managed polled device

Synopsis

```
struct input_polled_dev * devm_input_allocate_polled_device (struct device * dev);
```

Arguments

dev device owning the polled device being created

Description

Returns prepared struct input_polled_dev or NULL.

Managed polled input devices do not need to be explicitly unregistered or freed as it will be done automatically when owner device unbinds from * its driver (or binding fails). Once such managed polled device is allocated, it is ready to be set up and registered in the same fashion as regular polled input devices (using input_register_polled_device function).

If you want to manually unregister and free such managed polled devices, it can be still done by calling input_unregister_polled_device and input_free_polled_device, although it is rarely needed.

NOTE

the owner device is set up as parent of input device and users should not override it.

Name

input_free_polled_device — free memory allocated for polled device

Synopsis

```
void input_free_polled_device (struct input_polled_dev * dev);
```

Arguments

dev device to free

Description

The function frees memory allocated for polling device and drops reference to the associated input device.

Name

input_register_polled_device — register polled device

Synopsis

```
int input_register_polled_device (struct input_polled_dev * dev);
```

Arguments

dev device to register

Description

The function registers previously initialized polled input device with input layer. The device should be allocated with call to `input_allocate_polled_device`. Callers should also set up `poll` method and set up capabilities (id, name, phys, bits) of the corresponding input_dev structure.

Name

input_unregister_polled_device — unregister polled device

Synopsis

```
void input_unregister_polled_device (struct input_polled_dev * dev);
```

Arguments

dev device to unregister

Description

The function unregisters previously registered polled input device from input layer. Polling is stopped and device is ready to be freed with call to `input_free_polled_device`.

Matrix keyboars/keypads

Name

struct matrix_keymap_data — keymap for matrix keyboards

Synopsis

```
struct matrix_keymap_data {
  const uint32_t * keymap;
  unsigned int keymap_size;
};
```

Members

keymap — pointer to array of uint32 values encoded with KEY macro representing keymap

keymap_size — number of entries (initialized) in this keymap

Description

This structure is supposed to be used by platform code to supply keymaps to drivers that implement matrix-like keypads/keyboards.

Name

struct matrix_keypad_platform_data — platform-dependent keypad data

Synopsis

```
struct matrix_keypad_platform_data {
  const struct matrix_keymap_data * keymap_data;
  const unsigned int * row_gpios;
  const unsigned int * col_gpios;
  unsigned int num_row_gpios;
  unsigned int num_col_gpios;
  unsigned int col_scan_delay_us;
  unsigned int debounce_ms;
  unsigned int clustered_irq;
  unsigned int clustered_irq_flags;
  bool active_low;
  bool wakeup;
  bool no_autorepeat;
};
```

Members

keymap_data	pointer to matrix_keymap_data
row_gpios	pointer to array of gpio numbers representing rows
col_gpios	pointer to array of gpio numbers reporesenting colums
num_row_gpios	actual number of row gpios used by device
num_col_gpios	actual number of col gpios used by device
col_scan_delay_us	delay, measured in microseconds, that is needed before we can keypad after activating column gpio
debounce_ms	debounce interval in milliseconds
clustered_irq	may be specified if interrupts of all row/column GPIOs are bundled to one single irq
clustered_irq_flags	flags that are needed for the clustered irq
active_low	gpio polarity
wakeup	controls whether the device should be set up as wakeup source
no_autorepeat	disable key autorepeat

Description

This structure represents platform-specific data that use used by matrix_keypad driver to perform proper initialization.

Name

matrix_keypad_parse_of_params — Read parameters from matrix-keypad node

Synopsis

```
int matrix_keypad_parse_of_params (struct device * dev, unsigned int *
rows, unsigned int * cols);
```

Arguments

dev Device containing of_node

rows Returns number of matrix rows

cols Returns number of matrix columns *return* 0 if OK, <0 on error

Sparse keymap support

Name

struct key_entry — keymap entry for use in sparse keymap

Synopsis

```
struct key_entry {
  int type;
  u32 code;
  union {unnamed_union};
};
```

Members

type	Type of the key entry (KE_KEY, KE_SW, KE_VSW, KE_END); drivers are allowed to extend the list with their own private definitions.
code	Device-specific data identifying the button/switch
{unnamed_union}	anonymous

Description

This structure defines an entry in a sparse keymap used by some input devices for which traditional table-based approach is not suitable.

Name

sparse_keymap_entry_from_scancode — perform sparse keymap lookup

Synopsis

```
struct key_entry * sparse_keymap_entry_from_scancode (struct input_dev
* dev, unsigned int code);
```

Arguments

dev Input device using sparse keymap

code Scan code

Description

This function is used to perform struct key_entry lookup in an input device using sparse keymap.

Name

sparse_keymap_entry_from_keycode — perform sparse keymap lookup

Synopsis

```
struct key_entry * sparse_keymap_entry_from_keycode (struct input_dev
* dev, unsigned int keycode);
```

Arguments

dev Input device using sparse keymap

keycode Key code

Description

This function is used to perform struct key_entry lookup in an input device using sparse keymap.

Name

sparse_keymap_setup — set up sparse keymap for an input device

Synopsis

```
int sparse_keymap_setup (struct input_dev * dev, const struct key_entry
* keymap, int (*setup) (struct input_dev *, struct key_entry *));
```

Arguments

dev Input device

keymap Keymap in form of array of key_entry structures ending with KE_END type entry

setup Function that can be used to adjust keymap entries depending on device's deeds, may be NULL

Description

The function calculates size and allocates copy of the original keymap after which sets up input device event bits appropriately. Before destroying input device allocated keymap should be freed with a call to sparse_keymap_free.

Name

sparse_keymap_free — free memory allocated for sparse keymap

Synopsis

```
void sparse_keymap_free (struct input_dev * dev);
```

Arguments

dev Input device using sparse keymap

Description

This function is used to free memory allocated by sparse keymap in an input device that was set up by `sparse_keymap_setup`.

NOTE

It is safe to cal this function while input device is still registered (however the drivers should care not to try to use freed keymap and thus have to shut off interrupts/polling before freeing the keymap).

Name

sparse_keymap_report_entry — report event corresponding to given key entry

Synopsis

```
void sparse_keymap_report_entry (struct input_dev * dev, const struct
key_entry * ke, unsigned int value, bool autorelease);
```

Arguments

dev	Input device for which event should be reported
ke	key entry describing event
value	Value that should be reported (ignored by KE_SW entries)
autorelease	Signals whether release event should be emitted for KE_KEY entries right after reporting press event, ignored by all other entries

Description

This function is used to report input event described by given struct key_entry.

Name

sparse_keymap_report_event — report event corresponding to given scancode

Synopsis

```
bool sparse_keymap_report_event (struct input_dev * dev, unsigned int code, unsigned int value, bool autorelease);
```

Arguments

dev	Input device using sparse keymap
code	Scan code
value	Value that should be reported (ignored by KE_SW entries)
autorelease	Signals whether release event should be emitted for KE_KEY entries right after reporting press event, ignored by all other entries

Description

This function is used to perform lookup in an input device using sparse keymap and report corresponding event. Returns `true` if lookup was successful and `false` otherwise.

Chapter 10. Serial Peripheral Interface (SPI)

SPI is the "Serial Peripheral Interface", widely used with embedded systems because it is a simple and efficient interface: basically a multiplexed shift register. Its three signal wires hold a clock (SCK, often in the range of 1-20 MHz), a "Master Out, Slave In" (MOSI) data line, and a "Master In, Slave Out" (MISO) data line. SPI is a full duplex protocol; for each bit shifted out the MOSI line (one per clock) another is shifted in on the MISO line. Those bits are assembled into words of various sizes on the way to and from system memory. An additional chipselect line is usually active-low (nCS); four signals are normally used for each peripheral, plus sometimes an interrupt.

The SPI bus facilities listed here provide a generalized interface to declare SPI busses and devices, manage them according to the standard Linux driver model, and perform input/output operations. At this time, only "master" side interfaces are supported, where Linux talks to SPI peripherals and does not implement such a peripheral itself. (Interfaces to support implementing SPI slaves would necessarily look different.)

The programming interface is structured around two kinds of driver, and two kinds of device. A "Controller Driver" abstracts the controller hardware, which may be as simple as a set of GPIO pins or as complex as a pair of FIFOs connected to dual DMA engines on the other side of the SPI shift register (maximizing throughput). Such drivers bridge between whatever bus they sit on (often the platform bus) and SPI, and expose the SPI side of their device as a struct spi_master. SPI devices are children of that master, represented as a struct spi_device and manufactured from struct spi_board_info descriptors which are usually provided by board-specific initialization code. A struct spi_driver is called a "Protocol Driver", and is bound to a spi_device using normal driver model calls.

The I/O model is a set of queued messages. Protocol drivers submit one or more struct spi_message objects, which are processed and completed asynchronously. (There are synchronous wrappers, however.) Messages are built from one or more struct spi_transfer objects, each of which wraps a full duplex SPI transfer. A variety of protocol tweaking options are needed, because different chips adopt very different policies for how they use the bits transferred with SPI.

Name

struct spi_statistics — statistics for spi transfers

Synopsis

```
struct spi_statistics {
  spinlock_t lock;
  unsigned long messages;
  unsigned long transfers;
  unsigned long errors;
  unsigned long timedout;
  unsigned long spi_sync;
  unsigned long spi_sync_immediate;
  unsigned long spi_async;
  unsigned long long bytes;
  unsigned long long bytes_rx;
  unsigned long long bytes_tx;
#define SPI_STATISTICS_HISTO_SIZE 17
  unsigned long transfer_bytes_histo[SPI_STATISTICS_HISTO_SIZE];
};
```

Members

lock	lock protecting this structure
messages	number of spi-messages handled
transfers	number of spi_transfers handled
errors	number of errors during spi_transfer
timedout	number of timeouts during spi_transfer
spi_sync	number of times spi_sync is used
spi_sync_immediate	number of times spi_sync is executed immediately in calling context without queuing and scheduling
spi_async	number of times spi_async is used
bytes	number of bytes transferred to/from device
bytes_rx	number of bytes received from device
bytes_tx	number of bytes sent to device
transfer_bytes_histo[SPI_STATISTICS_HISTO_SIZE]	transfer bytes histogramm

Name

struct spi_device — Master side proxy for an SPI slave device

Synopsis

```
struct spi_device {
  struct device dev;
  struct spi_master * master;
  u32 max_speed_hz;
  u8 chip_select;
  u8 bits_per_word;
  u16 mode;
#define SPI_CPHA 0x01
#define SPI_CPOL 0x02
#define SPI_MODE_0 (0|0)
#define SPI_MODE_1 (0|SPI_CPHA)
#define SPI_MODE_2 (SPI_CPOL|0)
#define SPI_MODE_3 (SPI_CPOL|SPI_CPHA)
#define SPI_CS_HIGH 0x04
#define SPI_LSB_FIRST 0x08
#define SPI_3WIRE 0x10
#define SPI_LOOP 0x20
#define SPI_NO_CS 0x40
#define SPI_READY 0x80
#define SPI_TX_DUAL 0x100
#define SPI_TX_QUAD 0x200
#define SPI_RX_DUAL 0x400
#define SPI_RX_QUAD 0x800
  int irq;
  void * controller_state;
  void * controller_data;
  char modalias[SPI_NAME_SIZE];
  int cs_gpio;
  struct spi_statistics statistics;
};
```

Members

dev	Driver model representation of the device.
master	SPI controller used with the device.
max_speed_hz	Maximum clock rate to be used with this chip (on this board); may be changed by the device's driver. The spi_transfer.speed_hz can override this for each transfer.
chip_select	Chipselect, distinguishing chips handled by *master*.
bits_per_word	Data transfers involve one or more words; word sizes like eight or 12 bits are common. In-memory wordsizes are powers of two bytes (e.g. 20 bit samples use 32 bits). This may be changed by the device's driver, or left at the default (0) indicating protocol words are eight

	bit bytes. The spi_transfer.bits_per_word can override this for each transfer.
mode	The spi mode defines how data is clocked out and in. This may be changed by the device's driver. The “active low” default for chipselect mode can be overridden (by specifying SPI_CS_HIGH) as can the “MSB first” default for each word in a transfer (by specifying SPI_LSB_FIRST).
irq	Negative, or the number passed to `request_irq` to receive interrupts from this device.
controller_state	Controller's runtime state
controller_data	Board-specific definitions for controller, such as FIFO initialization parameters; from board_info.controller_data
modalias[SPI_NAME_SIZE]	Name of the driver to use with this device, or an alias for that name. This appears in the sysfs “modalias” attribute for driver coldplugging, and in uevents used for hotplugging
cs_gpio	gpio number of the chipselect line (optional, -ENOENT when when not using a GPIO line)
statistics	statistics for the spi_device

Description

A *`spi_device`* is used to interchange data between an SPI slave (usually a discrete chip) and CPU memory.

In *`dev`*, the platform_data is used to hold information about this device that's meaningful to the device's protocol driver, but not to its controller. One example might be an identifier for a chip variant with slightly different functionality; another might be information about how this particular board wires the chip's pins.

Name

struct spi_driver — Host side “protocol” driver

Synopsis

```
struct spi_driver {
  const struct spi_device_id * id_table;
  int (* probe) (struct spi_device *spi);
  int (* remove) (struct spi_device *spi);
  void (* shutdown) (struct spi_device *spi);
  struct device_driver driver;
};
```

Members

id_table — List of SPI devices supported by this driver

probe — Binds this driver to the spi device. Drivers can verify that the device is actually present, and may need to configure characteristics (such as bits_per_word) which weren't needed for the initial configuration done during system setup.

remove — Unbinds this driver from the spi device

shutdown — Standard shutdown callback used during system state transitions such as powerdown/halt and kexec

driver — SPI device drivers should initialize the name and owner field of this structure.

Description

This represents the kind of device driver that uses SPI messages to interact with the hardware at the other end of a SPI link. It's called a “protocol” driver because it works through messages rather than talking directly to SPI hardware (which is what the underlying SPI controller driver does to pass those messages). These protocols are defined in the specification for the device(s) supported by the driver.

As a rule, those device protocols represent the lowest level interface supported by a driver, and it will support upper level interfaces too. Examples of such upper levels include frameworks like MTD, networking, MMC, RTC, filesystem character device nodes, and hardware monitoring.

Name

spi_unregister_driver — reverse effect of spi_register_driver

Synopsis

```
void spi_unregister_driver (struct spi_driver * sdrv);
```

Arguments

sdrv the driver to unregister

Context

can sleep

Name

module_spi_driver — Helper macro for registering a SPI driver

Synopsis

```
module_spi_driver ( __spi_driver);
```

Arguments

__spi_driver spi_driver struct

Description

Helper macro for SPI drivers which do not do anything special in module init/exit. This eliminates a lot of boilerplate. Each module may only use this macro once, and calling it replaces `module_init` and `module_exit`

Name

struct spi_master — interface to SPI master controller

Synopsis

```
struct spi_master {
  struct device dev;
  struct list_head list;
  s16 bus_num;
  u16 num_chipselect;
  u16 dma_alignment;
  u16 mode_bits;
  u32 bits_per_word_mask;
#define SPI_BPW_MASK(bits) BIT((bits) - 1)
#define SPI_BIT_MASK(bits) (((bits) == 32) ? ~0U : (BIT(bits) - 1))
#define SPI_BPW_RANGE_MASK(min# max) (SPI_BIT_MASK(max) - SPI_BIT_MASK(min - 1))
  u32 min_speed_hz;
  u32 max_speed_hz;
  u16 flags;
#define SPI_MASTER_HALF_DUPLEX BIT(0)
#define SPI_MASTER_NO_RX BIT(1)
#define SPI_MASTER_NO_TX BIT(2)
#define SPI_MASTER_MUST_RX      BIT(3)
#define SPI_MASTER_MUST_TX      BIT(4)
  spinlock_t bus_lock_spinlock;
  struct mutex bus_lock_mutex;
  bool bus_lock_flag;
  int (* setup) (struct spi_device *spi);
  int (* transfer) (struct spi_device *spi,struct spi_message *mesg);
  void (* cleanup) (struct spi_device *spi);
  bool (* can_dma) (struct spi_master *master,struct spi_device *spi,struct spi_tr
  bool queued;
  struct kthread_worker kworker;
  struct task_struct * kworker_task;
  struct kthread_work pump_messages;
  spinlock_t queue_lock;
  struct list_head queue;
  struct spi_message * cur_msg;
  bool idling;
  bool busy;
  bool running;
  bool rt;
  bool auto_runtime_pm;
  bool cur_msg_prepared;
  bool cur_msg_mapped;
  struct completion xfer_completion;
  size_t max_dma_len;
  int (* prepare_transfer_hardware) (struct spi_master *master);
  int (* transfer_one_message) (struct spi_master *master,struct spi_message *mesg
  int (* unprepare_transfer_hardware) (struct spi_master *master);
  int (* prepare_message) (struct spi_master *master,struct spi_message *message);
  int (* unprepare_message) (struct spi_master *master,struct spi_message *message
```

```
  void (* set_cs) (struct spi_device *spi, bool enable);
  int (* transfer_one) (struct spi_master *master, struct spi_device *spi,struct s
  void (* handle_err) (struct spi_master *master,struct spi_message *message);
  int * cs_gpios;
  struct spi_statistics statistics;
  struct dma_chan * dma_tx;
  struct dma_chan * dma_rx;
  void * dummy_rx;
  void * dummy_tx;
};
```

Members

dev	device interface to this driver
list	link with the global spi_master list
bus_num	board-specific (and often SOC-specific) identifier for a given SPI controller.
num_chipselect	chipselects are used to distinguish individual SPI slaves, and are numbered from zero to num_chipselects. each slave has a chipselect signal, but it's common that not every chipselect is connected to a slave.
dma_alignment	SPI controller constraint on DMA buffers alignment.
mode_bits	flags understood by this controller driver
bits_per_word_mask	A mask indicating which values of bits_per_word are supported by the driver. Bit n indicates that a bits_per_word n+1 is supported. If set, the SPI core will reject any transfer with an unsupported bits_per_word. If not set, this value is simply ignored, and it's up to the individual driver to perform any validation.
min_speed_hz	Lowest supported transfer speed
max_speed_hz	Highest supported transfer speed
flags	other constraints relevant to this driver
bus_lock_spinlock	spinlock for SPI bus locking
bus_lock_mutex	mutex for SPI bus locking
bus_lock_flag	indicates that the SPI bus is locked for exclusive use
setup	updates the device mode and clocking records used by a device's SPI controller; protocol code may call this. This must fail if an unrecognized or unsupported mode is requested. It's always safe to call this unless transfers are pending on the device whose settings are being modified.
transfer	adds a message to the controller's transfer queue.
cleanup	frees controller-specific state

can_dma	determine whether this master supports DMA
queued	whether this master is providing an internal message queue
kworker	thread struct for message pump
kworker_task	pointer to task for message pump kworker thread
pump_messages	work struct for scheduling work to the message pump
queue_lock	spinlock to syncronise access to message queue
queue	message queue
cur_msg	the currently in-flight message
idling	the device is entering idle state
busy	message pump is busy
running	message pump is running
rt	whether this queue is set to run as a realtime task
auto_runtime_pm	the core should ensure a runtime PM reference is held while the hardware is prepared, using the parent device for the spidev
cur_msg_prepared	spi_prepare_message was called for the currently in-flight message
cur_msg_mapped	message has been mapped for DMA
xfer_completion	used by core `transfer_one_message`
max_dma_len	Maximum length of a DMA transfer for the device.
prepare_transfer_hardware	a message will soon arrive from the queue so the subsystem requests the driver to prepare the transfer hardware by issuing this call
transfer_one_message	the subsystem calls the driver to transfer a single message while queuing transfers that arrive in the meantime. When the driver is finished with this message, it must call `spi_finalize_current_message` so the subsystem can issue the next message
unprepare_transfer_hardware	there are currently no more messages on the queue so the subsystem notifies the driver that it may relax the hardware by issuing this call
prepare_message	set up the controller to transfer a single message, for example doing DMA mapping. Called from threaded context.
unprepare_message	undo any work done by `prepare_message`.
set_cs	set the logic level of the chip select line. May be called from interrupt context.
transfer_one	transfer a single spi_transfer. - return 0 if the transfer is finished, - return 1 if the transfer is still in progress. When the driver is finished with this transfer

	it must call `spi_finalize_current_transfer` so the subsystem can issue the next transfer. Note: transfer_one and transfer_one_message are mutually exclusive; when both are set, the generic subsystem does not call your transfer_one callback.
handle_err	the subsystem calls the driver to handle an error that occurs in the generic implementation of `transfer_one_message`.
cs_gpios	Array of GPIOs to use as chip select lines; one per CS number. Any individual value may be -ENOENT for CS lines that are not GPIOs (driven by the SPI controller itself).
statistics	statistics for the spi_master
dma_tx	DMA transmit channel
dma_rx	DMA receive channel
dummy_rx	dummy receive buffer for full-duplex devices
dummy_tx	dummy transmit buffer for full-duplex devices

Description

Each SPI master controller can communicate with one or more *`spi_device`* children. These make a small bus, sharing MOSI, MISO and SCK signals but not chip select signals. Each device may be configured to use a different clock rate, since those shared signals are ignored unless the chip is selected.

The driver for an SPI controller manages access to those devices through a queue of spi_message transactions, copying data between CPU memory and an SPI slave device. For each such message it queues, it calls the message's completion function when the transaction completes.

Name

struct spi_transfer — a read/write buffer pair

Synopsis

```
struct spi_transfer {
  const void * tx_buf;
  void * rx_buf;
  unsigned len;
  dma_addr_t tx_dma;
  dma_addr_t rx_dma;
  struct sg_table tx_sg;
  struct sg_table rx_sg;
  unsigned cs_change:1;
  unsigned tx_nbits:3;
  unsigned rx_nbits:3;
#define SPI_NBITS_SINGLE 0x01
#define SPI_NBITS_DUAL  0x02
#define SPI_NBITS_QUAD  0x04
  u8 bits_per_word;
  u16 delay_usecs;
  u32 speed_hz;
  struct list_head transfer_list;
};
```

Members

tx_buf	data to be written (dma-safe memory), or NULL
rx_buf	data to be read (dma-safe memory), or NULL
len	size of rx and tx buffers (in bytes)
tx_dma	DMA address of tx_buf, if *spi_message*.is_dma_mapped
rx_dma	DMA address of rx_buf, if *spi_message*.is_dma_mapped
tx_sg	Scatterlist for transmit, currently not for client use
rx_sg	Scatterlist for receive, currently not for client use
cs_change	affects chipselect after this transfer completes
tx_nbits	number of bits used for writing. If 0 the default (SPI_NBITS_SINGLE) is used.
rx_nbits	number of bits used for reading. If 0 the default (SPI_NBITS_SINGLE) is used.
bits_per_word	select a bits_per_word other than the device default for this transfer. If 0 the default (from *spi_device*) is used.
delay_usecs	microseconds to delay after this transfer before (optionally) changing the chipselect status, then starting the next transfer or completing this *spi_message*.

speed_hz	Select a speed other than the device default for this transfer. If 0 the default (from *spi_device*) is used.
transfer_list	transfers are sequenced through *spi_message*.transfers

Description

SPI transfers always write the same number of bytes as they read. Protocol drivers should always provide *rx_buf* and/or *tx_buf*. In some cases, they may also want to provide DMA addresses for the data being transferred; that may reduce overhead, when the underlying driver uses dma.

If the transmit buffer is null, zeroes will be shifted out while filling *rx_buf*. If the receive buffer is null, the data shifted in will be discarded. Only “len” bytes shift out (or in). It's an error to try to shift out a partial word. (For example, by shifting out three bytes with word size of sixteen or twenty bits; the former uses two bytes per word, the latter uses four bytes.)

In-memory data values are always in native CPU byte order, translated from the wire byte order (big-endian except with SPI_LSB_FIRST). So for example when bits_per_word is sixteen, buffers are 2N bytes long (*len* = 2N) and hold N sixteen bit words in CPU byte order.

When the word size of the SPI transfer is not a power-of-two multiple of eight bits, those in-memory words include extra bits. In-memory words are always seen by protocol drivers as right-justified, so the undefined (rx) or unused (tx) bits are always the most significant bits.

All SPI transfers start with the relevant chipselect active. Normally it stays selected until after the last transfer in a message. Drivers can affect the chipselect signal using cs_change.

(i) If the transfer isn't the last one in the message, this flag is used to make the chipselect briefly go inactive in the middle of the message. Toggling chipselect in this way may be needed to terminate a chip command, letting a single spi_message perform all of group of chip transactions together.

(ii) When the transfer is the last one in the message, the chip may stay selected until the next transfer. On multi-device SPI busses with nothing blocking messages going to other devices, this is just a performance hint; starting a message to another device deselects this one. But in other cases, this can be used to ensure correctness. Some devices need protocol transactions to be built from a series of spi_message submissions, where the content of one message is determined by the results of previous messages and where the whole transaction ends when the chipselect goes intactive.

When SPI can transfer in 1x,2x or 4x. It can get this transfer information from device through *tx_nbits* and *rx_nbits*. In Bi-direction, these two should both be set. User can set transfer mode with SPI_NBITS_SINGLE(1x) SPI_NBITS_DUAL(2x) and SPI_NBITS_QUAD(4x) to support these three transfer.

The code that submits an spi_message (and its spi_transfers) to the lower layers is responsible for managing its memory. Zero-initialize every field you don't set up explicitly, to insulate against future API updates. After you submit a message and its transfers, ignore them until its completion callback.

Name

struct spi_message — one multi-segment SPI transaction

Synopsis

```
struct spi_message {
  struct list_head transfers;
  struct spi_device * spi;
  unsigned is_dma_mapped:1;
  void (* complete) (void *context);
  void * context;
  unsigned frame_length;
  unsigned actual_length;
  int status;
  struct list_head queue;
  void * state;
};
```

Members

transfers	list of transfer segments in this transaction
spi	SPI device to which the transaction is queued
is_dma_mapped	if true, the caller provided both dma and cpu virtual addresses for each transfer buffer
complete	called to report transaction completions
context	the argument to `complete` when it's called
frame_length	the total number of bytes in the message
actual_length	the total number of bytes that were transferred in all successful segments
status	zero for success, else negative errno
queue	for use by whichever driver currently owns the message
state	for use by whichever driver currently owns the message

Description

A *`spi_message`* is used to execute an atomic sequence of data transfers, each represented by a struct spi_transfer. The sequence is “atomic” in the sense that no other spi_message may use that SPI bus until that sequence completes. On some systems, many such sequences can execute as as single programmed DMA transfer. On all systems, these messages are queued, and might complete after transactions to other devices. Messages sent to a given spi_device are always executed in FIFO order.

The code that submits an spi_message (and its spi_transfers) to the lower layers is responsible for managing its memory. Zero-initialize every field you don't set up explicitly, to insulate against future API updates. After you submit a message and its transfers, ignore them until its completion callback.

Name

spi_message_init_with_transfers — Initialize spi_message and append transfers

Synopsis

```
void spi_message_init_with_transfers (struct spi_message * m, struct
spi_transfer * xfers, unsigned int num_xfers);
```

Arguments

m	spi_message to be initialized
xfers	An array of spi transfers
num_xfers	Number of items in the xfer array

Description

This function initializes the given spi_message and adds each spi_transfer in the given array to the message.

Name

spi_write — SPI synchronous write

Synopsis

```
int spi_write (struct spi_device * spi, const void * buf, size_t len);
```

Arguments

spi device to which data will be written

buf data buffer

len data buffer size

Context

can sleep

Description

This function writes the buffer *buf*. Callable only from contexts that can sleep.

Return

zero on success, else a negative error code.

Name

spi_read — SPI synchronous read

Synopsis

```
int spi_read (struct spi_device * spi, void * buf, size_t len);
```

Arguments

spi device from which data will be read

buf data buffer

len data buffer size

Context

can sleep

Description

This function reads the buffer *buf*. Callable only from contexts that can sleep.

Return

zero on success, else a negative error code.

Name

spi_sync_transfer — synchronous SPI data transfer

Synopsis

```
int spi_sync_transfer (struct spi_device * spi, struct spi_transfer *
xfers, unsigned int num_xfers);
```

Arguments

spi	device with which data will be exchanged
xfers	An array of spi_transfers
num_xfers	Number of items in the xfer array

Context

can sleep

Description

Does a synchronous SPI data transfer of the given spi_transfer array.

For more specific semantics see `spi_sync`.

Return

Return: zero on success, else a negative error code.

Name

spi_w8r8 — SPI synchronous 8 bit write followed by 8 bit read

Synopsis

```
ssize_t spi_w8r8 (struct spi_device * spi, u8 cmd);
```

Arguments

spi device with which data will be exchanged

cmd command to be written before data is read back

Context

can sleep

Description

Callable only from contexts that can sleep.

Return

the (unsigned) eight bit number returned by the device, or else a negative error code.

Name

spi_w8r16 — SPI synchronous 8 bit write followed by 16 bit read

Synopsis

```
ssize_t spi_w8r16 (struct spi_device * spi, u8 cmd);
```

Arguments

spi device with which data will be exchanged

cmd command to be written before data is read back

Context

can sleep

Description

The number is returned in wire-order, which is at least sometimes big-endian.

Callable only from contexts that can sleep.

Return

the (unsigned) sixteen bit number returned by the device, or else a negative error code.

Name

spi_w8r16be — SPI synchronous 8 bit write followed by 16 bit big-endian read

Synopsis

```
ssize_t spi_w8r16be (struct spi_device * spi, u8 cmd);
```

Arguments

spi device with which data will be exchanged

cmd command to be written before data is read back

Context

can sleep

Description

This function is similar to spi_w8r16, with the exception that it will convert the read 16 bit data word from big-endian to native endianness.

Callable only from contexts that can sleep.

Return

the (unsigned) sixteen bit number returned by the device in cpu endianness, or else a negative error code.

Name

struct spi_board_info — board-specific template for a SPI device

Synopsis

```
struct spi_board_info {
  char modalias[SPI_NAME_SIZE];
  const void * platform_data;
  void * controller_data;
  int irq;
  u32 max_speed_hz;
  u16 bus_num;
  u16 chip_select;
  u16 mode;
};
```

Members

modalias[SPI_NAME_SIZE]	Initializes spi_device.modalias; identifies the driver.
platform_data	Initializes spi_device.platform_data; the particular data stored there is driver-specific.
controller_data	Initializes spi_device.controller_data; some controllers need hints about hardware setup, e.g. for DMA.
irq	Initializes spi_device.irq; depends on how the board is wired.
max_speed_hz	Initializes spi_device.max_speed_hz; based on limits from the chip datasheet and board-specific signal quality issues.
bus_num	Identifies which spi_master parents the spi_device; unused by `spi_new_device`, and otherwise depends on board wiring.
chip_select	Initializes spi_device.chip_select; depends on how the board is wired.
mode	Initializes spi_device.mode; based on the chip datasheet, board wiring (some devices support both 3WIRE and standard modes), and possibly presence of an inverter in the chipselect path.

Description

When adding new SPI devices to the device tree, these structures serve as a partial device template. They hold information which can't always be determined by drivers. Information that `probe` can establish (such as the default transfer wordsize) is not included here.

These structures are used in two places. Their primary role is to be stored in tables of board-specific device descriptors, which are declared early in board initialization and then used (much later) to populate a controller's device tree after the that controller's driver initializes. A secondary (and atypical) role is as a parameter to `spi_new_device` call, which happens after those controller drivers are active in some dynamic board configuration models.

Name

spi_register_board_info — register SPI devices for a given board

Synopsis

```
int spi_register_board_info (struct spi_board_info const * info,
unsigned n);
```

Arguments

info array of chip descriptors

n how many descriptors are provided

Context

can sleep

Description

Board-specific early init code calls this (probably during arch_initcall) with segments of the SPI device table. Any device nodes are created later, after the relevant parent SPI controller (bus_num) is defined. We keep this table of devices forever, so that reloading a controller driver will not make Linux forget about these hard-wired devices.

Other code can also call this, e.g. a particular add-on board might provide SPI devices through its expansion connector, so code initializing that board would naturally declare its SPI devices.

The board info passed can safely be __initdata ... but be careful of any embedded pointers (platform_data, etc), they're copied as-is.

Return

zero on success, else a negative error code.

Name

__spi_register_driver — register a SPI driver

Synopsis

```
int __spi_register_driver (struct module * owner, struct spi_driver *
sdrv);
```

Arguments

owner owner module of the driver to register

sdrv the driver to register

Context

can sleep

Return

zero on success, else a negative error code.

Name

spi_alloc_device — Allocate a new SPI device

Synopsis

```
struct spi_device * spi_alloc_device (struct spi_master * master);
```

Arguments

master Controller to which device is connected

Context

can sleep

Description

Allows a driver to allocate and initialize a spi_device without registering it immediately. This allows a driver to directly fill the spi_device with device parameters before calling `spi_add_device` on it.

Caller is responsible to call `spi_add_device` on the returned spi_device structure to add it to the SPI master. If the caller needs to discard the spi_device without adding it, then it should call `spi_dev_put` on it.

Return

a pointer to the new device, or NULL.

Name

spi_add_device — Add spi_device allocated with spi_alloc_device

Synopsis

```
int spi_add_device (struct spi_device * spi);
```

Arguments

spi spi_device to register

Description

Companion function to spi_alloc_device. Devices allocated with spi_alloc_device can be added onto the spi bus with this function.

Return

0 on success; negative errno on failure

Name

spi_new_device — instantiate one new SPI device

Synopsis

```
struct spi_device * spi_new_device (struct spi_master * master, struct
spi_board_info * chip);
```

Arguments

master Controller to which device is connected

chip Describes the SPI device

Context

can sleep

Description

On typical mainboards, this is purely internal; and it's not needed after board init creates the hard-wired devices. Some development platforms may not be able to use spi_register_board_info though, and this is exported so that for example a USB or parport based adapter driver could add devices (which it would learn about out-of-band).

Return

the new device, or NULL.

Name

spi_finalize_current_transfer — report completion of a transfer

Synopsis

```
void spi_finalize_current_transfer (struct spi_master * master);
```

Arguments

master the master reporting completion

Description

Called by SPI drivers using the core `transfer_one_message` implementation to notify it that the current interrupt driven transfer has finished and the next one may be scheduled.

Name

spi_get_next_queued_message — called by driver to check for queued messages

Synopsis

```
struct spi_message * spi_get_next_queued_message (struct spi_master *
master);
```

Arguments

master the master to check for queued messages

Description

If there are more messages in the queue, the next message is returned from this call.

Return

the next message in the queue, else NULL if the queue is empty.

Name

spi_finalize_current_message — the current message is complete

Synopsis

```
void spi_finalize_current_message (struct spi_master * master);
```

Arguments

master the master to return the message to

Description

Called by the driver to notify the core that the message in the front of the queue is complete and can be removed from the queue.

Name

spi_alloc_master — allocate SPI master controller

Synopsis

```
struct spi_master * spi_alloc_master (struct device * dev, unsigned size);
```

Arguments

dev the controller, possibly using the platform_bus

size how much zeroed driver-private data to allocate; the pointer to this memory is in the driver_data field of the returned device, accessible with `spi_master_get_devdata`.

Context

can sleep

Description

This call is used only by SPI master controller drivers, which are the only ones directly touching chip registers. It's how they allocate an spi_master structure, prior to calling `spi_register_master`.

This must be called from context that can sleep.

The caller is responsible for assigning the bus number and initializing the master's methods before calling `spi_register_master`; and (after errors adding the device) calling `spi_master_put` to prevent a memory leak.

Return

the SPI master structure on success, else NULL.

Name

spi_register_master — register SPI master controller

Synopsis

```
int spi_register_master (struct spi_master * master);
```

Arguments

master initialized master, originally from `spi_alloc_master`

Context

can sleep

Description

SPI master controllers connect to their drivers using some non-SPI bus, such as the platform bus. The final stage of `probe` in that code includes calling `spi_register_master` to hook up to this SPI bus glue.

SPI controllers use board specific (often SOC specific) bus numbers, and board-specific addressing for SPI devices combines those numbers with chip select numbers. Since SPI does not directly support dynamic device identification, boards need configuration tables telling which chip is at which address.

This must be called from context that can sleep. It returns zero on success, else a negative error code (dropping the master's refcount). After a successful return, the caller is responsible for calling `spi_unregister_master`.

Return

zero on success, else a negative error code.

Name

devm_spi_register_master — register managed SPI master controller

Synopsis

```
int devm_spi_register_master (struct device * dev, struct spi_master
* master);
```

Arguments

dev device managing SPI master

master initialized master, originally from `spi_alloc_master`

Context

can sleep

Description

Register a SPI device as with `spi_register_master` which will automatically be unregister

Return

zero on success, else a negative error code.

Name

spi_unregister_master — unregister SPI master controller

Synopsis

```
void spi_unregister_master (struct spi_master * master);
```

Arguments

master the master being unregistered

Context

can sleep

Description

This call is used only by SPI master controller drivers, which are the only ones directly touching chip registers.

This must be called from context that can sleep.

Name

spi_busnum_to_master — look up master associated with bus_num

Synopsis

```
struct spi_master * spi_busnum_to_master (u16 bus_num);
```

Arguments

bus_num the master's bus number

Context

can sleep

Description

This call may be used with devices that are registered after arch init time. It returns a refcounted pointer to the relevant spi_master (which the caller must release), or NULL if there is no such master registered.

Return

the SPI master structure on success, else NULL.

Name

spi_setup — setup SPI mode and clock rate

Synopsis

```
int spi_setup (struct spi_device * spi);
```

Arguments

spi the device whose settings are being modified

Context

can sleep, and no requests are queued to the device

Description

SPI protocol drivers may need to update the transfer mode if the device doesn't work with its default. They may likewise need to update clock rates or word sizes from initial values. This function changes those settings, and must be called from a context that can sleep. Except for SPI_CS_HIGH, which takes effect immediately, the changes take effect the next time the device is selected and data is transferred to or from it. When this function returns, the spi device is deselected.

Note that this call will fail if the protocol driver specifies an option that the underlying controller or its driver does not support. For example, not all hardware supports wire transfers using nine bit words, LSB-first wire encoding, or active-high chipselects.

Return

zero on success, else a negative error code.

Name

spi_async — asynchronous SPI transfer

Synopsis

```
int spi_async (struct spi_device * spi, struct spi_message * message);
```

Arguments

spi device with which data will be exchanged

message describes the data transfers, including completion callback

Context

any (irqs may be blocked, etc)

Description

This call may be used in_irq and other contexts which can't sleep, as well as from task contexts which can sleep.

The completion callback is invoked in a context which can't sleep. Before that invocation, the value of message->status is undefined. When the callback is issued, message->status holds either zero (to indicate complete success) or a negative error code. After that callback returns, the driver which issued the transfer request may deallocate the associated memory; it's no longer in use by any SPI core or controller driver code.

Note that although all messages to a spi_device are handled in FIFO order, messages may go to different devices in other orders. Some device might be higher priority, or have various “hard” access time requirements, for example.

On detection of any fault during the transfer, processing of the entire message is aborted, and the device is deselected. Until returning from the associated message completion callback, no other spi_message queued to that device will be processed. (This rule applies equally to all the synchronous transfer calls, which are wrappers around this core asynchronous primitive.)

Return

zero on success, else a negative error code.

Name

spi_async_locked — version of spi_async with exclusive bus usage

Synopsis

```
int spi_async_locked (struct spi_device * spi, struct spi_message *
message);
```

Arguments

spi device with which data will be exchanged

message describes the data transfers, including completion callback

Context

any (irqs may be blocked, etc)

Description

This call may be used in_irq and other contexts which can't sleep, as well as from task contexts which can sleep.

The completion callback is invoked in a context which can't sleep. Before that invocation, the value of message->status is undefined. When the callback is issued, message->status holds either zero (to indicate complete success) or a negative error code. After that callback returns, the driver which issued the transfer request may deallocate the associated memory; it's no longer in use by any SPI core or controller driver code.

Note that although all messages to a spi_device are handled in FIFO order, messages may go to different devices in other orders. Some device might be higher priority, or have various “hard” access time requirements, for example.

On detection of any fault during the transfer, processing of the entire message is aborted, and the device is deselected. Until returning from the associated message completion callback, no other spi_message queued to that device will be processed. (This rule applies equally to all the synchronous transfer calls, which are wrappers around this core asynchronous primitive.)

Return

zero on success, else a negative error code.

Name

spi_sync — blocking/synchronous SPI data transfers

Synopsis

```
int spi_sync (struct spi_device * spi, struct spi_message * message);
```

Arguments

spi device with which data will be exchanged

message describes the data transfers

Context

can sleep

Description

This call may only be used from a context that may sleep. The sleep is non-interruptible, and has no timeout. Low-overhead controller drivers may DMA directly into and out of the message buffers.

Note that the SPI device's chip select is active during the message, and then is normally disabled between messages. Drivers for some frequently-used devices may want to minimize costs of selecting a chip, by leaving it selected in anticipation that the next message will go to the same chip. (That may increase power usage.)

Also, the caller is guaranteeing that the memory associated with the message will not be freed before this call returns.

Return

zero on success, else a negative error code.

Name

spi_sync_locked — version of spi_sync with exclusive bus usage

Synopsis

```
int spi_sync_locked (struct spi_device * spi, struct spi_message * message);
```

Arguments

spi device with which data will be exchanged

message describes the data transfers

Context

can sleep

Description

This call may only be used from a context that may sleep. The sleep is non-interruptible, and has no timeout. Low-overhead controller drivers may DMA directly into and out of the message buffers.

This call should be used by drivers that require exclusive access to the SPI bus. It has to be preceded by a spi_bus_lock call. The SPI bus must be released by a spi_bus_unlock call when the exclusive access is over.

Return

zero on success, else a negative error code.

Name

spi_bus_lock — obtain a lock for exclusive SPI bus usage

Synopsis

```
int spi_bus_lock (struct spi_master * master);
```

Arguments

master SPI bus master that should be locked for exclusive bus access

Context

can sleep

Description

This call may only be used from a context that may sleep. The sleep is non-interruptible, and has no timeout.

This call should be used by drivers that require exclusive access to the SPI bus. The SPI bus must be released by a spi_bus_unlock call when the exclusive access is over. Data transfer must be done by spi_sync_locked and spi_async_locked calls when the SPI bus lock is held.

Return

always zero.

Name

spi_bus_unlock — release the lock for exclusive SPI bus usage

Synopsis

```
int spi_bus_unlock (struct spi_master * master);
```

Arguments

master SPI bus master that was locked for exclusive bus access

Context

can sleep

Description

This call may only be used from a context that may sleep. The sleep is non-interruptible, and has no timeout.

This call releases an SPI bus lock previously obtained by an spi_bus_lock call.

Return

always zero.

Name

spi_write_then_read — SPI synchronous write followed by read

Synopsis

```
int spi_write_then_read (struct spi_device * spi, const void * txbuf,
unsigned n_tx, void * rxbuf, unsigned n_rx);
```

Arguments

spi device with which data will be exchanged

txbuf data to be written (need not be dma-safe)

n_tx size of txbuf, in bytes

rxbuf buffer into which data will be read (need not be dma-safe)

n_rx size of rxbuf, in bytes

Context

can sleep

Description

This performs a half duplex MicroWire style transaction with the device, sending txbuf and then reading rxbuf. The return value is zero for success, else a negative errno status code. This call may only be used from a context that may sleep.

Parameters to this routine are always copied using a small buffer; portable code should never use this for more than 32 bytes. Performance-sensitive or bulk transfer code should instead use spi_{async,sync}() calls with dma-safe buffers.

Return

zero on success, else a negative error code.

Chapter 11. I²C and SMBus Subsystem

I²C (or without fancy typography, "I2C") is an acronym for the "Inter-IC" bus, a simple bus protocol which is widely used where low data rate communications suffice. Since it's also a licensed trademark, some vendors use another name (such as "Two-Wire Interface", TWI) for the same bus. I2C only needs two signals (SCL for clock, SDA for data), conserving board real estate and minimizing signal quality issues. Most I2C devices use seven bit addresses, and bus speeds of up to 400 kHz; there's a high speed extension (3.4 MHz) that's not yet found wide use. I2C is a multi-master bus; open drain signaling is used to arbitrate between masters, as well as to handshake and to synchronize clocks from slower clients.

The Linux I2C programming interfaces support only the master side of bus interactions, not the slave side. The programming interface is structured around two kinds of driver, and two kinds of device. An I2C "Adapter Driver" abstracts the controller hardware; it binds to a physical device (perhaps a PCI device or platform_device) and exposes a struct i2c_adapter representing each I2C bus segment it manages. On each I2C bus segment will be I2C devices represented by a struct i2c_client. Those devices will be bound to a struct i2c_driver, which should follow the standard Linux driver model. (At this writing, a legacy model is more widely used.) There are functions to perform various I2C protocol operations; at this writing all such functions are usable only from task context.

The System Management Bus (SMBus) is a sibling protocol. Most SMBus systems are also I2C conformant. The electrical constraints are tighter for SMBus, and it standardizes particular protocol messages and idioms. Controllers that support I2C can also support most SMBus operations, but SMBus controllers don't support all the protocol options that an I2C controller will. There are functions to perform various SMBus protocol operations, either using I2C primitives or by issuing SMBus commands to i2c_adapter devices which don't support those I2C operations.

Name

struct i2c_driver — represent an I2C device driver

Synopsis

```
struct i2c_driver {
  unsigned int class;
  int (* attach_adapter) (struct i2c_adapter *);
  int (* probe) (struct i2c_client *, const struct i2c_device_id *);
  int (* remove) (struct i2c_client *);
  void (* shutdown) (struct i2c_client *);
  void (* alert) (struct i2c_client *, unsigned int data);
  int (* command) (struct i2c_client *client, unsigned int cmd, void *arg);
  struct device_driver driver;
  const struct i2c_device_id * id_table;
  int (* detect) (struct i2c_client *, struct i2c_board_info *);
  const unsigned short * address_list;
  struct list_head clients;
};
```

Members

class	What kind of i2c device we instantiate (for detect)
attach_adapter	Callback for bus addition (deprecated)
probe	Callback for device binding
remove	Callback for device unbinding
shutdown	Callback for device shutdown
alert	Alert callback, for example for the SMBus alert protocol
command	Callback for bus-wide signaling (optional)
driver	Device driver model driver
id_table	List of I2C devices supported by this driver
detect	Callback for device detection
address_list	The I2C addresses to probe (for detect)
clients	List of detected clients we created (for i2c-core use only)

Description

The driver.owner field should be set to the module owner of this driver. The driver.name field should be set to the name of this driver.

For automatic device detection, both *`detect`* and *`address_list`* must be defined. *`class`* should also be set, otherwise only devices forced with module parameters will be created. The detect function must fill

at least the name field of the i2c_board_info structure it is handed upon successful detection, and possibly also the flags field.

If *detect* is missing, the driver will still work fine for enumerated devices. Detected devices simply won't be supported. This is expected for the many I2C/SMBus devices which can't be detected reliably, and the ones which can always be enumerated in practice.

The i2c_client structure which is handed to the *detect* callback is not a real i2c_client. It is initialized just enough so that you can call i2c_smbus_read_byte_data and friends on it. Don't do anything else with it. In particular, calling dev_dbg and friends on it is not allowed.

Name

struct i2c_client — represent an I2C slave device

Synopsis

```
struct i2c_client {
  unsigned short flags;
  unsigned short addr;
  char name[I2C_NAME_SIZE];
  struct i2c_adapter * adapter;
  struct device dev;
  int irq;
  struct list_head detected;
#if IS_ENABLED(CONFIG_I2C_SLAVE)
  i2c_slave_cb_t slave_cb;
#endif
};
```

Members

flags	I2C_CLIENT_TEN indicates the device uses a ten bit chip address; I2C_CLIENT_PEC indicates it uses SMBus Packet Error Checking
addr	Address used on the I2C bus connected to the parent adapter.
name[I2C_NAME_SIZE]	Indicates the type of the device, usually a chip name that's generic enough to hide second-sourcing and compatible revisions.
adapter	manages the bus segment hosting this I2C device
dev	Driver model device node for the slave.
irq	indicates the IRQ generated by this device (if any)
detected	member of an i2c_driver.clients list or i2c-core's userspace_devices list
slave_cb	Callback when I2C slave mode of an adapter is used. The adapter calls it to pass on slave events to the slave driver.

Description

An i2c_client identifies a single device (i.e. chip) connected to an i2c bus. The behaviour exposed to Linux is defined by the driver managing the device.

Name

struct i2c_board_info — template for device creation

Synopsis

```
struct i2c_board_info {
  char type[I2C_NAME_SIZE];
  unsigned short flags;
  unsigned short addr;
  void * platform_data;
  struct dev_archdata * archdata;
  struct device_node * of_node;
  struct fwnode_handle * fwnode;
  int irq;
};
```

Members

type[I2C_NAME_SIZE]	chip type, to initialize i2c_client.name
flags	to initialize i2c_client.flags
addr	stored in i2c_client.addr
platform_data	stored in i2c_client.dev.platform_data
archdata	copied into i2c_client.dev.archdata
of_node	pointer to OpenFirmware device node
fwnode	device node supplied by the platform firmware
irq	stored in i2c_client.irq

Description

I2C doesn't actually support hardware probing, although controllers and devices may be able to use I2C_SMBUS_QUICK to tell whether or not there's a device at a given address. Drivers commonly need more information than that, such as chip type, configuration, associated IRQ, and so on.

i2c_board_info is used to build tables of information listing I2C devices that are present. This information is used to grow the driver model tree. For mainboards this is done statically using `i2c_register_board_info`; bus numbers identify adapters that aren't yet available. For add-on boards, `i2c_new_device` does this dynamically with the adapter already known.

Name

I2C_BOARD_INFO — macro used to list an i2c device and its address

Synopsis

```
I2C_BOARD_INFO ( dev_type, dev_addr);
```

Arguments

dev_type identifies the device type

dev_addr the device's address on the bus.

Description

This macro initializes essential fields of a struct i2c_board_info, declaring what has been provided on a particular board. Optional fields (such as associated irq, or device-specific platform_data) are provided using conventional syntax.

Name

struct i2c_algorithm — represent I2C transfer method

Synopsis

```
struct i2c_algorithm {
  int (* master_xfer) (struct i2c_adapter *adap, struct i2c_msg *msgs,int num);
  int (* smbus_xfer) (struct i2c_adapter *adap, u16 addr,unsigned short flags, cha
  u32 (* functionality) (struct i2c_adapter *);
#if IS_ENABLED(CONFIG_I2C_SLAVE)
  int (* reg_slave) (struct i2c_client *client);
  int (* unreg_slave) (struct i2c_client *client);
#endif
};
```

Members

master_xfer	Issue a set of i2c transactions to the given I2C adapter defined by the msgs array, with num messages available to transfer via the adapter specified by adap.
smbus_xfer	Issue smbus transactions to the given I2C adapter. If this is not present, then the bus layer will try and convert the SMBus calls into I2C transfers instead.
functionality	Return the flags that this algorithm/adapter pair supports from the I2C_FUNC_* flags.
reg_slave	Register given client to I2C slave mode of this adapter
unreg_slave	Unregister given client from I2C slave mode of this adapter

The following structs are for those who like to implement new bus drivers

i2c_algorithm is the interface to a class of hardware solutions which can be addressed using the same bus algorithms - i.e. bit-banging or the PCF8584 to name two of the most common.

The return codes from the *master_xfer* field should indicate the type of error code that occurred during the transfer, as documented in the kernel Documentation file Documentation/i2c/fault-codes.

Name

struct i2c_bus_recovery_info — I2C bus recovery information

Synopsis

```
struct i2c_bus_recovery_info {
  int (* recover_bus) (struct i2c_adapter *);
  int (* get_scl) (struct i2c_adapter *);
  void (* set_scl) (struct i2c_adapter *, int val);
  int (* get_sda) (struct i2c_adapter *);
  void (* prepare_recovery) (struct i2c_adapter *);
  void (* unprepare_recovery) (struct i2c_adapter *);
  int scl_gpio;
  int sda_gpio;
};
```

Members

recover_bus	Recover routine. Either pass driver's `recover_bus` routine, or `i2c_generic_scl_recovery` or `i2c_generic_gpio_recovery`.
get_scl	This gets current value of SCL line. Mandatory for generic SCL recovery. Used internally for generic GPIO recovery.
set_scl	This sets/clears SCL line. Mandatory for generic SCL recovery. Used internally for generic GPIO recovery.
get_sda	This gets current value of SDA line. Optional for generic SCL recovery. Used internally, if sda_gpio is a valid GPIO, for generic GPIO recovery.
prepare_recovery	This will be called before starting recovery. Platform may configure padmux here for SDA/SCL line or something else they want.
unprepare_recovery	This will be called after completing recovery. Platform may configure padmux here for SDA/SCL line or something else they want.
scl_gpio	gpio number of the SCL line. Only required for GPIO recovery.
sda_gpio	gpio number of the SDA line. Only required for GPIO recovery.

Name

struct i2c_adapter_quirks — describe flaws of an i2c adapter

Synopsis

```
struct i2c_adapter_quirks {
  u64 flags;
  int max_num_msgs;
  u16 max_write_len;
  u16 max_read_len;
  u16 max_comb_1st_msg_len;
  u16 max_comb_2nd_msg_len;
};
```

Members

flags	see I2C_AQ_* for possible flags and read below
max_num_msgs	maximum number of messages per transfer
max_write_len	maximum length of a write message
max_read_len	maximum length of a read message
max_comb_1st_msg_len	maximum length of the first msg in a combined message
max_comb_2nd_msg_len	maximum length of the second msg in a combined message

Note about combined messages

Some I2C controllers can only send one message per transfer, plus something called combined message or write-then-read. This is (usually) a small write message followed by a read message and barely enough to access register based devices like EEPROMs. There is a flag to support this mode. It implies max_num_msg = 2 and does the length checks with max_comb_*_len because combined message mode usually has its own limitations. Because of HW implementations, some controllers can actually do write-then-anything or other variants. To support that, write-then-read has been broken out into smaller bits like write-first and read-second which can be combined as needed.

Name

module_i2c_driver — Helper macro for registering a I2C driver

Synopsis

```
module_i2c_driver ( __i2c_driver);
```

Arguments

__i2c_driver i2c_driver struct

Description

Helper macro for I2C drivers which do not do anything special in module init/exit. This eliminates a lot of boilerplate. Each module may only use this macro once, and calling it replaces `module_init` and `module_exit`

Name

i2c_register_board_info — statically declare I2C devices

Synopsis

```
int i2c_register_board_info (int busnum, struct i2c_board_info const *
info, unsigned len);
```

Arguments

busnum identifies the bus to which these devices belong

info vector of i2c device descriptors

len how many descriptors in the vector; may be zero to reserve the specified bus number.

Description

Systems using the Linux I2C driver stack can declare tables of board info while they initialize. This should be done in board-specific init code near `arch_initcall` time, or equivalent, before any I2C adapter driver is registered. For example, mainboard init code could define several devices, as could the init code for each daughtercard in a board stack.

The I2C devices will be created later, after the adapter for the relevant bus has been registered. After that moment, standard driver model tools are used to bind “new style” I2C drivers to the devices. The bus number for any device declared using this routine is not available for dynamic allocation.

The board info passed can safely be __initdata, but be careful of embedded pointers (for platform_data, functions, etc) since that won't be copied.

Name

i2c_verify_client — return parameter as i2c_client, or NULL

Synopsis

```
struct i2c_client * i2c_verify_client (struct device * dev);
```

Arguments

dev device, probably from some driver model iterator

Description

When traversing the driver model tree, perhaps using driver model iterators like *device_for_each_child*(), you can't assume very much about the nodes you find. Use this function to avoid oopses caused by wrongly treating some non-I2C device as an i2c_client.

Name

i2c_lock_adapter — Get exclusive access to an I2C bus segment

Synopsis

```
void i2c_lock_adapter (struct i2c_adapter * adapter);
```

Arguments

adapter Target I2C bus segment

Name

i2c_unlock_adapter — Release exclusive access to an I2C bus segment

Synopsis

```
void i2c_unlock_adapter (struct i2c_adapter * adapter);
```

Arguments

adapter Target I2C bus segment

Name

i2c_new_device — instantiate an i2c device

Synopsis

```
struct i2c_client * i2c_new_device (struct i2c_adapter * adap, struct
i2c_board_info const * info);
```

Arguments

adap the adapter managing the device

info describes one I2C device; bus_num is ignored

Context

can sleep

Description

Create an i2c device. Binding is handled through driver model `probe`/`remove` methods. A driver may be bound to this device when we return from this function, or any later moment (e.g. maybe hotplugging will load the driver module). This call is not appropriate for use by mainboard initialization logic, which usually runs during an `arch_initcall` long before any i2c_adapter could exist.

This returns the new i2c client, which may be saved for later use with `i2c_unregister_device`; or NULL to indicate an error.

Name

i2c_unregister_device — reverse effect of `i2c_new_device`

Synopsis

```
void i2c_unregister_device (struct i2c_client * client);
```

Arguments

`client` value returned from `i2c_new_device`

Context

can sleep

Name

i2c_new_dummy — return a new i2c device bound to a dummy driver

Synopsis

```
struct i2c_client * i2c_new_dummy (struct i2c_adapter * adapter, u16 address);
```

Arguments

adapter the adapter managing the device

address seven bit address to be used

Context

can sleep

Description

This returns an I2C client bound to the “dummy” driver, intended for use with devices that consume multiple addresses. Examples of such chips include various EEPROMS (like 24c04 and 24c08 models).

These dummy devices have two main uses. First, most I2C and SMBus calls except `i2c_transfer` need a client handle; the dummy will be that handle. And second, this prevents the specified address from being bound to a different driver.

This returns the new i2c client, which should be saved for later use with `i2c_unregister_device`; or NULL to indicate an error.

Name

i2c_verify_adapter — return parameter as i2c_adapter or NULL

Synopsis

```
struct i2c_adapter * i2c_verify_adapter (struct device * dev);
```

Arguments

dev device, probably from some driver model iterator

Description

When traversing the driver model tree, perhaps using driver model iterators like *device_for_each_child*(), you can't assume very much about the nodes you find. Use this function to avoid oopses caused by wrongly treating some non-I2C device as an i2c_adapter.

Name

i2c_add_adapter — declare i2c adapter, use dynamic bus number

Synopsis

```
int i2c_add_adapter (struct i2c_adapter * adapter);
```

Arguments

adapter the adapter to add

Context

can sleep

Description

This routine is used to declare an I2C adapter when its bus number doesn't matter or when its bus number is specified by an dt alias. Examples of bases when the bus number doesn't matter: I2C adapters dynamically added by USB links or PCI plugin cards.

When this returns zero, a new bus number was allocated and stored in adap->nr, and the specified adapter became available for clients. Otherwise, a negative errno value is returned.

Name

i2c_add_numbered_adapter — declare i2c adapter, use static bus number

Synopsis

```
int i2c_add_numbered_adapter (struct i2c_adapter * adap);
```

Arguments

adap the adapter to register (with adap->nr initialized)

Context

can sleep

Description

This routine is used to declare an I2C adapter when its bus number matters. For example, use it for I2C adapters from system-on-chip CPUs, or otherwise built in to the system's mainboard, and where i2c_board_info is used to properly configure I2C devices.

If the requested bus number is set to -1, then this function will behave identically to i2c_add_adapter, and will dynamically assign a bus number.

If no devices have pre-been declared for this bus, then be sure to register the adapter before any dynamically allocated ones. Otherwise the required bus ID may not be available.

When this returns zero, the specified adapter became available for clients using the bus number provided in adap->nr. Also, the table of I2C devices pre-declared using `i2c_register_board_info` is scanned, and the appropriate driver model device nodes are created. Otherwise, a negative errno value is returned.

Name

i2c_del_adapter — unregister I2C adapter

Synopsis

```
void i2c_del_adapter (struct i2c_adapter * adap);
```

Arguments

adap the adapter being unregistered

Context

can sleep

Description

This unregisters an I2C adapter which was previously registered by *i2c_add_adapter* or *i2c_add_numbered_adapter*.

Name

i2c_del_driver — unregister I2C driver

Synopsis

```
void i2c_del_driver (struct i2c_driver * driver);
```

Arguments

driver the driver being unregistered

Context

can sleep

Name

i2c_use_client — increments the reference count of the i2c client structure

Synopsis

```
struct i2c_client * i2c_use_client (struct i2c_client * client);
```

Arguments

client the client being referenced

Description

Each live reference to a client should be refcounted. The driver model does that automatically as part of driver binding, so that most drivers don't

need to do this explicitly

they hold a reference until they're unbound from the device.

A pointer to the client with the incremented reference counter is returned.

Name

i2c_release_client — release a use of the i2c client structure

Synopsis

```
void i2c_release_client (struct i2c_client * client);
```

Arguments

client the client being no longer referenced

Description

Must be called when a user of a client is finished with it.

Name

__i2c_transfer — unlocked flavor of i2c_transfer

Synopsis

```
int __i2c_transfer (struct i2c_adapter * adap, struct i2c_msg * msgs,
int num);
```

Arguments

adap Handle to I2C bus

msgs One or more messages to execute before STOP is issued to terminate the operation; each message begins with a START.

num Number of messages to be executed.

Description

Returns negative errno, else the number of messages executed.

Adapter lock must be held when calling this function. No debug logging takes place. adap->algo->master_xfer existence isn't checked.

Name

i2c_transfer — execute a single or combined I2C message

Synopsis

```
int i2c_transfer (struct i2c_adapter * adap, struct i2c_msg * msgs,
int num);
```

Arguments

adap Handle to I2C bus

msgs One or more messages to execute before STOP is issued to terminate the operation; each message begins with a START.

num Number of messages to be executed.

Description

Returns negative errno, else the number of messages executed.

Note that there is no requirement that each message be sent to the same slave address, although that is the most common model.

Name

i2c_master_send — issue a single I2C message in master transmit mode

Synopsis

```
int i2c_master_send (const struct i2c_client * client, const char *
buf, int count);
```

Arguments

client Handle to slave device

buf Data that will be written to the slave

count How many bytes to write, must be less than 64k since msg.len is u16

Description

Returns negative errno, or else the number of bytes written.

Name

i2c_master_recv — issue a single I2C message in master receive mode

Synopsis

```
int i2c_master_recv (const struct i2c_client * client, char * buf, int count);
```

Arguments

client Handle to slave device

buf Where to store data read from slave

count How many bytes to read, must be less than 64k since msg.len is u16

Description

Returns negative errno, or else the number of bytes read.

Name

i2c_smbus_read_byte — SMBus “receive byte” protocol

Synopsis

```
s32 i2c_smbus_read_byte (const struct i2c_client * client);
```

Arguments

client Handle to slave device

Description

This executes the SMBus “receive byte” protocol, returning negative errno else the byte received from the device.

Name

i2c_smbus_write_byte — SMBus “send byte” protocol

Synopsis

```
s32 i2c_smbus_write_byte (const struct i2c_client * client, u8 value);
```

Arguments

client Handle to slave device

value Byte to be sent

Description

This executes the SMBus “send byte” protocol, returning negative errno else zero on success.

Name

i2c_smbus_read_byte_data — SMBus “read byte” protocol

Synopsis

```
s32 i2c_smbus_read_byte_data (const struct i2c_client * client, u8 command);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

Description

This executes the SMBus “read byte” protocol, returning negative errno else a data byte received from the device.

Name

i2c_smbus_write_byte_data — SMBus “write byte” protocol

Synopsis

```
s32 i2c_smbus_write_byte_data (const struct i2c_client * client, u8 command, u8 value);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

value Byte being written

Description

This executes the SMBus “write byte” protocol, returning negative errno else zero on success.

Name

i2c_smbus_read_word_data — SMBus “read word” protocol

Synopsis

```
s32 i2c_smbus_read_word_data (const struct i2c_client * client, u8 command);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

Description

This executes the SMBus “read word” protocol, returning negative errno else a 16-bit unsigned “word” received from the device.

Name

i2c_smbus_write_word_data — SMBus “write word” protocol

Synopsis

```
s32 i2c_smbus_write_word_data (const struct i2c_client * client, u8 command, u16 value);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

value 16-bit “word” being written

Description

This executes the SMBus “write word” protocol, returning negative errno else zero on success.

Name

i2c_smbus_read_block_data — SMBus “block read” protocol

Synopsis

```
s32 i2c_smbus_read_block_data (const struct i2c_client * client, u8 command, u8 * values);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

values Byte array into which data will be read; big enough to hold the data returned by the slave. SMBus allows at most 32 bytes.

Description

This executes the SMBus “block read” protocol, returning negative errno else the number of data bytes in the slave's response.

Note that using this function requires that the client's adapter support the I2C_FUNC_SMBUS_READ_BLOCK_DATA functionality. Not all adapter drivers support this; its emulation through I2C messaging relies on a specific mechanism (I2C_M_RECV_LEN) which may not be implemented.

Name

i2c_smbus_write_block_data — SMBus “block write” protocol

Synopsis

```
s32 i2c_smbus_write_block_data (const struct i2c_client * client, u8 command, u8 length, const u8 * values);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

length Size of data block; SMBus allows at most 32 bytes

values Byte array which will be written.

Description

This executes the SMBus “block write” protocol, returning negative errno else zero on success.

Name

i2c_smbus_xfer — execute SMBus protocol operations

Synopsis

```
s32 i2c_smbus_xfer (struct i2c_adapter * adapter, u16 addr, unsigned short flags, char read_write, u8 command, int protocol, union i2c_smbus_data * data);
```

Arguments

adapter	Handle to I2C bus
addr	Address of SMBus slave on that bus
flags	I2C_CLIENT_* flags (usually zero or I2C_CLIENT_PEC)
read_write	I2C_SMBUS_READ or I2C_SMBUS_WRITE
command	Byte interpreted by slave, for protocols which use such bytes
protocol	SMBus protocol operation to execute, such as I2C_SMBUS_PROC_CALL
data	Data to be read or written

Description

This executes an SMBus protocol operation, and returns a negative errno code else zero on success.

Name

i2c_smbus_read_i2c_block_data_or_emulated — read block or emulate

Synopsis

```
s32 i2c_smbus_read_i2c_block_data_or_emulated (const struct i2c_client
* client, u8 command, u8 length, u8 * values);
```

Arguments

client Handle to slave device

command Byte interpreted by slave

length Size of data block; SMBus allows at most I2C_SMBUS_BLOCK_MAX bytes

values Byte array into which data will be read; big enough to hold the data returned by the slave. SMBus allows at most I2C_SMBUS_BLOCK_MAX bytes.

Description

This executes the SMBus “block read” protocol if supported by the adapter. If block read is not supported, it emulates it using either word or byte read protocols depending on availability.

The addresses of the I2C slave device that are accessed with this function must be mapped to a linear region, so that a block read will have the same effect as a byte read. Before using this function you must double-check if the I2C slave does support exchanging a block transfer with a byte transfer.

Chapter 12. High Speed Synchronous Serial Interface (HSI)

High Speed Synchronous Serial Interface (HSI) is a serial interface mainly used for connecting application engines (APE) with cellular modem engines (CMT) in cellular handsets. HSI provides multiplexing for up to 16 logical channels, low-latency and full duplex communication.

Name

struct hsi_channel — channel resource used by the hsi clients

Synopsis

```
struct hsi_channel {
  unsigned int id;
  const char * name;
};
```

Members

id Channel number

name Channel name

Name

struct hsi_config — Configuration for RX/TX HSI modules

Synopsis

```
struct hsi_config {
  unsigned int mode;
  struct hsi_channel * channels;
  unsigned int num_channels;
  unsigned int num_hw_channels;
  unsigned int speed;
  union {unnamed_union};
};
```

Members

mode	Bit transmission mode (STREAM or FRAME)
channels	Channel resources used by the client
num_channels	Number of channel resources
num_hw_channels	Number of channels the transceiver is configured for [1..16]
speed	Max bit transmission speed (Kbit/s)
{unnamed_union}	anonymous

Name

struct hsi_board_info — HSI client board info

Synopsis

```
struct hsi_board_info {
  const char * name;
  unsigned int hsi_id;
  unsigned int port;
  struct hsi_config tx_cfg;
  struct hsi_config rx_cfg;
  void * platform_data;
  struct dev_archdata * archdata;
};
```

Members

name	Name for the HSI device
hsi_id	HSI controller id where the client sits
port	Port number in the controller where the client sits
tx_cfg	HSI TX configuration
rx_cfg	HSI RX configuration
platform_data	Platform related data
archdata	Architecture-dependent device data

Name

struct hsi_client — HSI client attached to an HSI port

Synopsis

```
struct hsi_client {
  struct device device;
  struct hsi_config tx_cfg;
  struct hsi_config rx_cfg;
};
```

Members

device Driver model representation of the device

tx_cfg HSI TX configuration

rx_cfg HSI RX configuration

Name

struct hsi_client_driver — Driver associated to an HSI client

Synopsis

```
struct hsi_client_driver {
  struct device_driver driver;
};
```

Members

driver Driver model representation of the driver

Name

struct hsi_msg — HSI message descriptor

Synopsis

```
struct hsi_msg {
  struct list_head link;
  struct hsi_client * cl;
  struct sg_table sgt;
  void * context;
  void (* complete) (struct hsi_msg *msg);
  void (* destructor) (struct hsi_msg *msg);
  int status;
  unsigned int actual_len;
  unsigned int channel;
  unsigned int ttype:1;
  unsigned int break_frame:1;
};
```

Members

link	Free to use by the current descriptor owner
cl	HSI device client that issues the transfer
sgt	Head of the scatterlist array
context	Client context data associated to the transfer
complete	Transfer completion callback
destructor	Destructor to free resources when flushing
status	Status of the transfer when completed
actual_len	Actual length of data transferred on completion
channel	Channel were to TX/RX the message
ttype	Transfer type (TX if set, RX otherwise)
break_frame	if true HSI will send/receive a break frame. Data buffers are ignored in the request.

Name

struct hsi_port — HSI port device

Synopsis

```
struct hsi_port {
  struct device device;
  struct hsi_config tx_cfg;
  struct hsi_config rx_cfg;
  unsigned int num;
  unsigned int shared:1;
  int claimed;
  struct mutex lock;
  int (* async) (struct hsi_msg *msg);
  int (* setup) (struct hsi_client *cl);
  int (* flush) (struct hsi_client *cl);
  int (* start_tx) (struct hsi_client *cl);
  int (* stop_tx) (struct hsi_client *cl);
  int (* release) (struct hsi_client *cl);
  struct atomic_notifier_head n_head;
};
```

Members

device	Driver model representation of the device
tx_cfg	Current TX path configuration
rx_cfg	Current RX path configuration
num	Port number
shared	Set when port can be shared by different clients
claimed	Reference count of clients which claimed the port
lock	Serialize port claim
async	Asynchronous transfer callback
setup	Callback to set the HSI client configuration
flush	Callback to clean the HW state and destroy all pending transfers
start_tx	Callback to inform that a client wants to TX data
stop_tx	Callback to inform that a client no longer wishes to TX data
release	Callback to inform that a client no longer uses the port
n_head	Notifier chain for signaling port events to the clients.

Name

struct hsi_controller — HSI controller device

Synopsis

```
struct hsi_controller {
  struct device device;
  struct module * owner;
  unsigned int id;
  unsigned int num_ports;
  struct hsi_port ** port;
};
```

Members

device	Driver model representation of the device
owner	Pointer to the module owning the controller
id	HSI controller ID
num_ports	Number of ports in the HSI controller
port	Array of HSI ports

Name

hsi_id — Get HSI controller ID associated to a client

Synopsis

```
unsigned int hsi_id (struct hsi_client * cl);
```

Arguments

cl Pointer to a HSI client

Description

Return the controller id where the client is attached to

Name

hsi_port_id — Gets the port number a client is attached to

Synopsis

```
unsigned int hsi_port_id (struct hsi_client * cl);
```

Arguments

cl Pointer to HSI client

Description

Return the port number associated to the client

Name

hsi_setup — Configure the client's port

Synopsis

```
int hsi_setup (struct hsi_client * cl);
```

Arguments

cl Pointer to the HSI client

Description

When sharing ports, clients should either relay on a single client setup or have the same setup for all of them.

Return -errno on failure, 0 on success

Name

hsi_flush — Flush all pending transactions on the client's port

Synopsis

```
int hsi_flush (struct hsi_client * cl);
```

Arguments

cl Pointer to the HSI client

Description

This function will destroy all pending hsi_msg in the port and reset the HW port so it is ready to receive and transmit from a clean state.

Return -errno on failure, 0 on success

Name

hsi_async_read — Submit a read transfer

Synopsis

```
int hsi_async_read (struct hsi_client * cl, struct hsi_msg * msg);
```

Arguments

cl Pointer to the HSI client

msg HSI message descriptor of the transfer

Description

Return -errno on failure, 0 on success

Name

hsi_async_write — Submit a write transfer

Synopsis

```
int hsi_async_write (struct hsi_client * cl, struct hsi_msg * msg);
```

Arguments

cl Pointer to the HSI client

msg HSI message descriptor of the transfer

Description

Return -errno on failure, 0 on success

Name

hsi_start_tx — Signal the port that the client wants to start a TX

Synopsis

```
int hsi_start_tx (struct hsi_client * cl);
```

Arguments

cl Pointer to the HSI client

Description

Return -errno on failure, 0 on success

Name

hsi_stop_tx — Signal the port that the client no longer wants to transmit

Synopsis

```
int hsi_stop_tx (struct hsi_client * cl);
```

Arguments

cl Pointer to the HSI client

Description

Return -errno on failure, 0 on success

Name

hsi_port_unregister_clients — Unregister an HSI port

Synopsis

```
void hsi_port_unregister_clients (struct hsi_port * port);
```

Arguments

port The HSI port to unregister

Name

hsi_unregister_controller — Unregister an HSI controller

Synopsis

```
void hsi_unregister_controller (struct hsi_controller * hsi);
```

Arguments

hsi The HSI controller to register

Name

hsi_register_controller — Register an HSI controller and its ports

Synopsis

```
int hsi_register_controller (struct hsi_controller * hsi);
```

Arguments

hsi The HSI controller to register

Description

Returns -errno on failure, 0 on success.

Name

hsi_register_client_driver — Register an HSI client to the HSI bus

Synopsis

```
int hsi_register_client_driver (struct hsi_client_driver * drv);
```

Arguments

drv HSI client driver to register

Description

Returns -errno on failure, 0 on success.

Name

hsi_put_controller — Free an HSI controller

Synopsis

```
void hsi_put_controller (struct hsi_controller * hsi);
```

Arguments

hsi Pointer to the HSI controller to freed

Description

HSI controller drivers should only use this function if they need to free their allocated hsi_controller structures before a successful call to hsi_register_controller. Other use is not allowed.

Name

hsi_alloc_controller — Allocate an HSI controller and its ports

Synopsis

```
struct hsi_controller * hsi_alloc_controller (unsigned int n_ports,
gfp_t flags);
```

Arguments

n_ports Number of ports on the HSI controller

flags Kernel allocation flags

Description

Return NULL on failure or a pointer to an hsi_controller on success.

Name

hsi_free_msg — Free an HSI message

Synopsis

```
void hsi_free_msg (struct hsi_msg * msg);
```

Arguments

msg Pointer to the HSI message

Description

Client is responsible to free the buffers pointed by the scatterlists.

Name

hsi_alloc_msg — Allocate an HSI message

Synopsis

```
struct hsi_msg * hsi_alloc_msg (unsigned int nents, gfp_t flags);
```

Arguments

nents Number of memory entries

flags Kernel allocation flags

Description

nents can be 0. This mainly makes sense for read transfer. In that case, HSI drivers will call the complete callback when there is data to be read without consuming it.

Return NULL on failure or a pointer to an hsi_msg on success.

Name

hsi_async — Submit an HSI transfer to the controller

Synopsis

```
int hsi_async (struct hsi_client * cl, struct hsi_msg * msg);
```

Arguments

cl HSI client sending the transfer

msg The HSI transfer passed to controller

Description

The HSI message must have the channel, ttype, complete and destructor fields set beforehand. If nents > 0 then the client has to initialize also the scatterlists to point to the buffers to write to or read from.

HSI controllers relay on pre-allocated buffers from their clients and they do not allocate buffers on their own.

Once the HSI message transfer finishes, the HSI controller calls the complete callback with the status and actual_len fields of the HSI message updated. The complete callback can be called before returning from hsi_async.

Returns -errno on failure or 0 on success

Name

hsi_claim_port — Claim the HSI client's port

Synopsis

```
int hsi_claim_port (struct hsi_client * cl, unsigned int share);
```

Arguments

cl HSI client that wants to claim its port

share Flag to indicate if the client wants to share the port or not.

Description

Returns -errno on failure, 0 on success.

Name

hsi_release_port — Release the HSI client's port

Synopsis

```
void hsi_release_port (struct hsi_client * cl);
```

Arguments

cl HSI client which previously claimed its port

Name

hsi_register_port_event — Register a client to receive port events

Synopsis

```
int hsi_register_port_event (struct hsi_client * cl, void (*handler)
(struct hsi_client *, unsigned long));
```

Arguments

cl HSI client that wants to receive port events

handler Event handler callback

Description

Clients should register a callback to be able to receive events from the ports. Registration should happen after claiming the port. The handler can be called in interrupt context.

Returns -errno on error, or 0 on success.

Name

hsi_unregister_port_event — Stop receiving port events for a client

Synopsis

```
int hsi_unregister_port_event (struct hsi_client * cl);
```

Arguments

cl HSI client that wants to stop receiving port events

Description

Clients should call this function before releasing their associated port.

Returns -errno on error, or 0 on success.

Name

hsi_event — Notifies clients about port events

Synopsis

```
int hsi_event (struct hsi_port * port, unsigned long event);
```

Arguments

port Port where the event occurred

event The event type

Description

Clients should not be concerned about wake line behavior. However, due to a race condition in HSI HW protocol, clients need to be notified about wake line changes, so they can implement a workaround for it.

Events

HSI_EVENT_START_RX - Incoming wake line high HSI_EVENT_STOP_RX - Incoming wake line down

Returns -errno on error, or 0 on success.

Name

hsi_get_channel_id_by_name — acquire channel id by channel name

Synopsis

```
int hsi_get_channel_id_by_name (struct hsi_client * cl, char * name);
```

Arguments

cl HSI client, which uses the channel

name name the channel is known under

Description

Clients can call this function to get the hsi channel ids similar to requesting IRQs or GPIOs by name. This function assumes the same channel configuration is used for RX and TX.

Returns -errno on error or channel id on success.

Chapter 13. Pulse-Width Modulation (PWM)

Pulse-width modulation is a modulation technique primarily used to control power supplied to electrical devices.

The PWM framework provides an abstraction for providers and consumers of PWM signals. A controller that provides one or more PWM signals is registered as struct pwm_chip. Providers are expected to embed this structure in a driver-specific structure. This structure contains fields that describe a particular chip.

A chip exposes one or more PWM signal sources, each of which exposed as a struct pwm_device. Operations can be performed on PWM devices to control the period, duty cycle, polarity and active state of the signal.

Note that PWM devices are exclusive resources: they can always only be used by one consumer at a time.

Name

enum pwm_polarity — polarity of a PWM signal

Synopsis

```
enum pwm_polarity {
  PWM_POLARITY_NORMAL,
  PWM_POLARITY_INVERSED
};
```

Constants

PWM_POLARITY_NORMAL	a high signal for the duration of the duty- cycle, followed by a low signal for the remainder of the pulse period
PWM_POLARITY_INVERSED	a low signal for the duration of the duty- cycle, followed by a high signal for the remainder of the pulse period

Name

struct pwm_device — PWM channel object

Synopsis

```
struct pwm_device {
  const char * label;
  unsigned long flags;
  unsigned int hwpwm;
  unsigned int pwm;
  struct pwm_chip * chip;
  void * chip_data;
  struct mutex lock;
  unsigned int period;
  unsigned int duty_cycle;
  enum pwm_polarity polarity;
};
```

Members

label	name of the PWM device
flags	flags associated with the PWM device
hwpwm	per-chip relative index of the PWM device
pwm	global index of the PWM device
chip	PWM chip providing this PWM device
chip_data	chip-private data associated with the PWM device
lock	used to serialize accesses to the PWM device where necessary
period	period of the PWM signal (in nanoseconds)
duty_cycle	duty cycle of the PWM signal (in nanoseconds)
polarity	polarity of the PWM signal

Name

struct pwm_ops — PWM controller operations

Synopsis

```
struct pwm_ops {
  int (* request) (struct pwm_chip *chip, struct pwm_device *pwm);
  void (* free) (struct pwm_chip *chip, struct pwm_device *pwm);
  int (* config) (struct pwm_chip *chip, struct pwm_device *pwm,int duty_ns, int p
  int (* set_polarity) (struct pwm_chip *chip, struct pwm_device *pwm,enum pwm_pol
  int (* enable) (struct pwm_chip *chip, struct pwm_device *pwm);
  void (* disable) (struct pwm_chip *chip, struct pwm_device *pwm);
#ifdef CONFIG_DEBUG_FS
  void (* dbg_show) (struct pwm_chip *chip, struct seq_file *s);
#endif
  struct module * owner;
};
```

Members

request	optional hook for requesting a PWM
free	optional hook for freeing a PWM
config	configure duty cycles and period length for this PWM
set_polarity	configure the polarity of this PWM
enable	enable PWM output toggling
disable	disable PWM output toggling
dbg_show	optional routine to show contents in debugfs
owner	helps prevent removal of modules exporting active PWMs

Name

struct pwm_chip — abstract a PWM controller

Synopsis

```
struct pwm_chip {
  struct device * dev;
  struct list_head list;
  const struct pwm_ops * ops;
  int base;
  unsigned int npwm;
  struct pwm_device * pwms;
  struct pwm_device * (* of_xlate) (struct pwm_chip *pc,const struct of_phandle_ar
  unsigned int of_pwm_n_cells;
  bool can_sleep;
};
```

Members

dev	device providing the PWMs
list	list node for internal use
ops	callbacks for this PWM controller
base	number of first PWM controlled by this chip
npwm	number of PWMs controlled by this chip
pwms	array of PWM devices allocated by the framework
of_xlate	request a PWM device given a device tree PWM specifier
of_pwm_n_cells	number of cells expected in the device tree PWM specifier
can_sleep	must be true if the `.config`, `.enable` or `.disable` operations may sleep

Name

pwm_set_chip_data — set private chip data for a PWM

Synopsis

```
int pwm_set_chip_data (struct pwm_device * pwm, void * data);
```

Arguments

pwm PWM device

data pointer to chip-specific data

Returns

0 on success or a negative error code on failure.

Name

pwm_get_chip_data — get private chip data for a PWM

Synopsis

```
void * pwm_get_chip_data (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Returns

A pointer to the chip-private data for the PWM device.

Name

pwmchip_add_with_polarity — register a new PWM chip

Synopsis

```
int pwmchip_add_with_polarity (struct pwm_chip * chip, enum pwm_polarity polarity);
```

Arguments

chip the PWM chip to add

polarity initial polarity of PWM channels

Description

Register a new PWM chip. If chip->base < 0 then a dynamically assigned base will be used. The initial polarity for all channels is specified by the *polarity* parameter.

Returns

0 on success or a negative error code on failure.

Name

pwmchip_add — register a new PWM chip

Synopsis

```
int pwmchip_add (struct pwm_chip * chip);
```

Arguments

chip the PWM chip to add

Description

Register a new PWM chip. If chip->base < 0 then a dynamically assigned base will be used. The initial polarity for all channels is normal.

Returns

0 on success or a negative error code on failure.

Name

pwmchip_remove — remove a PWM chip

Synopsis

```
int pwmchip_remove (struct pwm_chip * chip);
```

Arguments

chip the PWM chip to remove

Description

Removes a PWM chip. This function may return busy if the PWM chip provides a PWM device that is still requested.

Returns

0 on success or a negative error code on failure.

Name

pwm_request — request a PWM device

Synopsis

```
struct pwm_device * pwm_request (int pwm, const char * label);
```

Arguments

pwm global PWM device index

label PWM device label

Description

This function is deprecated, use pwm_get instead.

Returns

A pointer to a PWM device or an ERR_PTR-encoded error code on failure.

Name

pwm_request_from_chip — request a PWM device relative to a PWM chip

Synopsis

```
struct pwm_device * pwm_request_from_chip (struct pwm_chip * chip,
unsigned int index, const char * label);
```

Arguments

chip PWM chip

index per-chip index of the PWM to request

label a literal description string of this PWM

Returns

A pointer to the PWM device at the given index of the given PWM chip. A negative error code is returned if the index is not valid for the specified PWM chip or if the PWM device cannot be requested.

Name

pwm_free — free a PWM device

Synopsis

```
void pwm_free (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Description

This function is deprecated, use `pwm_put` instead.

Name

pwm_config — change a PWM device configuration

Synopsis

```
int pwm_config (struct pwm_device * pwm, int duty_ns, int period_ns);
```

Arguments

pwm	PWM device
duty_ns	"on" time (in nanoseconds)
period_ns	duration (in nanoseconds) of one cycle

Returns

0 on success or a negative error code on failure.

Name

pwm_set_polarity — configure the polarity of a PWM signal

Synopsis

```
int pwm_set_polarity (struct pwm_device * pwm, enum pwm_polarity polarity);
```

Arguments

pwm	PWM device
polarity	new polarity of the PWM signal

Description

Note that the polarity cannot be configured while the PWM device is enabled.

Returns

0 on success or a negative error code on failure.

Name

pwm_enable — start a PWM output toggling

Synopsis

```
int pwm_enable (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Returns

0 on success or a negative error code on failure.

Name

pwm_disable — stop a PWM output toggling

Synopsis

```
void pwm_disable (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Name

of_pwm_get — request a PWM via the PWM framework

Synopsis

```
struct pwm_device * of_pwm_get (struct device_node * np, const char
* con_id);
```

Arguments

np device node to get the PWM from

con_id consumer name

Description

Returns the PWM device parsed from the phandle and index specified in the “pwms” property of a device tree node or a negative error-code on failure. Values parsed from the device tree are stored in the returned PWM device object.

If con_id is NULL, the first PWM device listed in the “pwms” property will be requested. Otherwise the “pwm-names” property is used to do a reverse lookup of the PWM index. This also means that the “pwm-names” property becomes mandatory for devices that look up the PWM device via the con_id parameter.

Returns

A pointer to the requested PWM device or an ERR_PTR-encoded error code on failure.

Name

pwm_get — look up and request a PWM device

Synopsis

```
struct pwm_device * pwm_get (struct device * dev, const char * con_id);
```

Arguments

dev device for PWM consumer

con_id consumer name

Description

Lookup is first attempted using DT. If the device was not instantiated from a device tree, a PWM chip and a relative index is looked up via a table supplied by board setup code (see `pwm_add_table`).

Once a PWM chip has been found the specified PWM device will be requested and is ready to be used.

Returns

A pointer to the requested PWM device or an `ERR_PTR`-encoded error code on failure.

Name

pwm_put — release a PWM device

Synopsis

```
void pwm_put (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Name

devm_pwm_get — resource managed `pwm_get`

Synopsis

```
struct pwm_device * devm_pwm_get (struct device * dev, const char *
con_id);
```

Arguments

`dev` device for PWM consumer

`con_id` consumer name

Description

This function performs like `pwm_get` but the acquired PWM device will automatically be released on driver detach.

Returns

A pointer to the requested PWM device or an `ERR_PTR`-encoded error code on failure.

Name

devm_of_pwm_get — resource managed `of_pwm_get`

Synopsis

```
struct pwm_device * devm_of_pwm_get (struct device * dev, struct device_node * np, const char * con_id);
```

Arguments

dev device for PWM consumer

np device node to get the PWM from

con_id consumer name

Description

This function performs like `of_pwm_get` but the acquired PWM device will automatically be released on driver detach.

Returns

A pointer to the requested PWM device or an `ERR_PTR`-encoded error code on failure.

Name

devm_pwm_put — resource managed `pwm_put`

Synopsis

```
void devm_pwm_put (struct device * dev, struct pwm_device * pwm);
```

Arguments

`dev` device for PWM consumer

`pwm` PWM device

Description

Release a PWM previously allocated using `devm_pwm_get`. Calling this function is usually not needed because devm-allocated resources are automatically released on driver detach.

Name

pwm_can_sleep — report whether PWM access will sleep

Synopsis

```
bool pwm_can_sleep (struct pwm_device * pwm);
```

Arguments

pwm PWM device

Returns

True if accessing the PWM can sleep, false otherwise.